

INSPECTION

1. REMOVE FUEL PUMP ECU
2. INSPECT FUEL PUMP ECU ([See page DI-210](#))
3. REINSTALL FUEL PUMP ECU