


Position of Parts in Body <RHD From Jul. 2006 Production>



- V 4 Door Courtesy SW (Front RH)
- V 5 Side Airbag Sensor (RH)
- V 6 Front Seat Outer Belt (RH)
- V 7 Pretensioner (Front RH)
- V 8 Front Seat Outer Belt Motor (RH)
- V 9 Fuel Sender Gage
- V 10 Airbag Sensor (Rear RH)
- V 11 Door Courtesy SW (Rear RH)
- V 12 Side Airbag Squib (Rear RH)
- V 15 Rear Seat Inner Belt (RH)
- V 16 Curtain Shield Airbag Squib (RH)
- V 17 Speaker (Rear RH)
- V 18 Pretensioner (Rear RH)
- V 19 Rear Seat Outer Belt (RH)
- V 20 Rear Window Defogger
- V 21 Speaker (Woofer)
- V 22 Junction Connector
- V 23 Junction Connector
- V 24 Absorber Control Actuator (Rear RH)
- V 26 Acceleration Sensor (Rear)
- V 27 Brake Control Power Supply Assembly
- V 28 Certification ECU
- V 30 Stereo Component Amplifier
- V 31 Stereo Component Amplifier
- V 32 Electrical Key Oscillator (Outside Luggage Room)
- V 33 Certification ECU
- V 34 Tire Pressure Warning Antenna and Receiver
- V 36 Door Control Receiver
- V 37 Theft Warning Siren
- V 38 Electrical Key Antenna (Glass)
- V 40 Room Lamp (Luggage)
- V 41 Stereo Component Amplifier
- V 42 Stereo Component Amplifier
- V 46 Junction Connector
- V 47 Stereo Component Amplifier
- V 50 Heated Oxygen Sensor (Bank 2 Sensor 2)
- V 51 Stereo Component Amplifier
- V 52 Stereo Component Amplifier
- V 53 Stereo Component Amplifier
- V 58 Multi-Media Interface ECU
- V 59 Stereo Component Amplifier
- V 61 Multi-Media Interface ECU

Position of Parts in Body <RHD From Jul. 2006 Production>

