



* 5: Before Aug. 2008 Production



- Q 8 Outer Scuff Lamp (LH)
- Q 9 Front Seat Outer Belt (LH)
- Q 10 Side Airbag Sensor (Front LH)
- Q 11 Door Courtesy SW (Front LH)
- Q 12 Pretensioner (Front LH)
- Q 13 Front Seat Outer Belt Motor (LH)
- Q 14 Fuel Suction Pump and Gage Assembly
- Q 15 Side Airbag Sensor (Rear LH)
- Q 16 Diode (Luggage Room Lamp)
- Q 17 Door Courtesy SW (Rear LH)
- Q 18 Noise Filter (Stop Lamp)
- Q 19 Curtain Shield Airbag Squib (LH)
- Q 20 Pretensioner (Rear LH)
- Q 21 Rear Window Defogger
- Q 22 Speaker (Satellite LH)
- Q 23 Room Lamp (Luggage)
- Q 24 Rear Sunshade Relay
- Q 25 Center Stop Lamp
- Q 26 Speaker (Satellite RH)
- Q 27 Noise Filter (Luggage Room Lamp)
- Q 30 Electrical Key Oscillator (Rear Seat)
- Q 33 Junction Connector
- Q 34 Junction Connector
- Q 35 Junction Connector
- Q 36 Junction Connector
- Q 37 Clearance Warning ECU
- Q 38 Seat Belt Control ECU
- Q 39 Fuel Lid Opener Motor
- Q 40 Rear Combination Lamp (LH)
- Q 41 Luggage Compartment Door Lock Cylinder
- Q 42 Door Lock Assembly (Luggage)
- Q 43 Television Camera
- Q 44 License Plate Lamp (RH)
- Q 45 Luggage Electrical Key SW
- Q 46 Rear Combination Lamp (RH)
- Q 47 License Plate Lamp (LH)
- Q 48 Electrical Key Oscillator (Inside Luggage Room)
- Q 50 Rear Combination Lamp (LH)

Position of Parts in Body <LHD>



Position of Parts in Body <LHD>

