



Position of Parts in Seat (LHD)




P2	Front Seat Inner Belt Assembly RH
Q10	Front Seat Inner Belt Assembly LH
Q13	Front Seat Airbag Assembly LH
a2	Power Seat Slide Motor RH (Front Seat Adjuster Assembly RH)
a3	Power Seat Tilt Motor RH (Front Seat Adjuster Assembly RH)
a4	Power Seat Lift Motor RH (Front Seat Adjuster Assembly RH)
a5	Front Power Seat Switch RH
a9	Seat Heater RH (Front Separate Type Seat Cushion Cover)
a10	Seat Cushion Climate Control Blower Assembly RH
a11	Front Seat Inner Belt Assembly RH
a12	No. 13 Junction Connector
b1	Power Seat Slide Motor LH (Front Seat Adjuster Assembly LH)
b2	Power Seat Tilt Motor LH (Front Seat Adjuster Assembly LH)
b3	Power Seat Lift Motor LH (Front Seat Adjuster Assembly LH)
b4	Front Power Seat Switch LH
b5	Seat Heater LH (Front Separate Type Seat Cushion Cover)
b6	Seat Cushion Climate Control Blower Assembly LH
b7	No. 14 Junction Connector
b8	Front Power Seat Switch LH
b9	Power Seat Slide Motor LH (Front Seat Adjuster Assembly LH)
b10	Front Lumbar Power Seat Switch
b11	Front Seat Inner Belt Assembly LH
b12	Front Power Seat Switch LH
b13	Front Seat Inner Belt Assembly LH
c1	Seat Back Climate Control Blower RH
c2	Power Seat Reclining Motor RH (Front Separate Type Seat Back Spring Assembly RH)
d1	Seat Back Climate Control Blower LH
d2	Power Seat Reclining Motor LH (Front Separate Type Seat Back Spring Assembly LH)
d3	Power Seat Lumbar Support Motor LH (Front Seat Back Spring Sub-Assembly LH)
o1	Front Seat Airbag Assembly RH
p1	Front Seat Airbag Assembly LH

Position of Parts in Seat (LHD)




90980-12366




90980-12374




90980-10942




90980-10825




90980-12341




90980-10825




90980-10807




90980-11528




90980-12180




90980-12366




90980-12346




90980-10825




90980-12341




90980-10825




90980-11782




90980-11528




90980-12180



90980-12346



90980-10807



90980-11841

Position of Parts in Seat (LHD)

