


Position of Parts in Seat <RHD Front>



- L 19 Front Seat Inner Belt Assembly LH
- L 20 Front Seat Inner Belt Assembly RH
- L 28 Front Seat Airbag Assembly RH
- L 29 Front Seat Airbag Assembly LH
- L 141 Television Display Assembly LH
- L 142 Television Display Assembly RH
- L 167 Television Display Assembly RH
- L 168 Television Display Assembly LH

- S 1 Front Power Seat Reclining Motor RH (Front Seat Back Frame Sub-Assembly RH)
- S 2 Front Lumber Support Pump Sub-Assembly RH
- S 3 Pneumatic Valve Control ECU (Front Seat RH) (Support)
- S 4 Pneumatic Valve Control ECU (Front Seat RH) (Refresh)
- S 5 Seat Back Climate Control Blower RH
- S 6 No. 3 Interior Illumination Light Assembly
- S 9 Headrest Motor RH (Front Seat Adjuster Assembly RH)
- S 10 Front Lumber Support Pump Sub-Assembly LH
- S 11 Pneumatic Valve Control ECU (Front Seat LH) (Support)
- S 12 Pneumatic Valve Control ECU (Front Seat LH) (Refresh)
- S 13 Seat Back Climate Control Blower LH
- S 14 No. 3 Interior Illumination Light Assembly
- S 15 Front Power Seat Reclining Motor LH (Front Seat Back Frame Sub-Assembly LH)
- S 17 Headrest Motor LH (Front Seat Adjuster Assembly LH)

- z 42 Front Seat Inner Belt Assembly RH , Seat Position Airbag Sensor RH

Position of Parts in Seat <RHD Front>

