

DTC	B1294	IMMOBOLIZER ECU COMMUNICATION STOP
------------	--------------	---

CIRCUIT DESCRIPTION

This DTC is detected when communication between the immobilizer ECU (steering lock ECU*¹ or transponder key ECU*²) and gateway ECU stops more than 10 seconds.

DTC No.	DTC Detection Condition	Trouble Area
B1294	Immobilizer ECU communication stops	• Steering lock ECU*¹ • (Transponder key ECU*² • Wire harness

*¹: w/ Smart key system

*²: w/o Smart key system

WIRING DIAGRAM

The wiring diagram is shown on the next page.


w/ Smart Key System

Legend:
 *1: LHD
 *2: RHD

Components and Connections:

- T5 Theft Warning ECU:** MPX (13) connected to P-L line.
- S17 Steering Lock ECU:** MPX2 (6) connected to P-L line; MPX1 (15) connected to P-L line.
- D28 Driver Seat ECU:** MPX1 (11*1, 14*2) connected to P-L line.
- R27*1 Rear LH Seat ECU / R28*2 Rear RH Seat ECU:** MPX1 (7) connected to P-L*2 line.
- P54*1 Power Seat Control Switch:** MPX1 (3) connected to P*1 line.
- Driver Door ECU:** MPX1*1, MPX2*2 connected to D25 (17*1, 26*2) and P-L line.
- Driver Side J/B:** DI (1*1, 11*2) and DE (9*1, 1*2) connected to P-L line; DI (3*1, 9*2) connected to P-L line; DI (14*1, 20*2) connected to P-L line.
- Passenger Side J/B:** PB (1*1, 2*2) and PE (4*1, 8*2) connected to R-L line; STR LOCK (2*1, 1*2) and PE (12*1, 16*2) connected to R-L line.
- FL Block Assy:** D/C CUT (4, 2, 1) and BATT (4, 2, 1) connected to R-L line; 4A (1) connected to B-L line.
- CPUB:** V-Y (1, 10) connected to R-L line; +B (10) connected to R-L line; GND (9) connected to W-B line.
- Battery:** Connected to the system.
- IH*1 / II*2:** Connected to the system.

w/o Smart Key System



INSPECTION PROCEDURE

w/ Smart Key System

1 INSPECT FUSE (MPX-B1, STR LOCK, D/C CUT fuse)


- (a) Remove the MPX-B1 and STR LOCK fuses from the passenger side J/B.
- (b) Remove the D/C CUT fuses from the FL Block assy.
- (c) Measure the resistance.

Standard: Below 1 Ω

NG REPLACE FUSE

OK

2 CHECK WIRE HARNESS (STEERING LOCK ECU - BODY GROUND)



- (a) Disconnect the S17 ECU connector.
- (b) Measure the voltage and resistance between the wire harness side connector and body ground.

Standard:

Tester Connection	Specified Condition
S17-1 (CPUB) - Body ground	10 to 14 V
S17-10 (+B) - Body ground	10 to 14 V
S17-9 (GND) - Body ground	Below 1 Ω


NG REPAIR OR REPLACE HARNESS AND CONNECTOR

OK


3 CHECK RESISTANCE OF COMMUNICATION LINE

Wire Harness Side


S17
Steering Lock ECU



T5
Theft Warning ECU



D25
Driver Door ECU



B79321
B79294

*1: LHD
*2: RHD

B80216

- (a) Disconnect the S17 ECU connector.
- (b) Disconnect the T5 ECU connector.
- (c) Disconnect the D25 ECU connector.
- (d) Measure the resistance between the wire harness side connectors.

Standard:
LHD models

Tester Connection	Specified Condition
S17-15 (MPX1) – D25-17 (MPX1)	Below 1 Ω
S17-6 (MPX2) – T5-13 (MPX)	Below 1 Ω

RHD models

Tester Connection	Specified Condition
S17-15 (MPX1) – D25-26 (MPX1)	Below 1 Ω
S17-6 (MPX2) – T5-13 (MPX)	Below 1 Ω

Result:

Result	Proceed to
Both are OK	A
One is OK	B
Both are NG	C

B

REPLACE STEERING LOCK ECU AND
REPAIR OR REPLACE HARNESS AND
CONNECTOR

C

REPAIR OR REPLACE HARNESS AND
CONNECTOR

A

REPLACE STEERING LOCK ECU

w/o Smart Key System

1 INSPECT FUSE (MPX-B1)

- (a) Remove the MPX-B1 fuse from the passenger side J/B.
- (b) Remove the D/C CUT fuse from the FL Block assy.
- (c) Measure the resistance.

Standard: Below 1 Ω

NG

REPLACE FUSE


OK

2 CHECK WIRE HARNESS (TRANSPONDER KEY ECU - BODY GROUND)

Wire Harness Side

T9

Transponder Key ECU Assy



B80100

- (a) Disconnect the T9 ECU connector.
- (b) Measure the voltage and resistance between the wire harness side connector and body ground.




Standard:

Tester Connection	Specified Condition
T9-1 (CPUB) - Body ground	10 to 14 V
T9-14 (GND) - Body ground	Below 1 Ω

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

3 CHECK RESISTANCE OF COMMUNICATION LINE**Wire Harness Side**

*1: LHD
Y *2: RHD

B79322

- Disconnect the T9 ECU connector.
- Disconnect the T5 ECU connector.
- Disconnect the D25 ECU connector.
- Measure the resistance between the wire harness side connectors.

Standard:**LHD models**

Tester Connection	Specified Condition
T9-4 (MPX1) - D25-17 (MPX1)	Below 1 Ω
T9-5 (MPX2) - T5-13 (MPX)	Below 1 Ω

RHD models

Tester Connection	Specified Condition
T9-4 (MPX1) - D25-26 (MPX2)	Below 1 Ω
T9-5 (MPX2) - T5-13 (MPX)	Below 1 Ω

Result:

Result	Proceed to
Both are OK	A
One is OK	B
Both are NG	C

B

**REPLACE TRANSPONDER KEY ECU ASSY
AND REPAIR OR REPLACE HARNESS AND
CONNECTOR**

C

**REPAIR OR REPLACE HARNESS AND
CONNECTOR**

A

REPLACE TRANSPONDER KEY ECU ASSY