


FUEL LID OPENER MOTOR CIRCUIT

CIRCUIT DESCRIPTION

The circuit opens the fuel lid when the ECU sends signals to the fuel lid opener switch.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 PERFORM ACTIVE TEST USING INTELLIGENT TESTER

- (a) Select the ACTIVE TEST, use the intelligent tester to generate a control command, and then check the fuel lid opener motor.

Luggage room J/B ECU:

Item	Test Detail	Diagnostic Note
Fuel Lid Open	Operate fuel lid motor OFF/ON	-

OK: Fuel lid opener is opened.

NG → Go to step 2

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOM TABLE (See page 05-2821)

2 CHECK FUSE (FUEL OPN)


- (a) Remove the FUEL OPN fuse from the luggage room J/B.
 (b) Measure the resistance.

Standard: Below 1 Ω

NG → REPLACE FUSE

OK

3 CHECK FUEL LID OPENER MOTOR ASSY



- (a) Apply battery voltage to the motor and check operation of the fuel lid opener motor.

OK:

Measurement Condition	Specified Condition
Battery positive (+) → Terminal 2	Moves to open direction
Battery negative (-) → Terminal 1	

NG → REPLACE FUEL LID OPENER MOTOR ASSY

OK


4 CHECK WIRE HARNESS (LUGGAGE ROOM J/B - FUEL LID OPENER MOTOR ASSY AND BODY GROUND)

Wire Harness Side

LL
Luggage Room J/B




LF
Luggage Room J/B




FUEL OPN (O)


F18
Fuel Lid Opener Motor Assy



LB
Luggage Room J/B



LA
Luggage Room J/B



Y

B75349

- (a) Disconnect the LA, LB, LF and LL J/B connectors.
- (b) Disconnect the F18 motor connector.
- (c) Measure the resistance of the wire harness side connectors.

Standard:

Tester Connection	Specified Condition
LL-1 (FUEL OPN-(P)) - Body Ground	10 to 4 V
LF-7 (FUEL OPN(O)) - F18-2	Below 1 Ω
F18-1 - LB-5	Below 1 Ω
LA-5 - Body Ground	Below 1 Ω

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOM TABLE (See page 05-2821)