

INSPECTION

1. **MEASURE PAD LINING THICKNESS**
(See step 1. on page [BR-24](#))
Standard thickness: 10.0 mm (0.394 in.)
Minimum thickness: 1.0 mm (0.039 in.)
2. **MEASURE DISC THICKNESS** (See page [BR-24](#))
Standard thickness: 18.0 mm (0.709 in.)
Minimum thickness: 16.0 mm (0.630 in.)
3. **MEASURE DISC RUNOUT** (See page [BR-24](#))
Maximum disc runout: 0.15 mm (0.0059 in.)
4. **IF NECESSARY, ADJUST DISC RUNOUT**
 - (a) Remove the 2 bolts and torque plate.
 - (b) Remove the hub nuts and the disc. Reinstall the disc 1/6 of a turn round from its original position on the hub. Install and torque the hub nuts.
Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)
Remeasure the disc runout. Make a note of the runout and the disc's position on the hub.
 - (c) Repeat (b) until the disc has been installed on the 4 remaining hub positions.
 - (d) If the minimum runout recorded in (b) and (c) is less than 0.15 mm (0.0059 in.), install the disc in that position.
 - (e) If the minimum runout recorded in (b) and (c) is greater than 0.15 mm (0.0059 in.), replace the disc and repeat step 3.
- (f) Install the torque plate and torque the mounting bolts.
Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)

