

DTC	41	IG Power Source Circuit
------------	-----------	--------------------------------

CIRCUIT DESCRIPTION


This is the power source for the ECU, hence the CPU and actuators.

DTC No.	DTC Detection Condition	Trouble Area
41	Vehicle speed is 3 km/h (1.9 mph) or more and voltage of ECU terminal IG1 remains at more than 17 V or below 9.5 V for more than 10 sec.	• Battery • IC regulator • Open or short in power source circuit

Fail safe function:

If trouble occurs in the power source circuit, the ECU cuts off current to the ABS control (solenoid) relay and prohibits ABS control.

WIRING DIAGRAM



W02195

INSPECTION PROCEDURE

1 Check battery positive voltage.

OK:


Voltage: 10 – 14 V

NG

Check and repair charging system.

OK

2 Check voltage between terminals IG1 and GND of ABS ECU connector.



PREPARATION:

Remove the ABS ECU with connectors still connected.

CHECK:

- (a) Turn the ignition switch ON.
- (b) Measure the voltage between terminals IG1 and GND of ABS ECU connector.

OK:


Voltage: 10 – 14 V

OK

Check and replace ABS ECU.

NG

3 Check continuity between terminals GND of ABS ECU connector and body ground.



CHECK:

Measure the resistance between terminal GND of ABS ECU connector and body ground.

OK:

Resistance: 1 Ω or less


NG

Repair or replace harness or connector.

OK

4 Check ECU-IG fuse.

FUSE BLOCK



ECU-IG

W02206

PREPARATION:

Remove the ECU-IG fuse from FUSE BLOCK.

CHECK:

Check the continuity of ECU-IG fuse.

OK:

Continuity

NG

Check for short in all harness and components connected to ECU-IG fuse (See attached wiring diagram).

OK

Check for open in harness and connector between ABS ECU and battery (See page [IN-27](#)).