

IGNITION SYSTEM

ON-VEHICLE INSPECTION

IGOUR-01

NOTICE:

"Cold" and "Hot" in the following sentences express the temperature of the coils themselves. "Cold" is from -10°C (14°F) to 50°C (122°F) and "Hot" is from 50°C (122°F) to 100°C (212°F).

1. INSPECT IGNITER AND SPARK TEST


Check that the spark occurs.


- (1) Disconnect the high-tension cords (from the ignition coil) from the distributor cap.
- (2) Hold the end approx. 12.5 mm (0.50 in.) from the body ground.
- (3) Check if spark occurs while engine is being cranked.

NOTICE:

To prevent gasoline from being injected from injectors during this test, crank the engine for no more than 1 – 2 seconds at a time.


If the spark does not occur, do the test as follows:






2. INSPECT HIGH-TENSION CORDS

- (a) Remove the No. 2 PCV hose.
- (b) Remove the air cleaner hose.
- (c) Disconnect the throttle cable.
- (d) Remove the 4 bolts, No. 2 and No. 3 cylinder head covers.




- (e) Disconnect the high-tension cords from the spark plugs.
 - (1) Remove the 2 mounting bolts of the No. 1 and No. 2 cord clamps.




- (2) Disconnect the high-tension cords at the rubber boot. Do not pull on the cords.

NOTICE:

Pulling on or bending the cords may damage the conductor inside.




- (f) Disconnect the high-tension cords from the distributor cap and ignition coil.
 - (1) Using a screwdriver, lift up the lock claw and disconnect the holder from the distributor cap (ignition coil).



- (2) Disconnect the high-tension cord at the grommet. Do not pull on the cords.

NOTICE:

- **Pulling on or bending the cords may damage the conductor inside.**
- **Do not wipe any of the oil from the grommet after the high-tension cord is disconnected.**




- (g) Using an ohmmeter, measure the high-tension cord resistance.

Maximum resistance: 25 kΩ per cord


If the resistance is greater than maximum, check the terminals. If necessary, replace the high-tension cord.

- (h) Reconnect the high-tension cords to the distributor cap and ignition coil.
 (i) Reconnect the high-tension cords to the spark plugs.
 (1) Secure the high-tension cords with the cord clamps as shown in the illustration.




- (2) Install the No. 1 and No. 2 cord clamps with the 2 bolts.

- (j) Reinstall the No. 2 and No. 3 cylinder head covers with the 4 bolts.
 (k) Reinstall the throttle cable.
 (l) Reinstall the air cleaner hose.
 (m) Reinstall the No. 2 PCV hose.




3. INSPECT SPARK PLUGS

- (a) Disconnect the high-tension cords from the spark plugs (See step 2).
 (b) Using a 16 mm plug wrench, remove the 6 spark plugs.



IG0152

- (c) Using a spark plug cleaner or wire brush, clean the spark plugs.




P03783

- (d) Check the spark plugs for electrode wear, threads damage and insulator damage.

If abnormal, replace the plugs.

Recommended spark plugs:

DENSO made	K16R-U
NGK made	BKR5EYA




P03792

- (e) Adjust the electrode gap.
Carefully bend the outer electrode to obtain the correct electrode gap.

Correct electrode gap: 0.8 mm (0.031 in.)

- (f) Using a 16 mm plug wrench, reinstall the 6 spark plugs.
Torque: 20 N·m (200 kgf·cm, 14 ft·lbf)
- (g) Reconnect the high-tension cords to the spark plugs (See step 2).



P08340


4. INSPECT IGNITION COILS

- (a) Disconnect the ignition coil connector.
(b) Disconnect the high-tension cord.
(c) Using an ohmmeter, measure the primary coil resistance between the positive (+) and negative (-) terminals.

Primary coil resistance:

Cold	0.36 – 0.55 Ω
Hot	0.45 – 0.65 Ω

If the resistance is not as specified, replace the ignition coil.



P08341



- (d) Using an ohmmeter, measure the secondary coil resistance between the positive (+) and high-tension terminals.

Secondary coil resistance:

Cold	9.0 – 15.4 k Ω
Hot	11.4 – 18.1 k Ω

If the resistance is not as specified, replace the ignition coil.

- (e) Reconnect the high-tension cord.
(f) Reconnect the ignition coil connector.

G1 and G2 Pickups**NE Pickup**P22357
P22358


B12083

5. INSPECT DISTRIBUTOR

- Disconnect the distributor connector.
- Remove the distributor cap without disconnecting the high-tension cords.
- Remove the rotor.
- Using a feeler gauge, measure the air gaps between the signal rotor and the pickup coil projection.

Air gap: 0.2 – 0.4 mm (0.008 – 0.016 in.)

If the gap is not as specified, replace the distributor housing assembly (See page IG-7).



P22359

B12084

- Using an ohmmeter, measure the signal generator (pick-up coil) resistance between the terminals.

Pickup coil resistance:


Cold	G1 and G-	185 – 275 Ω
	G2 and G-	185 – 275 Ω
	NE and G-	185 – 275 Ω
Hot	G1 and G-	240 – 325 Ω
	G2 and G-	240 – 325 Ω
	NE and G-	240 – 325 Ω

If the resistance is not as specified, replace the distributor housing assembly (See page IG-7).

- Reinstall the rotor.
- Reinstall the distributor cap.
- Reconnect the distributor connector.

6. INSPECT CRANKSHAFT POSITION SENSOR

- Disconnect the sensor connector and bracket.



P22961

B12085

- Using an ohmmeter, measure the sensor resistance between the terminals.

Resistance (NE+ – NE-):

Cold	1,630 – 2,740 Ω
Hot	2,065 – 3,225 Ω

If the resistance is not as specified, replace the sensor (See page IG-10).

- Reconnect the sensor bracket and connector.