



SERVICE HINTS

A30 AUTO ANTENNA ECU

- 8-GROUND : ALWAYS APPROX. **12** VOLTS
- 7-GROUND : APPROX. **12** VOLTS WITH THE IGNITION SW AT **ON** POSITION
- 17-GROUND : APPROX. **12** VOLTS WITH THE IGNITION SW AT **ACC** OR **ON** POSITION
- 5-GROUND : ALWAYS CONTINUITY

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A 9	22	A30	24	J 6	25
A10	22	F11	25	J 8	25
A29	24	J 3	25	R 1	25

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	18	R/B NO. 2 (FRONT SIDE OF LEFT FENDER)


□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA4	30	COWL WIRE AND ENGINE ROOM MAIN WIRE (RIGHT FENDER)
IJ1	34	COWL WIRE AND INSTRUMENT PANEL WIRE (INSTRUMENT PANEL CENTER)

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IE	32	RIGHT KICK PANEL


A 9 GRAY




A10 GRAY



A29 BLACK




A30




F11

(SEE PAGE 20)


J 3



J 6



J 8 BLUE



R 1

