


|     |    |                      |
|-----|----|----------------------|
| DTC | 21 | Solar Sensor Circuit |
|-----|----|----------------------|


CIRCUIT DESCRIPTION



A photo diode in the solar sensor detects solar radiation and sends signals to the A/C control assembly.

| DTC No | Detection Item                                                                                                                                                     | Trouble Area                                                                                                                                                  |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 21     | Open or short in solar sensor circuit.<br>Please note that display of diagnostic trouble code 21 is not abnormal when the sensor is not receiving solar radiation. | <ul style="list-style-type: none"><li>• Solar sensor.</li><li>• Harness or connector between solar sensor and A/C amplifier</li><li>• A/C amplifier</li></ul> |


WIRING DIAGRAM



I08324

# INSPECTION PROCEDURE

|   |                                                                         |
|---|-------------------------------------------------------------------------|
| 1 | Check voltage between terminals TS and FrSG of A/C amplifier connector. |
|---|-------------------------------------------------------------------------|



## PREPARATION:

Remove A/C amplifier with connectors still connected.

## CHECK:

- Turn ignition switch ON.
- Measure voltage between terminals TS and FrSG of A/C amplifier connector when the solar sensor is subjected to an electric light, and when the sensor is covered by a cloth.

## OK:

| Condition                          | Voltage     |
|------------------------------------|-------------|
| Sensor subjected to electric light | 0.8 – 4.3 V |
| Sensor covered by a cloth          | Below 0.8 V |


## HINT:

As the inspection light is moved away from the sensor, the voltage increases.

|    |               |
|----|---------------|
| NG | Go to step 2. |
|----|---------------|

OK

Proceed to next circuit inspection shown on problem symptoms table (See page [DI-769](#)). However, if DTC 21 is displayed, check and replace A/C amplifier.

**2 Check solar sensor.****PREPARATION:**

Remove solar sensor.

**CHECK:**

- (a) Cover the sensor by a cloth.
- (b) Measure resistance between terminals 1 and 2 of solar sensor connector.

**HINT:**

Connect positive (+) lead of ohmmeter to terminal 1 and negative (–) lead to terminal 2 of the solar sensor.

**OK:**

**Resistance :  $\infty \Omega$  (no continuity)**

**PREPARATION:**

- (a) Remove the cloth from the solar sensor and subject the sensor to electric light.
- (b) Measure resistance.

**OK:**

**Resistance : Approx. 4 k $\Omega$  (continuity)**

**HINT:**

As the electric light is moved away from the sensor, the resistance increases.

**NG****Replace solar sensor.****OK****3 Check harness and connector between A/C amplifier and solar sensor  
(See page IN-34).****NG****Repair or replace harness or connector.****OK****Check and replace A/C control assembly.**