


Diagnosis Circuit

CIRCUIT DESCRIPTION


This circuit sends a signal to the ECU that DTC output is required.

WIRING DIAGRAM



INSPECTION PROCEDURE

- 1 Check voltage between terminals Tc and E₁ of DLC3.

**PREPARATION:**

Turn ignition switch ON.

CHECK:

Measure voltage between terminals Tc and E₁ of DLC3.

OK:

Voltage: 10 – 14 V

OK

Proceed to next circuit inspection shown in problem symptom table (See page [DI-694](#)).

NG

- 2 Check harness and connector between instrument panel ECU (body ECU) and DLC3, DLC3 and body ground (See page [IN-34](#)).

NG

Repair or replace harness or connector.

OK

Check and replace instrument panel ECU (See page [IN-34](#)).