


DTC	P1300	Igniter Circuit Malfunction (No.1)
DTC	P1305	Igniter Circuit Malfunction (No.2)
DTC	P1310	Igniter Circuit Malfunction (No.3)
DTC	P1315	Igniter Circuit Malfunction (No.4)
DTC	P1320	Igniter Circuit Malfunction (No.5)
DTC	P1325	Igniter Circuit Malfunction (No.6)
DTC	P1330	Igniter Circuit Malfunction (No.7)
DTC	P1340	Igniter Circuit Malfunction (No.8)

CIRCUIT DESCRIPTION

A DIS (Direct Ignition System) has been adopted. The DIS improves the ignition timing accuracy, reduces high-voltage loss, and enhances the overall reliability of the ignition system by eliminating the distributor. The DIS is a 1-cylinder ignition system which ignites one cylinder with one ignition coil. In the 1-cylinder ignition system, the one spark plug is connected to the end of the secondary winding. High voltage generated in the secondary winding is applied directly to the spark plug. The spark of the spark plug pass from the center electrode to the ground electrode.

The ECM determines ignition timing and outputs the ignition signals (IGT) for each cylinder. Based on IGT signals, the power transistors in the igniter cuts off the current to the primary coil in the ignition coil is supplied to the spark plug that are connected to the end of the secondary coil. At the same time, the igniter also sends an ignition confirmation signal (IGF) as a fail-safe measure to the ECM.



DTC No.	DTC Detecting Condition	Trouble Area
P1300 P1305 P1310 P1315 P1320 P1325 P1330 P1340	No IGF signal to ECM while engine is running	• Open or short in IGF1 or IGF2 and IGT1 ~ 8 circuit from ignition coil with igniter • No.1 ~ No.8 ignition coil with igniter • ECM

The diagram illustrates the electrical system for the 2008 Honda CRF250L. It shows the power flow from the battery through a fusible link block and an engine room junction box (J/B) to various components. The ignition system consists of eight coils, each with a spark plug and a dedicated ground. The ECM (Electronic Control Module) is connected to the ignition system via IGT (Ignition Trigger) and IGF (Ignition Feedback) pins. The diagram also includes a noise filter connected to ground.

Legend:

- W-R: White-Red
- B-R: Blue-Red
- B-W: Blue-White
- R: Red
- L: Light Blue
- G: Green
- Y: Yellow
- B-Y: Blue-Yellow
- B-L: Blue-Light Blue
- L-B: Light Blue-Blue
- BR: Blue-Red (Noise Filter)

ECM Pinout:

Pin	Color	Signal
11	E6	IGT1
27	E6	IGF1
12	E6	IGT2
28	E6	IGF2
13	E6	IGT3
14	E6	IGT4
15	E6	IGT5
16	E6	IGT6
25	E6	IGT7
26	E6	IGT8

INSPECTION PROCEDURE

HINT:

- If DTC P1300 is displayed, check No.1 ignition coil with igniter circuit.
- If DTC P1305 is displayed, check No.2 ignition coil with igniter circuit.
- If DTC P1310 is displayed, check No.3 ignition coil with igniter circuit.
- If DTC P1315 is displayed, check No.4 ignition coil with igniter circuit.
- If DTC P1320 is displayed, check No.5 ignition coil with igniter circuit.
- If DTC P1325 is displayed, check No.6 ignition coil with igniter circuit.
- If DTC P1330 is displayed, check No.7 ignition coil with igniter circuit.
- If DTC P1340 is displayed, check No.8 ignition coil with igniter circuit.
- If DTC P1300, P1315, P1325, P1330 are output simultaneously, IGF1 circuit may be open or short.
- If DTC P1305, P1310, P1320, P1340 are output simultaneously, IGF2 circuit may be open or short.
- Read freeze frame data using LEXUS hand-held tester or OBD II scan tool. Because freeze frame records the engine conditions when the malfunction is detected, when troubleshooting it is useful for determining whether the vehicle was running or stopped, the engine warmed up or not, the air-fuel ratio lean or rich, etc. at the time of the malfunction.

1 Check spark plug and spark (See page IG-1).

NG

Go to step 4.

OK


2 Check for open and short in harness and connector in IGF and IGT signal circuit between ECM and ignition coil with igniter (See page IN-34).

NG

Repair or replace harness or connector.

OK

- 3 Disconnect ignition coil with igniter connector and check voltage between terminals IGF1, 2 of ECM connector and body ground.**

**PREPARATION:**

- (a) Remove the glove compartment door.
- (b) Disconnect the ignition coil with igniter connector.
- (c) Turn the ignition switch ON.

CHECK:

Measure voltage between terminals IGF1, 2 of the ECM connector and body ground.

OK:

Voltage: 4.5 ~ 5.5 V

OK

Replace ignition coil with igniter.

NG

Check and replace ECM (See page [IN-34](#)).


- 4 Check for open and short in harness and connector in IGT signal circuit between ECM and ignition coil with igniter (See page [IN-34](#)).**

NG

Repair or replace harness or connector.

OK

5 Check voltage between terminals IGT1 ~ 8 of ECM connector and body ground.



PREPARATION:


Remove the glove compartment door.

CHECK:

Measure voltage between terminals IGT1 ~ 8 of the ECM connector and body ground when engine is cranked.

OK:

Voltage: More than 0.1 V and less than 4.5 V



Reference: INSPECTION USING OSCILLOSCOPE

During cranking or idling, check waveform between terminals IGT1 ~ 8 and E1 of the ECM connector.

HINT:


Correct waveform appears as shown, with rectangle waves.

NG

Check and replace ECM (See page [IN-34](#)).

OK

6 Disconnect ignition coil with igniter connector and check voltage between terminals IGT1 ~ 8 of ECM connector and body ground.



PREPARATION:

- Remove the glove compartment door.
- Disconnect the ignition coil with igniter connector.

CHECK:

Measure voltage between terminals IGT1 ~ 8 of the ECM connector and body ground when engine is cranked.

OK:


Voltage: More than 0.1 V and less than 4.5 V

NG

Check and replace ECM (See page [IN-34](#)).

OK

7 Check ignition coil with igniter power source circuit.



PREPARATION:

Disconnect the ignition coil with igniter connector.

CHECK:

Measure voltage between terminal 1 of ignition coil with igniter connector and body ground, when ignition switch is turned to "ON" and "START" position.

OK:

Voltage: 9 ~ 14 V

OK

Repair ignition coil with igniter power source circuit.

NG

8 Check for open and short in harness and connector between ignition switch and ignition coil with igniter (See page [IN-34](#)).

NG

Repair or replace harness or connector.

OK

9 Check EFI main relay (Marking: EFI) (See page [SF-45](#)).

NG

Replace EFI main relay (marking: EFI).

OK

Replace ignition coil with igniter.