

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below (Proceed to the page given for that circuit).

DTC No. (See Page)	Detection Item	Trouble Area
B1213/13 (DI-747)	Tilt and telescopic ECU communication stop	• Wireharness • Tilt and telescopic ECU
B1215/15 (DI-749)	Door system communication bus malfunction (short circuit)	• Wireharness • ECU (Door system bus)
B1272/72 (DI-753)	Power seat ECU communication stop (w/ Seat memory vehicle only)	• Wireharness • Power seat ECU
B1276/76 (DI-755)	Power mirror control ECU communication stop (w/ Seat memory vehicle only)	• Wireharness • Power mirror control ECU

HINT:

When some of the DTC 15 is output, the DTC of other ECU communication stop is also output. In this case, please repair DTC 15 first. The following shows DTCs which are output when +B or GND short occurs on communication bus.

	Instrument panel system communication bus
GND short	After 10 seconds from detecting fail, Door system communication bus is able to communicate by bus cut function.
Communication possible ECU after bus is cut	Power seat ECU
DTC(B12XX) (): Option	13, 72, 76
+B short	(Same as GND short)
Communication possible ECU after bus is cut	(Same as GND short)
DTC(B12XX) (): Option	13, 72, 76