

PROBLEM SYMPTOMS TABLE

Perform troubleshooting of the circuits for the applicable problem symptom in the order given in the chart below. Proceed to the page located for each circuit.

HINT:

- If the instruction "Proceed to next circuit inspection shown on matrix chart" is given in the flow chart for each circuit, proceed to the circuit with the next highest number in the table to continue the check.
- If the trouble still reappears even though there are no abnormalities in any of the other circuits, then check and replace the Seat Position Control ECU as the last step.

Symptom	Suspect Area	See page
Both manual & return functions do not operate(All functions).	1. +B power source circuit 2. Power seat control switch circuit 3. Motor circuit 4. Power seat control ECU	DI-552 BE-126 DI-556 IN-34
Both manual & return functions do not operate(One function only).	1. Motor circuit 2. Power seat control ECU	DI-556 IN-34
One or all functions do not operate for manual operation only.	1. Power seat control switch circuit 2. Power seat control ECU	BE-126 IN-34
Memory function does not operate.	1. Power seat memory switch circuit 2. Ignition switch circuit 3. Power seat control ECU 4. Instrument panel ECU	DI-728 DI-563 IN-34 IN-34
Return operation does not stop when brake pedal is depressed.	1. Power seat control ECU 2. Instrument panel ECU	IN-34 IN-34
Only return function does not operate or operates a little, then stops (All return functions).	1. ECU power source circuit 2. Position sensor power source circuit 3. Power seat control ECU 4. Instrument panel ECU	DI-554 DI-559 IN-34 IN-34
Only return function does not operate or operates a little, then stops (Only one return function).	1. Position sensor circuit 2. Power seat control ECU	DI-561 IN-34