

PROBLEM SYMPTOMS TABLE

Perform troubleshooting of the circuits for the applicable problem symptom in the order given in the chart below. Proceed to the page located for each circuit.

HINT:

- If the instruction "Proceed to next circuit inspection shown on problem symptoms table" is given in the flow chart for each circuit, proceed to the circuit with the next highest number in the table to continue the check.
- If the trouble still reappears even though there are no abnormalities in any of the other circuits, then check and replace the Seat Position Control ECU as the last step.

Symptom	Suspect Area	See page
Both manual & return functions do not operate(All functions).	3. +B power source circuit 4. Power seat control switch circuit 5. Motor circuit 6. Power seat control ECU	DI-609 BE-126 DI-613 IN-34
Both manual & return functions do not operate(One function only).	1. Motor circuit 2. Power seat control ECU	DI-613 IN-34
One or all functions do not operate for manual operation only.	1. Power seat control switch circuit 2. Power seat control ECU	BE-126 IN-34
Memory function does not operate.	1. Power seat memory switch circuit 2. Ignition switch circuit 3. Power seat control ECU 4. Instrument panel ECU	DI-777 DI-620 IN-34 IN-34
Return operation does not stop when brake pedal is depressed.	1. Power seat control ECU 2. Instrument panel ECU	IN-34 IN-34
Only return function does not operate or operates a little, then stops (All return functions).	1. ECU power source circuit 2. Position sensor power source circuit 3. Power seat control ECU 4. Instrument panel ECU	DI-611 DI-616 IN-34 IN-34
Only return function does not operate or operates a little, then stops (Only one return function).	1. Position sensor circuit 2. Power seat control ECU	DI-618 IN-34