


ACC Power Source Circuit

CIRCUIT DESCRIPTION


This is the power source for A/C amplifier and servomotors, etc.

WIRING DIAGRAM



INSPECTION PROCEDURE


1	Check voltage between terminals ACC and GND of A/C amplifier connector.
----------	--

**PREPARATION:**


Remove A/C amplifier with connectors still connected.

CHECK:


- (a) Turn ignition switch to ACC.
- (b) Measure voltage between terminals ACC and GND of A/C amplifier.

OK:**Voltage : Battery positive voltage****OK****Proceed to next circuit inspection shown on problem symptoms table (See page [DI-937](#)).****NG**

2	Check continuity between terminal GND of A/C amplifier and body ground.
----------	--

**CHECK:**

Measure resistance between terminal GND of A/C amplifier and body ground.


OK:**Resistance : 0 Ω (continuity)****NG****Repair or replace harness or connector.**

OK

3

Check IGN fuse.

Cowl Side J/B

**PREPARATION:**

Remove IGN fuse from cowl side J/B.

CHECK:

Check continuity of IGN fuse.

OK:

Continuity

NG

Check for short in all the harness and components connected to the IGN fuse (See attached wiring diagram).

OK

Check and repair harness and connector between A/C amplifier.