

DTC	C1223 / 43	ABS Control System Malfunction
------------	-------------------	---------------------------------------

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1223 / 43	ABS control system is abnormal.	ABS control system

INSPECTION PROCEDURE

1	Check the DTC for the ABS (See page DI-326).
----------	---

1*Repair ABS control system according to the code output.*****2****Check for ECU connected to malfunction indicator light.**

*1: Output NG code

*2: Malfunction indicator light remains ON