

18. Panel Switch Does Not Function (A/C control only)

INSPECTION PROCEDURE

- | | |
|---|---|
| 1 | Display check mode (Panel Switch Check screen). |
|---|---|

NG

Replace the multi display.

OK

- | | |
|---|---|
| 2 | Check "AVC-LAN communication circuit" (See page DI-932). |
|---|---|

NG

Replace or repair AVC-LAN circuit.

OK

- | | |
|---|--|
| 3 | Check wire harness and connector between gateway ECU and A/C amplifier (Center ECU) (See page IN-34). |
|---|--|

NG

Repair or replace wire harness and connector.

OK

Check and replace A/C amplifier (Center ECU).