


|            |              |                                                                                                |
|------------|--------------|------------------------------------------------------------------------------------------------|
| <b>DTC</b> | <b>P2757</b> | <b>Torque Converter Clutch Pressure Control Solenoid Performance(Shift Solenoid Valve SLU)</b> |
|------------|--------------|------------------------------------------------------------------------------------------------|



## SYSTEM DESCRIPTION


The ECM uses the signals from the Throttle Position Sensor and Air-flow Meter to monitor the engagement condition of the lock-up clutch.

Then the ECM compares the engagement condition of the lock-up clutch with the lock-up schedule in the ECM memory to detect mechanical trouble of the shift solenoid valve SLU, valve body, torque converter clutch and automatic transmission assembly (clutch, brake or gear etc.).

| DTC No. | DTC Detecting Condition                                                                                                                                                    | Trouble Area                                                                                                                                                                                                        |
|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| P2757   | Lock-up does not occur when driving in the lock-up range (normal driving at 80 km/h [50 mph]), or lock-up remains ON in the lock-up OFF range.<br>(2-trip detection logic) | <ul style="list-style-type: none"> <li>• Shift solenoid valve SLU is stuck open or closed</li> <li>• Valve body blocked up or stuck</li> <li>• Lock-up clutch</li> <li>• Automatic transmission assembly</li> </ul> |

## INSPECTION PROCEDURE

|          |                                                  |
|----------|--------------------------------------------------|
| <b>1</b> | <b>Check shift solenoid valve SLU operation.</b> |
|----------|--------------------------------------------------|



### PREPARATION:

- Jack up the vehicle.
- Remove the oil pan.
- Remove the shift solenoid valve SLU.

### CHECK:

- Measure the resistance between terminals 1 and 2 of solenoid connector.

**Standard: 5.0 to 5.6 Ω at 20°C (68°F)**

- Connect the positive (+) lead with an 21 W bulb to terminal 2 of solenoid connector and negative (-) lead to terminal 1 of the solenoid valve connector, then check the movement of the valve.

**Standard: Solenoid sounds operation noise.**

### OK:

**Standard**

**NG**

**Replace the shift solenoid valve SLU  
(See page AT-8).**

**OK**

|   |                                                      |
|---|------------------------------------------------------|
| 2 | Check valve body (See page <a href="#">DI-262</a> ). |
|---|------------------------------------------------------|

NG

Replace the valve body (See page [AT-8](#)).

OK

|   |                                                                  |
|---|------------------------------------------------------------------|
| 3 | Check torque converter clutch (See page <a href="#">AT-35</a> ). |
|---|------------------------------------------------------------------|

OK

Repair or replace transmission (See page [AT-30](#)).

NG

Replace the torque converter clutch  
(See page [AT-30](#)).