


WIRING DIAGRAM



In case of using the hand-held tester, start the inspection from step 1 and in case of not using the hand-held tester, start from step 2.

1	Check light control switch using hand-held tester.
---	--

Check that the light control switch operate in ACTIVE TEST (See page [DI-1226](#)).

Proceed to next circuit inspection shown on problem symptoms table (See page DI-1242).

NG

2	Check light control switch (See page BE-36).
---	---

NG

Replace the light control switch.

OK

3	Check wire harness and connector between headlight control switch and Body ECU (Main) (See page IN-36).
---	--

NG

Repair or replace wire harness or connector.

OK

Proceed to next circuit inspection shown on
problem symptoms table
(See page [DI-1242](#)).