

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below, and proceed to the appropriate page.

DTC No. (See Page)	Circuit Inspection	Trouble Area
P0500/21 (DI-1029)	Vehicle Speed Sensor "A"	• Combination meter • Open or short in vehicle speed sensor circuit • Vehicle speed sensor • ECM
P0503/23 (DI-1029)	Vehicle Speed Sensor "A" Intermittent/Erratic/High	
P0571/52 (DI-1030)	Brake Switch "A" Circuit	• Short in stop light switch circuit • Stop light switch • ECM
P0607/54 (DI-1034)	Control Module Performance	• ECM