

## 22. No voice navigation.

### INSPECTION PROCEDURE

- |   |                                               |
|---|-----------------------------------------------|
| 1 | Set the volume to the max in the menu screen. |
|---|-----------------------------------------------|

OK

Normal. (Voice navigation is not available. No destination is set, or the vehicle is running off the route.)

NG

- |   |                                                                   |
|---|-------------------------------------------------------------------|
| 2 | Check wire harness (navigation ECU and driver side door speaker). |
|---|-------------------------------------------------------------------|

#### PREPARATION:

Disconnect the navigation ECU connector and driver side door speaker connector.

#### CHECK:

- (a) Check continuity between terminal AUO+ of navigation ECU connector and terminal 1 of driver side door speaker.
- (b) Check continuity between terminal AUO– of navigation ECU connector and terminal 2 of driver side door speaker.

#### OK:

Continuity

NG

Replace or repair wire harness.

OK

- |   |                                                                                             |
|---|---------------------------------------------------------------------------------------------|
| 3 | Check the sound. (Check if the radio sound can be heard from the driver side door speaker.) |
|---|---------------------------------------------------------------------------------------------|

OK

Replace the navigation ECU.

NG

Replace the speaker.