

9. Black screen appears when "MAP", "Menu" or "DESTINATION" switch pressed.

INSPECTION PROCEDURE

1	Check the navigation ECU.
---	---------------------------

CHECK:

Check voltage terminal +B.

OK:**+B: 10 - 14 V****CHECK:**

Check voltage terminal ACC when turning the ignition switch to ACC or ON position.

OK:**ACC: 10 - 14 V****CHECK:**

Check voltage terminals R, G, B, VR or VG.

OK:**R, G, B, VR or VG: See "Navigation ECU" of "TERMINAL OF ECU"****NG****Replace the wire harness when all terminals are faulty. Replace the wire harness when R,G,B terminal is faulty.****OK****Replace the multi-display.**