


DTC	B0115/47	Short in Side Squib LH Circuit
------------	-----------------	---------------------------------------

CIRCUIT DESCRIPTION

The side squib LH circuit consists of the airbag sensor assembly and the side airbag assembly LH. It causes the SRS to deploy when the SRS deployment conditions are satisfied. For details of the function of each component, see OPERATION on page [RS-3](#). DTC B0115/47 is recorded when a short is detected in the side squib LH circuit.

DTC No.	DTC Detecting Condition	Trouble Area
B0115/47	• Short in side squib LH circuit • Side squib LH malfunction • Airbag sensor assembly malfunction	• Side airbag assembly LH (Side squib LH) • Airbag sensor assembly • Floor No. 1 wire


WIRING DIAGRAM




H01454

INSPECTION PROCEDURE

- 1** Prepare for inspection (See step 1 on page [DI-933](#)).



- 2** Check floor No. 1 wire (side squib LH circuit).

**PREPARATION:**

Release the airbag activation prevention mechanism built in the connector of the floor No. 1 wire on the airbag sensor assembly side (See page [DI-706](#)).

CHECK:

Measure the resistance between SFL+ and SFL- of the floor No. 1 wire connector on the side airbag assembly LH (side squib LH) side.

OK:


Resistance: 1 MΩ or Higher

NG

Replace floor No. 1 wire.

OK

3 Check airbag sensor assembly.



PREPARATION:

- Connect the connector to the airbag sensor assembly.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.

CHECK:

- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Clear the DTC stored in memory (See page [DI-706](#)).
- Turn the ignition switch to LOCK, and wait at least for 10 seconds.
- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Check the DTC (See page [DI-706](#)).

OK:

DTC B0115/47 is not output.

HINT:


Codes other than code B0115/47 may be output at this time, but they are not relevant to this check.

NG

Replace airbag sensor assembly.

OK

4 Check side squib LH.



PREPARATION:

- Turn the ignition switch to LOCK.
- Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- Connect the side airbag assembly LH (side squib LH) connector.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.

CHECK:

- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Clear the DTC stored in memory (See page [DI-706](#)).
- Turn the ignition switch to LOCK, and wait at least for 10 seconds.
- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Check the DTC (See page [DI-706](#)).

OK:

DTC B0115/47 is not output.

HINT:

Codes other than code B0115/47 may be output at this time, but they are not relevant to this check.

NG

Replace side airbag assembly LH (side squib LH).

OK

From the results of the above inspection, the malfunctioning part can now be considered normal. To make sure of this, use the simulation method to check.