

DTC	C1515 / 15	VGRS Actuator Neutral Position Not Initialized
------------	-------------------	---

CIRCUIT DESCRIPTION

This code is set when the VGRS ECU or actuator have been replaced.

DTC No.	DTC Detecting Condition	Trouble Area
C1515/15	When the VGRS actuator angle adjustment has not been performed.	• VGRS actuator • VGRS ECU

INSPECTION PROCEDURE

1	Are any other VGRS codes present?
----------	--

YES

Repair circuit indicated by DTC output.

NO

2	Perform VGRS system calibration (See page DI-625).
----------	---

NEXT

3	Is DTC C1516/16 output? (VGRS actuator angle adjustment did not complete normally)
----------	---

NO

VGRS system calibration complete.

YES

(See page [DI-657](#))