


ECU Power Source Circuit

CIRCUIT DESCRIPTION


Battery positive voltage is continuously applied to the terminal +B of the wireless door lock ECU.

WIRING DIAGRAM



INSPECTION PROCEDURE

1	Check voltage between terminal +B of ECU connector and ground.
---	--



PREPARATION:

Remove the wireless door lock ECU connector being connected.

CHECK:

Measure voltage between terminal +B of wireless door lock ECU connector and ground.

OK:

Voltage: 10 - 14 V

OK


Proceed to next circuit inspection shown in problem symptom table (See page [DI-984](#)).

NG

2	Check wire harness and connector between wireless door lock ECU and body ECU (Main) (See page IN-36).
---	--

NG

Repair or replace harness or connector.

OK

Proceed to next circuit inspection shown in problem symptom table (See page [DI-984](#)).