



DTC	C1252 / 52	Hydraulic Brake Booster Pump Motor ON Time Abnormally Long
------------	-------------------	---

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1252 / 52	After the ignition switch has been turned ON, when the power is supplied to the pump motor for more than 5 minutes.	- Hydraulic brake booster pump motor - Hydraulic brake booster pump motor circuit - Pressure switch (PH or PL)

WIRING DIAGRAM



INSPECTION PROCEDURE**1 Check operation of hydraulic brake booster pump motor.****PREPARATION:**

Disconnect the 2 connectors from the hydraulic brake booster.

CHECK:

Connect battery positive $\oplus$ lead to BM1 or BM2 terminal and battery negative $\ominus$ lead to EM1 or EM2 terminal of the hydraulic brake booster (pump motor) connector.

OK:

The operation sound of the pump motor should be heard.

NG**Go to step 9.****OK****2 Check for short circuit (to B+) in harness and connector between BM1 or BM2 of hydraulic brake booster and ABS motor 1 relay or ABS motor 2 relay (See page IN-36).****NG****Repair or replace harness or connector.****OK****3 Check for short circuit (to B+) in harness and connector between MT of hydraulic brake booster and skid control ECU (See page IN-36).****NG****Repair or replace harness or connector.****OK**

4 Check pressure switch (PH).

In case of using the hand-held tester:

PREPARATION:

- Connect the hand-held tester to the DLC3.
- Turn the ignition switch ON and push the hand-held tester main switch ON.
- Select the DATALIST mode on the hand-held tester.

CHECK:

Depress the brake pedal more than 40 times with the ignition switch OFF then turn the ignition switch ON and check the pressure switch (PH) condition.

HINT:

When a pressure in power supply system is released, reaction force becomes light and stroke becomes longer.


OK:

"OFF" turns to "ON".

HINT:

OFF: Low pressure

ON: High pressure



In case of not using the hand-held tester:

PREPARATION:

- Disconnect the connector (5P) from the hydraulic brake booster.
- With the ignition switch OFF, depress the brake pedal more than 40 times to decrease the accumulator pressure.

HINT:

When a pressure in power supply system is released, reaction force becomes light and stroke becomes longer.

CHECK:

Measure resistance between terminals PH and PHG of hydraulic brake booster connector.

OK:

Resistance: 1.0 kΩ

PREPARATION:

- Connect the connector (5P) to the hydraulic brake booster.
- Disconnect the connector (5P) after ignition switch has been ON and the pump motor has stopped.

CHECK:

Measure resistance between terminals PH and PHG of hydraulic brake booster connector.

OK:

Resistance: 0 Ω

HINT:

After inspection, connect the connector and clear the DTC (See page [DI-600](#)).

NG

Replace hydraulic brake booster assembly.

OK

5 Check pressure switch (PL).**In case of using hand-held tester:****PREPARATION:**

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and push the hand-held tester main switch ON.
- (c) Select the DATALIST mode on the hand-held tester.

CHECK:

Depress the brake pedal more than 40 times with the ignition switch OFF then turn the ignition switch ON and check the pressure switch (PL) condition.


HINT:

When a pressure in power supply system is released, reaction force becomes light and stroke becomes longer.

OK:**"OFF" turns to "ON".****HINT:**

OFF: Low pressure

ON: High pressure

**In case of not using hand-held tester:****PREPARATION:**

- (a) Disconnect the connector (8P) from the hydraulic brake booster.
- (b) With the ignition switch OFF, depress the brake pedal more than 40 times to decrease the accumulator pressure.

HINT:

When a pressure in power supply system is released, reaction force becomes light and stroke becomes longer.

CHECK:

Measure resistance between terminals PL and PLG of hydraulic brake booster connector.

OK:**Resistance: 5.7 kΩ****PREPARATION:**

- (a) Connect the connector (8P) to the hydraulic brake booster.
- (b) Disconnect the connector (8P) after ignition switch has been ON and the pump motor has stopped.

CHECK:

Measure resistance between terminals PL and PLG of hydraulic brake booster connector.

OK:**Resistance: 1.0 kΩ**

HINT:

After inspection, connect the connector and clear the DTC (See page [DI-600](#)).

NG

Replace hydraulic brake booster assembly.

OK

6

Check for short circuit (to B+) in harness and connector between pressure switch and skid control ECU (See page [IN-36](#)).


NG

Repair or replace harness or connector.

OK

7

Check ABS motor 1 relay and ABS motor 2 relay.



BE1840
R15257
R15258

F00044

PREPARATION:

Remove the ABS motor 1 relay and ABS motor 2 relay from engine room J/B.

CHECK:

Check continuity between each pair of terminal of motor relay.

OK:

Terminals 3 and 4	Continuity (Reference value * ¹)
Terminals 1 and 2	Open

*1: ABS motor 1 relay 54 Ω

ABS motor 2 relay 62 Ω

CHECK:

(a) Apply battery positive voltage between terminals 3 and 4.

(b) Check continuity between terminals.

OK:

Terminals 1 and 2	Continuity
-------------------	------------

NG

Replace ABS motor 1 relay or ABS motor 2 relay.

OK

8

Check for short circuit in harness and connector between ABS motor 1 relay or ABS motor 2 relay and skid control ECU (See page [IN-36](#)).

NG

Repair or replace harness or connector.

OK

Check and replace skid control ECU.

9

Check for open or short circuit in harness and connector between hydraulic brake booster and skid control ECU (See page [IN-36](#)).

NG

Replace wire harness.

OK

10

Check hydraulic brake booster pump motor (See page [BR-55](#)).

NG

Replace hydraulic brake booster pump motor.

OK

Replace hydraulic brake booster.