

18. Panel Switch Does Not Function (A/C control only)

INSPECTION PROCEDURE

1 Display check mode (Panel Switch Check screen).

NG

Replace the multi display.

OK

2 Check "AVC-LAN communication circuit" (See page [DI-1668](#)).

NG

Replace or repair AVC-LAN circuit.

OK

3 Check for open and short in harness and connector between gateway ECU and multi-display.

NG

Repair or replace wire harness and connector.

OK

Check and replace A/C amplifier (Center ECU).