

12. Map DISC cannot be inserted.

INSPECTION PROCEDURE

1 Check the MAP DISC.

NG

Replace the MAP DISC.

OK

2 Insert a MAP DISC without tilt.

OK

Normal.

NG

3 Check the navigation ECU power source circuit (see page [DI-1649](#)).

NG

Replace or repair wire harness.

OK

Replace the navigation ECU.