


Sliding Roof Control Switch Circuit

CIRCUIT DISCRIPTION

This circuit sends the sliding roof control switch operation signal to the ECU.

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

If there is not the hand-held tester, begin with STEP 2.

1	Check sliding roof control switch operation.
---	---

PREPARATION:

Connect the hand-held tester to the DLC3.

CHECK:

- (a) Enter DATA LIST function of hand-held tester.
- (b) Check that switch status (ON/OFF) changes on the screen of hand-held tester as the sliding roof control switch of the vehicle is turned.

OK:

The switch status is normal.

OK

Replace sliding roof gear assembly with ECU
(See page [IN-36](#)).

NG

2	Check sliding roof control switch (See page BE-132).
---	---

NG

Replace sliding roof switch.

OK

3	Check wire harness and connectors between sliding roof gear assembly with ECU and overhead J/B assembly (See page IN-36).
---	--

NG

Repair and replace wire harness or connector.

OK

Proceed to next circuit inspection shown on
problem symptom table (See page [DI-1382](#)).