


REPLACEMENT


1. REMOVE FRONT DRIVE SHAFT

(See page SA-25)



2. REPLACE OIL SEAL


- (a) Using SST, remove the oil seal.
SST 09308-00010
- (b) Coat the hypoid gear oil to a new oil seal periphery.



- (c) Using SST and a hammer, install a new oil seal.
SST 09550-00032, 09950-70010 (09951-07100)
- (d) Coat the MP grease to the oil seal lip.

3. INSTALL FRONT DRIVE SHAFT

(See page SA-31)



4. FILL DIFFERENTIAL WITH HYPOID GEAR OIL

Torque: 49 N·m (500 kgf·cm, 36 ft·lbf)

Oil type: Hypoid gear oil API GL-5

Recommended oil viscosity:

Above -18°C (0°F) SAE 90

Below -18°C (0°F) SAE 80W-90 or 80W

Capacity: 1.60 liters (1.69 US qts, 1.41 Imp.qts)