

|            |                 |                                      |
|------------|-----------------|--------------------------------------|
| <b>DTC</b> | <b>B0116/48</b> | <b>Open in Side Squib LH Circuit</b> |
|------------|-----------------|--------------------------------------|

## CIRCUIT DESCRIPTION

The side squib LH circuit consists of the airbag sensor assembly and the side airbag assembly LH. It causes the SRS to deploy when the SRS deployment conditions are satisfied. For details of the function of each component, see OPERATION on page RS-3. DTC B0116/48 is recorded when an open is detected in the side squib LH circuit.


| DTC No.  | DTC Detecting Condition                                                                                                                                              | Trouble Area                                                                                                                                              |
|----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| B0116/48 | <ul style="list-style-type: none"> <li>• Open in side squib LH circuit</li> <li>• Side squib LH malfunction</li> <li>• Airbag sensor assembly malfunction</li> </ul> | <ul style="list-style-type: none"> <li>• Side airbag assembly LH (Side squib LH)</li> <li>• Airbag sensor assembly</li> <li>• Floor No. 1 wire</li> </ul> |

## WIRING DIAGRAM


See page DI-945.

## INSPECTION PROCEDURE

|          |                                                             |
|----------|-------------------------------------------------------------|
| <b>1</b> | <b>Prepare for inspection (See step 1 on page DI-1109).</b> |
|----------|-------------------------------------------------------------|



|          |                                                        |
|----------|--------------------------------------------------------|
| <b>2</b> | <b>Check floor No. 1 wire (side squib LH circuit).</b> |
|----------|--------------------------------------------------------|



### CHECK:

Measure the resistance between SFL+ and SFL- of the floor No. 1 wire connector on the side airbag assembly LH (side squib LH) side.

### OK:


**Resistance: Below 1  $\Omega$**

**NG**

**Replace floor No. 1 wire.**

**OK**

### 3 Check airbag sensor assembly.



#### PREPARATION:

- Connect the connector to the airbag sensor assembly.
- Using a service wire, connect SFL+ and SFL- of the floor No. 1 wire connector on the side airbag assembly LH (side squib LH) side.
- Connect the negative (-) terminal cable to the battery, and wait at least 2 seconds.

#### CHECK:

- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Clear the DTC stored in memory (See page [DI-882](#)).
- Turn the ignition switch to LOCK, and wait at least for 10 seconds.
- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Check the DTC (See page [DI-882](#)).

#### OK:

**DTC B0116/48 is not output.**

#### HINT:

Codes other than code B0116/48 may be output at this time, but they are not relevant to this check.

**NG**


**Replace airbag sensor assembly.**

**OK**

4


**Check side squib LH.**

Side Squib LH



DLC3

DTC B0116/48

H01018 AB0119  
H10600 H01074

H11028

**PREPARATION:**

- Turn the ignition switch to LOCK.
- Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- Connect the side airbag assembly LH (side squib LH) connector.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.

**CHECK:**

- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Clear the DTC stored in memory (See page [DI-882](#)).
- Turn the ignition switch to LOCK, and wait at least for 10 seconds.
- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Check the DTC (See page [DI-882](#)).

**OK:****DTC B0116/48 is not output.****HINT:**

Codes other than code B0116/48 may be output at this time, but they are not relevant to this check.

**NG****Replace side airbag assembly LH (side squib LH).****OK**

**From the results of the above inspection, the malfunctioning part can now be considered normal. To make sure of this, use the simulation method to check.**