

REPLACEMENT

REPLACEMENT REQUIREMENTS

In the following cases, replace the seatback assembly or seatback cover.

Case	Replacing part
If the side airbag has been deployed.	Seatback assembly
If the side airbag assembly has been found to be faulty in troubleshooting.	Seatback assembly
If the side airbag assembly has cuts during checking items (See page RS-45).	Seatback assembly
If the seatback cover has cuts and frayed seams during checking items (See page RS-45).	Seatback cover
If the side airbag assembly has been found to be faulty during checking items (See page RS-45).	Seatback assembly
If the seatback cover has been found to be faulty during checking items (See page RS-45).	Seatback cover
If the seatback assembly has been dropped.	Seatback assembly

CAUTION:

For removal and installation of the seatback assembly, see page [RS-42](#) and [RS-53](#). Be sure to follow the correct procedure.