

# ELECTRICAL SYSTEM

## CONTENTS

|                                     |    |  |     |
|-------------------------------------|----|--|-----|
| SPECIFICATIONS .....                | 2  | IGNITION COIL .....                                    | 101 |
| GENERAL SPECIFICATIONS .....        | 2  | WIRING HARNESS .....                                   | 102 |
| SERVICE SPECIFICATIONS .....        | 15 | FUSES .....  | 131 |
| TORQUE SPECIFICATIONS .....         | 16 | IGNITION SWITCH .....                                  | 133 |
| TROUBLESHOOTING .....               | 17 | METERS AND GAUGES .....                                | 134 |
| SERVICE ADJUSTMENT PROCEDURES ..... | 73 | LIGHTING SYSTEM .....                                  | 144 |
| BATTERY .....                       | 73 | WINDSHIELD WIPERS AND WASHER .....                     | 149 |
| CHARGING SYSTEM .....               | 74 | REAR WINDOW WIPER AND WASHER .....                     | 152 |
| IGNITION SYSTEM .....               | 77 | HEADLIGHT WASHER .....                                 | 154 |
| COMPONENT SERVICE .....             | 79 | HORN .....   | 156 |
| CHARGING SYSTEM .....               | 79 | CLOCK .....  | 158 |
| STARTING SYSTEM .....               | 84 | REAR WINDOW DEFOGGER .....                             | 159 |
| IGNITION SYSTEM .....               | 97 | RADIO AND STEREO .....                                 | 161 |
|                                     |    | POWER WINDOW .....                                     | 166 |
|                                     |    | 3-POINT ELR SEAT BELTS WITH<br>TENSION RELIEFERS ..... | 169 |



## SPECIFICATIONS

### GENERAL SPECIFICATIONS

#### Starter Motor

|  | Engine with M/T     | Engine with A/T     |
|--|---------------------|---------------------|
| Model No.                                      | M3T25882            | M2T53083            |
| Type   | Direct drive        | Reduction drive     |
| Output (nominal) kW/V                          | 0.9/12              | 1.2/12              |
| Turning direction (as viewed from pinion side) | Clockwise           | Clockwise           |
| No. of teeth of pinion                         | 8                   | 9                   |
| No-load characteristics                        |                     |                     |
| Terminal voltage V                             | 11.5                | 11.5                |
| Current A                                      | 60 or less          | 100 or less         |
| Speed rpm                                      | 6,500 or more       | 3,000 or more       |
| Under-cut depth mm (in.)                       | 0.5-1 (.020-.039)   | 0.5-1 (.020-.039)   |
| Service limit                                  | 0.2 (.008) or less  | 0.2 (.008) or less  |
| Commutator diameter mm (in.)                   | 38.7 (1.524)        | 32 (1.260)          |
| Service limit                                  | 37.7 (1.484)        | 31 (1.220)          |
| Pinion gap mm (in.)                            | 0.5-2.0 (.020-.079) | 0.5-2.0 (.020-.079) |

#### Distributor

|   | Federal                | California             |
|---|------------------------|------------------------|
| Model No.   | T3T61971<br>(MD073074) | T3T61972<br>(MD073075) |
| Type  | Contact-pointless type | Contact-pointless type |
| Igniter   | Built-in type          | Built-in type          |
| Turning direction   | Clockwise              | Clockwise              |
| Firing order  | 1-3-4-2                | 1-3-4-2                |
| Centrifugal advance<br>(distributor angle at distributor rpm) |                        |                        |
| Initial   | 0° at 750              | 0° at 750              |
| Middle  | 7° at 1,900            | 7° at 1,900            |
| Final   | 8.5° at 2,500          | 8.5° at 2,500          |
| Vacuum advance<br>(distributor angle at mm (in.) of mercury)  |                        |                        |
| Initial   | 0° at 130 (5.12)       | 0° at 130 (5.12)       |
| Middle  | 6.5° at 180 (7.09)     | 5.3° at 180 (7.09)     |
| Final   | 15° at 300 (11.81)     | 11.5° at 280 (11.02)   |

## SPECIFICATIONS



### Ignition Coil

|                                       |       |
|---------------------------------------|-------|
| Identification model No.              | E-089 |
| Primary resistance $\Omega$           | 1.2   |
| Secondary resistance $k\Omega$        | 13.7  |
| External resistor resistance $\Omega$ | 1.35  |

### Spark Plugs

|                   |                     |
|-------------------|---------------------|
| Model No. NGK     | BP5ES-11            |
| NIPPONDENSO       | W16EPR-U10          |
| Plug gap mm (in.) | 1.0-1.1 (.039-.043) |

### Alternator

|   |                               |                               |
|---|-------------------------------|-------------------------------|
| Model No.                                 | A5T21077<br>(MD064068)        | A2T41377<br>(MD074645)        |
| Output (nominal) V/A                      | 12/50                         | 12/55                         |
| Regulated voltage V                       | 14.4 $\pm$ 0.5 at 20°C (68°F) | 14.4 $\pm$ 0.5 at 20°C (68°F) |
| Polarity                                  | Minus (–) ground              | Minus (–) ground              |
| Turning direction (as viewed from pulley) | Clockwise                     | Clockwise                     |
| Voltage regulator                         | Electronic, built-in type     | Electronic, built-in type     |

### Battery

|  |   |  |
|--|---|--|
| Type                                       | NX100-S6 (S)-MF<br>(Maintenance free battery) | NX120-7-MF<br>(Maintenance free battery) |
| Capacity (20HR) Ah                         | 45  | 80                                       |
| Voltage V                                  | 12  | 12                                       |
| Electrolyte specific gravity [20°C (60°F)] | 1.280   | 1.280                                    |

#### NOTE

If the specific gravity of the battery electrolyte falls 0.06 or more, recharge the battery.



## SPECIFICATIONS

### Fuses

| Fusible links   | For Federal<br>(not available<br>in California) | For California<br>(can also be sold in Federal states) |   |
|---|---|--|---|
| <b>Main</b>   |   |  |   |
| Cable color   | Red   | Red  | Green   |
| Fusible link size mm <sup>2</sup> (in. <sup>2</sup> ) | 0.85 (.0013)                                    | 0.85 (.0013)   | 0.5 (.0008)                                     |
| Permissible continuous current A                      | 34  | 34   | 27  |
| Fusing current A                                      | 150   | 150  | 100   |
| <b>Sub</b>  |   |  |   |
| Cable color   | Ignition circuit<br>Green                       | Power window<br>circuit<br>Green                       | Headlight, headlight<br>washer circuit<br>Brown |
| Fusible link size mm <sup>2</sup> (in. <sup>2</sup> ) | 0.5 (.0008)                                     | 0.5 (.0008)  | 0.3 (.0005)                                     |
| Permissible continuous current A                      | 27  | 27   | 19  |
| Fusing current A                                      | 100   | 100  | 65  |
| Fuse capacity A                                       | 10  | 15   | 20  |
| Color   | Red   | Light blue   | Yellow  |

### Ignition Switch

#### Ignition switch

|      |   |
|------|---|
| Type | Rotary switch with steering wheel lock<br>and key-reminder switch |
|------|---|

#### Load capacity A

|        |    |
|--------|----|
| AM-ACC | 15 |
| AM-IG  | 30 |
| AM-ST  | 15 |
| AM-R   | 15 |

#### Key-reminder switch

|                 |   |
|-----------------|---|
| Load capacity W | 1 |
|-----------------|---|

## SPECIFICATIONS



### Meters and Gauges

#### Speedometer

|   |              |
|---|--------------|
| Speed indication range mph (km/h)             | 0-85 (0-137) |
| Indication ratings (range of allowable error) |              |
| Meter with "mph" indication mph               |              |
| 25 mph  | +2.5         |
|   | 0            |
| 50 mph  | +3.5         |
|   | +0.3         |
| 75 mph  | +5           |
|   | +1           |

#### Tachometer

|   |               |
|---|---------------|
| Type  | Pulse type    |
| Detection source                                  | Ignition coil |
| Red zone rpm                                      | 6,000-8,000   |
| Indication ratings (range of allowable error) rpm |               |
| 1,000 rpm   | ± 100         |
| 2,000 rpm   | ± 100         |
| 3,000 rpm   | ± 150         |
| 4,000 rpm   | ± 200         |
| 5,000 rpm   | ± 250         |

#### Fuel gauge

|   |  |
|---|--|
| Type                                      | Bi-metal type<br>(built-in constant voltage relay) |
| Constant voltage relay resistance value Ω | 68.72  |

#### Fuel gauge unit


|  |                     |
|--|---------------------|
| Type                                   | 7-V resistance type |
| Standard resistance value Ω            |                     |
| Float position "F" point               | 14.9-19.1           |
| Float position "E" point               | 113.5-126.5         |
| Float vertical movement range mm (in.) | 222-220 (8.81-8.97) |

#### Water temperature gauge

|      |               |
|------|---------------|
| Type | Bi-metal type |
|------|---------------|

#### Water temperature gauge unit

|                             |                 |
|-----------------------------|-----------------|
| Type                        | Thermistor type |
| Standard resistance value Ω |                 |
| 70°C (158°F)                | 90.5-117.5      |
| 115°C (239°F)               | 21.3-26.3       |



## SPECIFICATIONS

---

|   |                   |
|---|-------------------|
| Oil pressure gauge                              |                   |
| Type  | Bi-metal type     |
| Oil pressure gauge unit                         |                   |
| Type  | Bi-metal type     |
| Standard resistance value $\Omega$              |                   |
| 0 kPa (0 psi)                                   | 0                 |
| 588 kPa (85 psi)                                | 136               |
| Inclinometer                                    |                   |
| Type  | Gravity type      |
| Damping system                                  | Oil-filled system |
| Indication angle                                |                   |
| Forward, backward                               | 45° max.          |
| Right, left                                     | 45° max.          |
| Voltage meter                                   |                   |
| Type  | Bimetal type      |
| Indication ratings (range of allowable error) V |                   |
| 10 V  | $\pm 0.5$         |
| 14 V  | $\pm 0.5$         |

---


## SPECIFICATIONS



### Indicator and Warning Lights

W (SAE trade numbers)

|   |          |
|---|----------|
| 1. Upper-beam and passing indicator light | 1.4 (74) |
| 2. Turn-signal indicator lights           | 1.4 (74) |
| 3. Brake warning light                    | 1.4 (74) |
| 4. Oil pressure warning light             | 1.4 (74) |
| 5. Charging warning light                 | 1.4 (74) |
| 6. Fasten-seat-belt warning light         | 1.4 (74) |
| 7. Door-ajar warning light                | 1.4 (74) |
| 8. 4WD indicator light                    | 1.4 (74) |



### Sensor and Switches

#### Parking brake switch

|                                      |             |
|--------------------------------------|-------------|
| Rated load W                         | 5           |
| Voltage drop (at 12 V, rated load) V | 0.1 or less |

#### Brake fluid lever sensor

|                                      |             |
|--------------------------------------|-------------|
| Rated load W                         | 3.6         |
| Voltage drop (at 12 V, rated load) V | 0.1 or less |

#### Door switch


|                                      |             |
|--------------------------------------|-------------|
| Rated load W                         | 15          |
| Voltage drop (at 12 V, rated load) V | 0.2 or less |

#### Belt switch

|      |                      |
|------|----------------------|
| Type | Normally closed type |
|------|----------------------|

### Seat Belt Warning Timer

|                     |   |
|---------------------|---|
| Rated load          | 3.4 W (light) and $24 \frac{+10}{-0} \Omega$ (buzzer) |
| Operating voltage V | 8.0-16.0  |



## SPECIFICATIONS

### Buzzer

|  |        |
|--|--------|
| Rated voltage V                          | 13.5   |
| Operating voltage range V                | 11-15  |
| While buzzing (Terminal voltage at 13 V) |        |
| Sound pressure dB                        | 70 ± 5 |
| Fundamental frequency Hz                 | 700    |

### Lighting System

|                                       |             |
|---------------------------------------|-------------|
| Main lights W (SAE trade numbers)     |             |
| Headlights                            | 60/50       |
| Front combination lights              |             |
| Turn-signal lights                    | 27 (1156)   |
| Front side marker and position lights | 3.8 (194)   |
| Rear combination lights               |             |
| Turn-signal, stop and tail lights     | 27/8 (1157) |
| Rear side marker lights               | 3.8 (194)   |
| Back-up lights                        | 27 (1156)   |
| License plate lights                  | 6           |

|  |           |
|--|-----------|
| Sub lights W (SAE trade number)                |           |
| Dome light                                     | 10        |
| Combination meter illumination light           | 3.4 (158) |
| Cigarette lighter illumination light           | 1.4 (74)  |
| Heater panel illumination light                | 1.4 (74)  |
| Rear window defogger switch illumination light | 0.9       |
| Ashtray illumination light                     | 1.4 (74)  |

### Turn-signal flasher unit

|   |                |
|---|----------------|
| Type  | Condenser type |
| Rated load W  | 82.9-84.2      |
| Blinking frequency cycle/min<br>[12.8 V, 20°C (68°F)] | 85 ± 10        |

### Hazard warning flasher unit

|   |                |
|---|----------------|
| Type  | Heat-band type |
| Rated load W  | 49.4-168.8     |
| Blinking frequency cycle/min<br>[12.8 V, 20°C (68°F)] | 90 ± 10        |

## SPECIFICATIONS



### Column switch

#### Turn-signal switch

|   |             |
|---|-------------|
| Rated load A                                | 6.1-7.1     |
| Voltage drop (at 12 V and the rated load) V | 0.2 or less |

#### Dimmer switch

|   |             |
|---|-------------|
| Rated load A                                |             |
| High beam                                   | 16.1-18.7   |
| Low beam                                    | 9.4-10.8    |
| Voltage drop (at 12 V and the rated load) V | 0.2 or less |

#### Passing switch

|   |             |
|---|-------------|
| Rated load A                                |             |
| High beam                                   | 16.1-18.7   |
| Low beam                                    | 9.4-10.8    |
| Voltage drop (at 12 V and the rated load) V | 0.2 or less |

#### Lighting switch

|   |             |
|---|-------------|
| Rated load A                                | 0.17-0.27   |
| Voltage drop (at 12 V and the rated load) V | 0.2 or less |

#### Headlight washer switch

|   |             |
|---|-------------|
| Rated load A                                | 0.5         |
| Voltage drop (at 12 V and the rated load) V | 0.2 or less |

#### Hazard warning switch

|   |             |
|---|-------------|
| Voltage drop (at 12 V and the rated load) V | 0.2 or less |
|---|-------------|

#### Light control relay

|                                  |             |
|----------------------------------|-------------|
| Rated load W                     | 200         |
| Range of voltage used V          | 10-16       |
| Voltage drop between terminals V | 0.2 or less |

#### Dimmer control switch

|              |                          |
|--------------|--------------------------|
| Type         | Variable-resistance type |
| Rated load W | 15 (Min.)-26.6 (Max.)    |

#### Stop light switch

|   |              |
|---|--------------|
| Rated load W                                | 150          |
| Voltage drop (at 12 V and the rated load) V | 0.15 or less |



## SPECIFICATIONS

### Windshield Wipers and Washer

|   |                                    |
|---|------------------------------------|
| Wiper motor   |                                    |
| Type  | Permanent-magnet type              |
| Speed control system  | 3-brush system                     |
| Braking system  | Dynamic brake system               |
| Revolution under load rpm   |                                    |
| Low speed [1.9 Nm (1.4 ft.lbs.)]                                    | 35 ± 4                             |
| High speed [1.3 Nm (0.9 ft.lbs.)]                                   | 45 ± 8                             |
| Nominal torque Nm (ft.lbs.)   | 13 (9)                             |
| Wiper blades  |                                    |
| Wiping angle  |                                    |
| Driver's side   | 85.5°                              |
| Passenger's side  | 114°                               |
| Blade length mm (in.)   | 401 (16)                           |
| Washer motor and pump   |                                    |
| Motor type  | Direct current ferrite magnet type |
| Pump type   | Centrifugal type                   |
| Power consumption A   | 3.5 or less                        |
| Time of continuous use sec.   |                                    |
| With washer fluid   | Max. 60                            |
| Empty operation   | Max. 20                            |
| Nozzle jet pressure kPa (psi)                                       | 69 (10.0) or more                  |
| Tank capacity lit. (U.S.qts., Imp.qts.)                             | 1.5 (1.6, 1.3)                     |
| Intermittent wiper relay  |                                    |
| Intermittent cycle sec.   | 1.5 ± 0.7-10.5 ± 3                 |
| Delay time in combined intermittent wiper and washer operation sec. | 0.4-1.2                            |
| Load current A  | 5 (motor load)                     |
| Wiper switch  |                                    |
| Rated load A  | 0.5                                |
| Intermittent  | 0.22 ± 0.05                        |
| Low speed   | 3.5                                |
| High speed  | 4.5                                |
| Lock  | 18                                 |
| Voltage drop (at 12 V and the rated load) V                         | 0.2 or less                        |
| Washer switch   |                                    |
| Rated load A  | 3                                  |
| Voltage drop (at 12 V and the rated load) V                         | 0.5 or less                        |

## SPECIFICATIONS



### Rear Window Wiper and Washer

#### Wiper motor

|                              |                        |
|------------------------------|------------------------|
| Motor type                   | Ferrite magnet type    |
| Braking system               | Dynamic braking system |
| Revolution under no-load rpm | 50 ± 5                 |
| Nominal torque Nm (ft.lbs.)  | 6 (4) or more          |
| No-load current A            | 2 or less              |

#### Wiper blade

|                       |          |
|-----------------------|----------|
| Wiping angle          | 108°     |
| Blade length mm (in.) | 334 (13) |

#### Window washer motor and pump

|   |                                    |
|---|------------------------------------|
| Motor type                              | Direct current ferrite magnet type |
| Pump type                               | Centrifugal type                   |
| Power consumption A                     | 3.5 or less                        |
| Allowable period of continuous use sec. |                                    |
| With washer fluid                       | Max. 60                            |
| Empty operation                         | Max. 20                            |
| Nozzle jet-spray pressure kPa (psi)     | 78 (11.4) or more                  |
| Tank capacity lit. (U.S.qts., Imp.qt.)  | 1.1 (1.2, 1.0) or more             |

#### Wiper and washer switch

|   |             |
|---|-------------|
| Rated load A                                |             |
| Wiper switch                                | 3           |
| Washer switch                               | 5           |
| Voltage drop (at 12 V and the rated load) V | 0.2 or less |

### Headlight washer

#### Headlight washer motor

|   |                     |
|---|---------------------|
| Motor type                              | Ferrite magnet type |
| Pump type                               | Centrifugal type    |
| Power consumption A                     | 21 or less          |
| Nozzle injection pressure kPa (psi)     | 177 (25.6) or more  |
| Tank capacity lit. (U.S.qts., Imp.qts.) | 3.0 (3.2, 26)       |

#### Headlight washer control relay

|                    |            |
|--------------------|------------|
| Timer setting sec. | 0.52 ± 0.1 |
|--------------------|------------|

#### Check valve

|  |                   |
|--|-------------------|
| Valve opening and closing pressure kPa (psi) | 49-108 (7.1-15.6) |
|--|-------------------|



## SPECIFICATIONS

### Horn

|                              |             |
|------------------------------|-------------|
| Type                         | Flat type   |
| Effective sounding voltage V | 11-14.5     |
| Power consumption A          | 3.5 or less |
| Sound level dB               | 100-110     |
| Fundamental frequency Hz     |             |
| "low" sound                  | 340-380     |
| "high" sound                 | 400-440     |

### Clock

|   |   |
|---|---|
| Type  | Crystal oscillating type                      |
| Display type  | Fluorescent digital display (12 hour display) |
| Daily variation seconds/day<br>[at a power supply of 9 to 16V,<br>20°C(68°F) ambient temperature] | ± 2   |

### Cigarette Lighter

|   |                   |
|---|-------------------|
| Rated input W                           | 120               |
| Timing of plug pop-up                   | Within 18 seconds |
| Cigarette lighter light bulb capacity W | 1.4 x 1           |
| Ashtray light bulb capacity W           | 1.4 x 1           |

### Rear Window Defogger

|                                   |             |
|-----------------------------------|-------------|
| Rear window defogger switch       |             |
| Type                              | Seesaw type |
| Rated current A                   | 12          |
| Indicator light W                 | 0.9         |
| Rear window glass with defogger   |             |
| No. of printed heater lines       | 11          |
| Power consumption [20°C (68°F)] W | 102-138     |

## SPECIFICATIONS



### Radio and Stereo

#### Radio

|                       |                |   |           |
|-----------------------|----------------|---|-----------|
| Model                 | AR-8729 SEKR-Y |   |           |
| Receiving bands       | AM/FM-MPX      |   |           |
| Circuitry             | AM             | High frequency: 1 step; mid frequency:<br>1 step, superheterodyne amplification |           |
|                       | FM             | High frequency: 1 step; mid frequency:<br>1 step, superheterodyne amplification |           |
|                       |                | Ratio detection, PLL, FM stereo demodulation,<br>and noise killer circuits      |           |
| Reception frequencies | AM             | kHz   | 525-1,615 |
|                       | FM             | MHz   | 88-108    |

#### Tape player


|                    |  |     |           |
|--------------------|--|-----|-----------|
| Model              | RX-750 SY-RY                                   |     |           |
| Playback system    | 4-track auto-reverse stereo playback           |     |           |
| Adaptable tape     | Normal, C-90 or shorter tape                   |     |           |
| Output W           | 4  |     |           |
| Tape speed cm/sec. | 4.76   |     |           |
| Tuning system      | Manual search tuning, Mechanical memory tuning |     |           |
| Frequency coverage | AM   | kHz | 525-1,615 |
|                    | FM   | MHz | 88-108    |

#### Speakers

|                                |                                 |                               |
|--------------------------------|---------------------------------|-------------------------------|
| Model                          | SG-28A8                         | SG-3K44-G, SG-3K44-R          |
| Rated input power W            | 5 (Max. 7)                      | 5 (Max. 7)                    |
| Output sound pressure level dB | 88-92                           | 88-92                         |
| Mounting position              | Instrument panel, driver's side | Left and right center pillars |

#### Antenna

|      |                               |
|------|-------------------------------|
| Type | Whip antenna (Fender-mounted) |
|------|-------------------------------|



## SPECIFICATIONS

### Power Windows

#### Power window motor

|                            |  |
|----------------------------|--|
| Type                       | Permanent magnet type (built-in circuit breaker) |
| Revolutions under load rpm |  |
| At 1 Nm (.72 ft. lbs.)     | 60-90  |
| At 2 Nm (1.45 ft. lbs.)    | 50-80  |
| Bound current A            | 34 or less                                       |
| Direction of rotation      | Clockwise and counterclockwise                   |

#### Power window main switch

|                      |                      |
|----------------------|----------------------|
| Type                 | Automatic reset type |
| Rated load current A |                      |
| Lock switch          | 30                   |
| L.H. switch          | 11                   |
| R.H. switch          | 11                   |

#### Power window sub switch

|                      |                      |
|----------------------|----------------------|
| Type                 | Automatic reset type |
| Rated load current A | 11                   |

#### Power window relay

|  |             |
|--|-------------|
| Maximum contact current A  | 20          |
| Rated coil current A   | 0.13-0.19   |
| Voltage drop between terminals V<br>(at 12 V and the rated load current) | 0.2 or less |

### 3-Point ELR seat belts with tension relievers

|  |                    |
|--|--------------------|
| Belt switches  | Normally open type |
| Seat belt solenoids                                  |                    |
| Operating voltage V                                  | 8-16               |
| Continuous rating (50 Ω, 240 mA)                     | 2.88 W             |
| Insulation resistance (measured with 500-VDC megger) | 100 MΩ             |

# SPECIFICATIONS



## SERVICE SPECIFICATIONS

### Engine

#### General

Basic ignition timing  $7 \pm 2^\circ$  BTDC

### Meters and Gauges

#### Fuel gauge indication test

When resistance is  $17 \Omega$

Scale indication A

When resistance is  $120 \Omega$

Scale indication B

#### Fuel gauge continuity test

Resistance value  $\Omega$

Approx. 25

#### Water temperature gauge indication test

When resistance is  $23.8 \Omega$

Scale indication C

When resistance is  $104 \Omega$

Scale indication D

#### Water temperature gauge continuity test

Resistance value  $\Omega$

Approx. 55

#### Water temperature gauge unit operation check

When water temperature is  $70^\circ\text{C}$  ( $158^\circ\text{F}$ )  $\Omega$

104

#### Oil pressure gauge indication test

When resistance is  $120 \Omega$

Scale indication E

#### Oil pressure gauge continuity test

Resistance value  $\Omega$


Approx. 42

#### Voltage meter continuity test


Resistance value  $\Omega$

420


### Fuel gauge




### Water temperature gauge



### Oil pressure gauge





## SPECIFICATIONS

### Lighting System

#### Standard value

Headlight intensity 20,000 cd or more

### Windshield Wipers and Washer

#### Standard value

Wiper blade stopping position mm (in.) 37-47 (1.5-1.9)  
(distance between blade tip and front deck garnish)

### Rear Window Wiper and Washer

#### Standard value

Wiper blade stopping position mm (in.) 20 (.8)  
(distance between blade tip and back door window weatherstrip)

## TORQUE SPECIFICATIONS

### Fuel Gauge Unit

Nm (ft.lbs.)

Fuel gauge unit 1 (0.7)

### Windshield Wipers and Washer

Nm (ft.lbs.)

|                                |              |
|--------------------------------|--------------|
| Wiper pivot shaft mounting nut | 7 (5)        |
| Wiper arm locking nut          | 10-16 (7-12) |
| Wiper motor                    | 3 (2)        |

### Rear Window Wiper and Washer


Nm (ft.lbs.)

|                                     |            |
|-------------------------------------|------------|
| Rear wiper pivot shaft mounting nut | 8-12 (6-9) |
| Rear wiper arm locking nut          | 7-10 (5-7) |
| Rear wiper motor                    | 7-10 (5-7) |

## TROUBLESHOOTING




### BATTERY



#### CAUTION

While engine is running (alternator generating power), make sure that L-terminal is not grounded. If L-terminal is grounded, auxiliary diode will be short-circuited and no voltage will be available at L-terminal, so no power will be generated. Therefore, CHARGE lamp will remain lit.



## TROUBLESHOOTING

### TEST 5

With the engine stopped and the ignition switch in the "ON" position, measure the voltage at the "F" terminal (for testing the alternator).

High (nearly the same as battery voltage)

0 to 0.5 V

0.5 to 2 V

Malfunction of the regulator (power transistor open)

Field coil wiring damaged, or poor brush contact

⊕ diode short

With the ignition switch in the "OFF" position, pull the connector from the alternator. Then, measure the voltage at the "L" terminal. If the voltage is close to battery voltage, the (+) diode is short-circuited.

#### CAUTION

When measuring the voltage of the "F" terminal (for testing), be careful not to let the voltmeter probe contact the rear bracket. If by chance it does contact it, there's no problem if it's immediately pulled away.


## TROUBLESHOOTING



### TEST 6

#### Output current test


Disconnect the wiring from the "B" terminal of the alternator, and connect an ammeter (60 A or higher) between the wires and the terminal. Start the engine. Then immediately increase the engine speed to 2,500 to 3,000 rpm and quickly read the maximum value shown by the ammeter. Note that all loads on the electrical system should be "ON" when this test is made.



### TEST 7

#### Output current test (re-check)

Check for poor contact of the wiring between the "B" terminal of the alternator and the positive (+) terminal of the battery. After slightly discharging the battery make TEST 6 once again.




#### NOTE

Make TEST 8 if it is necessary after finishing TESTS 6 and 7.

### TEST 8

#### Regulated voltage test

(See p.8-76.)





## TROUBLESHOOTING

### Overcharge

#### TEST 1

While measuring the voltage at the "B" terminal of the alternator, slowly increase the engine rpm from idle speed.  
Is the "B" terminal voltage 15.5 V or more?

Not 15.5 V or more

15.5 V or less

Malfunction of alternator  
(malfunction of electronic  
voltage regulator, or negative  
(-) brush is grounded)

#### TEST 2

Measure and compare the voltage of the "F" terminal (for checking the alternator) at idle speed and at approx. 3,000 rpm.  
Is the voltage higher at 3,000 rpm?

Higher

Not higher, or no change

Malfunction of alternator  
(malfunction of electronic  
voltage regulator, or negative  
(-) brush is grounded)

#### NOTE

The voltage of the "F" terminal  
may not increase if the battery  
is discharged.

#### TEST 3

Regulated voltage test.  
(See p.8-76.)

$14.4 \pm 0.5$  V at 20°C

There is an abnormal condition

Alternator normal


Malfunction of alternator

# TROUBLESHOOTING




## ENGINE





## TROUBLESHOOTING




## TROUBLESHOOTING



### STARTING SYSTEM


The troubles of starting system may be divided into "Starting motor does not turn", "Starting motor turns but engine does not start" and "It takes some time before engine starts". When there is something wrong with starting system, therefore, it is important to determine which part of starting system is defective with starting motor attached to engine.

Generally, starting difficulty, aside from inoperative starting motor, is often attributable to defective ignition system, fuel system, battery, electrical wiring, etc. If makeshift corrective steps are taken without locating the cause, same trouble will develop again.






## TROUBLESHOOTING



### Point to Note when Checking

1. To measure a voltage drop across contacts B and M, make connections as shown. (1EL030)

If there is a voltage drop of more than 0.3 V per 100 A, hard starting could result, when engine resistance increases as in very cold weather. In such a case, replace switch assembly.






## IGNITION SYSTEM

The cause of hard engine starting is not always in the ignition system. Defective parts may exist in the fuel system, exhaust emission control system, starting system or the engine itself.

The role of the ignition system is to generate sufficient electric sparks at the proper time. To check the ignition system, therefore, it is necessary that the spark check and timing measurement are carefully performed.

For on-vehicle troubleshooting of the ignition system, the short cut is to determine on the basis of symptoms which is defective: the power supply, primary low-tension circuit or high-tension circuit. For example, when all spark plugs fail to produce sparks, the probable cause is in power supply or primary circuit. If misfiring occurs only at a specific spark plug, the high tension circuit is likely to be defective. If misfiring occurs occasionally, loose leads or spark plugs may be suspected.





## TROUBLESHOOTING

### Spark test (when engine can be cranked)

TEST 1. Disconnect high tension cable from center tower of distributor cap, hold end of cable about 5 to 10 mm (.2 to .4 in.) away from cylinder block of engine, crank engine with starter to check spark condition. (1EL038)

NOTE

If engine cannot be cranked, comply with method on next page.

No spark produced

Spark produced

TEST 2. With ignition key at ON position, measure voltage of (+) terminal of ignition coil.

Check cap, rotor, spark plugs, cables and ignition timing

Voltage equal to battery voltage

0 V

Defective wiring between battery and ignition coil

TEST 3. With ignition key at ON position, measure voltage of (-) terminal of ignition coil.

Voltage equal to battery voltage

About 1 V

0 V

Faulty igniter or opened ignition coil

TEST 4. Remove ignition coil, and install normal ignition coil. Make a spark test as in the same manner shown in TEST 1.


No spark produced


Spark produced

Faulty distributor pickup coil

Defective ignition coil

## TROUBLESHOOTING





## TROUBLESHOOTING

### SPEEDOMETER

| Symptom   | Probable cause  | Remedy   |
|---|---|--|
| The speedometer pointer and/or the odometer do not function | Flexible shaft improperly connected<br>Damaged flexible shaft                   | Repair the routing of the speedometer cable or replace the cable |
|   | Drive gear is broken  | Replace the speedometer  |
| The speedometer pointer moves off the scale                 | Oil inside meter<br>Damaged hair spring   |  |
|   | Oil inside meter<br>Deformed hair spring<br>Foreign matter caught on the magnet |  |
| The speedometer pointer moves erratically                   | Flexible shaft improperly routed  | Repair the routing of the speedometer cable or replace the cable |
|   | Worn induction panel end or bearing   | Replace the speedometer  |
| The speedometer functions but the odometer does not         | Gear malfunction inside the speedometer   |  |


#### NOTE


If oil is inside the meter, replace the speedometer cable as well. Check the transmission fluid quantity and check for clogged breather plug, too.



## GAUGES


## Fuel Gauge and Unit





## TROUBLESHOOTING

### Water Temperature Gauge and Unit



## TROUBLESHOOTING



### INCLINOMETER


| Symptom  | Probable cause  | Remedy                        |
|--|---|-------------------------------|
| When vehicle inclines forward or backward, pointer does not move up or down                  | Internal parts such as pointer and pendulum defective | Replace inclinometer assembly |
| When vehicle inclines to right or left, spherical dial does not perform follow-up operation. | Internal parts such as dial and pendulum defective    |                               |
| Oil-like fluid flows out from bottom of case   | Seal of oil case broken                               |                               |
| Pointer and spherical dial frequently swing during vehicle operation                         | Oil case broken and oil leaking                       |                               |



## TROUBLESHOOTING

### INDICATORS AND WARNING LIGHTS


#### Oil Pressure Warning Light



## TROUBLESHOOTING




**The warning light remains illuminated**





## TROUBLESHOOTING


### Charging Warning Light




## TROUBLESHOOTING




The warning light does not go off






## TROUBLESHOOTING

### Door-Ajar Warning Light






## Brake System Warning Light

Brake warning light does not light under following conditions.

- (1) When parking brake switch is ON
- (2) When brake fluid level sensor switch is ON





## TROUBLESHOOTING

**Brake warning light remains lit**

**NOTE**

Check the brake fluid level and make sure it is correct.

Inspect with parking brake lever released and ignition key at "ON"

**Caution**

Make sure that vehicle is maintained in level position and wheels chocked.

Does light remain lit after disconnection of parking brake switch connector?

No

Parking brake switch defective

Replace the parking brake switch

Does light remain lit after disconnection of brake fluid level sensor connector?

No

Brake fluid level sensor defective

Replace the brake fluid sensor

Yes

Ground side of brake warning light circuit short circuited

Repair the harness

**Brake warning light does not light when parking brake lever is pulled**

With ignition key in "ON" position, check by pulling parking brake lever

Does the indicator light illuminate when parking brake switch connector is disconnected and YG wire grounded?

No

Open circuit in harness between brake warning light and parking brake switch

Repair the harness

Yes

Parking brake switch defective


Replace the parking brake switch

## TROUBLESHOOTING



**Brake warning light does not illuminate when brake fluid level is low.**


**Caution**  
Be sure the vehicle is level and the wheels are chocked.





## TROUBLESHOOTING


### Fasten Seat Belt Warning Light and Buzzer



## TROUBLESHOOTING




**Seat belt warning buzzer does not sound when ignition key is turned to "ON" with driver's seat belt not buckled.**






## TROUBLESHOOTING


Fasten seat belt warning buzzer continues to after driver's seat belt is fastened.



Fasten seat belt warning light remains illuminated for 8 seconds after ignition key is set to "ON"



## TROUBLESHOOTING



### Lighting System


Check the illumination of all lights; if there are any problems, use the following chart to check the appropriate location. (For trouble symptom Nos. 3, 4, and 7, refer to the corresponding yes/no troubleshooting chart.)

| Location  | Trouble symptoms |   |   |   |   |   |   |
|---|------------------|---|---|---|---|---|---|
|   | 1                | 2 | 3 | 4 | 5 | 6 | 7 |
| Headlights<br>[Both left and right lights should illuminate in both high and low beams]   | x                | o | x | o | Δ | o | Δ |
| Passing lights<br>[Both left and right lights should illuminate in high beams when the passing switch is at "ON" position]                          | o                | x | x | o | o | Δ | Δ |
| Position, tail, rear side marker and license plate lights<br>[All of these lights should illuminate when the lighting switch is at the first stage] | o                | o | o | x | o | o | Δ |
| Probable cause  | ↓                | ↓ | ↓ | ↓ | ↓ | ↓ | ↓ |
| Light control relay   | —                | — | ● | ● | — | — | ● |
| Column switch<br>Dimmer switch segment  | ●                | — | ● | — | ● | — | ● |
| Passing switch segment  | —                | ● | ● | — | — | ● | ● |
| Lighting switch segment   | ●                | — | ● | ● | — | — | ● |
| Body ground points<br>Front pillar, inner   | —                | — | ● | — | — | — | ● |
| Left side of engine compartment   | —                | — | — | ● | — | — | ● |
| Between battery and body  | —                | — | — | ● | — | — | ● |
| Fuse block (No. 2 fuse)   | —                | — | — | ● | — | — | — |
| Light bulb  | ●                | — | ● | ● | ● | — | ● |

### Remarks


The symbols used in the table indicate the following:

- : Normal illumination
- Δ : Dim illumination
- x : No illumination
- : Parts requiring check



## TROUBLESHOOTING


### Trouble Symptom 3




## TROUBLESHOOTING




### Trouble symptom 4





## TROUBLESHOOTING


### Trouble Symptom 7



## TROUBLESHOOTING



### Stop Light





## TROUBLESHOOTING

Stop light does not go out

Stop light switch improperly adjusted or defective

Adjust stop light switch position  
Replace stop light switch

### Turn-signal and hazard lights

One of the turn-signal lights or indicator lights does not illuminate

Incorrect connector connection

Correct the connector


Improper ground connection

Correct the ground connection

Light bulb malfunction

Replace the light bulb


## TROUBLESHOOTING





## TROUBLESHOOTING


All lights illuminate, but flashing is irregular  
All lights illuminate without flashing



## TROUBLESHOOTING




**Hazard lights and indicator lights do not illuminate**





## TROUBLESHOOTING


### WINDSHIELD WIPERS AND WASHER



## TROUBLESHOOTING




**Washer does not operate**






## TROUBLESHOOTING

The wipers do not operate when the washer switch is turned on, but washer operates properly





The wipers do not operate at all when the wiper switch is set to the star mark





## TROUBLESHOOTING

**Wipers operate continuously even after wiper switch is set to the star mark**

Check with ignition key at "ACC" position.

Do wipers operate continuously when intermittent wiper control unit connector is disconnected and wiper switch is set to the star mark?

No

Intermittent wiper control unit defective

Replace intermittent wiper control unit

Yes

Short circuit in wiper switch

Replace column switch

**Intermittent time cannot be adjusted**

Inspect with ignition key at "OFF"

Disconnect wiper switch connector and operate time adjustment switch. Does resistance between 0.3-Y wire and 2-B wire vary between 0 and 50 ohms?

No

Faulty wiper switch variable resistor

Faulty column switch

Yes

Is there continuity between intermittent wiper relay and wiper switch?

No

Damaged harness between intermittent wiper relay and wiper switch

Repair harness

Yes


Faulty intermittent wiper relay


Replace intermittent wiper relay

## TROUBLESHOOTING




### REAR WINDOW WIPER AND WASHER





## TROUBLESHOOTING





CONTINUED FROM  
PREVIOUS PAGE

Set the igniton key to the  
"OFF" position

Does continuity exist between  
the 0.3B-wire and ground  
when the rear washer switch  
is turned on?

Yes


No

A poor connection of the rear  
wiper and washer switch  
connector, or a malfunction  
in the rear wiper and washer  
switch

Repair the connector or replace  
the wiper and washer switch

Improperly grounded


Correct the ground connection



## TROUBLESHOOTING

### HEADLIGHT WASHER


The headlight washer motor does not operate when the headlight washer switch is pressed




## TROUBLESHOOTING




CONTINUED FROM  
PREVIOUS PAGE



The headlight washer motor operates, but the washer fluid does not spray






## TROUBLESHOOTING

### HORN


| Symptom                                   | Probable cause                                     | Remedy                            |
|---|--|-----------------------------------|
| Sound volume of horn is low or fluctuates | A loose or bent adjustment screw                   | Adjust the horn                   |
|   | Water, dirt, or other foreign matter lodged inside | Replace the horn                  |
|   | A loose horn or bracket mounting bolt              | Tighten the bolt                  |
|   | A drop in battery voltage                          | Check the battery                 |
|   | A poor connection of the horn switch               | Repair or replace the horn switch |
|   | A poor connection of the horn ground terminal      | Repair                            |

**Horn does not sound**






## Key-Reminder Switch






## TROUBLESHOOTING



## TROUBLESHOOTING



Defogger does not operate





## TROUBLESHOOTING


### POWER WINDOWS


| Symptom   | Probable cause                       | Remedy  |
|---|--------------------------------------|---|
| None of the door windows will operate   | Burnt-out main fusible link          | Replace the main fusible link and isolate cause |
|   | Burnt-out sub fusible link           | Replace the sub fusible link and isolate cause  |
|   | Burnt-out fuse                       | Replace the fuse and isolate cause              |
|   | Poor grounding power window relay    | Correct grounding                               |
|   | Malfunctioning power window relay    | Replace the relay                               |
|   | Malfunctioning main switch           | Replace the main switch                         |
|   | Break in harness, or poor connection | Correct or replace the harness                  |
| The front door windows cannot be operated by using the main switches  | Malfunctioning main switch           | Replace the main switch                         |
|   | Break in harness, or poor connection | Correct or replace the harness                  |
|   | Malfunctioning motor                 | Replace motor                                   |
| The door windows can be operated by using the main switches, but cannot be operated by using the sub switches | Malfunctioning main switch           | Replace the main switch                         |
|   | Malfunctioning sub switch            | Replace the sub switch                          |
|   | Break in harness, or poor connection | Correct or replace the harness                  |
| The door windows can be operated even though the lock switch is at "ON"                                       | Malfunctioning main switch           | Replace the main switch                         |

## TROUBLESHOOTING




### RADIO AND STEREO






## TROUBLESHOOTING




## TROUBLESHOOTING




**Car stereo**  
**Insufficient volume**  
**Poor sound quality**




**The auto reverse does not function**






## TROUBLESHOOTING




## TROUBLESHOOTING




Poor radio sensitivity,  
excessive noise





## TROUBLESHOOTING

### 3-POINT ELR SEAT BELTS WITH TENSION RELIEFERS






## BATTERY

### General Information

The maintenance-free battery is, as the name implies, totally maintenance free and has no removable battery cell caps. Water never needs to be added to the maintenance-free battery. The battery is completely sealed, except for small vent holes in the cover. These vent holes allow what small amount of gasses are produced in the battery to escape. The special chemical composition inside the battery reduces the production of gas to an extremely small amount at normal charging voltages. The battery contains a visual test indicator which indicates the condition of the battery.




### Battery Visual Inspection

1. Make sure ignition switch is in OFF position and all battery feed accessories are OFF.
2. Disconnect battery cables from battery (negative first).
3. Remove battery from vehicle.

### Caution

Care should be taken in the event battery case is cracked or leaking to protect hands from the electrolyte. A suitable pair of rubber gloves (not the household type) should be worn when removing battery by hand.

4. Inspect battery carrier for damage caused by loss of acid from battery. If acid damage is present it will be necessary to clean area with a solution of clean warm water and baking soda. Scrub area with a stiff bristle brush and wipe off with a shop towel moistened with ammonia or baking soda in water.
5. Clean top of battery with same solution as described in Step 4.
6. Inspect battery case and cover for cracks. If cracks are present battery must be replaced.
7. Clean the battery posts with a suitable battery post cleaning tool.
8. Clean the inside surfaces of the terminal clamps with a suitable battery terminal cleaning tool. Replace damaged or frayed cables and broken terminal clamps.
9. Reinstall the battery in vehicle.
10. Connect cable clamps to battery post making sure top of clamp is flush with top of post.
11. Tighten the clamp nut securely.
12. Coat all connections with light mineral grease after tightening.




## SERVICE ADJUSTMENT PROCEDURES

### Charge Rate

If the test indicator is white, the battery should be charged as outlined below. When the dot appears or when maximum charge shown below is reached, charging should be stopped.

### Charge Rate Chart

| Battery       | NX100-S6 (S)-MF<br>(420 amps) |                     | NX120-7-MF<br>(600 amps) |                   |
|---------------|-------------------------------|---------------------|--------------------------|-------------------|
| Slow charging | 5 amps<br>10 hrs.             | 10 amps<br>5 hrs.   | 5 amps<br>12 hrs.        | 10 amps<br>6 hrs. |
| Fast charging | 20 amps<br>2.5 hrs.           | 30 amps<br>1.5 hrs. | 20 amps<br>3 hrs.        | 30 amps<br>2 hrs. |



### CHARGING SYSTEM

Problems in charging system could be due to improper fan belt deflection, faulty wiring or connector, or a discharged battery. A defective electronic voltage regulator is not always the cause. What is important in troubleshooting of charging system, therefore, is to determine whether the problem is due to a run-down or overcharged battery. Then check previously mentioned items before checking alternator. In this manner a fault in a circuit other than alternator might also be detected.

This alternator has an "F" terminal for checking, as shown in the illustration (6EL068), which is provided in order to make troubleshooting easier. The (F) in the circuit in the illustration (1EL042) is the "F" terminal for checking. The voltage of this terminal can be checked from outside the alternator through the access hole provided in the rear bracket.

The voltage readings of the "F" terminal indicate as follows:


#### 1. Ignition switch at "OFF"

Normal if voltage is 0 V. If voltage is close to battery voltage, the (+) diode is short-circuited, and, moreover, there is a malfunction of the electronic voltage regulator. If the voltage is 0.5 to 2.0 V, the (+) diode is short-circuited.


#### 2. Ignition switch "ON"

Under normal conditions, only voltage equivalent to the voltage drop (0.5 to 2.0 V) of the power transistor within the electronic voltage regulator will appear.

If a voltage close to battery voltage is noted, current is not flowing to the field coil, which means that there is a malfunction of the electronic voltage regulator. In this instance, there should be no voltage generation, so start the engine and confirm that there is none. Also check to be sure that field current flows and there is voltage generation at the instant when, with the engine running, the "F" terminal for checking is grounded to the rear bracket.



6EL068




If the voltage reading is 0 V, the possible causes could be wiring damage of the field coil, poor contact of the brushes, a malfunction of the electronic voltage regulator, poor contact of the connector, and/or poor contact in the ignition switch. In any case, the alternator will not generate. In addition, if the negative (-) brush is grounded, or if there is a short-circuit inside the electronic voltage regulator, the voltage of the "F" terminal will be 0 V, which means that there is an overcharge.

### 3. While engine is running

Under normal conditions, the voltage will increase as the engine rpm is increased. If, with the battery fully charged, there is no load on the alternator, voltage will be close to output voltage.

If the voltage remains low even though the engine rpm is increased, the regulator has not yet reached the operating voltage, or current is continuing to flow to the regulator. If the latter, an overcharge will result.





## **SERVICE ADJUSTMENT PROCEDURES**

## NOTES

1. After the engine has been started, the ammeter indication will drop as the battery reaches the fully charged condition.  
Read the indication at its maximum value while increasing the engine revolution.
2. If the battery is in the fully charged condition, current will not flow, resulting in a no-flow condition of the nominal output current. In this case, measure the output current after the battery has been discharged by cranking the engine or increase the electrical load by adding new parallel circuits.

Read the indication at its maximum value while increasing the engine revolution.

## REGULATED VOLTAGE TEST


1. Turn ignition switch OFF.
2. Disconnect the battery ground cable.
3. Disconnect the battery positive cable and connect a 60 A ammeter between the battery positive terminal and cable.
4. Connect a voltmeter between terminal "L" of alternator and ground.
5. Set the engine tachometer.
6. Reconnect the battery ground cable to the battery. The voltmeter should indicate 0 V; if it is not, the alternator or wiring is defective.
7. Short circuit the ammeter terminals and start the engine.

## NOTE

Make sure that the starter current does not flow through the ammeter while starting the engine.

8. Increase the engine speed to 2,000 to 3,000 rpm and check the ammeter reading. If the reading is 5 A or less, check the voltmeter reading. This reading is the regulated voltage. If the ammeter reading is more than 5 A, either continue charging until the reading drops below 5 A or replace the battery with one that is fully charged and then repeat the test.

Regulated voltage . . . . . 14.4 V  $\pm$  0.5 at 20°C (68°F)



6EL017

## HANDLING PRECAUTIONS

1. Make sure that alternator, battery, etc., are connected properly. If battery polarity is reversed, excessive current will flow from battery to alternator, and damage to diodes or wiring harness could result.
2. Do not disconnect battery terminals while engine is running. Surge voltage will be produced which could cause deterioration of diodes or transistors.
3. When battery is to be quick-charged, be sure to disconnect battery terminals first. If terminals are not disconnected, damage to diodes could result.
4. When a steam cleaner is used, make sure that alternator is not directly exposed to steam.



## IGNITION SYSTEM

### Ignition Timing Adjustment

Adjustment condition


Coolant temperature: 80 to 90°C (170 to 190°F)

Lights and all accessories: OFF

Transmission: N (Neutral)

1. Start engine and run at curb idle speed.
2. Connect tachometer and timing light.
3. Check basic ignition timing and adjust if necessary.

Basic ignition timing .....  $7 \pm 2^\circ$  BTDC




4. To adjust ignition timing, loosen distributor mounting nut and turn distributor housing. (1EL002)
5. After adjustment, securely tighten mounting nut.


### SPARK PLUG CABLE TEST

1. Disconnect spark plug cable from spark plug.

When spark plug cable is pulled out, be sure to pull by the cable cap. If spark plug is removed by pulling on cable only open circuit might result.



2. Hold the spark plug cable about 6-8 mm (.24-.31 in.) away from engine proper (grounding portion such as cylinder block) and crank engine to verify that sparks are produced.





## SERVICE ADJUSTMENT PROCEDURES


### SPARK PLUG INSPECTION AND TEST

1. Remove the spark plugs from the engine.
2. Visually check the spark plugs for the following and replace if defective.
  - Broken insulator.
  - Worn electrode.
  - Deposited carbon. Use a plug cleaner for cleaning. Clean porcelain insulator above shell as well.
  - Damaged or broken gasket.
  - Burnt condition of porcelain insulator at spark gap. If black carbon deposit is evident, probable cause is too rich a fuel mixture or extremely low air intake. Misfiring due to excessive spark gap is also suspected. If insulator is burnt white, too lean a fuel mixture, excessively advanced ignition timing, improperly tightened plug, etc. are suspected.
3. Connect the spark plug to the high tension cable, ground outer electrode (main body), and crank engine. In the atmosphere, only short sparks are produced because of small discharge gap. If the spark plug is good, however, sparks will occur in discharge gap (between electrodes). In a defective spark plug, no sparks will occur because of leak of insulation puncture.
4. Check plug gap with plug gap gauge. If it is not within specified limit, adjust by bending ground electrode. Make sure that the gap of even a new spark plug is checked before spark plug is mounted to engine.


Spark plug gap ..... 1.0-1.1 mm (.039-.043 in.)

5. Install the spark plug and tighten to specified torque. If it is overtightened, damage to threaded portion of cylinder head might result.


Spark plug ..... 20-29 Nm (15-21 ft.lbs.)



1EL034



1EL022



1EL038


### Spark Test Without Cranking

If spark test is performed by cranking while the catalyst is hot, unburned gas will be supplied to the catalyst, and this is not desirable to the catalyst.

For this reason, use the following methods which allow spark test to be performed without cranking.




1. Remove the distributor cap.
2. Check signal rotor position in relation to the pick-up. If it is not the position shown in the illustration (6EL069), turn the crankshaft manually so that the projection of the signal rotor is moved away from the center part of the pick-up. In other words, the signal rotor should be positioned so that current can flow to the ignition coil.
3. Disconnect the high-tension cable from the center tower of the distributor cap, and hold the end of the cable about 5 to 10 mm (.2 to .4 in.) away from the cylinder block of the engine. (1EL038)
4. Turn the ignition switch to "ON". Then, when a piece of metal (the tip of a screwdriver for instance) is inserted into the detection coil of the pick-up and then moved away, a spark can be generated. (6EL069)



## CHARGING SYSTEM

### COMPONENTS

1. Through bolt (3)
2. Nut
3. Spring washer
4. Pulley
5. Fan
6. Collar
7. Screw (3)
8. Seal (2)
9. Front bracket
10. Bearing
11. Retainer
12. Rotor
13. Stator
14. Screw
15. Insulator
16. Plate "L"
17. Brush holder and regulator
18. Rectifier
19. Rear bracket
20. Nut
21. Washer
22. Condenser
23. Plate "B"
24. Screw ("B"-terminal)



3EL028

### REMOVAL

1. Disconnect battery ground cable.
2. Remove the drive belt. See "Cooling system", Group 7, for detailed procedure.
3. Disconnect wiring and connector from the alternator.
4. Remove the brace bolt and support bolt and remove alternator from engine.



## COMPONENT SERVICE-CHARGING SYSTEM

### DISASSEMBLY

1. Remove the three through bolts.
2. Insert plain screwdriver between front bracket and stator core and pry downward. (3EL029)



#### Caution

Do not insert screwdriver too deep, as there is danger of damage to stator coil.

3. Clamp the rotor in a vise with pulley side up (protect rotor from vise jaws).
4. Remove pulley nut. Then remove spring washer, pulley, fan and collar.
5. Remove front bracket and two seals.
6. Remove the rotor from vise.
7. Remove the nut from "B" terminal and remove the washer and condenser.
8. Remove the brush holder screw and rectifier screws.
9. Remove the stator assembly from the rear bracket.
10. When stator is to be removed, unsolder three stator leads soldered to main diodes on rectifier. (3EL046)

#### Caution

1. When soldering or unsoldering, use care to make sure that heat of soldering iron is not transmitted to diodes for a long period. Finish soldering or unsoldering in as short a time as possible.
2. Use care that no undue force is exerted to leads of diodes.
11. When separate the rectifier from brush holder, unsolder two plates soldered to rectifier.




### INSPECTION

#### Rotor


1. Check rotor coil for continuity. Check to ensure that there is continuity between slip rings.

Resistance value .....  $2.5-4\Omega$

If resistance is extremely small, it means that there is a short. If there is no continuity or if there is short circuit, replace rotor assembly.




2. Check rotor coil for grounding. Check to ensure that there is no continuity between slip ring and core. If there is continuity, replace rotor assembly.






### Stator

1. Make continuity test on stator coil. Check to ensure that there is continuity between coil leads. If there is no continuity, replace stator assembly.



3EL010

2. Check coil for grounding. Check to ensure that there is no continuity between coil and core. If there is continuity, replace stator assembly.



3EL011

### Rectifier

#### 1. (+) HEATSINK ASSEMBLY TEST


Check for continuity between (+) heatsink and stator coil lead connection terminal with a circuit tester. If there is continuity in both directions, diode is shorted. Replace rectifier assembly.

#### 2. (-) HEATSINK ASSEMBLY TEST

Check for continuity between (-) heatsink and stator coil lead connection terminal. If there is continuity in both direction, diode is shorted, and rectifier assembly must be replaced.

#### 3. DIODE TRIO TEST

Check three diodes for continuity by connecting a circuit tester to both ends of each diode. If there is no continuity or no continuity in both directions, diode is defective and heatsink assembly must be replaced.




3EL013



## COMPONENT SERVICE-CHARGING SYSTEM


### BRUSH REPLACEMENT

1. Brush worn down to wear limit line should be replaced.



3EL015

2. If pigtail is unsoldered, brush and spring will come off.




3EL035

3. When only brush or brush spring is to be replaced, it can be replaced without removing stator, etc. With brush holder assembly raised as illustrated, unsolder pigtail of brush.


#### NOTE

If L- and B-terminals of rectifier assembly are bent, damage to rectifier moulding might result. Therefore, plates "B" and "L" should be gently bent at center.



3EL004

4. When installing new brush, solder pigtail so that brush will be pressed into holder about 5 mm (.2 in.).




3EL036



## REASSEMBLY

Perform reassembly in reverse procedure of disassembly, pay attention to the following item:


1. Before rotor is attached to rear bracket, insert wire through small hole made in rear bracket to lift brush. After rotor has been installed, the wire can be removed.



3EL018

## INSTALLATION

1. Install the alternator to the engine front case and insert the support bolt through the alternator leg into front case. Do not install the nut.
2. Install the brace bolt but do not tighten the bolt.
3. Push alternator toward front of engine and check clearance "A" between alternator leg and front case or timing chain case. If clearance is more than 0.2 mm (.008 in.), insert spacers [0.198 mm (.0078 in.) thick] as required. If support bolt is tightened without reducing clearance "A", alternator leg might be broken.
4. Install the washer and nut to the support bolt.
5. Install drive belt and adjust the drive belt tension.
6. Tighten first the brace bolt and then tighten the support bolt nut to the specified torque.



3EL019

### Tightening torque:

Alternator brace bolt . . . . . 12-14 Nm (9-10 ft.lbs.)

Alternator support bolt nut . . . . . 20-24 Nm (15-18 ft.lbs.)

7. Connect wiring and connector to the alternator.
8. Connect the battery ground cable.




## COMPONENT SERVICE-STARTING SYSTEM

### COMPONENTS

#### Direct drive type

1. Screw (2)
2. Front bracket
3. Washer
4. Snap ring
5. Stop ring
6. Overrunning clutch
7. Armature
8. Magnetic switch
9. Packing
10. Spring retainer
11. Lever spring
12. Spring seat
13. Lever
14. Washer
15. Yoke assembly
16. Brush holder
17. Brush spring
18. Rear bracket
19. Screw (2)
20. Through bolt (2)




#### NOTE

Numbers show order of disassembly.  
For reassembly, reverse order of disassembly.

6EL070

#### Reduction drive type

1. Screw (2)
2. Front bracket
3. Lever
4. Spring
5. Spring retainer
6. Center bracket
7. Packing
8. Magnetic switch
9. Snap ring
10. Stop ring
11. Pinion gear
12. Spring
13. Pinion shaft and overrunning clutch
14. Reduction gear
15. Adjusting washer
16. Washer
17. Retaining ring
18. Cover
19. Screw (2)
20. Bolt
21. Front ball bearing
22. Armature
23. Rear ball bearing
24. Yoke assembly
25. Brush holder
26. Rear bracket
27. Screw (2)
28. Through bolt (2)



6EL002



## REMOVAL

1. Disconnect battery ground cable.
2. Disconnect starting motor harness from the starter motor.
3. Remove the two starting motor mounting bolts and remove starter motor.


## INSPECTION (after removal)

### Pinion Gap Adjustment

1. Disconnect field coil wire from M-terminal of magnetic switch.
2. Connect a 12 V battery between S-terminal and M-terminal. (6EL050)
3. Set switch to "ON", and pinion will move out.


### Caution

This test must be performed quickly (in less than 10 seconds) to prevent coil from burning.





4. Check pinion to stopper clearance (pinion gap) with a feeler gauge. (6EL003)  
If pinion gap is out of specification, adjust by adding or removing washers between magnetic switch and front bracket.

Pinion gap ..... 0.5-2.0 mm (.020-.079 in.)



5. Lightly push back the pinion, and measure the amount of travel, which represents the pinion gap. Adjust the thickness (number) of washers at switch area so that the gap becomes 0.5 to 2.0 mm (.020 to .079 in.).





## COMPONENT SERVICE-STARTING SYSTEM


### Pull-in Test of Magnetic Switch

1. Disconnect field coil wire from M-terminal of magnetic switch.
2. Connect a 12 V battery between S-terminal and M-terminal. (6EL004)

#### Caution

This test must be performed quickly (in less than 10 seconds) to prevent coil from burning.

3. If pinion moves out, then pull-in coil is good. If it doesn't, replace magnetic switch.




### Hold-in Test of Magnetic Switch

1. Disconnect field coil wire from M-terminal of magnetic switch.
2. Connect a 12 V battery between S-terminal and body. (6EL005)

#### Caution

This test must be performed quickly (in less than 10 seconds) to prevent coil from burning.

3. If pinion remains out, everything is in order. If pinion moves in, hold-in circuit is open. Replace magnetic switch.




### Return Test of Magnetic Switch

1. Disconnect field coil wire from "M" terminal of magnetic switch.
2. Connect a 12 V battery between M-terminal and body. (6EL006)

#### Caution


This test must be performed quickly (in less than 10 seconds) to prevent coil from burning.

3. Pull pinion out and release. If pinion quickly returns to its original position, everything is in order. If it doesn't replace magnetic switch.



### Free Running Test

1. Place starter motor in a vise equipped with soft jaws and connect a fully-charged, 12 volt battery to starter motor as follows:
2. Connect a test ammeter (100 amperes scale) and carbon pile rheostat in series with battery positive post and starter motor terminal.
3. Connect a voltmeter (15 volt scale) across starter motor.
4. Rotate carbon pile to full-resistance position. (6EL071)






5. Connect battery cable from battery negative post to starter motor body.
6. Adjust rheostat until battery voltage shown on voltmeter reads 11.5 volts.
7. Check specifications for maximum amperage draw and minimum rpm.


Voltage ..... 11.5 Volts  
 Amperage draw ..... 60 Amps  
 Minimum rpm ..... 6,800 rpm

#### DISASSEMBLY-DIRECT DRIVE TYPE


1. Disconnect field coil wire from "M" terminal of magnetic switch.




2. Remove two magnetic switch mounting screws and remove magnetic switch.




3. Remove two through bolts and two screws.
4. Remove rear bracket.






## COMPONENT SERVICE-STARTING SYSTEM


5. Slide the two brushes from brush holder by prying retaining springs back.
6. Remove brush holder.
7. Remove yoke assembly.




8. Remove washer from rear end of armature.



9. Remove spring retainer, spring and spring seat from front bracket.




10. Remove armature assembly and lever from front bracket.






11. Remove washer from front bracket.




6EL079

12. Press stop ring off snap ring with suitable socket.



6EL080

13. Remove snap ring with snap ring pliers and then remove stop ring and overrunning clutch.



6EL081




## COMPONENT SERVICE-STARTING SYSTEM

### DISASSEMBLY-REDUCTION


#### Drive Type

1. Disconnect the field coil wire from "M" terminal of magnetic switch.




5EL016

2. Remove the two magnetic switch mounting screws and remove the magnetic switch.




5EL017

3. Remove the two through bolts and two screws, and then remove the rear bracket.



5EL018


4. Slide the two brushes from brush holder by prying retaining springs back, and then remove the brush holder assembly.
5. Remove the yoke assembly.
6. Remove the armature.




5EL019




7. Remove the pinion shaft end cover from the center cover.
8. Measure the pinion shaft end play using feeler gauge for reassembly.
9. Remove the retaining ring and washer from the pinion shaft.
10. Remove the center bracket.




11. Remove the lever spring retainer and spring.
12. Remove the adjusting washer and reduction gear.



13. Remove the clutch shift lever and two lever holder.




14. Press the stop ring off the snap ring with suitable socket.






## COMPONENT SERVICE-STARTING SYSTEM

15. Remove the snap ring with screwdriver, and then remove the stop ring.
16. Remove the pinion and spring from pinion shaft.



17. Remove the overrunning clutch from the front bracket.




### CLEANING STARTER MOTOR PARTS

1. Do not immerse parts in cleaning solvent. Immersing the yoke and field coil assembly and/or armature will damage insulation. Wipe these parts with a cloth only.
2. Do not immerse drive unit in cleaning solvent. Overrunning clutch is pre-lubricated at the factory and solvent will wash lubrication from clutch.
3. The drive unit may be cleaned with a brush moistened with cleaning solvent and wiped dry with a cloth.




## BRUSHES AND SPRINGS-REPLACEMENT

1. Brushes that are worn beyond wear limit line, or are oil-soaked, should be replaced.
2. When replacing field coil brushes, crush worn brush with pliers, taking care not to damage pigtails.
3. Sand pigtails end with sandpaper to ensure good soldering.
4. Insert pigtails into hole provided in new brush and solder it. Make sure that pigtails and excess solder do not come out onto brush surface.
5. When replacing ground brush, slide the brush from brush holder by prying retaining spring back.



1EL010




1EL049

## TESTING ARMATURE

### Testing Armature for Short Circuit


1. Place armature in a growler.
2. Hold a thin steel blade parallel and just above while rotating armature slowly in growler. A shorted armature will cause blade to vibrate and be attracted to the core. Replace shorted armature.




6EL082

### Testing Armature for Grounding

1. Touch armature coil core and the end of each commutator bar with a pair of test lamp prods.
2. If lamp lights, it indicates a grounded armature. Replace grounded armature.



6EL083




## COMPONENT SERVICE-STARTING SYSTEM

### Testing Commutator Runout

1. Place armature in a pair of "V" blocks and check runout with a dial indicator.
2. Check both shaft and commutator. A bent shaft requires replacement of armature.
3. If commutator runout exceeds 0.05 mm (.002 in.), commutator should be refaced. Remove only enough metal to provide a smooth, even surface.


Commutator runout ..... Max 0.05 mm (.002 in.)  
Under cut depth ..... 0.5 mm (.02 in.)



6EL084

### TESTING FIELD COILS FOR GROUNDING


1. Touch one probe of test lamp to series field coil lead and other probe to yoke. Lamp should not light. If lamp lights, coils are grounded. If field coils are grounded, replace field coil and yoke assembly.



6EL085

### TESTING BRUSH HOLDER

1. Touch each of the insulated brush holders with one test probe, while holding other test probe against brush holder plate.
2. The lamp should not light during this test since the brush holders are insulated. If the lamp lights brush holders on brush holder plate are grounded. Replace brush holder assembly if brush holders are grounded.




6EL086


### SERVICING DRIVE UNIT

#### Overrunning Clutch

1. While holding clutch housing, rotate the pinion. Drive pinion should rotate smoothly in one direction, but should not rotate in opposite direction. If clutch does not function properly, replace overrunning clutch assembly.
2. Inspect pinion for wear or burrs. If pinion is worn or burred, replace overrunning clutch assembly. If pinion is damaged, also inspect ring gear for wear or burrs.



1EL012





### FRONT AND REAR BRACKET BUSHING-DIRECT DRIVE TYPE

1. Inspect bushing for wear or burr. If bushing is worn or burred, replace front bracket assembly or rear bracket assembly.

### REASSEMBLY

Reassemble starter motor in the reverse order of disassembly with the following exception.

1. Using a suitable pulling tool, pull overrunning clutch stop ring over snap ring.





## COMPONENT SERVICE-STARTING SYSTEM

### INSTALLATION

1. Clean both surfaces of starter motor flange and rear plate.
2. Install starter motor to engine and tighten two bolts to specified torque.

Starter motor mounting bolts . . . . .  
22-31 Nm (16-23 ft.lbs.)


3. Connect battery cable and switch wire to starter motor.
4. Connect battery ground cable.

# COMPONENT SERVICE-IGNITION SYSTEM



## COMPONENTS

1. Breather
2. Cap
3. Contact carbon
4. Rotor
5. Lead wire
6. Earth wire
7. Igniter
8. Pin
9. Rotor
10. Breaker base
11. Vacuum controller for dual diaphragm
12. Vacuum controller for single diaphragm
13. Rotor shaft
14. Spring retainer (2)
15. Governor spring (2)
16. Governor weight (2)
17. Distributor shaft
18. Oil seal
19. Packing
20. Distributor housing
21. O-ring
22. Washer
23. Gear
24. Pin




### NOTE

Numbers show order of disassembly.  
For reassembly, reverse order of disassembly.

6EL087

## DISASSEMBLY

1. Lightly clamp distributor in a vise equipped with soft jaws.
2. Remove retaining clips and lift off distributor cap and seal ring.
3. Pull-off rotor from rotor shaft.
4. Remove two vacuum controller mounting screws.
5. Remove link of controller from pin on the breaker base, and then remove vacuum controller.




6EL088




## COMPONENT SERVICE-IGNITION SYSTEM

6. Remove two screws and remove igniter.
7. Remove lead wire (black).




6EL089

8. Remove signal rotor shaft tightening screw and two breaker plate retaining screws.
9. Remove signal rotor shaft and breaker plate assembly.




6EL090

10. Remove signal rotor shaft from signal rotor.



6EL091


11. Remove two spring retainers with pliers and then remove two governor springs.
12. Remove two governor weights.



6EL092




13. Mark location of drive gear on distributor shaft.
14. Place drive gear on soft base (wood block) so that roll pin can be removed.
15. Using a pin punch, remove roll pin.
16. Remove drive gear and washer.
17. Remove distributor shaft from housing.




## REASSEMBLY


1. Clean and inspect all parts.
2. Install shaft into housing.
3. Install drive gear into distributor shaft at previously marked location. Then install new roll pin.



4. Install governor weights on the governor plate.
5. Install governor springs and spring retainer.




6. Install signal rotor shaft into distributor shaft.
7. Install breaker plate to housing. Position the breaker plate so that the projection (A) fits into the groove (B).
8. Tighten two breaker plate retaining screws.






## COMPONENT SERVICE-IGNITION SYSTEM


9. Install signal rotor to rotor shaft. Position the signal rotor so that the dowel pin fits into the groove.




10. Install igniter to breaker plate and install two screws.
11. Connect one end of lead wire to igniter mounting screw and other end to breaker plate.



12. Adjust air gap between signal rotor and pick-up of igniter.




13. Connect vacuum control link to breaker plate and tighten two vacuum controller screws.
14. Install rotor to rotor shaft.
15. Install seal ring and distributor cap to housing and set the retaining clips.






## INSTALLATION

1. Turn crankshaft until piston of No. 1 cylinder is at top dead center of compression stroke.
2. Align mating mark on distributor housing with mating mark (punch) on distributor driven gear. (1EL018)



1EL018

3. Install distributor to cylinder head while aligning mating mark on distributor attaching flange with center of distributor installing stud and tighten nuts. (1EL019)
4. Adjust ignition timing.



1EL019

## IGNITION COIL

### INSPECTION


1. Using a circuit tester, measure resistance. An open- or short-circuited coil should be replaced.

Model No.

Primary resistance E-064 .....  
1.1-1.3  $\Omega$  at 20°C (68°F)


Secondary resistance .....  
11.6-15.8 k $\Omega$  at 20°C (68°F)

External resistor resistance .....  
1.2-1.5  $\Omega$  at 20°C (68°F)




3EL001

2. Check resin portion for cracks. If there are cracks, replace.
3. Check for fluid (oil) leaks. If there are leaks, replace.



## COMPONENT SERVICE-WIRING HARNESS


### WIRING HARNESES



16W763



Engine compartment — Front



NOTE


\* : For California (can also be sold in Federal States).

\*\* : indicates connection for vehicles with an air conditioner.



## COMPONENT SERVICE-WIRING HARNESS

## Engine compartment - Rear




## NOTE

\* : For California (can also be sold in Federal States)

## COMPONENT SERVICE-WIRING HARNESS

### Instrument panel




#### NOTE

\* : For California (can also be sold in Federal States).  
 \*\* : indicates connection for vehicles with an air conditioner.






## COMPONENT SERVICE-WIRING HARNESS



Door

# COMPONENT SERVICE-WIRING HARNESS




## NOTE

\* : Routing of the dome light wiring harness for vehicles equipped with a metal-top.


\*\* : Routing of the dome light wiring harness for vehicles equipped with a canvas-top.

Frame




16W698

COMPONENT SERVICE-WIRING HARNESS




## COMPONENT SERVICE-WIRING HARNESS

Back door – Vehicles without a rear wiper and washer




Back door – Vehicles with a rear wiper and washer











## COMPONENT SERVICE-WIRING HARNESS



16W628

## CENTRALIZED GROUND POINTS




## NOTE

\* : For California (can also be sold in Federal States).




## COMPONENT SERVICE-WIRING HARNESS


### RELAY MOUNTING LOCATIONS




**A** Front pillar (right side)




**B** Fender shield, inner (left side)



**C** Front pillar, inner (left side)




**D** Dash panel, upper (inside right)



1. Light control relay
2. E.S.S. relay
3. Headlight washer relay
4. Turn-signal flasher unit
5. Hazard warning flasher unit
6. Power window relay
7. Intermittent wiper relay
8. Carburetor control unit  
[For California  
(can also be sold in Federal States)]
9. Seat belt timer
10. Heater relay




## SPARE TERMINALS




16W722


1 Front speaker




3 Rear wiper and washer switch




5 Radio




2 ACC spare terminal



4 Rear speaker



6 Headlight washer motor and relay




## NOTES

- (1) If ACC spare terminal 1 is used, it must not be used for more than 5 A.
- (2) If the vehicle is not equipped with the optional equipment corresponding to a spare terminal, that spare terminal will be secured to the main line with blue tape.




## COMPONENT SERVICE-WIRING HARNESS




16W722


**7** Air conditioner compressor and low pressure switch




**8** Air conditioner unit




**9** Rear Heater




**10** Power Window



**11** Air conditioner switch




**12** Air conditioner (For California  
(can also be sold in Federal states)





## READING THE HARNESS DIAGRAMS

## Harness Diagram Example



16E962

## How to Read the Accompanying

| NO. | WIRE   | CIRCUIT              |   |   |
|-----|--------|----------------------|---|---|
| 1   | -2FB-  | IGNITION SWITCH <ST> |   |   |
| 2   | RL     | FUSE BLOCK (1) ←     |   |   |
| 3   | GY     | HORN <E>             |   |   |
| 4   | GL     | HORN <B> ←           |   |   |
| 5   | 0.85GB |                      |   |   |
|     |        |                      | 6 | 7 |
|     |        |                      |   |   |
|     |        |                      | 8 | 9 |

1. The connector terminal number indicated in the diagram.
2. The numbers indicate the nominal cross-sectional area of the wire; refer to the table at right. If a number is not used, it indicates that the cross-sectional area of the wire is  $0.5 \text{ mm}^2$ .
3. "F" indicates that this is flexible wire.

| No.  | Nominal size $\text{mm}^2$ | SAE gauge No. | Permissible current   |             |
|------|----------------------------|---------------|-----------------------|-------------|
|      |                            |               | In engine compartment | Other areas |
| 0.3  | 0.3                        | AWG 22        | —                     | 5 A         |
| —    | 0.5                        | AWG 20        | 7 A                   | 13 A        |
| 0.85 | 0.85                       | AWG 18        | 9 A                   | 17 A        |
| 1.25 | 1.25                       | AWG 16        | 12 A                  | 22 A        |
| 2    | 2.0                        | AWG 14        | 16 A                  | 30 A        |
| 3    | 3.0                        | AWG 12        | 21 A                  | 40 A        |
| 5    | 5.0                        | AWG 10        | 31 A                  | 54 A        |




## COMPONENT SERVICE-WIRING HARNESS

4. The letters indicate the color of the wire.

| Symbol | B     | G     | L    | O      | R   | W     | Y      | Br    |
|--------|-------|-------|------|--------|-----|-------|--------|-------|
| Color  | Black | Green | Blue | Orange | Red | White | Yellow | Brown |

Wires which have two-color insulation covering are indicated by two letters. The first letter indicates the cable color and the second letter indicates the trace marking (color).

Example



M16063

5. Indicates the circuits which are connected.


6. The letters in angular brackets indicate which part of the circuit this terminal is connected to; refer to the following table.

| Letter | Meaning                              | Letter | Meaning                  |
|--------|--------------------------------------|--------|--------------------------|
| ACC    | Accessory                            | L      | Load                     |
| AS     | Auto-stop                            | LO     | Low-speed terminal       |
| B      | Battery                              | LI     | License plate lights     |
| BACK   | Back-up lights                       | OIL    | Oil pressure             |
| BEAM   | Headlight upper beam indicator light | RL     | Rear left                |
| BK     | Brake                                | RR     | Rear right               |
| CHG    | Charging                             | S      | Soft                     |
| DEF    | Defogger                             | ST     | Starter                  |
| DR     | Door                                 | STOP   | Stop lights              |
| E      | Ground                               | TAC    | Tachometer               |
| FL     | Front left                           | TAIL   | Tail lights              |
| FR     | Front right                          | TEMP   | Water temperature        |
| H      | Hard                                 | TUL    | Turn-signal light, left  |
| HI     | High speed terminal                  | TUR    | Turn-signal light, right |
| HL     | Headlight low beam                   | W      | Washer                   |
| HU     | Headlight high beam                  | +      | Positive terminal        |
| IG     | Ignition                             | -      | Negative terminal        |
| ILL    | Illumination                         | 4WD    | 4WD indicator light      |
| IND    | Indicator light                      |        |                          |

7. Parentheses contain supplementary information; in the example, the "1" indicates the number 1 fuse of the fuse block.

8. The boxed numbers   indicate to which terminal is connected.


9. If neither a circuit nor a number is listed, it indicates that this wire of this terminal is not connected to another terminal.



## WIRING CONNECTORS

### Connector Classifications

Electrical wiring connectors can be classified according to the type of terminals (such as pin terminals or flat terminals), the number of poles (terminals), whether they are male or female, whether they have a locking device or not, etc. In this Service Manual, connectors will generally be classified as follows:




16YQ49

### 1. Classification according to terminal type

Connectors illustrated with outer lines shaped so that the top corners are cut diagonally usually have pin terminals, and those illustrated with outer lines shaped so that the top is cut into stairsteps usually have flat terminals.


Note that connectors illustrated with diagonally cut corners on which one section is marked with an "X" are small flat terminal connectors. The "X" indicates the position of a guide to prevent the connector from being improperly connected.



36K030

### 2. Classification according to number of poles

The number of sections represents the number of poles inside the connector. However, sections in the illustration marked with an "X" or blacked in do not represent poles.



There are 18 sections; however, because two of the sections are blacked in, there are only 16 poles.


36K031



## COMPONENT SERVICE-WIRING HARNESS

### 3. Classification according to male and female

Connectors illustrated with double outer lines are male, and those with single outer lines are female.



### 4. Classification according to the presence of a locking device



If a flat terminal connector is illustrated with a projection at the top, it indicates that the connector is equipped with a locking device.

#### NOTE

- (1) Because all pin terminal connectors, small flat terminal connectors, and sealed connectors are equipped with locking devices, there are special indications in the graphic illustrations.
- (2) Housing lance lock connectors have lances inside the connector housing which securely lock the terminals to prevent them from becoming disconnected, thus providing increased reliability.


### 5. Classification according to sealed connector


Classification of round shape-sealed connector (pin terminal water-proofed connector) which is used for engine wiring harness is the same as above.



### Terminal numbers

If a pair of connectors (male and female) is illustrated as disconnected, the corresponding terminal numbers will be positioned symmetrically. Therefore when the pair of connectors is connected, the corresponding terminal numbers on the male and female connectors will match.





16W707



## COMPONENT SERVICE-WIRING HARNESS



| No. | WIRE   | CIRCUIT                                     | No. | WIRE    | CIRCUIT   |
|-----|--------|---|-----|---------|---|
| 1   | 3W     | MAIN FUSIBLE LINK <BATTERY>                 | 100 | 8       | COMBINATION METER <E>                           |
| 2   | 5W     | ALTERNATOR <B>                              | 101 | 1.25B   | HEADLIGHT WASHER RELAY <E>                      |
| 3   | 2W     | FUSIBLE LINK                                | 102 | 0.3B    | AIR CONDITIONER WIRING HARNESS A                |
| 4   | 3W     | FUSE BLOCK                                  | 103 | 0.3B    | COLUMN SWITCH <E>                               |
| 5   | 2BW    | IGNITION SWITCH <IG>                        | 104 | 0.85B   | CENTER PANEL WIRING HARNESS <E>                 |
| 6   | 2BW    | IGNITION COIL <>                            | 105 | 0.3B    | COMBINATION GAUGE <E>                           |
| 7   | 2BR    | IGNITION SWITCH                             | 106 | 0.3B    | BRAKE FLUID LEVEL SENSOR                        |
| 8   | 2BY    | IGNITION SWITCH <ST>                        | 107 | 0.3B    | REAR WIPER AND WASHER SWITCH <E>                |
| 9   | 2BW    | IGNITION SWITCH <ACC>                       | 108 | B       | FRAME WIRING HARNESS <E>                        |
| 10  | 2R     | LIGHT CONTROL RELAY                         | 109 | RG      | DOOR SWITCH (L.H.)                              |
| 11  | 1.25R  | LIGHT CONTROL RELAY                         | 110 | 2B      | GROUND  |
| 12  | 1.25RL | LIGHT CONTROL RELAY                         | 111 | 0.3RL   | COMBINATION GAUGE <IG>                          |
| 13  | 1.25RL | HEADLIGHT (L.H.) <B>                        | 112 | 0.3RL   | CENTER PANEL WIRING HARNESS <B>                 |
| 14  | 0.85RW | HEADLIGHT (R.H.) <HL>                       | 113 | 0.3RY   | COMBINATION GAUGE                               |
| 15  | 0.85RW | HEADLIGHT (L.H.) <HL>                       | 114 | 0.85L   | ALTERNATOR <ACC>                                |
| 16  | R      | LIGHT CONTROL RELAY                         | 115 | RL      | COMBINATION METER <IG>                          |
| 17  | 1.25RW | LIGHT CONTROL RELAY                         | 116 | RL      | COMBINATION METER <IG>                          |
| 18  | GW     | LIGHT CONTROL RELAY                         | 117 | YC      | PARKING BRAKE SWITCH                            |
| 19  | 0.85R  | HEADLIGHT (L.H.) <HU>                       | 118 | LW      | RADIO <ACC>                                     |
| 20  | 0.85R  | HEADLIGHT (R.H.) <HU>                       | 119 | 0.3GW   | FUSE BLOCK (10)                                 |
| 21  | 0.85R  | HORN <S>                                    | 120 | 0.85WL  | FRONT COMBINATION LIGHT (R.H.)                  |
| 22  | 0.85B  | HORN <H>                                    | 122 | RG      | FRONT COMBINATION LIGHT (L.H.)                  |
| 23  | 0.85B  | HORN <S>                                    | 123 | 0.3RG   | FRAME WIRING HARNESS <TAIL>                     |
| 24  | 0.85B  | HORN <H>                                    | 126 | 0.3YG   | BRAKE FLUID LEVEL SENSOR                        |
| 25  | 0.85B  | HORN <H>                                    | 127 | 1.25L   | HEADLIGHT WASHER RELAY                          |
| 26  | 1.25R  | FUSE BLOCK                                  | 128 | 0.3LB   | HEADLIGHT WASHER RELAY                          |
| 27  | 0.85GL | FRONT COMBINATION LIGHT (L.H.)              | 129 | 0.3LW   | HEADLIGHT WASHER RELAY                          |
| 28  | 0.85GY | FRONT COMBINATION LIGHT (R.H.)              | 130 | 0.3LW   | HEADLIGHT WASHER RELAY                          |
| 29  | 0.3R   | UPPER BELT FUSE                             | 131 | 0.3WB   | FRAME WIRING HARNESS <W>                        |
| 30  | 0.3R   | COMBINATION METER <BEAM>                    | 132 | 0.3BW   | FRAME WIRING HARNESS <LO>                       |
| 31  | 1.25GB | HAZARD WARNING FLASHER UNIT <B>             | 133 | 0.3B    | FRAME WIRING HARNESS <AS>                       |
| 32  | 0.85RL | TURN-SIGNAL FLASHER UNIT <IG>               | 134 | 0.3RB   | COMBINATION METER <B>                           |
| 33  | 1.25GO | HAZARD WARNING FLASHER UNIT                 | 135 | B       | B/LP AND 4WD INDICATOR LIGHT WIRING HARNESS <E> |
| 34  | GR     | TURN-SIGNAL FLASHER UNIT                    | 136 | BY      | DIMMER CONTROL SWITCH                           |
| 35  | 0.3GL  | COMBINATION METER                           | 137 | YB      | COMBINATION METER <OIL>                         |
| 36  | WL     | FRAME WIRING HARNESS                        | 138 | 0.3BW   | SPEAKER <FR>                                    |
| 37  | 0.3GY  | COMBINATION METER                           | 139 | 0.3BY   | SPEAKER <FL>                                    |
| 38  | WR     | FRAME WIRING HARNESS                        | 140 | 0.3B    | SPEAKER <FR>                                    |
| 39  | 0.85L  | WIPER MOTOR <ACC>                           | 141 | B       | SPEAKER <FL>                                    |
| 40  | LO     | WIPER MOTOR <LO>                            | 142 | R       | INHIBITOR SWITCH                                |
| 41  | LB     | WIPER MOTOR <HI>                            | 143 | RL      | INHIBITOR SWITCH                                |
| 42  | LW     | WIPER MOTOR <AS>                            | 144 | 0.3GW   | INHIBITOR SWITCH                                |
| 43  | L      | WASHER MOTOR <ACC>                          | 145 | BY      | INHIBITOR SWITCH                                |
| 44  | 0.85Y  | INTERMITTENT WIPER RELAY                    | 146 | 2BY     | INHIBITOR SWITCH                                |
| 45  | WL     | WASHER MOTOR                                | 147 | -0.85WG | HAZARD WARNING SWITCH <ST>                      |
| 46  | 0.85GR | FUSE BLOCK (7)                              | 148 | WL      | HAZARD WARNING SWITCH <RL>                      |
| 47  | 0.85G  | HAZARD SWITCH                               | 149 | WR      | HAZARD WARNING SWITCH <RR>                      |
| 48  | 2R     | FUSE BLOCK (5)                              | 150 | GL      | HAZARD WARNING SWITCH <FL>                      |
| 49  | 2B     | FRAME WIRING HARNESS                        | 151 | GY      | HAZARD WARNING SWITCH <FR>                      |
| 50  | BR     | DEFOGGER SWITCH <IND>                       | 152 | 0.3GW   | HAZARD WARNING SWITCH <ILL>                     |
| 51  | 2LR    | FUSE BLOCK (6)                              | 153 | 0.3BY   | HAZARD WARNING SWITCH <ILL>                     |
| 52  | 2L     | HEATER FAN SWITCH <B>                       | 155 | BW      | E.S.S. SOLENOID VALVE                           |
| 53  | LR     | HEATER RELAY <IG>                           | 156 | 2L      | AIR CONDITIONER WIRING HARNESS C                |
| 54  | 0.85LW | HEATER MOTOR <LO>                           | 157 | B       | E.S.S. RELAY                                    |
| 55  | 1.25LY | HEATER MOTOR                                | 158 | WW      | E.S.S. RELAY                                    |
| 56  | 1.25LB | HEATER MOTOR                                | 159 | 2L      | E.S.S. SOLENOID VALVE                           |
| 57  | 2LR    | HEATER MOTOR <HI>                           | 160 | 0.3GW   | AIR CONDITIONER WIRING HARNESS C                |
| 58  | GR     | COLUMN SWITCH                               | 161 | 0.5BY   | AIR CONDITIONER SWITCH                          |
| 59  | 1.25BW | FUEL-CUT SOLENOID VALVE                     | 162 | 0.5BY   | AIR CONDITIONER SWITCH                          |
| 60  | 2BW    | FUEL-CUT SOLENOID VALVE                     | 165 | BG      | SPEAKER <RL>                                    |
| 61  | HB     | DOME LIGHT WIRING HARNESS <B>               | 166 | BR      | SPEAKER <RR>                                    |
| 62  | RG     | DOME LIGHT WIRING HARNESS                   | 167 | B       | SPEAKER <RL>                                    |
| 63  | 0.3RG  | COMBINATION METER                           | 168 | B       | SPEAKER <RL>                                    |
| 64  | YB     | OIL PRESSURE SWITCH                         | 169 | 0.85BW  | AIR CONDITIONER WIRING HARNESS B                |
| 65  | L      | FUSE BLOCK (9)                              | 170 | RB      | DOME LIGHT WIRING HARNESS <B>                   |
| 66  | 1.25Y  | HIGH BEAM FUSE                              | 171 | B       | DOME LIGHT WIRING HARNESS <B>                   |
| 67  | 0.85W  | COMBINATION METER <CHG>                     | 172 | RG      | DOME LIGHT WIRING HARNESS <DR>                  |
| 68  | 0.3YL  | INTERMITTENT WIPER RELAY <W>                | 173 | LW      | AIR CONDITIONER WIRING HARNESS A                |
| 69  | L      | INTERMITTENT WIPER RELAY <ACC>              | 174 | 0.3Y    | SEAT BELT SWITCH                                |
| 70  | BR     | INTERMITTENT WIPER RELAY <LO>               | 175 | 0.3B    | SEAT BELT SWITCH (L.H.)                         |
| 71  | Y      | FRAME WIRING HARNESS <LO>                   | 176 | 0.3RL   | SEAT BELT SOLENOID                              |
| 72  | RL     | FRAME WIRING HARNESS                        | 177 | 0.3B    | SEAT BELT SOLENOID                              |
| 73  | YL     | WATER TEMPERATURE GAUGE UNIT                | 178 | 0.3RB   | SEAT BELT SWITCH                                |
| 75  | YR     | B/LP AND 4WD INDICATOR LIGHT WIRING HARNESS | 179 | GR      | KEY-REMINDER SWITCH                             |
| 76  | R      | B/LP AND 4WD INDICATOR LIGHT WIRING HARNESS | 180 | G       | KEY-REMINDER SWITCH                             |
| 77  | 3LR    | AIR CONDITIONER WIRING HARNESS A            | 181 | G       | COMBINATION METER                               |
| 78  | 0.85BW | AIR CONDITIONER WIRING HARNESS B            | 182 | 0.3YB   | COMBINATION METER                               |
| 79  | WL/B   | IGNITION COIL <>                            | 183 | 0.3RL   | BELT WARNING TIMER                              |
| 80  | 1.25LW | HEADLIGHT WASHER <B>                        | 184 | 0.3B    | BELT WARNING TIMER                              |
| 81  | GW     | FUSE BLOCK (2)                              | 185 | YW      | DOOR SWITCH (L.H.)                              |
| 82  | 0.3Y   | INTERMITTENT WIPER RELAY                    | 194 | 0.85BW  | REAR HEATER WIRING HARNESS                      |
| 83  | YR     | COMBINATION METER                           | 195 | 0.85B   | REAR HEATER WIRING HARNESS <E>                  |
| 84  | LW     | SPARE TERMINAL <ACC>                        | 201 | BY      | AIR CONDITIONER WIRING HARNESS A                |
| 85  | 0.3BY  | RADIO <ILL>                                 | 202 | 0.85L   | AIR CONDITIONER WIRING HARNESS A                |
| 86  | 0.3GW  | FRAME WIRING HARNESS                        | 215 | RL      | SEAT BELT SOLENOID                              |
| 87  | GW     | COMBINATION METER <ILL>                     | 216 | 0.3YB   | SEAT BELT SOLENOID                              |
| 88  | 0.3RY  | CENTER PANEL WIRING HARNESS <ILL>           | 217 | 0.3B    | SEAT BELT SOLENOID                              |
| 89  | 0.3GW  | CENTER PANEL WIRING HARNESS <ILL>           | 220 | 0.3RL   | POWER WINDOW RELAY                              |
| 90  | 2B     | COLUMN SWITCH <E>                           | 221 | 0.3B    | POWER WINDOW RELAY                              |
| 91  | B      | FRONT COMBINATION LIGHT (R.H.) <E>          | 222 | 2LR     | POWER WINDOW RELAY                              |
| 92  | B      | FRONT COMBINATION LIGHT (L.H.) <E>          | 223 | 2L      | POWER WINDOW RELAY                              |
| 93  | B      | INTERMITTENT WIPER RELAY <E>                | 224 | 2B      | DOOR WIRING HARNESS (DRIVER'S SIDE)             |
| 94  | 0.3B   | DEFOGGER SWITCH <E>                         | 225 | 2LB     | DOOR WIRING HARNESS (DRIVER'S SIDE)             |
| 95  | 0.3B   | HEATER RELAY <E>                            | 226 | 3W      | FUSIBLE LINK                                    |
| 96  | B      | DOME LIGHT WIRING HARNESS <E>               | 229 | 2RL     | DOOR WIRING HARNESS (DRIVER'S SIDE)             |
| 98  | 0.3B   | DIMMER CONTROL SWITCH <E>                   | 230 | 2GL     | DOOR WIRING HARNESS (DRIVER'S SIDE)             |
| 99  | B      | COMBINATION METER <E>                       | 231 | 2L      | DOOR WIRING HARNESS                             |


NOTES  
 \* : Vehicles with an automatic transmission.  
 \*\* : Vehicles equipped with an air conditioner.  
 \*\*\* : Vehicles with power windows.

# COMPONENT SERVICE-WIRING HARNESS



## CONTROL WIRING HARNESS

For California (can also be sold in Federal States)



| NO. | WIRE   | CIRCUIT                     |                          |
|-----|--------|-----------------------------|--------------------------|
| 1   | SB     | CARBURETOR CONTROL UNIT (A) | OXYGEN SENSOR            |
| 2   | 1.25GY | CARBURETOR CONTROL UNIT (A) | AIR TEMPERATURE SENSOR   |
| 3   | G      | CARBURETOR CONTROL UNIT (A) | THROTTLE POSITION SENSOR |
| 4   | GR     | CARBURETOR CONTROL UNIT (A) | AIR TEMPERATURE SENSOR   |
| 5   | GB     | CARBURETOR CONTROL UNIT (A) | VACUUM SWITCH            |
| 6   | 1.25B  | CARBURETOR CONTROL UNIT (A) | GROUND                   |
| 7   | 2BW    | CARBURETOR CONTROL UNIT (A) | IGNITION COIL (+)        |
| 8   | 2BW    | CARBURETOR CONTROL UNIT (A) | MAIN FUSIBLE LINK        |
| 9   | 2RL    | CARBURETOR CONTROL UNIT (A) | IGNITION COIL (-)        |
| 10  | SB     | CARBURETOR CONTROL UNIT (A) | WATER TEMPERATURE SENSOR |
| 11  | 1.25B  | CARBURETOR CONTROL UNIT (A) | THROTTLE POSITION SENSOR |
| 12  | YG     | CARBURETOR CONTROL UNIT (A) | AIR CONDITIONER          |
| 13  | YR     | CARBURETOR CONTROL UNIT (A) | CARBURETOR ASSEMBLY      |
| *14 | 0.85BW | CARBURETOR CONTROL UNIT (B) | CARBURETOR ASSEMBLY      |
| 15  | YW     | CARBURETOR CONTROL UNIT (B) | SOLENOID VALVE ASSEMBLY  |
| 16  | YL     | CARBURETOR CONTROL UNIT (B) | AIR CONDITIONER          |
| 18  | RW     | CARBURETOR CONTROL UNIT (B) | SOLENOID VALVE ASSEMBLY  |
| *20 | 0.85L  | CARBURETOR CONTROL UNIT (B) | CARBURETOR ASSEMBLY      |
| 21  | GL     | CARBURETOR CONTROL UNIT (B) | SOLENOID VALVE ASSEMBLY  |
| 22  | YG     | CARBURETOR CONTROL UNIT (B) | CARBURETOR ASSEMBLY      |
| 23  | B      | VACUUM SWITCH               | 37                       |
| 26  | 1.25BW | CARBURETOR ASSEMBLY         | 7                        |
| 27  | 1.25BW | CARBURETOR ASSEMBLY         | 7                        |
| 28  | 1.25BW | CARBURETOR ASSEMBLY         | 7                        |
| 29  | 1.25BW | CARBURETOR ASSEMBLY         | 7                        |
| 30  | 1.25BW | SOLENOID VALVE              | 7                        |
| 31  | GY     | WATER TEMPERATURE SENSOR    | 2                        |
| 32  | GY     | CARBURETOR                  | 2                        |
| 33  | B      | GROUND                      | 1                        |
| 35  | 1.25B  | GROUND                      | 6                        |
| 36  | B      | GROUND                      | 10                       |
| 37  | 1.25B  | GROUND                      | 35                       |


NOTE

\*Vehicles equipped with an air conditioner.



## COMPONENT SERVICE-WIRING HARNESS


### BACK-UP LIGHT AND 4WD INDICATOR LIGHT WIRING HARNESS



16W704

| NO. | WIRE | CIRCUIT              |                            |
|-----|------|----------------------|----------------------------|
| 1   | R    | FRONT WIRING HARNESS | BACK-UP LIGHT SWITCH       |
| 2   | RL   | FRONT WIRING HARNESS | BACK-UP LIGHT SWITCH       |
| 3   | BR   | FRONT WIRING HARNESS | 4WD INDICATOR LIGHT SWITCH |
| 4   | YR   | FRONT WIRING HARNESS | 4WD INDICATOR LIGHT SWITCH |

### DOME LIGHT WIRING HARNESS




16W635

| NO. | WIRE | CIRCUIT              |                 |
|-----|------|----------------------|-----------------|
| 1   | RB   | FRONT WIRING HARNESS | DOME LIGHT <B>  |
| 2   | B    | FRONT WIRING HARNESS | DOME LIGHT <E>  |
| 3   | RG   | FRONT WIRING HARNESS | DOME LIGHT <DR> |

# COMPONENT SERVICE-WIRING HARNESS



## CENTER PANEL WIRING HARNESS




| NO. | WIRE   | CIRCUIT                          |                                      |
|-----|--------|----------------------------------|--------------------------------------|
| 1   | 0.85LW | FRONT WIRING HARNESS <ACC>       | CIGARETTE LIGHTER                    |
| 2   | GW     | FRONT WIRING HARNESS <ILL+>      | CIGARETTE LIGHTER ILLUMINATION LIGHT |
| 3   | 0.85B  | FRONT WIRING HARNESS <E>         | CIGARETTE LIGHTER ILLUMINATION LIGHT |
| 4   | 0.3RB  | FRONT WIRING HARNESS <B>         | CLOCK                                |
| 5   | 0.3GY  | FRONT WIRING HARNESS <ILL->      | HEATER CONTROL ILLUMINATION LIGHT    |
| 6   | B      | CLOCK <E>                        | 3                                    |
| 7   | LW     | CLOCK <ACC>                      | 1                                    |
| 8   | 0.3GW  | CLOCK <ILL+>                     | 2                                    |
| 9   | 0.3GW  | FRONT WIRING HARNESS <ILL+>      | HEATER CONTROL ILLUMINATION LIGHT    |
| 10  | 0.3B   | ASHTRAY ILLUMINATION LIGHT <E>   | 3                                    |
| 11  | 0.3GW  | ASHTRAY ILLUMINATION LIGHT <ILL> | 2                                    |



## COMPONENT SERVICE-WIRING HARNESS

### FRAME WIRING HARNESS – Vehicles without a rear wiper and washer




16W695

| NO. | WIRE  | CIRCUIT                              |   |
|-----|-------|--------------------------------------|---|
| 1   | 0.3GW | FRONT WIRING HARNESS                 | BACK DOOR WIRING HARNESS <LI>             |
| 2   | B     | FRONT WIRING HARNESS                 | BACK DOOR WIRING HARNESS <E>              |
| 3   | 2B    | FRONT WIRING HARNESS                 | BACK DOOR WIRING HARNESS <DEF>            |
| 8   | 0.3GY | FRONT WIRING HARNESS                 | REAR COMBINATION LIGHT (R.H.) <TURN/STOP> |
| 9   | G     | FRONT WIRING HARNESS                 | REAR COMBINATION LIGHT (R.H.)             |
| 10  | RG    | FRONT WIRING HARNESS                 | REAR COMBINATION LIGHT (R.H.) <TAIL>      |
| 11  | RL    | FRONT WIRING HARNESS                 | REAR COMBINATION LIGHT (R.H.) <BACK>      |
| 12  | 0.3GL | FRONT WIRING HARNESS                 | REAR COMBINATION LIGHT (L.H.) <TURN/STOP> |
| 13  | Y     | FRONT WIRING HARNESS                 | FUEL GAUGE UNIT                           |
| 15  | B     | REAR COMBINATION LIGHT (R.H.) <E>    | 2   |
| 16  | 0.3G  | REAR COMBINATION LIGHT (L.H.)        | 9   |
| 17  | 0.3RG | REAR COMBINATION LIGHT (L.H.) <TAIL> | 10  |
| 18  | 0.3RL | REAR COMBINATION LIGHT (L.H.) <BACK> | 11  |
| 19  | B     | REAR COMBINATION LIGHT (L.H.) <E>    | 2   |
| 31  | GW    | SIDE MARKER LIGHT (L.H.)             | 17  |
| 32  | 0.3B  | SIDE MARKER LIGHT (L.H.)             | 19  |
| 33  | 0.3GW | SIDE MARKER LIGHT (R.H.)             | 10  |
| 34  | 0.3B  | SIDE MARKER LIGHT (R.H.)             | 15  |

# COMPONENT SERVICE-WIRING HARNESS



## FRAME WIRING HARNESS – Vehicles with a rear wiper and washer




| NO. | WIRE   | CIRCUIT                              |   |
|-----|--------|--------------------------------------|---|
| 1   | 0.3GW  | FRONT WIRING HARNESS                 | BACK DOOR WIRING HARNESS <LI>               |
| 2   | B      | FRONT WIRING HARNESS                 | BACK DOOR WIRING HARNESS <E>                |
| 3   | 2B     | FRONT WIRING HARNESS                 | BACK DOOR WIRING HARNESS <DEF>              |
| 4   | L      | FRONT WIRING HARNESS                 | BACK DOOR WIRING HARNESS (REAR WIPER) <ACC> |
| 5   | 0.3BrW | FRONT WIRING HARNESS                 | BACK DOOR WIRING HARNESS (REAR WIPER) <LO>  |
| 6   | 0.3Br  | FRONT WIRING HARNESS                 | BACK DOOR WIRING HARNESS (REAR WIPER) <AS>  |
| 7   | 0.3WB  | FRONT WIRING HARNESS                 | BACK DOOR WIRING HARNESS (REAR WASHER)      |
| 8   | 0.3GY  | FRONT WIRING HARNESS                 | REAR COMBINATION LIGHT (R.H.) <TURN/STOP>   |
| 9   | G      | FRONT WIRING HARNESS                 | REAR COMBINATION LIGHT (R.H.)               |
| 10  | RG     | FRONT WIRING HARNESS                 | REAR COMBINATION LIGHT (R.H.) <TAIL>        |
| 11  | RL     | FRONT WIRING HARNESS                 | REAR COMBINATION LIGHT (R.H.) <BACK>        |
| 12  | 0.3GL  | FRONT WIRING HARNESS                 | REAR COMBINATION LIGHT (L.H.) <TURN/STOP>   |
| 13  | Y      | FRONT WIRING HARNESS                 | FUEL GAUGE UNIT                             |
| 15  | B      | REAR COMBINATION LIGHT (R.H.) <E>    | 2   |
| 16  | 0.3G   | REAR COMBINATION LIGHT (L.H.)        | 9   |
| 17  | 0.3RG  | REAR COMBINATION LIGHT (L.H.) <TAIL> | 10  |
| 18  | 0.3RL  | REAR COMBINATION LIGHT (L.H.) <BACK> | 11  |
| 19  | B      | REAR COMBINATION LIGHT (L.H.) <E>    | 2   |
| 31  | GW     | SIDE MARKER LIGHT (L.H.)             | 17  |
| 32  | 0.3B   | SIDE MARKER LIGHT (L.H.)             | 19  |
| 33  | 0.3GW  | SIDE MARKER LIGHT (R.H.)             | 10  |
| 34  | 0.3B   | SIDE MARKER LIGHT (R.H.)             | 15  |



## COMPONENT SERVICE-WIRING HARNESS

### BACK DOOR WIRING HARNESS – Vehicles without a rear wiper and washer




| NO. | WIRE | CIRCUIT                 |                         |
|-----|------|-------------------------|-------------------------|
| 1   | FGW  | FRAME WIRING HARNESS    | LICENSE PLATE LIGHT <B> |
| 2   | FB   | FRAME WIRING HARNESS    | LICENSE PLATE LIGHT <E> |
| 3   | 2FB  | FRAME WIRING HARNESS    | DEFOGGER                |
| 7   | GW   | LICENSE PLATE LIGHT <B> | 1                       |
| 8   | B    | LICENSE PLATE LIGHT <E> | 2                       |

# COMPONENT SERVICE-WIRING HARNESS



## BACK DOOR WIRING HARNESS – Vehicles with a rear wiper and washer




| NO. | WIRE  | CIRCUIT                 |                         |
|-----|-------|-------------------------|-------------------------|
| 1   | FGW   | FRAME WIRING HARNESS    | LICENSE PLATE LIGHT <B> |
| 2   | FB    | FRAME WIRING HARNESS    | LICENSE PLATE LIGHT <E> |
| 3   | 2FB   | FRAME WIRING HARNESS    | DEFOGGER                |
| 4   | FL    | FRAME WIRING HARNESS    | REAR WIPER MOTOR <ACC>  |
| 5   | FBrW  | FRAME WIRING HARNESS    | REAR WIPER MOTOR <LO>   |
| 6   | FBr   | FRAME WIRING HARNESS    | REAR WIPER MOTOR <AS>   |
| 7   | GW    | LICENSE PLATE LIGHT <B> | 1                       |
| 8   | B     | LICENSE PLATE LIGHT <E> | 2                       |
| 9   | 0.3WB | FRAME WIRING HARNESS    | REAR WIPER MOTOR <->    |
| 10  | 0.3L  | REAR WASHER MOTOR <+>   | 4                       |



## COMPONENT SERVICE-WIRING HARNESS

### DOOR WIRING HARNESS – Vehicles with a rear power window


#### Left side



16W753

| NO. | WIRE   | CIRCUIT                              |
|-----|--------|--------------------------------------|
| 1   | 2FL    | FRONT WIRING HARNESS                 |
| 2   | 2FL    | FRONT WIRING HARNESS                 |
| 3   | 2FW    | FRONT WIRING HARNESS                 |
| 4   | 1.25FG | FRONT WIRING HARNESS                 |
| 5   | 1.25FR | FRONT WIRING HARNESS                 |
| 14  | 1.25R  | POWER WINDOW MAIN SWITCH             |
| 15  | 1.25G  | POWER WINDOW MAIN SWITCH             |
|     |        | POWER WINDOW MAIN SWITCH <B>         |
|     |        | POWER WINDOW MAIN SWITCH <E>         |
|     |        | POWER WINDOW MAIN SWITCH             |
|     |        | POWER WINDOW MAIN SWITCH (R.H.-UP)   |
|     |        | POWER WINDOW MAIN SWITCH (R.H.-DOWN) |
|     |        | POWER WINDOW MOTOR                   |
|     |        | POWER WINDOW MOTOR                   |

#### Right side




16W752

| NO. | WIRE | CIRCUIT                        |
|-----|------|--------------------------------|
| 1   | 2FR  | FRONT WIRING HARNESS           |
| 2   | 2FL  | FRONT WIRING HARNESS           |
| 3   | 2RB  | POWER WINDOW MOTOR             |
| 4   | 2FG  | FRONT WIRING HARNESS           |
| 5   | 2GB  | POWER WINDOW MOTOR             |
|     |      | POWER WINDOW SUB SWITCH (UP)   |
|     |      | POWER WINDOW SUB SWITCH <B>    |
|     |      | POWER WINDOW SUB SWITCH (UP)   |
|     |      | POWER WINDOW SUB SWITCH (DOWN) |
|     |      | POWER WINDOW SUB SWITCH (DOWN) |

# COMPONENT SERVICE-WIRING HARNESS



## AIR CONDITIONER WIRING HARNESS A




| NO. | WIRE   | CIRCUIT                |                            |
|-----|--------|------------------------|----------------------------|
| 1   | 0.85WB | BLOWER SWITCH          | AIR CONDITIONER SWITCH     |
| 2   | 0.85LB | AIR CONDITIONER SWITCH | THERMO SWITCH              |
| 3   | B      | AIR CONDITIONER SWITCH | 7                          |
| 4   | 0.85GB | THERMO SWITCH          | POWER RELAY B              |
| 5   | 0.85L  | POWER RELAY B          | POWER RELAY A              |
| 6   | 0.85LW | POWER RELAY B          | FRONT WIRING HARNESS <ACC> |
| 7   | 0.85B  | POWER RELAY B          | FRONT WIRING HARNESS <E>   |
| 8   | 0.85BY | POWER RELAY A          | FRONT WIRING HARNESS       |
| 9   | 0.85LR | POWER RELAY A          | FUSE                       |
| 10  | 0.85BW | POWER RELAY A          | FRONT WIRING HARNESS       |
| 11  | 3LR    | FUSE                   | FRONT WIRING HARNESS       |
| 12  | 0.85L  | FRONT WIRING HARNESS   | 9                          |



## COMPONENT SERVICE-WIRING HARNESS


### AIR CONDITIONER WIRING HARNESS B



16W666

| NO. | WIRE   | CIRCUIT              |                     |
|-----|--------|----------------------|---------------------|
| 1   | 0.85BW | FRONT WIRING HARNESS | LOW PRESSURE SWITCH |
| 2   | 0.85BW | FRONT WIRING HARNESS | LOW PRESSURE SWITCH |

### AIR CONDITIONER WIRING HARNESS C



16W750

| NO. | WIRE   | CIRCUIT                  |                      |
|-----|--------|--------------------------|----------------------|
| 1   | 0.85BW | FRONT WIRING HARNESS     | MAGNETIC CLUTCH      |
| 2   | 0.85BW | IDLE-UP SOLENOID VALVE   | 1                    |
| 3   | 0.85B  | IDLE-UP SOLENOID VALVE   | DIODE                |
| 4   | 0.85BY | WATER TEMPERATURE SWITCH | FRONT WIRING HARNESS |
| 5   | 0.85BW | E.S.S. SOLENOID VALVE    | DIODE                |
| 6   | 0.85L  | E.S.S. SOLENOID VALVE    | FRONT WIRING HARNESS |
| 7   | 0.85L  | POWER RELAY C            | FRONT WIRING HARNESS |
| 8   | 0.85GB | POWER RELAY C            | CONDENSER FAN MOTOR  |
| 9   | 0.85BW | POWER RELAY C            | 1                    |
| 10  | 0.85B  | POWER RELAY C            | GROUND               |
| 11  | 0.85GY | CONDENSER FAN MOTOR      | 10                   |
| 12  | 0.85BW | DIODE                    | FRONT WIRING HARNESS |
| 13  | 0.85BW | DIODE                    | 12                   |




## FUSIBLE LINKS

The fusible links consist of main link and sub link. Every circuit except the starter motor uses fusible links.


### Main fusible link

Connected to the positive (+) terminal of the battery.



### Sub fusible link

The sub fusible link is secured with tape to the wiring harness at the rear of the left front fender shield.




### Inspection

Check for a burnt fusible link with a circuit tester, since visual diagnosis may be difficult.

If a fusible link burns out, the cause is a short or some other problem in the circuit. Carefully determine the cause and correct it before replacing the fusible link.

When replacing fusible links, be sure to use a fusible link of the specified capacity.



## COMPONENT SERVICE-FUSES

### FUSE BLOCK


The fuse block is located on the left hand side of the instrument panel.

#### Inspection

If any of the fuses are to be replaced, be sure to use a fuse of the specified capacity.

#### NOTE

If a fuse has failed, locate the cause and completely eliminate the problem before installing a new fuse.




### Fuse Capacity Table

| Power supply circuit  | Fuse No. | Rated capacity A | Applicable circuits  |
|-----------------------|----------|------------------|--|
| Battery               | 1        | 20               | Clock, Dome light, Door switches, Hazard warning flashers  |
| Headlight relay       | 2        | 10               | Tail lights, License plate lights, Illumination lights, Headlight washer relay, Position lights                    |
| Ignition switch (IG)  | 3        | 10               | Heater relay, Seat belt warning timer, Turn-signal lights, Alternator, Seat belt switches, power window relay      |
|                       | 4        | 10               | Back-up lights, Fuel and water temperature gauges, indicator and warning lights, oil pressure gauge, voltage meter |
|                       | 5        | 15               | Rear window defogger, Rear heater  |
| Battery               | 6        | 20               | Heater   |
|                       | 7        | 15               | Key-reminder switch, Stop lights, Buzzer, Seat belt switch (L.H.) Door switch (L.H.)                               |
| Ignition switch (ACC) | 8        | 15               | Windshield wipers and washer, Headlight washer relay, Intermittent wiper relay, Horn                               |
|                       | 9        | 10               | Rear window wiper and washer   |
|                       | 10       | 15               | Cigarette lighter, Radio, Tape player, Clock (ACC), Spare terminal   |

### INDEPENDENT FUSE

An independent fuse is provided behind the left-hand headlight, for the high beam indicator light.



# COMPONENT SERVICE-IGNITION SWITCH




## COMPONENTS

### Ignition switch

| Key position | Terminal | 1 | 2 | 3 | 4 | 5 |
|--------------|----------|---|---|---|---|---|
| LOCK         |          |   |   |   |   |   |
| ACC          |          | ○ | ○ |   |   |   |
| ON           |          | ○ | ○ | ○ |   |   |
| START        |          | ○ |   | ○ | ○ | ○ |


### Key-reminder switch

| Key position             | Terminal | 1 | 2 |
|--------------------------|----------|---|---|
| When the key is removed  |          | ○ | ○ |
| When the key is inserted |          |   |   |



## REPLACEMENT OF THE IGNITION SWITCH SEGMENT

1. Disconnect the negative cable from the terminal of the battery.
2. Remove the column cover. (Refer to GROUP 19.)
3. Remove the band clip of the wiring harness, and then disconnect the ignition switch harness connector and the key-reminder switch harness connector.
4. Remove the ignition switch segment and key-reminder switch mounting screws, and then pull the switch segment out of the key cylinder. (16W741)






## COMPONENT SERVICE-IGNITION SWITCH/METERS AND GAUGES

### INSTALLATION


1. Secure the column switch harness and ignition switch harness to the steering column with band clips to make sure that the harnesses are not caught in the boss or moving portion of the column cover.
2. The ignition harness connector and the key-reminder switch harness connector should be connected to the front wiring harness together with the column switch harness connector at the left side of steering support bracket. (16W730)



### METERS AND GAUGES


#### COMPONENTS

1. Speedometer cable
2. Buzzer
3. Printed-circuit board
4. Meter cover
5. Meter case
6. Meter glass
7. Meter hood
8. Speedometer
9. Fuel gauge, water temperature gauge
10. Tachometer
11. Window plate
12. Combination meter pad
13. Voltage gauge
14. Inclinometer
15. Oil pressure gauge
16. Meter wiring harness




### REMOVAL

1. Remove the meter cover.






2. Remove the screws from the bottom of the case. (16W740)
3. Remove the bolt from the upper part of the case. (16W508)



4. Disconnect the speedometer cable from the meter case by pushing the stopper of the plug on the speedometer cable side of the connection. (16W744)
5. Disconnect the connectors of the meter harness and the buzzer (located behind the meter case), and also of the body harness.
6. Disconnect the connectors (all located behind the meter case at the bottom) of the hazard switch, the rear window defogger, and the rear wiper/washer switch, and then remove the meter case.

## INSTALLATION


When installing the instrument cluster, be sure to secure the speedometer cable and connector positively.



## SPEEDOMETER

### Replacement of the Speedometer Cable


1. Replace the cable assembly if there is a malfunction.
2. When connecting the cable to the speedometer, insert the cable until the stopper properly fits to the speedometer groove. (16F554)



3. After installing the speedometer, pull the speedometer cable through the grommet in the fire wall until the cable marking is visible from the engine compartment side.
4. Apply a drying sealant to the outside surface of the grommet. (16W540)
5. Securely clamp the speedometer cable to the frame clip at the marking (yellow) on the transmission side.

### Caution

Disconnect installation of the cable may cause the meter indication to fluctuate, damage a harness, or produce noise.





## COMPONENT SERVICE-METERS AND GAUGES

### TACHOMETER

#### Inspection

Connect a tach-dwell meter, and then compare the meter readings at various engine speeds with the values indicated on the tachometer. If there is a large error, replace the tachometer.

rpm

| Engine speed | Tolerance |
|--------------|-----------|
| 1,000        | $\pm 100$ |
| 2,000        | $\pm 100$ |
| 3,000        | $\pm 150$ |
| 4,000        | $\pm 200$ |
| 5,000        | $\pm 250$ |

#### Caution

The tachometer is the negative-ground type, and therefore should not be connected in reverse polarity to the battery. If the tachometer is connected in reverse polarity, the transistors and diodes will be damaged.


### FUEL GAUGE AND UNIT

#### Inspection

##### FUEL GAUGE INDICATION TEST

Disconnect the wiring connector from the fuel gauge unit inside the luggage compartment. Connect a resistance between the terminals and confirm the gauge indications.

| Indication point | Resistance value |
|------------------|------------------|
| Empty            | 120 $\Omega$     |
| Full             | 17 $\Omega$      |




##### FUEL GAUGE CONTINUITY TEST


Measure the resistance value between the terminals with an ohmmeter.

Resistance value . . . . . Approx. 25  $\Omega$

#### NOTE

If the resistance value is extremely small, there may be a short in the coil. If it is extremely large, there may be a broken wire or some other problem in the coil. In either case, replace the gauge.





### Replacement of the Fuel Gauge Unit

1. Remove the fuel gauge unit. (03W505)


#### Caution

Since the fuel gauge unit is mounted to the side of the tank, drain the fuel first. The in-tank filter of the fuel gauge unit should be handled carefully because there is the danger of the filter coming out of position.

2. When installing the fuel gauge unit, be careful not to bend the float arm.
3. After installation, confirm that the unit is securely grounded.

#### Tightening torque

Fuel gauge unit ..... 1 Nm (0.7 ft.lbs.)




### WATER TEMPERATURE GAUGE AND UNIT

#### Inspection

##### WATER TEMPERATURE GAUGE INDICATION TEST

1. Disconnect the wiring connector from the water temperature gauge unit inside the engine compartment.
2. Connect a resistance to the connector, and then confirm the gauge indications.


| Indication point  | Resistance value |
|-------------------|------------------|
| (1) 115°C (239°F) | 23.8 Ω           |
| (2) 70°C (158°F)  | 104 Ω            |



##### WATER TEMPERATURE GAUGE CONTINUITY TEST

Measure the resistance value between the terminals with an ohmmeter.

Resistance value ..... Approx. 55 Ω




#### NOTE

If the resistance value is extremely small, there may be a short in the coil; if it is extremely large, there may be a broken wire or some other problem in the coil. In either case, replace the gauge.

### WATER TEMPERATURE GAUGE UNIT OPERATION CHECK

Measure the resistance with the gauge unit in hot water at 70°C (158°F).

Resistance value ..... 104 Ω



#### Caution

The gauge unit should be held with its housing 3 mm (.12 in.) away from the surface of the hot water.

**INCLINOMETER****Outline**


The inclinometer is an instrument which indicates the forward or backward inclination (pitching) or side to side inclination (rolling) of vehicle.

Motion of a pendulum in the system is displayed on the system. The pitching and rolling pointer is supported by a double support mechanism in which the rolling fulcrum is supported in such a way as to be rotatable around the case and the pitching fulcrum supported on the rolling system.

**Construction**

The inclinometer consists of an outer case which inclines with the vehicle, a pointer which is provided in an oil case and always maintains a level position, and a spherical dial. The spherical dial is coupled through the dial support plate to the rolling damper plate. The rolling damper plate is swivel bearing coupled to a stationary frame by the center axis, so it can incline side-to-side, but is always held in a level position by a pendulum. The pointer is coupled with the pitching damper plate.


Since the pitching damper plate is swivel bearing coupled to the rolling damper plate by the center axis, it can incline forward and backward, but is always maintained in a level position by the pendulum.






## Operation

The side-to-side inclination angle should be read on a scale of the front panel as indicated by the horizontal centerline of the spherical dial, whereas the forward or backward inclination angle should be read on a scale of the spherical dial as indicated by the pointer.




### SIDE-TO-SIDE INCLINATION

The front panel inclines with the vehicle, but the spherical dial maintains a horizontal condition, so the horizontal centerline of the spherical dial shows the side-to-side inclination angle.




### FORWARD OR BACKWARD INCLINATION


The spherical dial inclines forward or backward with the vehicle, but the pointer maintains a level position, so the pointer indicates the forward or backward inclination angle.



### COMBINED FORWARD OR BACKWARD AND SIDE-TO-SIDE INCLINATION

The forward or backward inclination angle and the side-to-side inclination angle are indicated by the pointer and spherical dial.






## COMPONENT SERVICE-METERS AND GAUGES

### Removal

1. Remove the combination meter. (Refer to p. 8-134.)
2. Remove the pad. (16W781)
3. Remove the meter case attaching screws.
4. Disconnect the connectors of the meter harness located behind the meter case.
5. Remove the inclinometer from the meter case.

### Caution


To prevent internal trouble, the meter must not be dropped or subjected to shock or must not be abruptly inclined to the extent that the maximum indication angle is exceeded.



16W781

### Installation

1. Make sure that all water bubbles in the oil case are collected in the upper bubble collecting portion before installation. (16W780)
2. With the vehicle in a level position (unladen), check to ensure that the spherical dial and pointer indicate a level position.
3. If the spherical dial and pointer do not indicate that the vehicle is level, adjust the inclinometer by inserting shims between it and either the combination gauge bracket or the instrument panel. If the pointer indication is very far from horizontal, replace the inclinometer.



16W780

## OIL PRESSURE GAUGE AND UNIT

### Removal


1. Remove the combination meter.
2. Remove the pad.
3. Disconnect the oil pressure gauge from the meter wiring harness.
4. Remove the oil pressure gauge to meter case attaching screws.

### Inspection

#### OIL PRESSURE GAUGE INDICATION TEST

Disconnect the wiring connector from the oil pressure gauge unit inside the engine compartment.

Connect a resistance to the connector, and then confirm the gauge indications. (16W785, 16W597)



16W597

| Indication point     | Resistance value |
|----------------------|------------------|
| (1) 588 kPa (85 psi) | 120Ω             |




## OIL PRESSURE GAUGE CONTINUITY TEST

Measure the resistance value between the terminals with an ohmmeter.

### NOTE

If the resistance value is extremely small, there may be a short in the coil; if it is extremely large, there may be a broken wire or some other problem in the coil.



16W779

## VOLTAGE METER


### Removal

1. Remove the combination meter.
2. Remove the pad.
3. Disconnect the voltage meter from the meter wiring harness.
4. Remove the voltage meter to meter case attaching screws.

### Inspection


#### VOLTAGE METER CONTINUITY TEST

1. Connect an ohmmeter to the voltmeter. (16W779)
2. Confirm that the value indicated on the ohmmeter agrees with the standard value.



16W779

Resistance value ..... 420Ω




## COMPONENT SERVICE-METERS AND GAUGES

### SEAT BELT WARNING SYSTEM

1. If the driver turns the ignition key to "ON" while his seat belt is unbuckled, the seat belt warning system is activated to provide an audible and visual reminder through a buzzer and light to fasten the seat belt properly.
2. The seat belt warning system consists of a belt switch, buzzer, warning light, belt warning timer.


#### Seat Belt Warning Timer

The timer operates when the ignition key is in the "ON" position and terminals 2 and 3 are electrically connected to terminal 4 (ground). (16W731)



#### Seat Belt Warning Light and Buzzer


When the seat belt switch is ON (seat belts not buckled) with the ignition key at the ON position, the seat belt warning timer causes the seat belt warning light to illuminate and the buzzer to sound for 4 to 8 seconds. If the seat belt switch is set to OFF (the seat belts buckled) during the seat belt warning timer interval, only the buzzer is cancelled.



#### Seat Belt Switch

##### CONTINUITY TEST


1. Pull back the floor mat and disconnect the seat belt switch connector from where it is at the attachment to the buckle stalk assembly.
2. Use an ohmmeter to check for a short circuit at the 0.3-Y wire and the 0.3-RB wire of the driver's seat belt switch. (16W732)
3. If the ohmmeter reads no resistance with the buckle unlocked and indicates an open circuit when the buckle is locked, the belt switch is operating properly.
4. If a microswitch is defective, the buckle stalk assembly containing microswitch should be replaced. For replacement, see GROUP 23.






## System Inspection

1. Disconnect the seat belt warning timer connector.
2. When the 0.3-YB wire (terminal 2) and 0.3-B wire (terminal 4) are connected with a jumper wire, the seat belt warning light should illuminate. If it fails to illuminate, check the bulb, key-reminder switch and fuse. (16C953)
3. Also the buzzer should sound when the 0.3-RB wire (terminal 3) and 0.3-B wire (terminal 4) are connected with a jumper wire. In this condition, fasten the buckle; if the buzzer stops sounding, the seat belt switch is good. (16C953)
4. If the buzzer does not sound when terminal 3 and terminal 4 are connected with a jumper wire, and check continuity of the seat belt switch. If these is continuity in the seat belt switch, replace the buzzer.
5. After performing the above inspections, connect the seat belt warning timer.
6. With the ignition switch turned to IG, verify the function of the seat belt warning system.




16C953




## COMPONENT SERVICE-LIGHTING SYSTEM

### COMPONENTS



### HEADLIGHTS

1. The headlight system consists of two sealed-beam bulbs.
2. The bulbs are the dual filament type for low and high beams and are marked by a number 2DI molded in the lens.
3. The low beam is intended for use in congested areas and on highways when oncoming vehicles are within a distance of 153 m (500 ft.).
4. The high beam is intended primarily for distant illumination and for use on the open highway when there are no oncoming vehicles.



## AIMING

### Pre-aiming Instructions

1. Test dimmer switch operation.
2. Confirm operation of high beam indicator light mounted in instrument cluster.
3. Inspect for badly rusted or faulty headlight assemblies. These conditions must be corrected before a satisfactory adjustment can be made.
4. Fill the fuel tank.
5. Position vehicle on a level floor.
6. Bounce the front of the vehicle up and down three times by applying your body weight to the hood or bumper.
7. Check tire inflation.
8. Rock vehicle sideways to allow it to assume its normal position.
9. There should be no other load in the vehicle except the driver or substituted weight of approximately 70 kg (150 lbs.) placed in driver's seat.
10. Thoroughly clean headlight lenses.
11. Adjust headlights by following the instructions for the headlight tester.


### Removal

1. Remove the radiator grille, front combination light and headlight bezel. (Refer to GROUP 23.)
2. Disconnect the harness connector from the bulb socket.
3. Remove the retaining ring from the mounting ring. (16W559)

### Caution


**Do not disturb headlight adjusting screws.**


4. Remove the headlight assembly.



### LIGHT CONTROL RELAY


1. Check to ensure that when battery voltage is applied between terminals 2 and 3 and between terminals 5 and 6 an operating sound (click) is heard. (F16077, 16W515)
2. In the above conditions, check to see if the battery voltage is applied to terminals 1 and 4. (F16077, 16W515)





## COMPONENT SERVICE-LIGHTING SYSTEM

### LIGHTING SWITCH




NOTE  
R' and L' indicate lane-changing operation.

16W734

| Terminal |        |                           | Lighting switch |      |      | Dimmer and passing switch |                |   | Turn-signal switch |   |        | Headlight washer switch |    | Horn switch |    |
|----------|--------|---------------------------|-----------------|------|------|---------------------------|----------------|---|--------------------|---|--------|-------------------------|----|-------------|----|
| No.      | Wire   | Used for                  | OFF             | 3005 | 3006 | D <sub>1</sub>            | D <sub>2</sub> | P | L (L')             | N | R (R') | OFF                     | ON | OFF         | ON |
| 1        | (G)    | Lighting switch (3005)    |                 | ○    | ○    |                           |                |   |                    |   |        |                         |    |             |    |
| 2        | R      | Lighting switch (3006)    |                 |      | ○    |                           |                | ○ |                    |   |        |                         |    |             |    |
| 3        | 0.85GR | Turn-signal power supply  |                 |      |      |                           |                |   | ○                  |   |        | ○                       |    |             |    |
| 4        | 0.85GL | Turn-signal light (L.H.)  |                 |      |      |                           |                |   | ○                  |   |        |                         |    |             |    |
| 5        | 0.85GY | Turn-signal light (R.H.)  |                 |      |      |                           |                |   |                    | ○ |        | ○                       |    |             |    |
| 6        | 2RW    | Dimmer switch (low beam)  |                 |      |      | ○                         |                | ○ |                    |   |        |                         |    |             |    |
| 7        | 2R     | Dimmer switch (high beam) |                 |      |      |                           | ○              | ○ |                    |   |        |                         |    |             |    |
| 8        | (B)    | Lighting switch ground    |                 | ○    | ○    |                           |                |   |                    |   |        |                         |    |             |    |
| 9        | GB     | Horn switch               |                 |      |      |                           |                |   |                    |   |        |                         |    |             | ○  |
| 10       | (L)    | Headlight washer relay    |                 |      |      |                           |                |   |                    |   |        |                         | ○  |             | ○  |
| 11       | 2B     | Ground                    |                 |      |      | ○                         | ○              | ○ |                    |   |        |                         | ○  |             | ○  |
| 12       | 0.85WG | Stop light switch         |                 |      |      |                           |                |   |                    | ○ |        |                         |    |             |    |
| 13       | 0.85WR | Stop light (R.H.)         |                 |      |      |                           |                |   | ○                  | ○ |        |                         |    |             |    |
| 14       | 0.85WL | Stop light (L.H.)         |                 |      |      |                           |                |   | ○                  | ○ |        |                         |    |             |    |

NOTE

The sizes for wires whose size is not specified in the "Wire" column above are 0.3 mm<sup>2</sup> for items in parentheses, and 0.5 mm<sup>2</sup> for all others.





## HAZARD WARNING SWITCH

### Inspeciton

Move the switch to ON and OFF, and check the continuity between the terminals.

| Terminal No. | Switch position |    | Connection point               |
|--------------|-----------------|----|--------------------------------|
|              | OFF             | ON |                                |
| 1            |                 |    | Fuse block No.2                |
| 2            |                 |    | Ground                         |
| 3            |                 |    | Front turn-signal light (L.H.) |
| 4            |                 |    | Rear turn-signal light (L.H.)  |
| 5            |                 |    | Stop light switch              |
| 6            |                 |    | Turn-signal flasher unit       |
| 7            |                 |    | Hazard warning flasher unit    |
| 8            |                 |    | Column switch                  |
| 9            |                 |    | Column switch                  |
| 10           |                 |    | Front turn-signal light (R.H.) |
| 11           |                 |    | Rear turn-signal light (R.H.)  |

## TURN-SIGNAL AND HAZARD WARNING FLASHER UNIT






## COMPONENT SERVICE-LIGHTING SYSTEM

### Installation


1. Connect the black connector to the turn-signal flasher unit. (16W747)
2. The ground wires for turn-signal flasher unit and front-wiring harness should be tightened together. (16W747)



### DIMMER CONTROL SWITCH

#### Inspection

1. With the connector disconnected, measure the continuity between the dimmer control switch terminals with an ohmmeter. (F16599)
2. If the resistance value varies smoothly between 0 and 10 ohms throughout the entire operation range, the dimmer control switch is functioning properly. (F16599)






## COMPONENTS

1. Wipers and washer switch assembly
2. Wiper blade
3. Wiper arm
4. Wiper linkage
5. Wiper motor
6. Washer nozzle
7. Washer motor
8. Washer tank
9. Intermittent wiper relay

|   | Nm    | ft.lbs. |
|---|-------|---------|
| A | 10-16 | 7-12    |
| B | 7     | 5       |
| C | 3     | 2       |



## WIPER MOTOR AND LINKAGE

### Removal

1. Remove the wiper arms and the pivot shaft mounting nuts, then push the pivot shafts toward the inside.
2. Loosen the wiper motor mounting bolts, and then with the motor pulled out slightly, disconnect the linkage and the motor. (C16555)
3. Remove both the motor and the linkage.



### Caution

Because the installation angle of the crank arm and the motor has been set, do not separate them unless it is necessary to do so. If they must be separated, do so only after marking the mounting positions.

### Installation

Install the wiper arms on the pivot shafts so that the stopping position of the wiper blades is at the specified point.  
(16Y1568)

Wiper blade stopping position (distance between blade tip and front deck garnish) . . . . .  
37-47 mm (1.5-1.9 in.)





## COMPONENT SERVICE-WINDSHIELD WIPERS AND WASHER


### WINDSHIELD WASHER

#### Inspection and Adjustment

Check the washer fluid spray pattern.

Adjust by moving the nozzle.

mm (in.)



16Y1569

### INTERMITTENT WIPER RELAY

#### Inspection

If the wipers do not stop in the correct position when the wiper switch is set to the star mark:

- (1) Check whether the output of the voltage from terminal 3 is synchronized with the operation of the wipers.

|                                |      |
|--------------------------------|------|
| When the wipers are stopped:   | 12 V |
| When the wipers are operating: | 0 V  |

If the wipers do not operate intermittently when the wiper switch is set to the star mark:


- (1) Perform the same check as described above.

If the wipers do not operate when the wiper switch is set to the star mark:

- (1) Confirm that power is being supplied to terminals 1 and 4.
- (2) Confirm that the voltage between terminal 6 and ground is 0 V.
- (3) Confirm that the voltage between terminal 3 and ground is 0 V.

If the wipers do not operate when the washer switch is turned ON:

- (1) Confirm that power is being supplied to terminals 1 and 4.
- (2) Confirm that the voltage between terminal 5 and ground is 0 V while the washer switch is ON.
- (3) Confirm that the voltage between terminal 3 and ground is 12 V at the moment that the washer switch is turned on, and that the voltage is 0 V approximately one second later. Also, confirm that the voltage is 0 V 2 to 5 seconds after the washer switch is turned off.




16Y1869



## WINDSHIELD WIPER AND WASHER SWITCH ASSEMBLY (COLUMN SWITCH)

### Inspection

Move the column switch to each position to check for continuity between terminals.



| Terminal |      |                                    | Wiper/washer switch |            |            |           |                         | Intermittent time adjusting switch |
|----------|------|------------------------------------|---------------------|------------|------------|-----------|-------------------------|------------------------------------|
| No.      | Wire | Used for                           | OFF                 | INT<br>(★) | LOW<br>(1) | HI<br>(2) | SHORT ~ LONG<br>(S) (L) |                                    |
| 1        | YL   | Washer switch (ON)                 | ○                   | ○          | ○          | ○         |                         |                                    |
| 2        | LB   | Wiper switch (High speed)          | —                   | —          | —          | ○         |                         |                                    |
| 3        | 2B   | Ground                             | ○                   | ○          | ○          | ○         | ○                       | ○                                  |
| 4        | BY   | Wiper switch (Intermittent)        | —                   | ○          | —          | —         |                         |                                    |
| 5        | BR   | Wiper switch (OFF)                 | ○                   | ○          | —          | —         |                         |                                    |
| 6        | LO   | Wiper switch (Low speed)           | ○                   | ○          | ○          | —         |                         |                                    |
| 7        | 0.3Y | Intermittent time adjusting switch | —                   | —          | —          | —         | ○                       |                                    |

### Remarks

The dotted lines indicate that the automatic-return switch is ON.




## COMPONENT SERVICE-REAR WINDOW WIPER AND WASHER

### COMPONENTS

1. Rear wiper and washer switch
2. Rear wiper blade
3. Rear wiper arm
4. Rear wiper motor
5. Rear washer tank lid
6. Rear washer tank
7. Rear washer motor
8. Joint
9. Rear washer nozzle

|   | Nm   | ft.lbs. |
|---|------|---------|
| A | 7-10 | 5-7     |
| B | 8-12 | 6-9     |
| C | 7-10 | 5-7     |




16W568

### REAR WIPER MOTOR AND WIPER ARM

#### Removal

1. Remove the spare wheel from the back door.
2. Remove the wiper arm and remove the pivot shaft locking nut.
3. Remove the back door trim and remove the waterproof film. (Refer to GROUP 23.)
4. Remove the rear wiper motor mounting bolts and remove the rear wiper motor. (16W516)




16W516

#### Installation

Adjust the mounting position of the wiper arm so that the stopping position of the wiper blade agrees with the standard value.

Wiper blade stopping position (distance between  
blade tip and back door window weatherstrip . . . . .  
20 mm (.8 in.)




16W517



## REAR WASHER TANK

### Removal


1. Remove the right rear quarter trim.
2. Remove the rear washer tank mounting screws and then remove the tank. (16W519)



## REAR WASHER NOZZLE

### Inspection and Adjustment


Check the washer fluid spray pattern.  
Adjust the nozzle.



## REAR WIPER AND WASHER SWITCH

### Removal


Remove the switch from the instrument cluster and disconnect the connector.



### Inspection

Operate the switch and check the continuity between the terminals.

| Position        | Terminal | 1 | 2 | 3 | 4 |
|-----------------|----------|---|---|---|---|
| Washer          |          | ○ |   |   | ○ |
| Wiper OFF       |          |   | ○ | ○ |   |
| Wiper ON        |          |   |   | ○ | ○ |
| Wiper<br>Washer |          | ○ |   | ○ | ○ |








## COMPONENT SERVICE-HEADLIGHT WASHER

### COMPONENTS


1. Headlight washer control relay
2. Headlight washer switch
3. Headlight washer motor
4. Headlight washer tank
5. Bracket
6. Main hose
7. Clamp
8. Check valve
9. Nozzle clamp
10. Headlight washer nozzle



### HEADLIGHT WASHER TANK

#### Removal

Remove the headlight washer tank mounting bolts and remove the tank.






## HEADLIGHT WASHER CONTROL RELAY

### Continuity Test

1. Check for continuity between the terminals of the headlight washer control relay with an ohmmeter. (Y16696)
2. If the results obtained do not agree with the conditions of continuity shown in the chart below, replace the relay.

| 1 | 2 | 3 | 4 | 5 |
|---|---|---|---|---|
| — |   | + |   |   |
|   | — | + |   |   |
|   |   | + | — |   |
|   |   | + |   | — |




### NOTE

Connect the test probe (+) to terminal 3. There should be no continuity in the opposite direction; therefore, during inspection, pay attention to the direction of continuity when connecting the test probe.

## HEADLIGHT WASHER NOZZLES

### Removal

1. Remove the radiator grille and headlight bezels. (Refer to GROUP 23.)
2. Remove the nozzle clamp and remove the washer nozzle from the grille filler panel. (16W545)




16W545



## COMPONENT SERVICE-HORN

### COMPONENTS


1. Horn (high pitch)
2. Horn (low pitch)
3. Center pad
4. Fixture
5. Horn cable
6. Contact plate
7. Horn button
8. Contact cup
9. Horn spring
10. Pad



16W590  
16D861

### REMOVAL

1. Remove the radiator grille. (Refer to GROUP 23.)
2. Disconnect the horn connectors.
3. Remove the horn mounting bolts. (16W697)



16W697

### INSPECTION

1. Check horn switch contact for burned-out or short-circuited.
2. Check horn switch spring for broken or damaged.
3. Check horn switch harness for damage.
4. Check horn adjustment screw for looseness.
5. Check the horn for water, dirt or other foreign matter lodged.



## HORN ADJUSTMENT

Secure the horn bracket in a vice, and then connect a battery of the specified voltage (12 volts).

Sound the horn, and adjust it by turning the adjusting screw.

1. The sound volume is too low:

Turn the adjusting screw in the "UP" direction within a range of about  $180^\circ$ , and then lock it in position when a satisfactory sound volume has been obtained.

2. The sound volume is too loud:

Turn the adjusting screw  $20^\circ$  to  $30^\circ$  in the "DOWN" direction, and then lock it in position when a satisfactory sound volume has been obtained.


3. Horn will not sound:

Turn the adjusting screw slightly in the "UP" direction until the horn sounds, find a satisfactory sound volume by continuing to turn the screw within a range of  $180^\circ$ , and then lock the screw in place.

If a satisfactory volume cannot be obtained, replace the horn.

### Caution


After the adjustment, apply lacquer to prevent the adjusting screw from becoming loose.






## COMPONENT SERVICE-CLOCK

### COMPONENTS



### REMOVAL

1. Remove the center console. (Refer to GROUP 23.)
2. Remove the mounting screws and disconnect the power supply connector. (16W553)




### TIME ADJUSTMENT

Adjust the clock as follows:

1. To adjust the hour, push button (1).
2. To adjust the minutes, push button (2).
3. To clear away the minutes display, push button (3).

Example of time adjustment

| Before adjustment | After adjustment |
|-------------------|------------------|
| 10:01 – 10:29     | 10:00            |
| 10:30 – 10:59     | 11:00            |




### Caution

This clock is a delicate mechanism containing a crystal oscillator, transistors, etc., and should be handled with care. Specialized technical skill is needed to repair the internal mechanism; do not attempt to disassemble it. If the clock itself is malfunctioning, replace the entire assembly. When bake-finishing a paint coat, take care not to allow the clock to be exposed to temperatures exceeding 60°C (140°F).



## COMPONENTS

1. Rear window defogger switch
2. Rear window defogger glass




16W708

## PRINTED HEATER LINES

### Inspection

1. The printed heater lines should be tested while the engine is running at 2,000 rpm and the battery is being charged.
2. Turn the defogger switch to the "ON" position, and use voltmeter to measure the voltage of each printed heater line at the rear window glass center point "A".
3. If all of the heater lines indicate approximately 6V, the rear window printed heater lines are functioning properly.
4. If a voltage of 12V is indicated at point "A", the wire is broken between point "A" and the negative (-) terminal. Move the test probe gradually toward the negative (-) terminal and search for the place where there is a sudden change in the voltage (to 0V).
5. This place where the voltage suddenly changes indicates the location of the broken wire.
6. If 0V is indicated at point "A", the wire is broken between point "A" and the positive (+) terminal. Find the point where there is a sudden change in the voltage (to 12V), as described in step 4. above.




16Y332


### Repair

1. Prepare the following items:
  - Conductive paint
  - Paint thinner
  - Masking tape, decal, etc.
  - Unleaded gasoline
  - Thin brush

Wipe the glass adjacent to the broken heater line, clean with unleaded gasoline, and bond a decal or masking tape as shown.



16F650



## COMPONENT SERVICE-REAR WINDOW DEFOGGER

2. Shake the electroconductive paint container well, and remove the amount of paint needed. Dilute it with a small quantity of paint thinner, and apply three coats with the brush at intervals of about 15 minutes.
3. Remove the tape or decal and leave the repaired defogger unused for a while before supplying power.
4. For a better finish, scrape away excess deposits with a knife after drying is complete (one day later).


### Caution

After repair, clean the glass with a soft dry shop towel or wipe along the printed heater line with a slightly moistened shop towel.

## REAR WINDOW DEFOGGER SWITCH

### Removal

Remove the switch from the instrument cluster and push the connector bar to detach the switch.



16W609


### Inspection

Operate the switch and check continuity between the terminals.

| Position | Terminal | 1 | * | 2 | 3 | 4 | 5 | * | 6 |
|----------|----------|---|---|---|---|---|---|---|---|
| OFF      |          | ○ | Ⓐ | ○ |   |   | ○ | Ⓐ | ○ |
| ON       |          | ○ | Ⓐ | ○ | ○ | ○ | ○ | Ⓐ | ○ |

### NOTE

\* Denotes indicator light.




16W696



## COMPONENTS

1. Whip antenna
2. Front speaker
3. Radio
4. Tape player
5. Rear speaker



## ANTENNA TRIMMER


The antenna trimmer is essential for matching the antenna with the radio in order to obtain the maximum sensitivity of the radio. It must be adjusted with the antenna actually mounted on the vehicle. If the trimmer is not adjusted properly, the radio suffers from not only low sensitivity but also noises, such as external noise and noise from passing vehicles. In the following cases, therefore, adjust it as described below:


- (1) When radio is installed.
- (2) If antenna is replaced.
- (3) If radio has low sensitivity.
- (4) If radio is noisy.

## Trimmer Adjustment

Make the following preparations for adjustment.

- (1) Turn the ignition key to the "ACC" position.
- (2) Extend the antenna all the way.
- (3) Tune accurately to a station near 1,400 kHz in order to receive a broadcast in as weak an electric field as can be barely received. If there is no station near 1,400 kHz, tune to any high-frequency station (above 1,000 kHz) available. If there are two or more stations near 1,400 kHz, choose the stronger one.
- (4) Set the volume control to the proper volume.
- (5) Set the tone control to high-pitched tone.





Be sure that preparations 1 through 5 have been correctly made.

Insert a screwdriver into the trimmer adjusting hole.

Turn the screwdriver clockwise or counterclockwise for maximum sensitivity (maximum broadcast wave sound).

If the optimum sensitivity point cannot be found, check for an antenna malfunction or a broken wire.

### NOISE SUPPRESSION

Noise interfering with radio reception may be roughly classified as follows:

(1) Noise produced by the vehicle itself

    Noise from the ignition circuit, alternator circuit, etc.

(2) Noise generated in the radio itself

    Thermal noise from transistors, IC, resistor, etc.

(3) Atmospheric noise

    Noise from other cars, neon signs, etc.

The radio has devices to suppress noise of the radio itself and atmospheric noise, but it is difficult to eliminate them completely. Noise produced by the vehicle includes whining from the alternator system, and a strong, impulsive, fast popping noise from the ignition system.

Before performing any checking or adjustments, first confirm the following points.

- Adjust the antenna trimmer completely.
- Set the pushbuttons (tuning) properly.
- Extend the antenna all the way.

#### Prevention of Ignition Circuit Noise

A resistance-equipped cable is used for the high-tension cable in order to prevent noise; however, if any noise from the ignition circuit does occur, check the tightness and ground connection of the positive (+) terminal of the noise filter, and, if necessary, check the noise filter.

#### Caution

Be careful not to connect the noise filter to the high-tension cable; doing so could damage the noise filter.

#### Prevention of Other Circuit Noise

For other noises, take necessary corrective actions in accordance with the following items and the NOISE SUPPRESSION CHART.

Polish the grounding cable terminal, and connect it properly.






Polish the pillar antenna ground terminal, and connect it properly.

Ground electric parts completely.

Keep the antenna cable and speaker lead wire away from other electric wiring.



## NOISE SUPPRESSION CHART

| Symptom  | Noise source                 | Remedy  |
|--|------------------------------|---|
| Unusual noise related to engine speed.                         | Engine                       | <p>Securely ground the engine, frame and/or body and engine hood.</p>   |
|  |                              | 16E710  |
| “Clatter” noise related to the flashing of turn signal lights. | Turn signals                 | <p>Connect a <math>0.5 \mu\text{F}</math> noise-suppression capacitor to the B-terminal of the flasher unit.</p>    |
|  |                              | 16E712  |
| Abnormal noise when the horn is operated.                      | Horn                         | <p>1. Connect a <math>0.5 \mu\text{F}</math> noise-suppression capacitor to the + B-terminal of the horn.<br/> 2. For an FM radio, connect an LC filter to the horn terminals.</p>  |
|  |                              | 16E713  |
| Noise when the windshield washer operates.                     | Washer motor                 | <p>Connect an LC filter between the terminal of the washer motor and the power source wire.</p>   |
|  |                              | 16F671  |
| Unusual noise when the engine is started.                      | Water temperature gauge unit | <p>Connect a <math>0.1 \mu\text{F}</math> noise-suppression capacitor to the terminal of the water temperature gauge unit.</p>    |
|  |                              | 16F672  |


## RADIO AND TAPE PLAYER

### Removal

1. Remove the radio switch knobs, loosen the mounting nuts, and then detach the radio panel.
2. Remove the center console, loosen the mounting screws on the side of the radio, and then remove the radio. (16W518)
3. Disconnect the antenna lead wire, the speaker connector, and the power supply connector from the back of the radio.

### NOTE

The fuse box for the radio circuits is located on the back of the radio; therefore, the radio must be removed in order to replace a fuse.




16W518

## FRONT SPEAKER

### Removal

1. Remove the speaker mounting screws. (16W520)
2. Remove the speaker from inside of the instrument panel.
3. Disconnect the speaker wiring connector.




16W520

## REAR SPEAKER

### Removal

1. Remove the speaker mounting screws. (16W545)
2. Remove the speaker and disconnect the speaker wiring connector.




16W545

## ANTENNA

### Removal


1. Disconnect the antenna lead wire from the back of the radio.
2. Remove antenna mast. (16EA96)




16EA96




3. Remove splash shield mounting bolts and screws.
4. Detach splash shields from fender about a half of rearward.
5. Remove the antenna mounting nut. (16W709)



6. Remove the screw which mounts the antenna bracket to the body from inside the fender. (16S597)
7. Remove the antenna toward the bottom.







## COMPONENTS SERVICE-POWER WINDOW

### COMPONENTS


1. Sub switch
2. Main switch
3. Power window motor
4. Power window regulator assembly
5. Power window relay



16W764



18W671



16W759

### NOTE

For information regarding adjustments, removal, inspection, and installation, or installation procedures other than those contained in this section on the Power Window Regulator System, refer to GROUP 23.




## POWER WINDOW MOTOR

### Removal

1. Detach the regulator assembly. (Refer to GROUP 23.)
2. Disconnect the power window motor from the regulator assembly. (18Y415)

### Caution

When loosening the connecting screws of the regulator and the motor assembly, the compressed force of the regulator spring may cause the regulator arm to spring up.




18Y415

### Inspection

Connect the motor terminals directly to the battery and check that the motor operates smoothly.

Next, reverse the polarity and check that the motor operates smoothly in the reverse direction.



18Y151




## COMPONENTS SERVICE-POWER WINDOW

### POWER WINDOW SWITCH

#### Inspection

#### MAIN SWITCH

Check for continuity in accordance with the following connection table.




| Switch                       | Terminal   | L.H. side |   |   |   | R.H. side |   |   |   | LOCK |   |
|------------------------------|------------|-----------|---|---|---|-----------|---|---|---|------|---|
|                              |            | 1         | 4 | 3 | 6 | 2         | 4 | 7 | 6 | 4    | 5 |
| Power window switch (manual) | UP         | ○         | ○ | ○ | ○ | ○         | ○ | ○ | ○ |      |   |
|                              | OFF        | ○         |   | ○ |   | ○         |   | ○ |   | ○    | ○ |
|                              | DOWN       | ○         |   | ○ |   | ○         |   | ○ |   | ○    |   |
| Lock switch                  | ON (LOCK)  |           |   |   |   |           |   |   |   |      |   |
|                              | OFF (FREE) |           |   |   |   |           |   |   |   | ○    | ○ |

### SUB SWITCH

Check for continuity in accordance with the following connection table.

| Switch | Terminal | 2 | 1 | 5 | 4 | 3 |
|--------|----------|---|---|---|---|---|
|        |          | ○ | ○ |   |   |   |
| UP     |          |   |   | ○ | ○ |   |
| OFF    |          |   | ○ |   | ○ | ○ |
| DOWN   |          | ○ |   | ○ |   | ○ |





## POWER WINDOW RELAY

### Inspection


Check for continuity between the terminals with the power ON and OFF.

While power is OFF

- Between terminals 1 – 2 ..... no continuity
- Between terminals 3 – 4 ..... continuity

While power is ON

- Between terminals 1 – 2 ..... continuity




## 3-POINT ELR SEAT BELTS WITH TENSION RELIEFERS

### SEAT BELT SWITCH

#### Inspection

1. Pull back the floor mat and disconnect the seat belt switch connection from where it is at the attachment to the buckle stalk assembly.
2. Use an ohmmeter to check the YB wire and the B wire for breakage. (16W733)
3. If there is no continuity when the buckle is unlocked and continuity when it is locked, the seat belt switch can be assumed to be functioning properly.
4. If a microswitch is defective, the buckle stalk assembly containing the microswitch should be replaced. For replacement. (Refer to GROUP 23.)



### SOLENOID

#### Inspection

1. Lock the buckle and set the ignition key to "ON".
2. Pull the seat belt out slightly from the retractor and allow about 40 mm (1.5 in.) to be taken up.
3. Pull the seat belt out again and let go of it. If the retractor stops and there is slack in the seat belts, the solenoid can be assumed to be functioning properly.
4. If the results of the above test are not satisfactory, inspect the seat belt switch. If no problem can be found, replace the entire seat belt assembly in order to replace the seat belt solenoid.