

FUEL

		E13AA--
FUEL SYSTEM <6G72 ENGINE>	3	
GENERAL INFORMATION	3	
Multi Point Injection System Diagram	3	
SPECIFICATIONS	4	
General Specifications	4	
Service Specifications	5	
Sealant	5	
SPECIAL TOOLS	5	
TROUBLESHOOTING	7	
Explanation of Troubleshooting Procedures	7	
Explanation and Precaution Related to Harness Checking	8	
Engine Warning Lamp	9	
Self-diagnosis	10	
Read Out of Malfunction Code	11	
Check Chart Classified by Problem Symptoms	12	
Problem Symptoms Table (For Your Information)	13	
SERVICE ADJUSTMENT PROCEDURES	14	
Accelerator Cable Inspection and Adjustment	14	
Fuel Filter Replacement	14	
Fuel Gauge Unit Replacement	15	
2-way Valve Replacement	15	
Fuel Pump Operation Check	15	
How To Reduce The Fuel Line Internal Pressure	16	
Throttle Body (Throttle Valve Area) Cleaning	16	
		Fixed SAS Adjustment
		18
		Basic Idle Speed Adjustment
		18
		ON-VEHICLE INSPECTION OF MPI COMPONENTS
		20
		Component Location
		20
		Component Inspection Procedure
		22
		Power Supply and Ignition Switch-IG
		23
		Engine Control Unit Power Earth
		26
		Fuel Pump
		27
		Air Flow Sensor
		30
		Intake Air Temperature Sensor
		34
		Barometric Pressure Sensor
		36
		Engine Coolant Temperature Sensor
		38
		Throttle Position Sensor
		40
		Idle Position Switch
		42
		Top Dead Center Sensor
		44
		Crank Angle Sensor
		48
		Ignition Switch-ST (M/T only)
		50
		Ignition Switch-ST and Inhibitor Switch (A/T only)
		52
		Vehicle Speed Sensor
		54
		Air Conditioner Switch and Power Relay
		56
		Oxygen Sensor
		58
		Injectors
		61
		Idle Speed Control Servo (Stepper Motor)
		66
		Ignition Coil and Power Transistor
		71
		Purge Control Solenoid Valve
		75
		Fuel Pressure
		77

WARNING REGARDING SERVICING OF SUPPLEMENTAL RESTRAINT SYSTEM (SRS) EQUIPPED VEHICLES WARNING!

- (1) **Improper service or maintenance of any component of the SRS, or any SRS-related component, can lead to personal injury or death to service personnel (from inadvertent firing of the air bag) or to the driver (from rendering the SRS inoperative.)**
- (2) **Service or maintenance of any SRS component or SRS-related component must be performed only at an authorized MITSUBISHI dealer.**
- (3) **MITSUBISHI dealer personnel must thoroughly review this manual, and especially its GROUP 52B – Supplemental Restraint System (SRS) and GROUP 00 – Maintenance Service before beginning any service or maintenance of any component of the SRS or any SRS-related component.**

NOTE

The SRS includes the following components: SRS diagnosis unit, SRS warning light, air bag module, clock spring and interconnecting wiring. Other SRS-related components (that may have to be removed/installed in connection with SRS service or maintenance) are indicated in the table of contents by an asterisk (*).

FUEL SYSTEM <6G72 - 24VALVE ENGINE, 6G74 ENGINE>	79-1
GENERAL INFORMATION	79-1
Multi Point Injection System Diagram	79-1
SPECIFICATIONS	79-3
General Specifications	79-3
Service Specifications	79-4
Sealant	79-4
SPECIAL TOOLS	79-4
TROUBLESHOOTING	79-7
Explanation of Troubleshooting Procedures	79-7
Explanation and Precaution Related to Harness Checking	79-8
Engine Warning Lamp	79-9
Self-diagnosis	79-10
Read Out of Malfunction Code	79-17
Check Chart Classified by Problem Symptoms	79-19
Problem Symptoms Table (For Your Information)	79-20
SERVICE ADJUSTMENT PROCEDURES	79-21
Accelerator Cable Inspection and Adjustment	79-21
Fuel Filter Replacement	79-21
Fuel Gauge Unit Replacement	79-21
2-way Valve Replacement	79-21
Fuel Pump Operation Check	79-21
How To Reduce The Fuel Line Internal Pressure	79-21
Throttle Body (Throttle Valve Area) Cleaning	79-21
Idle Position Switch and Throttle Position Sensor Adjustment	79-22
Fixed SAS Adjustment	79-23
Basic Idle Speed Adjustment	79-24
ON-VEHICLE INSPECTION OF MPI COMPONENTS	79-26
Component Location	79-26
Component Inspection Procedure	79-33
Power Supply (Control Relay) and Ignition Switch-IG	79-34
Engine Control Unit Power Earth	79-37
Fuel Pump	79-38
Air Flow Sensor	79-41
Intake Air Temperature Sensor	79-46
Barometric Pressure Sensor	79-49
Engine Coolant Temperature Sensor	79-51
Throttle Position Sensor	79-54
Idle Position Switch	79-57
Cam Position Sensor	79-60
Crank Angle Sensor	79-64
Ignition Switch-ST [M/T only]	79-67
Ignition Switch-ST and Inhibitor Switch [A/T only]	79-68
Vehicle Speed Sensor	79-70
Power Steering Fluid Pressure Switch	79-72
Air Conditioner Switch and Power Relay	79-74
Detonation Sensor <DOHC>	79-76
Electrical Load Switch <DOHC>	79-78
Oxygen Sensor	79-80
Injectors	79-83
Idle Speed Control Servo (Stepper Motor Type)	79-88
Ignition Coil and Ignition Power Transistor <SOHC>	79-93
Ignition Coil and Ignition Power Transistor <DOHC>	79-99
Variable Induction Control Solenoid Valve <DOHC>	79-103
Purge Solenoid	79-105
EGR Control Solenoid Valve	79-107
Anti-skid Brake Signal	79-109
Fuel Pressure	79-109
Fuel Pressure Test <SOHC>	79-110
Fuel Pressure Test <DOHC>	79-113
FUEL SYSTEM <4G64 ENGINE>	80
GENERAL INFORMATION	80
Multi Point Injection System Diagram	80
SPECIFICATIONS	81
General Specifications	81
Service Specifications	82
Sealant	82
SPECIAL TOOLS	82
TROUBLESHOOTING	84
Explanation of Troubleshooting Procedures	84
Explanation and Precaution Related to Harness Checking	84
Engine Warning Lamp	84
Self-diagnosis	85
Read out of Malfunction Code	86
Check Chart Classified by Problem Symptoms	87
Problem Symptoms Table (For Your Information)	88
SERVICE ADJUSTMENT PROCEDURES	89
Accelerator Cable Inspection and Adjustment	89
Fuel Filter Replacement	89
Fuel Gauge unit Replacement	89
2-way Valve Replacement	89

Fuel Pump Operation Check	89	Fuel Injection Pump Inspection	145
How To Reduce The Fuel Line Internal Pressure	89	Injection Nozzle Inspection and Adjustment	146
Throttle Body (Throttle Valve Area) Cleaning	90	Acceleration Lever Control Check During Anti-Skid Brake Operation	148
Idle Position Switch and Throttle Position Sensor Adjustment	91	FUEL SYSTEM <4M40 ENGINE>	150-1
Fixed SAS Adjustment	92	SPECIFICATIONS	150-1
Basic Idle Speed Adjustment	93	General Specifications	150-1
ON-VEHICLE INSPECTION OF MPI COMPONENTS	95	Service Specifications	150-1
Component Location	95	SPECIAL TOOL	150-1
Component Inspection Procedure	97	SERVICE ADJUSTMENT PROCEDURES ..	150-2
Power Supply	98	Fuel Injection Timing Inspection and Adjustment	150-2
Engine Control Unit Power Earth	100	Engine Idling Speed Inspection and Adjustment	150-2
Fuel Pump	101	Accelerator Cable Inspection and Adjustment	150-2
Air Flow Sensor	104	Fuel Filter Replacement	150-2
Intake Air Temperature Sensor	108	Evacuation of Water from Fuel Filter	150-2
Barometric Pressure Sensor	110	Evacuation of Air from Fuel Line	150-2
Engine Coolant Temperature Sensor	111	Fuel Gauge Unit Replacement	150-2
Throttle Position Sensor	112	2-way Valve Replacement	150-2
Idle Position Switch	114	Fuel Injection Pump Inspection	150-2
Servo Valve Position Sensor	116	Accelerator Lever Control Check During Anti-Skid Brake (ABS) Operation	150-2
Top Dead Center Sensor	118	Injection Nozzle Inspection and Adjustment	150-3
Crank Angle Sensor	121	FUEL PUMP <4G64, 6G72, 6G74> ..	151
Ignition Switch-ST	123	INJECTION NOZZLE <4D56, 4M40> ..	152
Vehicle Speed Sensor	123	INJECTION PUMP <4D56> ..	154
Air Conditioner Switch and Power Relay	123	INJECTION PUMP <4M40> ..	155-1
Oxygen Sensor	124	FUEL TANK	156
Injectors	126	FUEL LINE AND VAPOR LINE <4G64, 6G72, 6G74> ..	160
Idle Speed Control Servo (DC Motor)	131	FUEL LINE <4D56, 4M40> ..	163
Ignition Coil and Power Transistor	133	ACCELERATOR CABLE AND PEDAL ..	165
Purge Control Solenoid Valve	137	AUTO-CRUISE CONTROL SYSTEM ..	168
Fuel Pressure	138	SPECIFICATIONS	168
FUEL SYSTEM <4D56 ENGINE> ..	142	General Specifications	168
SPECIFICATIONS	142	Service Specifications	168
General Specifications	142	SPECIAL TOOLS	168
Service Specifications	142	TROUBLESHOOTING	169
SPECIAL TOOLS	142	Troubleshooting Quick-reference Chart	169
SERVICE ADJUSTMENT PROCEDURES ..	143	Self-diagnosis Checking	185
Fuel Injection Timing Inspection and Adjustment	143	Input Checking	186
Engine Idling Speed Inspection and Adjustment	143	SERVICE ADJUSTMENT PROCEDURES ..	188
Accelerator Cable Inspection and Adjustment	143	AUTO-CRUISE CONTROL* ..	195
Fuel Filter Replacement	143		
Evacuation of Water from Fuel Filter	144		
Evacuation of Air from Fuel Line	144		
Fuel Gauge Unit Replacement	144		
2-way Valve Replacement	145		

NOTES

FUEL SYSTEM <6G72 Engine>

GENERAL INFORMATION


MULTI POINT INJECTION SYSTEM DIAGRAM

E13BBAG

- *1 Oxygen sensor
- *2 Air-flow sensor
- *3 Intake air temperature sensor
- *4 Engine coolant temperature sensor
- *5 Throttle position sensor
- *6 Idle position switch
- *7 Top dead center sensor
- *8 Crank angle sensor
- *9 Barometric pressure sensor

- Ignition switch-ST
- Ignition switch-IG1
- Power supply
- Vehicle-speed sensor
- Air conditioner switch
- Inhibitor switch <AT>

- *1 Injector
- *2 Idle speed control servo
- *3 Purge control solenoid valve
- Fuel pump control (control relay)
- Air conditioner power relay
- Ignition timing control
- Self-diagnosis circuit
- Engine warning lamp



7FU1163

Vacuum hose colour
 R: Red
 B: Black
 L: Light Blue

SPECIFICATIONS**GENERAL SPECIFICATIONS**

E13CA-A

Items	Specifications	
Fuel		
Tank capacity	dm ³ (U.S.gal., Imp.gal.)	
Standard Wheelbase		75 (19.8, 16.5)
Long Wheelbase		92 (24.3, 20.2)
Fuel pump		
Type		Electrical, in-tank type
Driven by		Electric motor
Throttle body		
Throttle bore	mm (in.)	55 (2.165)
Throttle position sensor		Variable resistor type
Idle speed control servo		Stepper motor type
Idle position switch		Stepper motor type by-pass air control system with the Fast Idle Air Valve
		Rotary contact type
Engine control unit		
Identification model No.		E2T37472
Sensors		
Air flow sensor		Karman vortex type
Barometric pressure sensor		Semiconductor type
Intake air temperature sensor		Thermistor type
Engine coolant temperature sensor		Thermistor type
Oxygen sensor		Zirconia type
Vehicle-speed sensor		Reed switch type
Top dead centre sensor		Photo interruptor type
Crank angle sensor		Photo interruptor type
Actuators		
Control relay type		Contact switch type
Injector type and number		Electromagnetic, 6
Purge control solenoid valve		ON/OFF type solenoid valve
Fuel pressure regulator		
Regulated pressure	kPa (kg/cm ² , psi)	335 (3.35, 47.6)

SERVICE SPECIFICATIONS

E13CB-A

Items	Specifications
Standard value	
Accelerator cable play	mm (in.)
Basic ignition timing	
Curb idle speed	r/min.
Idle speed when air conditioner ON	r/min.
Basic idle speed	r/min.
Throttle position sensor output voltage	V
Throttle position sensor resistance	kΩ
Idle speed control servo (stepper motor) coil resistance [at 20°C (68°F)]	Ω
Intake air temperature sensor resistance [at 20°C (68°F)]	kΩ
Engine coolant temperature sensor resistance 20°C (68°F)	kΩ
80°C (176°F)	
Fuel pressure (at curb idle)	kPa (kg/cm ² , psi)
Vacuum hose disconnection	330–350 (3.3–3.5, 47–50)
Vacuum hose connection	Approx. 270 (2.7, 38)
Injector coil resistance [at 20°C (68°F)]	Ω
	13–16


SEALANT









E13CE-A

Items	Specified sealant	Quantity
Engine coolant temperature sensor threaded portion	3M Nut Locking Part No. 4171 or equivalent	As required

SPECIAL TOOLS


E13DA-A

Tool	Number	Name	Use
	MB991341	Multi-use tester assembly	<ul style="list-style-type: none"> • Reading diagnosis code • MPI system inspection
	MB991419	ROM pack (for multi-use tester)	<ul style="list-style-type: none"> • Reading diagnosis code • MPI system inspection
	MB991348	Test harness set	<ul style="list-style-type: none"> • Adjustment of throttle position sensor • Inspection with oscilloscope

Tool	Number	Name	Use
	MD998706	Injector test set	<ul style="list-style-type: none"> • Checking injection condition of injector
	MD998740	Injector test adaptor	
	MD998746	Clip	
	MD998464	Test harness (4 pin, square)	<ul style="list-style-type: none"> • Oxygen sensor inspection
	MD998463	Test harness (6 pin, square)	<ul style="list-style-type: none"> • Idle speed control servo inspection • Inspection with oscilloscope
	MD998753	Extension hose	<ul style="list-style-type: none"> • Measurement of fuel pressure
	MD998700	Hose adapter	
For red harness (for DLI)  For white harness (for LC)  	MB991223	Inspection harness set connector <ul style="list-style-type: none"> • Pin contact pressure inspection harness • Marketing tester connection probe (for general connectors) 	Measurement of terminal voltages

TROUBLESHOOTING




E13EFAJ



EXPLANATION OF TROUBLESHOOTING PROCEDURES

The effective troubleshooting procedures for troubles of the MPI system are explained in the following.

1. Checking trouble symptom
 - Reproduce the problem symptom and check the contents of the trouble and the conditions under which the symptom occurs (engine condition, operating state, etc.).
2. Reading self-diagnosis code
 - Read the self-diagnosis code and when a fault code is output, correct the fault referring to DIAGNOSIS CHART.
3. Estimating causes of trouble and setting check item
 - Referring to CHECK CHART CLASSIFIED BY PROBLEM SYMPTOMS, determine the check items and procedures to be followed.
4. Checking engine control unit input and output signals
 - Using a multi-use tester or analyzer, check the input and output signals of the engine control unit.
 - If the input and output signals are normal, the sensor input/actuator control is judged as normal. Then, check the input and output signals of the next check item.
5. Checking harnesses of MPI system components
 - If the input and output signals of the engine control unit are not normal, check the body harnesses of the MPI system components and repair as necessary.
 - After repair, check the input and output signals of the engine control unit again. If they are normal this time, check the input and output signals of the next check item.
6. Checking individual MPI system components
 - If the body harnesses are normal but the input and output signals of the engine control unit are abnormal, check the MPI system components individually and repair or replace as necessary.
 - After repair or replacement, check the input and output signals of the engine control unit again. If they are normal this time, check the input and output signals of the next check item.
7. Re-examining causes of trouble and checking and repairing
 - If the harness check and individual component check have resulted normal but the input and output signals of the engine control unit are abnormal, re-examine the causes of trouble referring to the troubleshooting hints. Then, check and repair including other groups.
8. Confirming completion of repair and preventing reoccurrence
 - Try to reproduce the problem symptom to make sure that the symptom will not occur again.
 - Remove the true cause of the trouble to prevent its reoccurrence.




EXPLANATION AND PRECAUTION RELATED TO HARNESS CHECKING


- Connector symbols are described as seen from the terminal end for the connector.
- The abbreviation "SV" used for the normal judgment value when checking the voltage is the abbreviation for system voltage.

- Be sure to use the special tool (test harness) when, for a waterproof connector, checking while the circuit is conductive. If probe is inserted from the harness side, the waterproof capability will be lowered, thereby causing/corrosion, so never do so.
- When a connector is disconnected in order to check terminal voltage, etc., never insert a probe if the terminal to be checked is a female pin, because the forceful insertion of a probe will cause improper or incomplete contact.
- Also, if there is no test harness that conforms to the connector, use the test harness set (MB991348) which can be directly connected between the terminals.


- When disconnecting the connector and inspecting the terminal voltage, etc., if the inspection terminal is a female pin, the special tool (inspection harness set: MB991223) should be used instead of inserting a probe.

- When checking for damaged or disconnected wiring of a harness (open circuit) and if both ends of the harness are unconnected, use a jumper wire to earth one end of the harness, and then check for continuity between the other end and earth. By doing this, you can check for damaged or disconnected wiring, and, if there is no continuity, the harness should be repaired.





- When checking for a harness short-circuit (short-circuit to earth), open one end of the harness and then check for continuity between the other end and earth. If there is continuity, the harness is short-circuited to earth and should be repaired.




- If the voltage (power-supply voltage) supplied to a sensor is not normal, repair the harness. If the voltage to the sensor is still not normal after the harness has been repaired, replace the engine control unit and check again.

ENGINE WARNING LAMP (CHECK ENGINE LAMP)

Among the self-diagnosis items, a engine warning lamp comes on to notify the driver of the emission control items when an irregularity is detected. However, when an irregular signal returns to normal and the engine control unit judges that it has returned to normal, the engine warning lamp goes out. Moreover, when the ignition switch is turned off, the lamp goes out. Even if the ignition switch is turned on again, the lamp does not come on until the irregularity is detected. Here, immediately after the ignition switch is turn on, the engine warning lamp is lit for 5 seconds to indicated that the engine warning lamp operates normally.

Item indicated by the lightening engine warning lamp



Engine control unit	Crank angle sensor
Oxygen sensor	Top dead centre sensor
Air flow sensor	Barometric pressure sensor
Intake air temperature sensor	Ignition timing adjustment signal
Throttle position sensor	Injector
Engine coolant temperature sensor	

Caution

Engine warning lamp will come on when the line of terminal for ignition timing adjustment is short-circuited. Therefore, the lamp will come on even when the terminal for ignition timing adjustment is earthed at the time of adjusting ignition timing. In this case, however, it is not abnormal.

ENGINE WARNING LAMP INSPECTION

- (1) Check to be sure, when the ignition switch is set to the "ON" position, that the lamp illuminates for about five seconds and then switches OFF.
- (2) If the lamp does not illuminate, check for damage or disconnection of the harness, or for a blown fuse or a failed light bulb.

SELF-DIAGNOSIS

The engine control unit monitors the input/output signals (some signals at all times and the others under specified conditions) of the engine control unit. When it is noticed that an irregularity has continued for a specified time or longer from when the irregular signal is initially monitored, passing a certain number, the engine control unit judges that an irregularity has occurred, memorizes the malfunction code, and outputs the signal to the self-diagnosis output terminals. There are 13 diagnosis items, including the normal state, and the diagnosis results can be read out with a multi-use tester. Moreover, since memorization of the malfunction codes is backed up directly by the battery, the diagnosis results are memorized even if the ignition key is turned off. The malfunction codes will, however, be erased when the battery terminal or the engine control unit connector is disconnected.

The malfunction codes are also erased by setting the ignition switch to the "ON" position and then sending the malfunction-code-erase signal from the multi-use tester to the engine control unit.

Caution

If the sensor connector is disconnected while the ignition switch is ON, the malfunction code is memorized. In this instance, either send the malfunction-code-erase signal from the multi-use tester to the engine control unit, the diagnosis memory will be erased.

The 13 diagnosis items are provided as follows, and if plural items are activated, they are all indicated sequentially from the smallest code number.

Caution

Ignition timing adjustment signal malfunction code is output when the ignition timing adjustment terminal line is short-circuited to the earth. Therefore, the malfunction code is output when the ignition timing adjustment terminal is earthed, however, this is not a malfunction.

DIAGNOSIS CHART

Output preference order	Diagnosis item	Diagnosis code		Check item (Remedy)
		No.	Memory	
1	Engine control unit	—	—	(Replace engine control unit)
2	Oxygen sensor	11	Retained	<ul style="list-style-type: none"> • Harness and connector • Oxygen sensor • Fuel pressure • Injectors (Replace if defective.) • Intake air leaks
3	Air flow sensor	12	Retained	<ul style="list-style-type: none"> • Harness and connector (If harness and connector are normal, replace air flow sensor assembly.)
4	Intake air temperature sensor	13	Retained	<ul style="list-style-type: none"> • Harness and connector • Intake air temperature sensor
5	Throttle position sensor	14	Retained	<ul style="list-style-type: none"> • Harness and connector • Throttle position sensor • Idle position switch


Output preference order	Diagnosis item	Diagnosis code		Check item (Remedy)
		No.	Memory	
6	Engine coolant temperature sensor	21	Retained	<ul style="list-style-type: none"> • Harness and connector • Engine coolant temperature sensor
7	Crank angle sensor	22	Retained	<ul style="list-style-type: none"> • Harness and connector (If harness and connector are normal, replace distributor assembly.)
8	Top dead centre sensor	23	Retained	<ul style="list-style-type: none"> • Harness and connector (If harness and connector are normal, replace distributor assembly.)
9	Vehicle speed sensor (reed switch)	24	Retained	<ul style="list-style-type: none"> • Harness and connector • Vehicle speed sensor (reed switch)
10	Barometric pressure sensor	25	Retained	<ul style="list-style-type: none"> • Harness and connector (If harness and connector are normal, replace barometric pressure sensor assembly.)
11	Ignition timing adjustment signal	36	—	<ul style="list-style-type: none"> • Harness and connector
12	Injector	41	Retained	<ul style="list-style-type: none"> • Harness and connector • Injector coil resistance
13	Normal state	—	—	—

NOTE

Replace the engine control unit if a malfunction code is output although the inspection reveals that there is no problem with the check items.

READ OUT OF MALFUNCTION CODE PRECAUTIONS FOR OPERATION

- (1) When battery voltage is low; no detection of failure is possible. Be sure to check the battery for voltage and other conditions before starting the test.
- (2) Diagnosis item is erased if the battery or the engine control unit connector is disconnected. Do not disconnect the battery before the diagnosis result is completely read.



READING STEPS - USING THE MULTI-USE TESTER (MUT)

- (1) Read and make a note of the self-diagnosis output.
- (2) Refer to the diagnosis chart to remedy the problem.
- (3) After turning the ignition switch once to OFF, turn it back to ON.
- (4) Erase the problem codes.
- (5) Recheck that everything is normal.



CHECK CHART CLASSIFIED BY PROBLEM SYMPTOMS

Problem symptoms	Starting	Idling stability			Driving						Stopping	Reference page	
	Will not start	Starting problem	Idling instability (Rough idling)	Incorrect idling speed	Improper idling continuity	Hesitation, sag	Poor acceleration	Stumble	Shock	Surge	Knocking	Run-on (Dieseling)	
Check Items													
Power Supply and Ignition Switch-IG	①①												P. 13-23
Engine Control Unit Power Earth	②②												P. 13-26
Fuel Pump	③③	①①		①①	①①	①①							P. 13-27
Air Flow Sensor				⑧⑧		⑤⑤			③①				P. 13-30
Intake Air Temperature Sensor			⑤		④④	④④			①①				P. 13-34
Barometric Pressure Sensor			⑦		⑦⑦	⑥⑥			②②				P. 13-36
Engine Coolant Temperature Sensor		③⑥⑤	①①	⑤⑤	⑥⑥	⑤⑤	④④	③③					P. 13-38
Throttle Position Sensor				⑤⑤		③③	④④						P. 13-40
Idle Position Switch			③③	②②	④④								P. 13-42
Top Dead Center Sensor	⑤⑤	⑥⑦		⑧⑦				②②					P. 13-44
Crank Angle Sensor	⑥⑥	⑦⑧		⑨⑧				③③					P. 13-48
Ignition Switch-ST <M/T>	④④	③④											P. 13-50
Ignition Switch-ST and Inhibitor Switch <A/T>	④④	③④		④									P. 13-52
Vehicle Speed Sensor				⑥									P. 13-54
Air Conditioner Switch and Power Relay			③										P. 13-56
Oxygen Sensor			⑨										P. 13-58
Injectors	⑧⑧	②②	②②		③③	②②	②②	①①	①①		①		P. 13-61
Idle Speed Control Servo (Stepper Motor)		④⑤	①①	⑥③	②②								P. 13-66
Ignition Coil and Power Transistor	⑦⑦			⑩⑨		⑦⑦		①①					P. 13-71
Purge Control Solenoid Valve			⑧										P. 13-75
Fuel Pressure		⑥⑥	④④		⑦⑥	③③	③③	②②	②②				P. 13-77

○: Warm engine (figures inside the ○ indicate the checking sequence.)

□: Cold engine (figures inside the □ indicate the checking sequence.)

PROBLEM SYMPTOMS TABLE (FOR YOUR INFORMATION)

Item	Symptom	
Starting	Won't start (no initial combustion)	The starter is used to crank the engine, but there is no combustion within the cylinders, and the engine won't start.
	Starting problem (initial combustion, then stall) (Starting takes a long time.)	There is combustion within the cylinders, but then the engine soon stalls. Engine won't start quickly.
	Idling instability (Rough idling)	Engine speed doesn't remain constant; changes during idling. Usually, a judgement can be based upon the movement of the tachometer pointer, and the vibration transmitted to the steering wheel, shift lever, body, etc. This is called rough idling.
Idling stability	Incorrect idling speed	The engine doesn't idle at the usual correct speed.
	Improper idling continuity Die out Pass out	This non-continuity of idling includes the following elements. (1) Die out The engine stalls when the foot is taken from the accelerator pedal, regardless of whether the vehicle is moving or not. (2) Pass out The engine stalls when the accelerator pedal is depressed or while it is being used.
	Hesitation Sag	"Hesitation" is the delay in response of the vehicle speed (engine r/min) that occurs when the accelerator is depressed in order to accelerate from the speed at which the vehicle is now traveling, or a temporary drop in vehicle speed (engine r/min) during such acceleration. Serious hesitation is called "sag".
Driving		
	Poor acceleration	Poor acceleration is inability to obtain an acceleration corresponding to the degree of throttle opening, even though acceleration is smooth, or the inability to reach maximum speed.
	Stumble	Engine r/min response is delayed when the accelerator pedal is initially depressed for acceleration from the stopped condition.
		
	Shock	The feeling of a comparatively large impact or vibration when the engine is accelerated or decelerated.
Stopping	Surge	This is repeated surging ahead during constant speed travel or during variable speed travel.
	Knocking	A sharp sound like a hammer striking the cylinder walls during driving and which adversely affects driving.
	Run-on (Dieseling)	The engine continues to run even after the switch is turned OFF. This is called dieseling.

SERVICE ADJUSTMENT PROCEDURES


ACCELERATOR CABLE INSPECTION AND

ADJUSTMENT

<VEHICLES WITHOUT AUTO-CRUISE CONTROL SYSTEM>


E13FCAZ1

For models equipped with the auto-cruise control system, refer to P. 13-188.



- (1) Check that there are no sharp bends in the accelerator cable.
- (2) Check that the throttle link is touching the fixed SAS stopper.
- (3) Move the plate so that the inner cable play is at the standard value, and tighten the adjusting bolt.

Standard value: 1–2 mm (0.04–0.08 in.)



FUEL FILTER REPLACEMENT


E13FZAL


- (1) Hold the fuel filter with a spanner, and remove the eye bolt.

Caution

The fuel line has some residual pressure, so cover it with a rag.

- (2) Remove the fuel filter.
- (3) Use a new gasket when installing the fuel filter, and tighten the eye bolt of the high pressure fuel hose to the specified torque.
- (4) After installing, check that there are no fuel leaks.
 - ① Apply battery voltage to the fuel pump drive terminal to operate the fuel pump. (Refer to P.13-15)
 - ② Check that there are no leaks in the fuel line when the fuel is under pressure.







FUEL GAUGE UNIT REPLACEMENT

E13FDAC1

- (1) Take out the carpet in the cargo compartment and remove the floor cover.



- (2) Disconnect the connector from the fuel gauge unit, and remove the fuel gauge unit.
- (3) Install the fuel gauge unit so that the packing stoppers (2 places) match the hole in the fuel gauge unit.
- (4) Install the floor cover packing and the floor cover.



2-WAY VALVE REPLACEMENT


E13FFAC1

- (1) Remove the filler neck protector inside the left rear fender.
- (2) Replace the 2-way valve.

Caution

Be careful not to mistake the direction of the 2-way valve.

- (3) Install the filler neck protector.



FUEL PUMP OPERATION CHECK


E13FGCE




- (1) Use the multi-use tester to force-drive the fuel pump, and check the operation of the fuel pump.
(For inspection using the multi-use tester, refer to P.13-28.)
- (2) If the fuel pump does not operate, inspect by the following procedure, and if the results are normal, then inspect the drive circuit.
 - ① Turn the ignition switch to OFF.
 - ② When the fuel pump drive connector is connected directly to the battery, check if the sound of the fuel pump operation can be heard.

NOTE

As the fuel pump is an in-tank type, the fuel pump sound is hard to hear, so remove the fuel tank cap and check from the tank inlet.

- (3) Check if the fuel pressure can be felt by pinching the high pressure fuel hose with fingertips.





HOW TO REDUCE THE FUEL LINE INTERNAL PRESSURE

E13HABG

When removing the fuel pipe and hose, etc., fuel under high pressure will be inside the fuel line, so carry out the following procedure to release the pressure to prevent the fuel from spraying out.

- (1) Take out the carpet in the cargo compartment and remove the floor cover.
- (2) Disconnect the fuel pump unit connector.
- (3) After starting the engine and letting it run until it stops, turn the ignition switch to OFF.
- (4) Connect the fuel pump unit connector.
- (5) Install the floor cover packing and the floor cover.

THROTTLE BODY (THROTTLE VALVE AREA) CLEANING

E13HAJB1

- (1) Start the engine and warm it up until the temperature of the engine coolant reaches 80°C (176°F) or higher; then stop the engine.
- (2) Disconnect the air intake hose at the throttle body side.
- (3) Plug the bypass intake port inlet in the throttle body.

Caution

Never let cleaning liquid get into the bypass intake.

- (4) Spray cleaning liquid (from the intake port of the throttle body) onto the valve, and then leave as is for about five minutes.
- (5) Start the engine and race it a few times; then let it run at idle speed for about one minute.


NOTE

The engine idling speed is unstable (or the engine stalls), let the engine run with the throttle valve slightly open.

- (6) If deposits are not removed from the throttle valve, repeat steps (4) and (5).
- (7) Remove the plug from the bypass intake port inlet in the throttle body.
- (8) Connect the air intake hose.
- (9) Using the multi-use tester, erase the self-diagnosis code.
- (10) Adjust the basic idle speed. (Refer to P. 13-18.)

NOTE


If hunting of the idling engine occurs after adjusting the basic idling speed, remove the battery (–) cable from the battery terminal for more than 10 seconds, and then idle the engine again.




IDLE POSITION SWITCH AND THROTTLE POSITION SENSOR ADJUSTMENT

E13HAKD1


(1) Disconnect the connector of the throttle-position sensor.



(2) Using jumper wires, connect an ohmmeter across terminal ② (idle position switch) and terminal ④ (sensor earth) of the throttle position sensor.




(3) Insert a 0.65 mm (0.0256 in.) thick feeler gauge between the fixed SAS and throttle lever.



(4) Loosen the throttle position sensor mounting bolts and turn the throttle position sensor body fully clockwise.

(5) In this condition, check that there is continuity across terminals ① and ②.




(6) Slowly turn the throttle position sensor counterclockwise until you find a point at which there is no continuity across terminals ① and ②. Then, tighten the throttle position sensor mounting bolt securely.

(7) Connect the throttle position sensor connector.

- (8) Connect the multi use tester (MUT) to the diagnosis connector.
- (9) Turn the ignition switch ON (but do not start the engine).
- (10) Using the MUT, select item No. 14 and read the throttle position sensor output voltage.

Standard value: 400–1,000 mV

- (11) If the voltage is out of specification, check the throttle position sensor and associated harnesses.
- (12) Remove the feeler gauge.
- (13) Turn the ignition switch OFF.



FIXED SAS ADJUSTMENT

E13HAMC1

NOTE

1. The fixed SAS has been factory-adjusted. Never attempt to move it.
2. Should it be out of proper adjustment, adjust by following the procedure given below.

- (1) Sufficiently slacken the accelerator cable.
- (2) Loosen the lock nut on the fixed SAS.
- (3) Sufficiently loosen the fixed SAS by turning it counterclockwise to fully close the throttle valve.
- (4) Tighten the fixed SAS slowly to find a point at which it contacts the throttle lever (where the throttle valve starts opening). From that point, tighten the fixed SAS further $1\frac{1}{4}$ turns.
- (5) Holding the fixed SAS to prevent it from turning, tighten the lock nut securely.
- (6) Adjust the accelerator cable tension. (Refer to P. 13-14.).
- (7) Adjust the basic idle speed.
- (8) Adjust the idle position switch and throttle position sensor (TPS). (Refer to P. 13-17.).


BASIC IDLE SPEED ADJUSTMENT

E13HAND

NOTE

1. The basic idle speed has been factory-adjusted with the speed adjusting screw (SAS) and does not normally require adjustment.
2. If the adjustment is required, first check that the ignition plug, injector, ISC servo, and compression pressure are normal.


- (1) Before starting the inspection and adjustment procedures, set the vehicle in the following conditions:
 - Engine coolant temperature: 80 to 95°C (176 to 205°F)
 - Lights, electric cooling fan, accessories: OFF
 - Transmission: Neutral (P for vehicles with an automatic transmission)
 - Steering wheel: Straightforward position



(2) Connect the multi use tester (MUT) to the diagnosis connector.

NOTE

When the multi-use tester is connected, the diagnosis control terminal will be earthed.



(3) Remove the waterproof female connector from the ignition timing adjusting connector (brown).

(4) Using a jumper wire, earth the ignition timing adjusting terminal.

(5) Start the engine and run at idle.

(6) Check the basic idle speed. Using the MUT, select item No. 22 and read the idle speed.

Standard value: $700 \pm 50 \text{ r/min}$.


NOTE

1. The engine speed may be low by 20 to 100 r/min. while the vehicle is new [distance driven approx. 500 km (300 miles) or less], but no adjustment is necessary.
2. If the engine stalls or speed is low despite a sufficient distance driven [approx. 500 km (300 miles) or more], it is probably due to deposits on the throttle valve. In this case, clean the throttle valve. (Refer to P. 13-16.).

(7) If the basic idle speed is out of specification, adjust by turning the speed adjusting screw (SAS).

NOTE

If the idle speed is higher than the standard value even with SAS fully tightened, check to see if there is evidence of the fixed SAS being moved. If the fixed SAS seems to have been moved, adjust it. If it does not seem to have been moved, there may be a leak caused by deteriorated fast idle air valve (FIAV). In such a case, replace the throttle body.



(8) Turn the ignition switch OFF.


(9) Remove the jumper wire from the ignition timing adjusting terminal and replace the connector back again.

(10) Start the engine again and run at idle for 10 minutes to make sure that the engine runs at proper idle speed.


ON-VEHICLE INSPECTION OF MPI COMPONENTS

E13QAAC

COMPONENT LOCATION



















16E0128



7FU1167

Name	Symbol	Name	Symbol
Air conditioner relay	A	Idle speed control servo	C
Air conditioner switch	M	Ignition coil (power transistor)	F
Air flow sensor (incorporating intake air temperature sensor and barometric pressure sensor)	B	Ignition timing adjustment terminal	Q
Crank angle sensor and top dead center sensor	G	Injector	J
Engine control relay	L	Oxygen sensor	K
Engine control unit	O	Purge control solenoid valve	I
Engine coolant temperature sensor	E	Self-diagnosis connector	P
Fuel pump check terminal	H	Throttle position sensor (with idle position switch)	D
		Vehicle-speed sensor (reed switch)	N







COMPONENT INSPECTION PROCEDURE USING MULTI-USE TESTER (MUT)

- (1) Check by the service data and actuator test function. If any abnormality is found, check the body harness, components, etc. and repair as necessary.
- (2) After repair, check again with the MUT to make sure that the input and output signals are now normal.
- (3) Erase the self-diagnosis trouble code in memory.
- (4) Disconnect the MUT.
- (5) Start the engine and perform running test, etc. to make sure that the troubles have been corrected.

POWER SUPPLY AND IGNITION SWITCH-IG



OPERATION





- While the ignition switch is ON, battery power supply is supplied to the engine control unit, injectors, air-flow sensor, etc.
- When the ignition switch is switched ON, battery voltage is supplied from the ignition switch to the engine control unit. When battery voltage is supplied to the engine control unit, the power transistor is switched ON and current flows to the engine control relay coil.
- As a result, the engine control relay switch is switched ON, and power is supplied, by way of the engine control relay switch, from the battery to the engine control unit.


INSPECTION

Using Multi-use tester (MUT)

Function	Item No.	Data display	Check conditions	Standard value	V
Data reading	16	Engine control unit power-supply voltage	Ignition switch: ON	SV	


HARNESS INSPECTION





ENGINE CONTROL RELAY INSPECTION

(1) Disconnect the control relay.



(2) Using jumper wires, connect terminal ⑩ of the control relay to the $+$ terminal of the battery and connect terminal ⑧ of the relay to the $-$ terminal of the battery.

CAUTION

• When connecting the jumper wires, be careful not to connect them to the wrong terminals, since this could damage the relay.

(3) Measure the voltage at terminal ④ and terminal ⑤ of the control relay while coming off and on the connection of the jumper wire to the battery $-$ terminal.

Jumper wire	Terminal ④ voltage	Terminal ⑤ voltage
Connected	SV	SV
Disconnected	0V	0V

(4) Using jumper wires, connect terminal ⑨ of the control relay to the $+$ terminal of the battery and connect terminal ⑥ of the relay to the $-$ terminal of the battery.

(5) Check the continuity between terminal ② and terminal ③ of the control relay while coming off and on the connection of the jumper wire to the battery $-$ terminal.


Jumper Wire	Continuity between Terminals ② and ③
Connected	Continuity
Disconnected	No Continuity

(6) Using jumper wires, connect terminal ③ of the control relay to the $+$ terminal of the battery and connect terminal ⑦ of the relay to the $-$ terminal of the battery.


(7) Measure the voltage at terminal ② of the control relay while coming off and on the connection of the jumper wire to the battery $-$ terminal.

Jumper Wire	Terminal ② Voltage
Connected	SV
Disconnected	0V


(8) Replace the control relay if faulty.



ENGINE CONTROL UNIT POWER EARTH




Engine control unit



01A0191

Engine control unit connector



01L0838

OPERATION

Earthing of the engine control unit




TROUBLESHOOTING HINTS

If there is incorrect or incomplete contact of the engine control unit's earth line, the engine control unit will not function correctly.

HARNESS INSPECTION

<p>1</p> <p>01P0150</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Engine control unit connector: Disconnected 	
		<p>Repair the harness. (101—Earth, 106—Earth)</p>

FUEL PUMP



OPERATION

- Activates the fuel pump during engine cranking and while the engine is running.
- When the ignition switch is set to the START position, current flows, by way of the control relay coil, from the ignition switch to earth. As a result, the control relay switch is switched ON, and the power for activation of the fuel pump is supplied, by way of the control relay switch, from the battery to the fuel pump.





- While the engine is running, the engine control unit switches ON the power transistor, after which current flows to the control relay coil, and the power for activation of the fuel pump is supplied to the fuel pump.
- When the control relay switch is switched ON, battery voltage is also applied to the engine control unit, and so the engine control unit detects the fact that the power for activation of the fuel pump is being supplied to the fuel pump.








INSPECTION

Using Multi-use tester (MUT)

Function	Item No.	Activation	Check conditions	Check description	Normal condition
Actuator test	07	Activates fuel pump and circulates fuel.	<ul style="list-style-type: none"> • Engine cranking • Fuel pump forced activation Make the check under both of above conditions. 	Pinch the return hose and feel the pulsations of the fuel flow.	Pulsations can be felt.
				Listen (close to the fuel tank) for pump sounds.	Sounds can be heard.

HARNESS INSPECTION

1  <p>7FU1124</p>	<p>Check the fuel pump.</p> <ul style="list-style-type: none"> • Apply battery voltage to the checking terminal and operate the pump. <div style="display: flex; justify-content: space-around;">  → 2  → 4 </div>
2  <p>1FU0521</p>	<p>Check the earth circuit of the fuel pump.</p> <ul style="list-style-type: none"> • Connector: Disconnected <div style="display: flex; justify-content: space-around;">  → 3  → Repair the harness. (B1 - Earth) </div>
3  <p>1FU0522</p>	<p>Check for continuity between the fuel pump and the checking terminal.</p> <ul style="list-style-type: none"> • Connector: Disconnected <div style="display: flex; justify-content: space-around;">  → 4  → Repair the harness. (B2 - C1) </div>
4  <p>7FU1037</p>	<p>Check for continuity between the checking terminal and the control relay terminal.</p> <ul style="list-style-type: none"> • Control relay connector: Disconnected • Fuel pump connector: Disconnected <div style="display: flex; justify-content: space-around;">  → 5  → Repair the harness. (A2 - C1) </div>

5  Ⓐ Harness side connector 7FU0474	<p>Measure the power supply voltage of the control relay.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: START (when checking Ⓛ [9]) • Ignition switch: ON (when checking Ⓛ [3]) <table border="1" data-bbox="693 337 1052 474"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>8 or higher</td> </tr> </table>	Voltage (V)	8 or higher	 6  Ⓐ Harness side connector 7FU0475
Voltage (V)				
8 or higher				
6  Ⓐ Harness side connector 7FU0475	<p>Check for an open-circuit, or a short-circuit to earth, between the control relay and the engine control unit.</p> <ul style="list-style-type: none"> • Control relay connector: Disconnected • Engine control unit connector: Disconnected 	 7  Ⓐ Harness side connector 7FU0476		
7  Ⓐ Harness side connector 7FU0476	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Connector: Disconnected 	 8  Ⓐ Harness side connector 6FU1333		
8  Ⓐ Harness side connector 6FU1333	<p>Check for an open-circuit, or a short-circuit to earth, between the control relay and the fuel pump.</p> <ul style="list-style-type: none"> • Control relay connector: Disconnected • Fuel pump connector: Disconnected 	 STOP  <p>Repair the harness. (Ⓐ[2]—Ⓑ[2])</p>		



ENGINE CONTROL RELAY INSPECTION

Refer to P. 13-25.


FUEL PUMP INSPECTION

Refer to P. 13-15.

AIR FLOW SENSOR



16Z451



OPERATION

- The flow sensor is incorporated within the air cleaner; it functions to convert the amount of engine air intake to pulse signals of a frequency proportional to the amount of engine air intake, and to input those signals to the engine control unit. The engine control unit then, based upon those signals, calculates the amount of fuel injection, etc.
- The power for the air flow sensor is supplied from the control relay to the air flow sensor, and is earthed at the engine control unit. The air flow sensor, by intermitting the flow of the 5V voltage applied from the engine control unit, produces pulse signals.

TROUBLESHOOTING HINTS

Hint 1:

If the engine sometimes stalls, try starting the engine and shaking the air flow sensor harness. If the engine then stalls, incorrect or improper contact of the air flow sensor connector is the probable cause.

Hint 2:

If, when the ignition switch is switched ON (but the engine is not started), the air flow sensor output frequency is any value other than zero, a malfunction of the air flow sensor or of the engine control unit is the probable cause.

Hint 3:

If idling is possible even though the air flow sensor output frequency is deviated from the standard value, the cause is usually a malfunction other than of the air flow sensor.

[Examples]

- (1) the flow of air within the air flow sensor is disturbed. (Air duct disconnection or clogged air cleaner element.)
- (2) Incomplete combustion within a cylinder. (Malfunction of spark plugs, ignition coil, injectors, compression pressure, etc.)
- (3) Air is taken into the intake manifold through a leaking gasket, etc.

INSPECTION
Using Multi-use tester (MUT)
Air flow sensor

Function	Item No.	Data display	Check conditions	Engine conditions	Standard value Hz
Data reading	12	Sensor detection air flow (frequency)	<ul style="list-style-type: none"> • Engine coolant temperature: 80–95°C (176–203°F) • Lights and accessories: OFF • Transmission: neutral (P range for vehicles with A/T) • Steering wheel: neutral position 	700 r/min. (idling)	25–45
				2,000 r/min.	70–90
				Racing	Frequency increases by racing.

NOTE


When the vehicle is new [driven approximately 500 km (300 miles) or less], the air-flow sensor output frequency may be approximately 10% higher than indicated above.

Air flow sensor reset signal

Function	Item no.	Data display	Inspection condition	Engine condition	Normal display
Data list	34	Reset signal condition	<ul style="list-style-type: none"> • Engine is warming up 	700 r/min. (Idle)	ON
				2000 r/min.	OFF


Volumetric efficiency

Function	Item no.	Data display	Inspection condition	Engine condition	Normal display
Data list	37	Volumetric efficiency	<ul style="list-style-type: none"> • Engine coolant temperature: 80–95°C (176–203°F) • Lights, electrical cooling fan and all accessories: OFF • Transmission: Neutral (P range for vehicles with A/T) • Steering wheel: Straight forward position 	700 r/min. (idle)	20–35%
				2000 r/min.	15–30%
				Racing	Volumetric efficiency increases according to amount of racing.


Wave Pattern Inspection Using an Analyzer
Measurement Method

- (1) Disconnect the air flow sensor connector, and connect the special tool (test harness: MB991348) in between. (All terminals should be connected.)
- (2) Connect the analyzer special patterns pickup to terminal ③ of the air flow sensor connector.


Standard wave pattern



Observation conditions

Function	Special patterns
Pattern height	Low
Pattern selector	Display
Engine r/min.	Idle r/min. (700 r/min.)

Observation conditions (from conditions on previous page, engine speed is increased by racing.)



Wave pattern observation points

Check that cycle time T becomes shorter and the frequency increases when the engine speed is increased.

Examples of abnormal wave patterns

- Example 1

Cause of problem

Sensor interface malfunction

Wave pattern characteristics

Rectangular wave pattern is output even when the engine is not started.


- Example 2

Cause of problem





Damaged rectifier or vortex generation column

Wave pattern characteristics

Unstable wave pattern with non-uniform frequency. However, when an ignition leak occurs during acceleration, the wave pattern will be distorted temporarily, even if the air flow sensor is normal.







HARNESS INSPECTION

<p>1</p>	<p>(A) Harness side connector</p> 	<p>Measure the power supply voltage.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: ON <table border="1" data-bbox="644 347 1011 495"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>SV</td> </tr> </table>	Voltage (V)	SV	<p> → 2</p> <p>Repair the harness. (A 4 — Control relay) or check the control relay</p> <p> →</p>
Voltage (V)					
SV					
<p>2</p>	<p>(A) Harness side connector</p> 	<p>Measure the terminal voltage.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: ON <table border="1" data-bbox="644 726 1011 874"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>4.8 – 5.2</td> </tr> </table>	Voltage (V)	4.8 – 5.2	<p> → 3</p> <p>Repair the harness. (A 3 — 10)</p> <p> →</p>
Voltage (V)					
4.8 – 5.2					
<p>3</p>	<p>(A) Harness side connector</p> 	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Connector: Disconnected 	<p> → 4</p> <p>Repair the harness. (A 5 — 17, 24)</p> <p> →</p>		
<p>4</p>	<p>(A) Harness side connector</p> 	<p>Engine control unit harness side connector</p> <p>Check for continuity between the air flow sensor and the engine control unit.</p> <ul style="list-style-type: none"> • Air flow sensor connector: Disconnected • Engine control unit connector: Disconnected 	<p> → </p> <p>Repair the harness. (A 7 — 57)</p> <p> →</p>		

INTAKE AIR TEMPERATURE SENSOR

M13YGAA



OPERATION

- The intake air temperature sensor functions to convert the temperature of the air (intaken to the engine) to voltage, and to input that voltage (as signals) to the engine control unit. The engine control unit, based upon those signals, then corrects the amount of fuel injection, etc.
- The 5V power supply within the engine control unit is supplied, by way of the resistance within the unit, to the intake air temperature sensor, it passes through the intake air temperature sensor, which is

a type of resistor, and is earthed at the engine control unit. Note that the resistance of the intake air temperature sensor decreases when the temperature of the intake air increases.

- The intake air temperature sensor terminal voltage becomes higher when the resistance of the intake air temperature sensor increases, and becomes lower when the resistance decreases. Consequently, the intake air temperature sensor terminal voltage varies in accordance with the temperature of the intake air, becoming lower when the temperature of the intake air increases.

TROUBLESHOOTING HINTS



Because the intake air temperature of the intake air in the air cleaner, it indicates a temperature different than the temperature of the outside air when the engine is running.



INSPECTION


Using Multi-use tester (MUT)

Function	Item No.	Data display	Check conditions	Intake air temperature °C (°F)	Standard value °C
Data reading	13	Sensor detection temperature	Ignition switch: ON Or, engine running	When -20 (-4)	-20
				When 0 (32)	0
				When 20 (68)	20
				When 40 (104)	40
				When 80 (176)	80

HARNESS INSPECTION

1	Ⓐ Harness side connector 	Check for continuity of the earth circuit. • Connector: Disconnected	 → 2
			 → Repair the harness. (Ⓐ 5—17, 24)


2	Ⓐ Harness side connector 	Measure the power supply voltage. • Connector: Disconnected • Ignition switch: ON	 → 
		Voltage (V) 4.5 – 4.9	 → Repair the harness. (Ⓐ 6—8)



SENSOR INSPECTION

- 1) Disconnect the air flow sensor connectors.
- 2) Measure resistance between terminals ⑤ and ⑥.

Temperature °C (°F)	Resistance kΩ
0 (32)	6.0
20 (68)	2.7
80 (176)	0.4







- 3) Measure resistance while heating the sensor using a hair drier.

Temperature °C (°F)	Resistance kΩ
Higher	Smaller


- 4) If the value deviates from the standard value or the resistance remains unchanged, replace the air flow sensor assembly.

BAROMETRIC PRESSURE SENSOR




Air flow
sensor
connector

Barometric pressure sensor




Engine
control
unit



7FU1177

Engine control unit connector



01L0838

OPERATION

- The barometric pressure sensor functions to convert the barometric pressure to voltage, and to input that voltage (as signals) to the engine control unit. The engine control unit, based upon those signals, then corrects the amount of fuel injection, etc.
- The 5V power supply within the engine control unit is supplied to the barometric pressure

sensor; it passes through the circuitry within the sensor, and is earthed at the engine control unit.

- The barometric-pressure sensor output voltage is supplied to the engine control unit in proportion to the barometric pressure (absolute pressure).

TROUBLESHOOTING HINTS

Hint 1:

If there is a malfunction of the barometric pressure sensor, driveability of the vehicle will become worse particularly at high altitude.

Hint 2:




If, during high-speed driving, there is a noticeable sharp drop of the displayed pressure of the barometric-pressure sensor, check for clogging of the air cleaner.

INSPECTION




Using Multi-use tester (MUT)

Function	Item No.	Data display	Check conditions	Altitude m (ft.)	Standard value	mmHg
Data reading	25	Sensor detection pressure	Ignition switch: ON	When at 0 (0)	760	
				When at 600 (1,969)	710	
				When at 1,200 (3,937)	660	
				When at 1,800 (5,906)	610	

HARNESS INSPECTION



ENGINE COOLANT TEMPERATURE SENSOR



OPERATION

- The engine coolant temperature sensor functions to convert the barometric pressure to voltage, and to input that voltage (as signals) to the engine control unit. The engine control unit, based upon those signals, regulates the amount of fuel injection and the fast-idling speed when the engine is cold.
- The 5V power supply within the engine control unit is supplied, by way of the resistance within the unit, to the engine coolant temperature sensor; it passes through the engine coolant temperature sensor, which is a type of resistor, and is earthed at the engine control unit. Note that the resistance of the engine coolant temperature sensor decreases when the temperature of the engine coolant increases.

- The engine coolant temperature sensor terminal voltage becomes higher when the resistance of the engine coolant temperature sensor increases, and becomes lower when the resistance decreases. Consequently, the engine coolant temperature sensor terminal voltage varies in accordance with the temperature of the engine coolant, becoming lower when the temperature of the engine coolant increases.

TROUBLESHOOTING HINTS


If, during engine warm-up, the fast-idling speed is not correct, or black smoke is emitted, the problem is usually a malfunction of the coolant temperature sensor.


INSPECTION

Using Multi-use tester (MUT)


Function	Item No.	Data display	Check conditions	Engine coolant temperature °C (°F)	Standard value °C
Data reading	21	Sensor detection temperature	Ignition switch: ON Or, engine running	When -20 (-4)	-20
				When 0 (32)	0
				When 20 (68)	20
				When 40 (104)	40
				When 80 (176)	80

HARNESS INSPECTION

1	 7FU0668	Check for continuity of the earth circuit. <ul style="list-style-type: none"> • Connector: Disconnected 	 → 2  → Repair the harness. (A 2 — 17, 24)
----------	--	---	---

2	 7FU0669	Measure the power supply voltage. <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: ON 	 → STOP  → Repair the harness. (A 1 — 20)
----------	---	---	--

SENSOR INSPECTION



- (1) Remove engine coolant temperature sensor from the intake manifold.
- (2) With temperature sensing portion of coolant temperature sensor immersed in hot water check resistance.



Temperature °C (°F)	Resistance kΩ
0 (32)	5.8
20 (68)	2.4
40 (104)	1.1
80 (176)	0.3

- (3) If the resistance deviates from the standard value greatly, replace the sensor.


INSTALLATION

- (1) Apply specified sealant to threaded portion.
Specified sealant: 3M Nut locking No. 4171 or equivalent
- (2) Install engine coolant temperature sensor and tighten it to specified torque.
Sensor tightening torque: 30 Nm (3.0 kgm, 22 ft.lbs)
- (3) Fasten harness connectors securely.


THROTTLE POSITION SENSOR



18Z461



7FU0481



01L0838

OPERATION

- The throttle position sensor functions to convert the degree of opening of the throttle valve to voltage, and to input that voltage (as signals) to the engine control unit. The engine control unit, based upon those signals, then regulates the amount of fuel injection, etc.
- The 5V power supply within the engine control unit is supplied to the throttle position sensor, after which it passes through the resistance within the sensor and is earthed at the engine control unit.
- When the throttle valve shaft is rotated all the way from the idling position to the fully open position, the resistance between the throttle position sensor's variable-resistance terminal and the earth terminal also increases in accordance with that rotation, and, as a result, the voltage of the throttle position sensor's variable-resistance terminal also becomes higher in accordance with that rotation.

TROUBLESHOOTING HINTS

Hint 1:

The signals of the throttle position sensor are more important for control of the automatic transmission than for control of the engine; shifting "impact shocks" are produced if there is a malfunction of the throttle position sensor.




Hint 2:


If the voltage of the throttle position sensor deviates from the standard value, check once again after making the throttle position sensor adjustment. In addition, if there are any indications that the fixed SAS has been moved, adjust the fixed SAS.

INSPECTION**Using Multi-use tester (MUT)**


Function	Item No.	Data display	Check conditions	Throttle valve	Standard value	mv
Data reading	14	Sensor detection voltage	Ignition switch: left ON for 15 seconds or more	Set to idling position.	300 – 1,000	
				Open gradually.	Becomes higher proportionally to valve opening	
				Open fully.	4,500 – 5,500	

HARNESS INSPECTION

1	 <p>Ⓐ Harness side connector ④③②①</p> <p>7FU0482</p>	<p>Measure the power supply voltage of the throttle position sensor.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: ON <table border="1"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>4.8 – 5.2</td> </tr> </table>	Voltage (V)	4.8 – 5.2	 <p>→ 2</p>	
Voltage (V)						
4.8 – 5.2						
2	 <p>Ⓐ Harness side connector ④③②①</p> <p>7FU0483</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Connector: Disconnected 	 <p>→ 3</p>	<p>Repair the harness. (Ⓐ 4 – 23)</p>		
3	 <p>Ⓐ Harness side connector ④③②①</p> <p>Engine control unit harness side connector ⑯</p> <p>7FU0484</p>	<p>Check for an open-circuit, or a short-circuit to earth, between the engine control unit and the throttle position sensor.</p> <ul style="list-style-type: none"> • Throttle position sensor connector: Disconnected • Engine control unit connector: Disconnected 	 <p>→ STOP</p>	<p>Repair the harness. (Ⓐ 3 – 19)</p>		

**SENSOR INSPECTION**


(1) Disconnect the throttle position sensor connector.



(2) Measure resistance between terminal ④ (sensor earth) and terminal ① (sensor power).

Standard value: 3.5–6.5 kΩ

(3) Connect a pointer type ohmmeter between terminal ④ (sensor earth) and terminal ② (sensor output).
 (4) Operate the throttle valve slowly from the idle position to the full open position and check that the resistance changes smoothly in proportion with the throttle valve opening angle.





(5) If the resistance is out of specification, or fails to change smoothly, replace the throttle position sensor.


TPS installation torque: 2.0 Nm (0.2 kgm, 1.5 ft.lbs)

For the idle position switch and throttle position sensor adjusting procedure, refer to P. 13-17.


IDLE POSITION SWITCH




Engine control unit



Ⓐ Harness side connector



Ⓐ Equipment side connector



OPERATION

- The idle-position switch functions to convert (to HIGH/LOW-level voltage) data as to whether the accelerator is depressed or released, and to input that voltage (as signals) to the engine control unit. The engine control unit, based upon those signals, regulates the idle-speed control servo.
- Voltage within the engine control unit is applied, by way of the resistance, to the idle-position switch. When the foot is taken off the accelerator, the idle-position switch is switched ON, so the current is earthed. As a result, the idle-position switch terminal voltage changes from HIGH to LOW level.




TROUBLESHOOTING HINTS

If there is an abnormal condition of the idle-position switch output even though the results of the checking of the idle-position switch harness and of the component itself indicate a normal condition, the cause may be presumed to be one of the following.

- (1) Improper adjustment of the accelerator cable or the automatic-cruise-control cable.
- (2) Improper adjustment of the fixed SAS.

INSPECTION**Using Multi-use tester (MUT)**

Function	Item No.	Data display	Check conditions	Throttle valve	Normal display
Data reading	26	Switch status	Ignition switch: ON (Operate the accelerator several times and check.)	Set to idling position.	ON
				Open slightly.	OFF


HARNESS INSPECTION**SENSOR INSPECTION**

- (1) With the accelerator pedal released, check to be sure that the throttle valve lever or the fixed SAS is pushed.

NOTE

If it is not pushed, adjust the fixed SAS (Refer to P. 13-18.)

- (2) Disconnect the throttle position sensor connector.



(3) Check the continuity across the throttle position sensor connector terminal ① (Sensor earth) and ② (Idle position switch).

Accelerator pedal	Continuity
Depressed	Non-conductive ($\infty\Omega$)
Released	Conductive (0 Ω)

NOTE


If there is no continuity when the accelerator pedal is returned, loosen the throttle-position sensor installation screw; then, after turning all the way in the clockwise direction, check again.

(4) Replace the throttle-position sensor (idle-position switch incorporated) if there is a malfunction.



NOTE

For the idle position switch and throttle position sensor adjusting procedure, refer to P. 13-17.

TOP DEAD CENTER SENSOR



Ⓐ Equipment side connector

OPERATION

- The top dead center sensor functions to detect the top dead center position of the No. 1 cylinder and to convert those data to pulse signals that are input to the engine control

unit. the engine control unit, based upon those signals, calculates the sequence of fuel injection.

- The power for the top dead center sensor is supplied from the control relay and is earthed to the vehicle body. The top dead center sensor, by intermitting the flow (to earth) of the 5V voltage applied from the engine control unit, produces pulse signals.


rect, resulting in such problems as engine stalling, unstable idling, and poor acceleration.

TROUBLESHOOTING HINTS

If there is a malfunction of the top dead center sensor, the sequential injection will not be cor-

INSPECTION

Wave Pattern Inspection Using an Analyzer




Measurement Method

- Disconnect the crankshaft angle sensor connector and connect the special tool (test harness: MB991348) in between. (All terminals should be connected.)
- Connect the analyzer special patterns pickup to terminal ① of the crankshaft angle sensor connector. (When inspecting the TDC sensor signal wave pattern.)
- Connect the analyzer special patterns pickup to terminal ② of the crankshaft angle sensor connector. (When inspecting the crankshaft angle sensor signal wave pattern.)

Standard wave pattern


Observation conditions

Function	Special patterns
Pattern height	Low
Pattern selector	Display
Engine r/min.	Idle r/min. (700 r/min.)



Wave pattern observation points

Check that cycle time T becomes shorter and the frequency increases when the engine speed is increased.



Examples of abnormal wave patterns


- Example 1

Cause of problem

Sensor interface malfunction

Wave pattern characteristics

Short wave pattern is output even when the engine is not started.



- Example 2

Cause of problem

Loose timing belt

Abnormality in sensor disk

Wave pattern characteristics



Wave pattern is displaced to the left or right.

HARNESS INSPECTION

<p>1</p> <p>Ⓐ Harness side connector</p> <p>7FU0496</p>	<p>Measure the power supply voltage.</p> <ul style="list-style-type: none"> • Sensor connector: Disconnected • Ignition switch: ON <table border="1" data-bbox="675 1455 1122 1561"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>SV</td> </tr> </table>	Voltage (V)	SV	<p>OK → 2</p> <p>OK → Repair the harness. (Ⓐ3—Engine control relay)</p>
Voltage (V)				
SV				

2

Ⓐ Harness side connector



7FU0497

Check for continuity of the earth circuit.

- Connector: Disconnected




3

Repair the harness.
(Ⓐ4—Earth)

3

Ⓐ Harness side connector



7FU0498

Check the output circuit voltage.


- Connector: Disconnected
- Ignition switch: ON

Voltage (V)



4.8 – 5.2

STOP
Repair the harness.
(Ⓐ1—[22])

CRANK ANGLE SENSOR



Ⓐ Equipment side connector



7FU0553

7FU0873

OPERATION

- The crank-angle sensor functions to detect the crank angle (position) of each cylinder, and to convert those data to pulse signals, which are then input to the engine control unit. The engine control unit, based upon those signals, calculates the engine rpm, and also regulates the fuel injection timing and the ignition timing.
- The power for the crank-angle sensor is supplied from the control relay and is earthed to the vehicle body. The crank-angle sensor, by intermittently the flow (to earth) of the 5V voltage applied from the engine control unit, produces pulse signals.

TROUBLESHOOTING HINTS

Hint 1:

If an impact is suddenly felt during driving or the engine suddenly stalls during idling, try shaking the crank-angle sensor during idling. If the engine stalls, the cause may be presumed to be improper or incomplete contact of the crank-angle

sensor's connector.

Hint 2:

If the crank-angle sensor output rpm is 0 r/min. during cranking when the engine cannot be started, the cause may be presumed to be a malfunction of the crank-angle sensor or a broken timing belt.

Hint 3:

If the indicated value of the crank-angle sensor output rpm is 0 r/min. during cranking when the engine cannot be started, the cause may be presumed to be a failure of the ignition coil's primary current to intermittently pulse correctly, so a malfunction of the ignition system circuitry, the ignition coil and/or the power transistor is the probable cause.

Hint 4:

If idling is possible even though the crank-angle sensor indicated r/min. is a deviation from the standard value, the cause is usually a malfunction of something other than the crank-angle sensor.

Examples:

- (1) Malfunction of the engine coolant-temperature sensor.
- (2) Malfunction of the idle-speed control servo.
- (3) Improper adjustment of the standard idling speed.

INSPECTION

Using Multi-use tester (MUT)


Function	Item No.	Data display	Check conditions	Check description	Normal condition
Data reading	22	Cranking r/min.	<ul style="list-style-type: none"> • Engine is being cranked. • Tachometer connected. (The tachometer is used to check the intermittent pulsation of the ignition coil's primary current.) 	Compare the cranking rpm and the rpm indicated by the multi-use tester.	Both agree.


Function	Item No.	Data display	Check conditions	Engine coolant temperature °C (°F)	Standard value r/min.
Data reading	22	Idling r/min.	<ul style="list-style-type: none"> • Engine: idling • Idle-position switch: ON 	When -20 (-4)	1,500–1,700
				When 0 (32)	1,250–1,450
				When 20 (68)	1,050–1,250
				When 40 (104)	850–1,050
				When 80 (176)	600–800

Wave Pattern Inspection Using an Analyzer


Refer to the top dead center sensor section (P.13-44).

HARNESS INSPECTION


1  7FU0496	<p>Measure the power supply voltage.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: ON <table border="1" style="width: 100%; text-align: center;"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>SV</td> </tr> </table>	Voltage (V)	SV	 2 <p>Repair the harness. (④③—Engine control relay)</p>
Voltage (V)				
SV				

2  7FU0497	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Connector: Disconnected 	 3 <p>Repair the harness. (④—Earth)</p>
---	---	---

13-50 FUEL SYSTEM <6G72 Engine> – On-Vehicle Inspection of MPI Components


3  7FU0501	Check the voltage of the output circuit. <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: ON <table border="1" style="width: 100%; text-align: center;"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>4.8–5.2</td> </tr> </table>	Voltage (V)	4.8–5.2	 →   → Repair the harness. (A2–21)
Voltage (V)				
4.8–5.2				

IGNITION SWITCH-ST [M/T ONLY]



1FU0638

Engine control unit connector



01L0838

OPERATION



- The ignition switch-ST inputs HIGH-level signals to the engine control unit during engine cranking. The engine control unit, based on those signals, regulates fuel injection during starting, etc.
- When the ignition switch is set to START, the battery voltage during engine cranking is, by way of the ignition switch, applied to the engine control unit, and the engine control unit thus detects the fact that the engine is cranking.

INSPECTION



Using Multi-use tester (MUT)

Function	Item No.	Data display	Check conditions	Engine	Normal display
Data reading	18	Switch status	• Ignition switch: ON	Stopped	OFF
				Cranking	ON


HARNESS INSPECTION

1	 <p>Engine control unit harness side connector 103</p> <p>6FU1258</p>	<p>Measure the input voltage to the engine control unit.</p> <ul style="list-style-type: none"> • Engine control unit connector: Disconnected • Ignition switch: START <table border="1" data-bbox="660 347 1036 495"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>8 or higher</td> </tr> </table>	Voltage (V)	8 or higher	 2 <p>Repair the harness. (108 — Ignition switch)</p> 
Voltage (V)					
8 or higher					
2	 <p>Engine control unit harness side connector 104</p> <p>6FU1259</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Engine control unit connector: Disconnected 	  <p>Repair the harness (104—Earth)</p> 		

IGNITION SWITCH-ST and INHIBITOR SWITCH [A/T only]



Engine control unit connector



01L0838

OPERATION

- The ignition switch-ST inputs HIGH-level signals to the engine control unit during engine cranking. The engine control unit, based on those signals, regulates fuel injection during starting, etc.
- When the ignition switch is set to START, the battery voltage during engine cranking is, by way of the ignition switch, and the inhibitor switch, applied to the engine control unit, and the engine control unit thus detects the fact that the engine is cranking. Note that battery voltage is not applied to the engine control unit if the position of the select lever is other than the "P" or "N" range.
- The inhibitor switch functions to convert the voltage to HIGH level or LOW level depending upon whether the select lever is at the "P" or "N" range or is at some position other than the "P" or "N" range, and inputs the result to the engine control unit. The engine control unit, based upon those signals, then regulates the operation of the idle-speed control servo.
- Battery voltage within the engine control unit is applied, by way of the resistance, to the inhibitor switch. When the select lever is set to the "P" or "N" range, continuity is created, via the starter motor, between the engine control unit's inhibitor switch terminal and earth, and the terminal voltage becomes LOW level.

TROUBLESHOOTING HINTS

If the output of the inhibitor switch is abnormal even though the results of the checking of the inhibitor switch harness and of the component itself are normal, it is probable that the cause is improper adjustment of the control cable.

INSPECTION**Using Multi-use tester (MUT)**




Ignition switch – ST

Function	Item No.	Data display	Check conditions	Engine	Normal display
Data reading	18	Switch status	<ul style="list-style-type: none"> • Ignition switch: ON 	Stopped	OFF
				Cranking	ON

Inhibitor switch

Function	Item No.	Data display	Check conditions	Select lever position	Normal display
Data reading	29	Shift position	<ul style="list-style-type: none"> • Ignition switch: ON 	P or N	P or N
				D, 2, L or R	D, 2, L or R




HARNESS INSPECTION

1  7FU1126	Measure the power supply voltage of the inhibitor switch. <ul style="list-style-type: none"> • Engine control unit connector: Disconnected • Inhibitor switch connector: Disconnected • Ignition switch: START <table border="1" data-bbox="660 937 1036 1085"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>SV</td> </tr> </table>	Voltage (V)	SV	 → 2  → Check the power supply circuit.
Voltage (V)				
SV				
2  7FU1126	Measure the inhibitor switch terminal input voltage. <ul style="list-style-type: none"> • Engine control unit connector: Connected • Inhibitor switch connector: Disconnected • Ignition switch: ON <table border="1" data-bbox="660 1295 1036 1445"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>SV</td> </tr> </table>	Voltage (V)	SV	 → 3  → Repair the harness. (A7—104)
Voltage (V)				
SV				
3  6FU1258	Measure the input voltage of engine control unit <ul style="list-style-type: none"> • Engine control unit connector: Disconnected • Inhibitor switch connector: Connected • Select lever: P range • Ignition switch: START <table border="1" data-bbox="660 1675 1036 1805"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>8 or higher</td> </tr> </table>	Voltage (V)	8 or higher	 → STOP  → Repair the harness. (A12—108)
Voltage (V)				
8 or higher				

INHIBITOR SWITCH INSPECTION

Refer to GROUP 23 – Service Adjustment Procedures.

VEHICLE SPEED SENSOR



OPERATION


- The vehicle-speed sensor is incorporated within the speedometer; it converts vehicle-speed data to pulse signals and inputs those signals to the engine control unit. The engine control unit, based upon those signals, regulates the idle-speed servo, etc.
- The vehicle-speed sensor, by intermitting by the lead switch the flow (to earth) of the approxi-

mately 5V voltage applied from the engine control unit, produces vehicle-speed signals.


TROUBLESHOOTING HINTS

If there is damaged or disconnected wiring, or a short-circuit, of the vehicle-speed sensor signal circuit, the engine may stall when the vehicle speed is reduced and the vehicle is stopped.

HARNESS INSPECTION



2



Measure the power supply voltage of the vehicle speed sensor.

- Connector: Disconnected
- Ignition switch: ON

Voltage (V)

4.5 – 4.9




3

Repair the harness.
(④ ① – ⑩)



3



Check for continuity of the earth circuit.

- Connector: Disconnected



STOP







Repair the harness.
(④ ⑬ – Earth)

SENSOR INSPECTION

Refer to GROUP 54 – Meters and Gauges

AIR CONDITIONER SWITCH AND POWER RELAY



7FU0821

OPERATION

- The air conditioner switch applies battery voltage to the engine control unit when the air conditioner is switched ON.
- When the air conditioner signals are input, the engine control unit activates the idle-speed control servo, and also switches ON the power transistor. As a result, current flows to the power relay coil and the relay switch is switched ON; the air conditioner compressor's magnetic clutch is activated.

TROUBLESHOOTING HINTS


If the air conditioner compressor's magnetic clutch is not activated when the air conditioner switch is switched ON during idling, it is probable that the cause is a malfunction of the air conditioner control system.

INSPECTION**Using Multi-use tester (MUT)****Air conditioner switch**

Function	Item No.	Data display	Check conditions	Air conditioner switch	Normal display
Data reading	28	Switch status	<ul style="list-style-type: none"> • Engine idling (The air conditioner compressor should be activated when the air conditioner switch is switched ON.) 	OFF	OFF
				ON	ON




Air conditioner power relay

Function	Item No.	Data display	Check conditions	Air conditioner switch	Normal display
Data reading	49	Air conditioner power relay status	<ul style="list-style-type: none"> • Engine: idling after warm up 	OFF	OFF (Compressor clutch non-activation)
				ON	ON (Compressor clutch activation)

HARNESS INSPECTION**AIR CONDITIONER INSPECTION**


Refer to GROUP 55.

OXYGEN SENSOR



7FU1110

Engine control unit connector



01L0838

OPERATION

- The oxygen sensor functions to detect the concentration of oxygen in the exhaust gas; it converts those data to voltage, and inputs the resulting signals to the engine control unit.
- If the air/fuel mixture ratio is richer than the theoretical air/fuel mixture ratio (i.e., if the concentration of oxygen in the exhaust gas is sparse), a voltage of approximately 1V is output; if the air/fuel mixture ratio is leaner than the theoretical air/fuel mixture ratio (i.e., if the concentration is dense), a voltage of approximately 0V is output.
- The engine control unit, based upon those signals, regulates the amount of fuel injection so that the air/fuel mixture ratio becomes the theoretical air/fuel mixture ratio.
- Battery power supply is applied, by way of the control relay, to the oxygen sensor heater. As a result, the sensor element is heated by the heater, so that the oxygen sensor shows excellent response even if the temperature of the exhaust gas is low.

TROUBLESHOOTING HINTS

Hint 1:

The exhaust gas purification performance will worsen if there is a malfunction of the oxygen sensor.

Hint 2:

If the oxygen sensor output voltage deviates from the standard value even though the results of the checking of the oxygen sensor are normal, the cause is probably a malfunction of a component related to air/fuel mixture ratio control.

[Examples]




- Malfunction of an injector.
- Air leakage into the intake manifold from a leaking gasket.
- Malfunction of the air-flow sensor, the intake air temperature sensor, the barometric-pressure sensor, or the engine coolant temperature sensor.


INSPECTION

Using Multi-use tester (MUT)

Function	Item No.	Data display	Check conditions	Engine condition r/min.	Standard value mV
Data reading	11	Sensor detection voltage	• Engine: warm-up (Make the mixture lean by engine speed reduction, and rich by racing.)	When sudden deceleration from 4,000	200 or lower
				When engine is suddenly raced	600–1,000
			• Engine: warm up using the oxygen sensor signal, check the air/fuel mixture ratio, and also check the condition of control by the engine control unit	700 (Idling)	400 or lower ↓ 600–1,000
				2,000	


HARNESS INSPECTION

 <p>④ Harness side connector</p> <p>7FU1131</p>	<p>Measure the power supply voltage of the oxygen sensor.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: ON <table border="1" data-bbox="644 979 1101 1095"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>SV</td> </tr> </table>	Voltage (V)	SV	 <p>2</p>  <p>Repair the harness. (④—Engine control relay)</p>
Voltage (V)				
SV				
 <p>④ Harness side connector</p> <p>Engine control unit harness side connector</p> <p>7FU1132</p>	<p>Check for an open-circuit, or a short-circuit to earth, between the engine control unit and the oxygen sensor.</p> <ul style="list-style-type: none"> • Oxygen sensor connector: Disconnected • Engine control unit connector: Disconnected 	 <p>3</p>  <p>Repair the harness. (④—④)</p>		
 <p>④ Harness side connector</p> <p>7FU1133</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Connector: Disconnected 	  <p>STOP</p>  <p>Repair the harness. (②—⑦, ④— (③—Earth))</p>		



SENSOR INSPECTION

- (1) Disconnect the oxygen sensor connector.
- (2) Check that there is continuity [approx. $20\ \Omega$ at 20°C (68°F)] between oxygen sensor connector terminal ① and terminal ③.
- (3) If there is no continuity, replace the oxygen sensor.



- (4) Warm the engine until the engine coolant temperature reaches 80°C (176°F) or more.
- (5) Use the jumper leads to connect the oxygen sensor terminal ① (connect (+) terminal) and terminal ③ (connect (-) terminal) to the battery (+) and (-) terminals respectively.

Caution

Be careful when connecting the jumper leads, as connecting the terminals incorrectly will damage the oxygen sensor.




- (6) Connect a digital-type voltmeter to terminal ② and terminal ④.
- (7) While repeatedly racing the engine, measure the oxygen sensor output voltage.

Engine	Oxygen sensor output voltage	Notes
When racing the engine	0.6–1.0V	When the air/fuel mixture ratio is enriched by racing the engine repeatedly, a normal oxygen sensor will output a voltage of 0.6–1.0V.


NOTE

For removal and installation of the oxygen sensor, refer to GROUP 15 – Exhaust Pipe, Main Muffler and Catalytic Converter.

INJECTORS



7FU0692



01L0838

OPERATION

- The injectors are electromagnetic-valve-equipped injection nozzles that function to inject fuel based upon injection signals from the engine control unit.
- Because the surface area of the injection ports is fixed and because the pressure of the fuel relative to the pressure within the manifold is also regulates to a fixed pressure, the amount of fuel injection by injectors is determined by the length

of time that the needle valve is open, or, in other words, by the length of time of current flow to the solenoid coil.

- Battery power supply is supplied, by way of the control relay, to the injectors. When the engine control unit switches ON the power transistor within the unit and current flows to the solenoid coil, the injectors open and fuel is injected.

TROUBLESHOOTING HINTS

Hint 1:

If there is a problem with starting while the engine is warm, perform the combustion test and check for leakage of the injectors.

Hint 2:

If the engine can't be started, and the injectors are not activated during cranking, the cause is probably a malfunction such as described below, not with the injectors.

- (1) Malfunction of the circuit for supply of power to the engine control unit, or of the earth circuit.
- (2) Malfunction of the control relay.
- (3) Malfunction of the crank-angle sensor and/or the top dead center sensor.

Hint 3:

If there is a cylinder for which the idling condition does not change when, during idling, the fuel injection of the

injectors is cut off in sequence, check that cylinder as described below.

- (1) Check the injector and harness.
- (2) Check the spark plugs and the high-tension cable.
- (3) Check the compression pressure.

Hint 4:

If the injector activation time deviates from the standard value even though the results of the checking of the injector's harness and of the injector itself are normal, the cause may be presumed to be one of the following.

- (1) Incomplete combustion within the cylinder.
(Malfunction of the spark plugs, the ignition coil, the compression pressure, etc.)
- (2) Increased engine resistance.

INSPECTION**Using Multi-use tester (MUT)**

Function	Item No.	Data display	Check conditions	Engine coolant temperature C° (°F)	Standard value ms
Data reading	41	Activation time ^{*1}	Engine cranking	When 0 (32) ^{*2}	Approx. 14
				When 20 (68)	Approx. 40
				When 80 (176)	Approx. 9


Function	Item No.	Data display	Check conditions	Engine condition r/min.	Standard value ms
Data reading	41	Activation time ^{*3}	<ul style="list-style-type: none"> • Engine coolant temp: 85–95°C (185–205°F) • Lights and accessories: OFF • Transmission: neutral (P range for vehicles with A/T) • Steering wheel: neutral position 	700 (idling) r/min.	2.7–3.2
				2,000	2.6–3.1
				When raced suddenly	Increases.

NOTE


*¹: Indicates the injector-activation time when the power source voltage is 11V and the cranking speed is 250 rpm or less.

*²: At a coolant temperature of 0°C (32°F), there is synchronous injection for all six cylinders.

*³: For a new vehicle [driven approximately 500 km (300 miles) or less] the injector-activation may be about ten percent longer than indicated above.

**Wave Pattern Inspection Using an Analyzer**

- (1) Disconnect the injector connector, and connect the special tool (test harness: MB991348) in between. (The power side and the ECU side terminals should both be connected.)
- (2) Connect the analyzer special patterns pickup to the ECU test harness clip.

Standard wave pattern**Observation conditions**


Function	Special patterns
Pattern height	Variable
Variable knob Pattern selector	Display
Engine r/min.	Idle r/min. (700 r/min.)

Wave pattern observation points

Point A: Height of back electromotive force in the solenoid coil

Contrast with standard wave pattern	Probable cause
Solenoid coil back electromotive force is low or doesn't appear at all.	Short in the injector solenoid

Point B: Injector drive time




- The injector drive timing will synchronize with the multi-use tester display.
- When the engine is suddenly raced, the drive time will be greatly extended at first, but the drive time will soon match the engine speed.

HARNESS INSPECTION

1	<p>7FU0669</p> <p>Harness side connector A B C D E F 2 1</p>	<p>Measure the power supply voltage of the injector.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: ON <table border="1"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>SV</td> </tr> </table>	Voltage (V)	SV		2	<p>Repair the harness. (A B C D E F) —Engine control relay Check the power supply.</p>
Voltage (V)							
SV							

2	<p>7FU0693</p> <p>Harness side connector A B C D E F 2 1</p> <p>Engine control unit harness side connector 51 52 60 61 105 109</p>	<p>Check for an open-circuit, or a short-circuit to earth, between the engine control unit and the injector.</p> <ul style="list-style-type: none"> • Engine control unit connector: Disconnected • Injector connector: Disconnected 		STOP	<p>Repair the harness. (A B C D E F) — 51 52 60 61 105 109</p>
----------	--	--	--	-------------	--



ACTUATOR INSPECTION

Measuring Resistance Between Terminals


- (1) Disconnect the connector for the injectors.
- (2) Measure the resistance between terminals.

Standard value: 13–16 Ω at 20°C (68°F)


- (3) Connect the connector for the injectors.

Checking the Injection Condition


- (1) Following the steps below, bleed out the residual pressure within the fuel pipe line to prevent flow of the fuel. (Refer to P. 13-16.)
- (2) Remove the injector.
- (3) Arrange the special tool (injector test set), adaptor, fuel pressure regulator and clips as shown in the illustration below.



- (4) Connect the battery's negative (-) terminal.
- (5) Apply battery voltage to the fuel pump check terminal and activate the fuel pump.




- (6) Activate the injector and check the atomized spray condition of the fuel. The condition can be considered satisfactory unless it is extremely poor.






- (7) Stop the actuation of the injector, and check for leakage from the injector's nozzle.

Standard value: 1 drop or less per minute

- (8) Activate the injector without activating the fuel pump; then, when the spray emission of fuel from the injector stops, disconnect the special tool and restore it to its original condition.




IDLE SPEED CONTROL SERVO (STEPPER MOTOR)



7FU0518

Engine control unit connector



01L0838

OPERATION

- The amount of air taken in during idling is regulated by the opening and closing of the servo valve located in the air passage that bypasses the throttle valve.
- The servo valve is opened or closed by the activation of the stepper motor (incorporated within the idle-speed control servo) in the forward or reverse direction.
- Battery power supply is supplied, by way of the control relay, to the coil of the stepper motor. The engine control unit switches ON the power transistors (located within the engine control unit) in sequential order, and, when current flows to the stepper motor coil, the stepper motor is activated in the forward or reverse direction.

TROUBLESHOOTING HINTS

Hint 1:

If the number stepper motor steps increases to 100–120 steps or decreases to 0 step, the cause may be presumed to be a malfunction of the stepper motor or damaged or disconnected wiring of the harness.

Hint 2:

If the number of stepper motor steps deviates from the standard value even through the results of the checking of the harness of the idle-speed control servo and of the component itself indicate no abnormal condition, the cause may be presumed to be one of the following.

- (1) Improper adjustment of the standard idling speed.
- (2) Deposits adhered to the throttle valve.
- (3) Leakage of air into the intake manifold from a gasket gap, etc.
- (4) Incomplete combustion within the cylinder. (Malfunction of the spark plugs, the ignition coil, the injectors, the compression pressure, etc.)

INSPECTION

Using Multi-use tester (MUT)


Function	Item No.	Data display	Check conditions	Load conditions	Standard value STP
Data reading	45	Stepper motor steps	<ul style="list-style-type: none"> • Engine coolant temperature: 85–95°C (185–205°F) • Lights and accessories: OFF • Transmission: neutral (P range for vehicles with A/T) • Steering wheel: neutral position • Idle-position switch: ON (The compressor clutch should be activated when the air conditioner switch is switched ON.) • Engine: idling 	• Air conditioner switch: OFF	2–12
				• Air conditioner switch: ON	30–70
				<ul style="list-style-type: none"> • Air conditioner switch: ON • Selector lever: shift to D range 	20–60

NOTE

When the vehicle is new [driven approximately 500 km (300 miles) or less] the number of steps may be about 30 steps greater than the standard value indicated above.

Caution

When the select lever is shifted to the "D" range, the brakes must be used to prevent the vehicle from moving forward.



Wave Pattern Inspection Using an Analyzer


Observation method

- (1) Disconnect the stepper motor connector, and connect the special tool (test harness: MB998463) in between.
- (2) Connect the analyzer special patterns pickup to the stepper motor-side connector terminal ① (red clip on the special tool), terminal ③ (green clip), terminal ④ (black clip) and terminal ⑥ (yellow clip) respectively.

Standard wave pattern

Observation conditions

Function	Special patterns
Pattern height	High
Pattern selector	Display
Engine condition	Turn the ignition switch from OFF to ON (without starting the engine).
	While the engine is idling, turn the air conditioner switch to ON.
	Immediately after starting the warm engine (approx. 1 minute).



Wave pattern observation points


Check that the standard wave pattern appears when the stepper motor is operating.

(Point A): Presence or absence of induced electromotive force from the motor turning. (Refer to the abnormal wave pattern.)

Contrast with standard wave pattern	Probable cause
Induced electromotive force does not appear or is extremely small.	Motor is malfunctioning

(Point B): Height of coil reverse electromotive force

Contrast with standard wave pattern	Probable cause
Coil reverse electromotive force does not appear or is extremely small.	Short in the coil



Abnormal wave pattern

Cause of problem

Motor is malfunctioning. (Motor is not operating.)


Wave pattern characteristics

Induced electromotive force from the motor turning does not appear.

HARNESS INSPECTION

1	<p>④ Harness side connector</p> <p>01L0395</p>	<p>Measure the power supply voltage of idle speed control servo.</p> <ul style="list-style-type: none"> Idle speed control servo connector: Disconnected Ignition switch: ON <table border="1"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>SV</td> </tr> </table>	Voltage (V)	SV	2	<p>OK</p> <p>Repair the harness. (Engine control relay-④② Engine control relay-④⑤)</p> <p>OK</p>
Voltage (V)						
SV						

2




Check for an open-circuit, or a short-circuit to earth, between the engine control unit and idle speed control servo.

- Engine control unit connector: Disconnected
- Idle speed control servo connector: Disconnected



Repair then
harness.
(④-58,
④-59,
④-67,
④-68)



ACTUATOR INSPECTION

Checking Operation Sound

- (1) Check that when the ignition switch is placed in the ON position (the engine not started), the operating sound of the stepper motor can be heard over the idle speed control servo.
- (2) If no operating sound can be heard, check the stepper motor drive circuit. (If the circuit is good, a defective stepper motor or engine control unit is suspected.)


Checking the Coil Resistance


- (1) Disconnect the idle speed control servo connector and connect the special tool (test harness).
- (2) Measure the resistance between terminal ② (White clip of the special tool) of the connector at the idle speed control servo side and terminal ① (red clip) or terminal ③ (blue clip).

Standard value: 28–33 Ω [at 20°C (68°F)]

- (3) Measure the resistance between terminal ⑤ (green clip of the special tool) of the connector at the idle speed control servo side and terminal ⑥ (yellow clip) or terminal ④ (black clip).


Standard value: 28–33 Ω [AT 20°C (68°F)]







Checking the operation

- (1) Remove the throttle body.
- (2) Remove the stepper motor.



- (3) Connect the special tool (test harness) to the Idle speed control servo connector.
- (4) Connect the positive $+$ terminal of a power source (approx 6V) to the white clip or the green clip.
- (5) Holding the idle speed control servo as shown in the illustration, connect the negative $-$ terminal of the power source to each clip in the sequence described below, and check whether or not there is vibration (a feeling of very slight shaking of the stepper motor) as a result of activation of the stepper motor.
 - ① Connect the negative $-$ terminal of the power source to the red and black clips.
 - ② Connect the negative $-$ terminal of the power source to the blue and black clips.
 - ③ Connect the negative $-$ terminal of the power source to the blue and yellow clips.
 - ④ Connect the negative $-$ terminal of the power source to the red and yellow clips.
 - ⑤ Connect the negative $-$ terminal of the power source to the red and black clips.
 - ⑥ Repeat the test in the reverse (⑤—①) sequence.
- (6) If, as a result of this test, vibration is felt, the stepper motor can be considered to be normal.

IGNITION COIL AND POWER TRANSISTOR



01L0838

OPERATION

- When the power transistor unit is switched ON by the signals from the engine control unit, the primary current of the ignition coil will flow. When the power transistor unit is switched OFF, the primary current flow is interrupted, and high voltage is produced at the secondary coil.
- When the engine control unit switches OFF the power transistor within the unit, the battery voltage within the unit is applied to the power transistor unit, and the power transistor unit is switched ON. In addition, the power transistor unit is switched OFF when the engine control unit switches ON the power transistor within the unit.

INSPECTION


Using Multi-use tester (MUT)

Spark advance value

Function	Item No.	Data display	Check conditions	Engine condition r/min.	Standard value °BTDC
Data reading	44	Spark advance	<ul style="list-style-type: none"> • Engine: warm • Timing light: set (The timing light is set so as to check the actual ignition timing.) 	700 (Idling)	7-23
				2,000	25-31

Ignition timing adjustment mode

Function	Item No.	Data display	Inspection condition	Engine condition	Normal display
Data list	36	Existence of continuity at earth connection of the ignition timing adjustment terminal	Engine: idling	Earth the ignition timing adjustment terminal.	ON
				Remove the earth connection of the ignition timing adjustment terminal.	OFF



Wave Pattern Inspection Using an Analyzer


- Ignition coil primary signal
Refer to GROUP 16 – Ignition System.
- Power transistor control signal
<Measurement method>

- Disconnect the power transistor connector, and connect the special tool (test harness: MB991348) in between. (All terminals should be connected.)
- Connect the analyzer special patterns pickup to the power transistor connector terminal ③.

Standard wave pattern

Observation conditions


Function	Special patterns
Pattern height	Low
Pattern selector	Display
Engine	Approx. 1200 r/min.



7FU1206

Wave pattern observation points

(Point): Condition of wave pattern build-up and maximum voltage (Refer to abnormal wave pattern examples 1 and 2.)



Examples of abnormal wave patterns

- Example 1


Wave pattern during engine cranking

Cause of problem

Broken wire in ignition primary circuit

Wave pattern characteristics

Top-right part of the build-up section cannot be seen, and voltage value is approximately 2V too low.



Example 2

Wave pattern during engine cranking



Cause of problem




Malfunction in power transistor

Wave pattern characteristics

Power voltage results when the power transistor is ON.

HARNESS INSPECTION





<p>3</p> <p>Ⓐ Harness side connector</p>  <p>7FU0837</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Connector: Disconnected 	<p>OK → 4</p> <p>OKX → Repair the harness. (Ⓐ2—Earth)</p>		
<p>4</p> <p>Ⓐ Harness side connector</p>  <p>7FU0838</p>	<p>Measure the voltage of the control signal circuit of the power transistor.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: START <table border="1" data-bbox="718 684 1085 832"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>2 – 6</td> </tr> </table>	Voltage (V)	2 – 6	<p>OK → 5</p> <p>OKX → Repair the harness. (Ⓐ1—54)</p>
Voltage (V)				
2 – 6				
<p>5</p> <p>Ignition timing adjustment connector</p>  <p>7FU1060</p>	<p>Measure the voltage of the ignition timing adjustment terminal.</p> <ul style="list-style-type: none"> • Ignition switch: ON <table border="1" data-bbox="718 1064 1085 1211"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>4.0 – 5.2</td> </tr> </table>	Voltage (V)	4.0 – 5.2	<p>OK → STOP</p> <p>OKX → Repair the harness. (Ⓒ1—12)</p>
Voltage (V)				
4.0 – 5.2				

ACTUATOR INSPECTION


Refer to Group 16.

PURGE CONTROL SOLENOID VALVE



01A0324

Engine control unit connector



01L0838

OPERATION

- The purge-control solenoid valve is an ON/OFF type of solenoid valve; it functions to regulate the introduction of purge air from the canister to the intake air plenum.
- Battery power supply is supplied, by way of the control relay, to the purge-control solenoid valve. When the engine control unit switches ON the power transistor within the unit, current flows to the coil, and purge air is introduced.


INSPECTION

Using Multi-use tester (MUT)


Function	Item No.	Activation	Check conditions	Normal condition
Actuator test	08	Solenoid valve is switched from OFF to ON.	• Ignition switch: ON	Operating sound is heard when driven.

HARNESS INSPECTION

1



Harness side connector



7FU0525

Measure the power supply voltage.

- Connector: Disconnected
- Ignition switch: ON

Voltage (V)

SV




2

Repair the harness.
(Engine control relay –
(A1))

2

Harness side connector



7FU0526

Check for an open-circuit, or a short-circuit to earth, between the purge control solenoid valve and the engine control unit.

- Purge control solenoid valve connector: Disconnected
- Engine control unit connector: Disconnected



STOP



Repair the harness.
(A2–62)

ACTUATOR INSPECTION


Refer to Group 17.

FUEL PRESSURE**HOW TO REDUCE THE FUEL LINE INTERNAL PRESSURE**

Refer to P. 13-16.

FUEL PUMP OPERATION CHECK

Refer to P. 13-15.




M13FNAD

FUEL PRESSURE TEST


- (1) Reduce the internal pressure of the fuel pipes and hoses.
- (2) Disconnect the fuel high pressure hose at the delivery pipe side.

Caution


Cover the hose connection with rags to prevent splash of fuel that could be caused by some residual pressure in the fuel pipe line.




- (3) Set a fuel pressure gauge on the special tool, placing an adequate O-ring or gasket between the gauge end special tool prevent fuel leaks.



- (4) Attach the special tool set in step (3) to the delivery pipe.
- (5) Connect the (–) battery terminal.




- (6) Connect a jumper wire to the terminal for activation of the fuel pump and to the positive (+) terminal of the battery to activate the fuel pump. With fuel pressure applied, check to be sure that there is no fuel leakage from the fuel pressure gauge and the special tool connection part.
- (7) Disconnect the jumper wire (from the terminal for activation of the fuel pump) to stop the fuel pump.
- (8) Start the engine and let it idle.



(9) Measure the fuel pressure during idling.

Standard value: Approx. 270 kPa (2.7 kg/cm², 38 psi) at curb idle



(10) Disconnect the vacuum hose from the fuel pressure regulator, and then measure the fuel pressure while using a finger to plug the end of the hose.

Standard value: 330–370 kPa (3.3–3.5 kg/cm², 47–53 psi) at curb idle speed

(11) Check to be sure that the fuel pressure during idling does not decrease even after the engine is raced a few times.

(12) Use a finger to gently press the fuel return hose while repeatedly racing the engine, and check to be sure that there is fuel pressure in the return hose also.

NOTE

There will be no fuel pressure in the return hose if there is insufficient fuel flow.

(13) If the fuel pressure measured in steps (9) to (12) deviates from the standard value range, check for the probable cause by referring to the table below, and then make the appropriate repair.

Condition	Probable cause	Remedy
<ul style="list-style-type: none"> • Fuel pressure is too low. • Fuel pressure drops during racing. • No fuel pressure in fuel return hose. 	<p>Fuel filter is clogged.</p> <p>Malfunction of the valve seat within the fuel pressure regulator, or fuel leakage to return side caused by spring deterioration.</p> <p>Fuel pump low discharge pressure.</p>	<p>Replace the fuel filter.</p> <p>Replace the fuel pressure regulator.</p> <p>Replace the fuel pump.</p>
Fuel pressure is too high.	<p>The valve within the fuel pressure regulator is sticking.</p> <p>Clogging of the fuel return hose and/or the pipe.</p>	<p>Replace the fuel pressure regulator.</p> <p>Clean or replace the hose and/or pipe.</p>
No change of the fuel pressure when vacuum hose is connected and when not connected.	Damaged vacuum hose or nipple clogging.	Replace the vacuum hose, or clean the nipple.

(14) Stop the engine and check for a change of the value indicated by the fuel pressure gauge. The condition is normal if there is no decrease of the indicated value within two minutes. If there is a decrease of the indicated value, monitor the speed of the decrease, and, referring to the table below, determine the cause of the problem and make the appropriate repair.

Condition	Probable cause	Remedy
After the engine is stopped, the fuel pressure drops gradually.	Injector leakage.	Replace the injector.
	Leakage at the fuel pressure regulator valve seat.	Replace the fuel pressure regulator.
There is a sudden sharp drop of the fuel pressure immediately after the engine is stopped.	The check valve (within the fuel pump) is not closed.	Replace the fuel pump.

(15) Remove all remaining pressure from inside the fuel pipe. (Refer to P. 13-16.)
 (16) Disconnect the fuel pressure gauge and the special tool from the delivery pipe.

Caution

Because there will be a slight amount of remaining pressure in the fuel pipe line, use rags to cover so that fuel doesn't splatter.

(17) Replace the O-ring at the end of the fuel high-pressure hose with a new one.
 (18) After connecting the fuel high-pressure hose to the delivery pipe, tighten the installation bolt at the specified torque.

Tightening torque: 5 Nm (0.5 kgm, 3.6 ft.lbs)

(19) Check to be sure that there is no fuel leakage.



- ① Apply battery voltage to the terminal for activation of the fuel pump so as to activate the fuel pump.
- ② With fuel pressure applied, check for leakage of the fuel line.

FUEL SYSTEM <6G72 – 24Valve Engine, 6G74 Engine>

GENERAL INFORMATION

MULTI POINT INJECTION SYSTEM DIAGRAM



<SOHC>



Vacuum hose color
 B: Black
 G: Green
 L: Light blue
 R: Red
 Y: Yellow

7FU1738

<DOHC>



7FU1510

SPECIFICATIONS**GENERAL SPECIFICATIONS**

E13CA-A


Items	Specifications	
Fuel		
Tank capacity	dm ³ (U.S.gal., Imp.gal.)	
Standard Wheelbase		75 (19.8, 16.5)
Long Wheelbase		92 (24.3, 20.2)
Fuel pump		
Type		Electrical, in-tank type
Driven by		Electric motor
Throttle body		
Throttle bore	mm (in.)	60 (2.36)
Throttle position sensor		Variable resistor type
Idle speed control servo		Stepper motor type
		Stepper motor type by-pass air control system with the Fast Idle Air Valve
Idle position switch		Rotary contact type
Engine control unit		
Identification model No.		
<SOHC>		E2T37483
<DOHC>		E2T39974 <Up to 1994 model> E2T39977 <From 1995 model>
Sensors		
Air flow sensor		Karman vortex type
Barometric pressure sensor		Semiconductor diffusion-type
Intake air temperature sensor		Thermistor type
Engine coolant temperature sensor		Thermistor type
Oxygen sensor		Zirconia type
Vehicle-speed sensor		Reed switch type
Inhibitor switch		Contact switch type
Detonation sensor <DOHC>		Piezoelectric type
Cam position sensor		Hall element type
Crank angle sensor		Hall element type
Power steering pressure switch		Contact switch type
Actuators		
Control relay type		Contact switch type
Injector type and number		Electromagnetic, 6
Purge control solenoid valve		ON/OFF type solenoid valve
EGR control solenoid valve		Duty cycle type solenoid valve
Fuel pressure regulator		
Regulated pressure	kPa (kg/cm ² , psi)	329 (3.35, 47.6)








SERVICE SPECIFICATIONS





SEALANT


Items	Specified sealant	Remarks
Engine coolant temperature sensor threaded portion	3M Nut Locking Part No. 4171 or equivalent	Drying sealant

SPECIAL TOOLS

Tool	Number	Name	Use
	MB991502	MUT-II	<ul style="list-style-type: none"> ● Reading diagnosis code ● MPI system inspection
	16X0607	ROM pack	

Tool	Number	Name	Use
	MB991529	Diagnosis code check harness	<ul style="list-style-type: none"> • Reading diagnosis code • Basic idle speed adjustment
	MB991348	Test harness set	<ul style="list-style-type: none"> • Adjustment of throttle position sensor • Inspection with analyzer
	MD998464	Test harness (4 pin, square)	<ul style="list-style-type: none"> • Oxygen sensor inspection
	MD998474	Test harness (8 pin, square)	<ul style="list-style-type: none"> • Inspection with analyzer
	MD998706	Injector test set	<ul style="list-style-type: none"> • Checking injection condition of injector
	MD998740	Injector test adaptor	
	MD998746	Clip	
	MD998463	Test harness (6 pin, square)	<ul style="list-style-type: none"> • Idle speed control servo inspection • Inspection with analyzer

Tool	Number	Name	Use
	MD998709	Adapter hose	<SOHC> Measurement of fuel pressure
	MD998742	Hose adapter	
	MD998753	Extension hose	<DOHC> • Measurement of fuel pressure
	MD998700	Hose adapter	
For red harness (for DLI) 	MB991223	Inspection harness set connector • Pin contact pressure inspection harness	• Measurement of terminal voltages
For white harness (for LC) 		• Marketing tester connection probe (for general connectors)	







TROUBLESHOOTING

EXPLANATION OF TROUBLESHOOTING PROCEDURES

Effective troubleshooting procedures for MPI system problems are given below.

1. Verification of trouble symptom
 - Reproduce trouble symptom and verify the characteristics of the trouble and the conditions (engine condition, driving conditions, etc.) under which it is produced.
2. Reading of self-diagnosis code
 - Read self-diagnosis code and if a malfunction code is output, locate and correct the trouble referring to the DIAGNOSIS CHART.
3. Estimation of the causes of trouble and setting of check items
 - Referring to the Check Chart, verify the check items and checking order for the trouble symptom.
4. Inspection of engine control unit input signals
 - Inspect the engine control unit input signals by using the MUT-II or an analyzer.
 - Sensor input is normal if input signals are normal, then inspect the next inspection item.
5. Inspection of engine control unit output signals and actuator operation
 - Inspect the engine control unit output signals and actuator operation by using the MUT-II. Drive the actuator by instructing the actuator test function and verify the actuator operation.
 - Inspect the engine control unit output signals by using an oscilloscope.
 - Actuator control is normal if engine control unit output signals and actuator are normal, then inspect the next inspection item.
6. Inspection of MPI system component harnesses
 - If the engine control unit input/output signals are abnormal, check the MPI system component body harness and repair as necessary.
 - After repair, check the engine control unit input/output signals again. If they are normal, proceed to check the input/output signals of the next check item.
7. Inspection of individual MPI system components
 - If the body harness is normal but the engine control unit input/output signals are abnormal, check individual MPI system components and repair or replace as necessary.
 - After repair or replacement, check the engine control unit input/output signals again. If they are normal, proceed to check the input/output signals of the next check item.




8. Re-inspection and repair of trouble symptom
 - If the harness inspection and individual component inspection results are normal but the engine control unit input/output signals are abnormal, re-examine the causes of trouble referring to the troubleshooting hints and the checks and repairs included in other groups.
9. Verification and prevention of reoccurrence after repair
 - Perform tests to see if the same problems occur again and make sure that the same problems will not be repeated.
 - Remove the true causes of the trouble to prevent its reoccurrence.



EXPLANATION AND PRECAUTION RELATED TO HARNESS CHECKING

- Connector symbols are described as seen from the terminal end for the connector.
- The abbreviation "SV" used for the normal judgment value when checking the voltage is the abbreviation for system voltage.
- Be sure to use the special tool (test harness) when, for a waterproof connector, checking while the circuit is conductive. If probe is inserted from the harness side, the waterproof capability will be lowered, thereby causing/corrosion, so never do so.
- When a connector is disconnected in order to check terminal voltage, etc., never insert a probe if the terminal to be checked is a female pin, because the forceful insertion of a probe will cause improper or incomplete contact.
- Also, if there is no test harness that conforms to the connector, use the test harness set (MB991348) which can be directly connected between the terminals.
- When disconnecting the connector and inspecting the terminal voltage, etc., if the inspection terminal is a female pin, the special tool (inspection harness set: MB991223) should be used instead of inserting a probe.

- When checking for damaged or disconnected wiring of a harness (open circuit) and if both ends of the harness are unconnected, use a jumper wire to earth one end of the harness, and then check for continuity between the other end and earth. By doing this, you can check for damaged or disconnected wiring, and, if there is no continuity, the harness should be repaired.



- When checking for a harness short-circuit (short-circuit to earth), open one end of the harness and then check for continuity between the other end and earth. If there is continuity, the harness is short-circuited to earth and should be repaired.
- Use an analog voltmeter resistor (or a circuit tester) when inspecting the continuity.

- If the impressed voltage is not normal even if wire is normal, change the engine control unit and inspect again.
- Use a digital voltmeter (or a circuit tester) when measuring the voltage. Use an analog voltmeter, however, when inspecting the power transistor drive voltage.

ENGINE WARNING LAMP (CHECK ENGINE LAMP)

Among the self-diagnosis items, a engine warning lamp comes on to notify the driver of the emission control items when an irregularity is detected.

However, when an irregular signal returns to normal and the engine control unit judges that it has returned to normal, the engine warning lamp goes out.

Moreover, when the ignition switch is turned off, the lamp goes out. Even if the ignition switch is turned on again, the lamp does not come on until the irregularity is detected. Here, immediately after the ignition switch is turn on, the engine warning lamp is lit for 5 seconds to indicated that the engine warning lamp operates normally.

Item indicated by the lightening engine warning lamp

Engine control unit	Cam position sensor
Oxygen sensor	Barometric pressure sensor
Air flow sensor	Detonation sensor <DOHC>
Intake air temperature sensor	Ignition timing adjustment signal
Throttle position sensor	Injector
Engine coolant temperature sensor	EGR system
Crank angle sensor	Ignition coil. Power transistor unit

Caution

Engine warning lamp will come on when the line of terminal for ignition timing adjustment is short-circuited. Therefore, the lamp will come on even when the terminal for ignition timing adjustment is earthed at the time of adjusting ignition timing. In this case, however, it is not abnormal.

ENGINE WARNING LAMP INSPECTION

- (1) Check to be sure, when the ignition switch is set to the "ON" position, that the lamp illuminates for about five seconds and then switches OFF.
- (2) If the lamp does not illuminate, check for damage or disconnection of the harness, or for a blown fuse or a failed light bulb.

SELF-DIAGNOSIS

The engine control unit monitors the input/output signals (some signals at all times and the others under specified conditions) of the engine control unit. When it is noticed that an irregularity has continued for a specified time or longer from when the irregular signal is initially monitored, passing a certain number, the engine control unit judges that an irregularity has occurred, memorizes the malfunction code, and outputs the signal to the self-diagnosis output terminals. There are 18 diagnosis items, including the normal state, and the diagnosis results can be read out with a voltmeter or MUT-II. Moreover, since memorization of the malfunction codes is backed up directly by the battery, the diagnosis results are memorized even if the ignition key is turned off. The malfunction codes will, however, be erased when the battery terminal or the engine control unit connector is disconnected.

The malfunction codes are also erased by setting the ignition switch to the "ON" position and then sending the malfunction-code-erase signal from the MUT-II to the engine control unit.

Caution

If the sensor connector is disconnected while the ignition switch is ON, the malfunction code is memorized. In this instance, either send the malfunction-code-erase signal from the MUT-II to the engine control unit, or disconnect the battery's negative (-) terminal for ten seconds or longer; the diagnosis memory will be erased.

The 18 diagnosis items are provided as follows, and if plural items are activated, they are all indicated sequentially from the smallest code number.

Caution

Ignition timing adjustment signal malfunction code is output when the ignition timing adjustment terminal line is short-circuited to the earth. Therefore, the malfunction code is output when the ignition timing adjustment terminal is earthed, however, this is not a malfunction.

DIAGNOSIS CHART

Output preference order	Diagnosis item	Diagnosis code		Check item (Remedy)
		No.	Memory	
1	Engine control unit	—	—	(Replace engine control unit)
2	Oxygen sensor	11	Retained	<ul style="list-style-type: none"> ● Harness and connector ● Oxygen sensor ● Fuel pressure ● Injectors (Replace if defective) ● Intake air leaks
3	Air flow sensor	12	Retained	<ul style="list-style-type: none"> ● Harness and connector (if harness and connector are normal, replace air flow sensor assembly.)
4	Intake air temperature sensor	13	Retained	<ul style="list-style-type: none"> ● Harness and connector ● Intake air temperature sensor
5	Throttle position sensor	14	Retained	<ul style="list-style-type: none"> ● Harness and connector ● Throttle position sensor ● Idle position switch
6	Engine coolant temperature sensor	21	Retained	<ul style="list-style-type: none"> ● Harness and connector ● Engine coolant temperature sensor
7	Crank angle sensor	22	Retained	<ul style="list-style-type: none"> ● Harness and connector (If harness and a connector are normal, replace distributor assembly.)
8	Cam position sensor	23	Retained	<ul style="list-style-type: none"> ● Harness and connector (If harness and a connector are normal, replace distributor assembly.)
9	Vehicle speed sensor (reed switch)	24	Retained	<ul style="list-style-type: none"> ● Harness and connector ● Vehicle speed sensor (reed switch)
10	Barometric pressure sensor	25	Retained	<ul style="list-style-type: none"> ● Harness and connector (If harness and connector are normal, replace barometric sensor assembly.)

Output preference order	Diagnosis item	Diagnosis code		Check item (Remedy)
		No.	Memory	
11	Detonation sensor <DOHC>	31	Retained	<ul style="list-style-type: none"> ● Harness and connector (If harness and connector are normal; replace detonation sensor.)
12	Ignition timing adjustment signal	36	—	<ul style="list-style-type: none"> ● Harness and connector
13	Injector	41	Retained	<ul style="list-style-type: none"> ● Harness and connector ● Injector oil resistance
14	EGR system	43	Retained	<ul style="list-style-type: none"> ● Harness and connector ● EGR temperature sensor ● EGR valve ● EGR solenoid ● EGR valve control vacuum
15	Ignition coil, Power transistor unit (No. 1–4 cylinder)	44	Retained	<ul style="list-style-type: none"> ● Harness and connector ● Ignition coil ● Power transistor unit
16	Ignition coil, Power transistor unit (No. 2–5 cylinder)	52	Retained	<ul style="list-style-type: none"> ● Harness and connector ● Ignition coil ● Power transistor unit
17	Ignition coil, Power transistor unit (No. 3–6 cylinder)	53	Retained	<ul style="list-style-type: none"> ● Harness and connector ● Ignition coil ● Power transistor unit
18	Normal state	—	—	—

NOTE

Replace the engine control unit if a malfunction code is output although the inspection reveals that there is no problem with the check items.

TROUBLE DIAGNOSIS QUICK REFERENCE CHART

Trouble code No.	Diagnosis item	Description	Major cause	Remarks (Symptoms, etc.)
–	Engine control unit	Trouble in engine control unit itself	–	<ul style="list-style-type: none"> • Engine stalls • Engine cannot be started.
11	Oxygen sensor	Air-fuel ratio feedback control (closed loop control) is in effect but oxygen sensor signal voltage does not change (air-fuel mixture lean/rich).	(1) Defective oxygen sensor (2) Open or short circuit in oxygen sensor circuit, or connector in loose contact (3) Improper fuel pressure (4) Defective injector (5) Air drawn in through gasket clearance, etc. (6) Defective engine control unit	<ul style="list-style-type: none"> • Poor exhaust emission purifying performance
				<ul style="list-style-type: none"> • Poor exhaust emission purifying performance • Poor startability • Unstable idling • Poor acceleration
12	Air flow sensor	Air flow sensor signal frequency 10Hz or less even with engine running	(1) Defective air flow sensor (2) Open or short circuit in air flow sensor circuit, or connector in loose contact (3) Defective engine control unit	<ul style="list-style-type: none"> • Poor acceleration* • Improper idling speed* • Unstable idling*
13	Intake air temperature sensor	(1) Intake air temperature sensor signal voltage over 4.5V (2) Intake air temperature sensor signal voltage less than 0.27V	(1) Defective intake air temperature sensor (2) Open or short circuit in intake air temperature sensor circuit, or connector in loose contact (3) Defective engine control unit	<ul style="list-style-type: none"> • Somewhat poor driveability* • At high temperatures <ul style="list-style-type: none"> (a) Poor startability* (b) Unstable idling*
14	Throttle position sensor	(1) Throttle position sensor signal voltage less than 0.2V (2) Throttle position sensor signal voltage over 2V even with idle position switch at ON	(1) Throttle position sensor out of order or maladjusted (2) Open or short circuit in throttle position sensor circuit, or connector in poor contact (3) Idle position switch ON failure (4) Short circuit in idle position signal line (5) Defective engine control unit	<ul style="list-style-type: none"> • Somewhat poor acceleration • Engine stalls
				<ul style="list-style-type: none"> • Engine stalls. • Engine cannot be raced.

NOTE

* : Failsafe/backup function is in operation.

Trouble code No.	Diagnosis item	Description	Major cause	Remarks (Symptoms, etc.)
21	Engine coolant temperature sensor	(1) Engine coolant temperature sensor signal voltage over 4.6V (2) Engine coolant temperature sensor signal voltage less than 0.11V (3) Engine coolant temperature sensor signal indicates a low engine coolant temperature while the engine is in warmup operation.	(1) Defective engine coolant temperature sensor (2) Open or short circuit in engine coolant temperature sensor circuit, or connector in poor contact (3) Defective engine control unit	With engine cold ● Poor startability* ● Unstable idling* ● Poor acceleration*
22	Crank angle sensor	(1) Cranking the engine for more than four seconds does not cause the crank angle sensor signal voltage to change (go high or low). (2) Abnormal crank angle sensor signal	(1) Defective crank angle sensor (2) Open or short circuit in crank angle sensor circuit, or connector in loose contact (3) Defective cam position sensor, or connector in loose contact (4) Defective engine control unit	● Engine stalls. ● Engine cannot be started.
23	Cam position sensor	(1) Cam position sensor signal voltage does not change (go high or low) even with the engine running. (2) Abnormal top dead center signal pattern	(1) Defective cam position sensor (2) Open or short circuit in cam position sensor circuit, or connector in loose contact (3) Defective crank angle sensor, or connector in loose contact (4) Defective engine control unit	● Engine stalls.*
24	Vehicle speed sensor (reed switch)	With the engine in accelerated operation at an engine speed of over 3,000 r/min, the vehicle speed sensor signal voltage does not change (go high or low).	(1) Defective vehicle speed sensor (2) Open or short circuit in vehicle speed sensor circuit, or connector in loose contact (3) Defective engine control unit	When the vehicle is stopped with the engine in decelerated operation, the engine might stall.

NOTE

* : Failsafe/backup function is in operation.

Trouble code No.	Diagnosis item	Description	Major cause	Remarks (Symptoms, etc.)
25	Barometric pressure sensor	(1) Barometric pressure sensor signal voltage over 4.5V (2) Barometric pressure sensor signal voltage less than 0.2V	(1) Defective barometric pressure sensor (2) Open or short circuit in barometric pressure sensor circuit, or connector in loose contact (3) Defective engine control unit	● Unstable idling* ● Poor acceleration* ● Poor startability*
31	Detonation sensor <DOHC>	Abnormal detonation sensor signal voltage	(1) Defective detonation sensor (2) Open or short circuit in detonation sensor circuit, or connector in loose contact (3) Defective engine control unit	● Poor acceleration*
36	Ignition timing adjustment signal	Ignition timing adjustment signal line short-circuited to earth	(1) Ignition timing adjustment signal line short-circuited to earth (2) Defective engine control unit	● Poor acceleration ● Overheated engine
41	Injector	Injector is not driven for more than four consecutive seconds during engine cranking or idling operation	(1) Defective injector (2) Open or short circuit in injector circuit, or connector in loose contact (3) Defective engine control unit	● Poor idling ● Poor acceleration ● Poor startability
44	Ignition coil and power transistor unit for 1-4 cylinders	With the engine running, no ignition signal is input (except in cases where no ignition signal is input to all the cylinders)	(1) Defective ignition coil (2) Open or short circuit in primary ignition circuit, or connector in loose contact (3) Defective power transistor unit (4) Defective engine control unit	● Unstable idling* ● Poor acceleration* ● Poor startability*
52	Ignition coil and power transistor unit for 2-5 cylinders	With the engine running, no ignition signal is input (except in cases where no ignition signal is input to all the cylinders)	(1) Defective ignition coil (2) Open or short circuit in primary ignition circuit, or connector in loose contact (3) Defective power transistor unit (4) Defective engine control unit	● Unstable idling* ● Poor acceleration* ● Poor startability*
53	Ignition coil and power transistor unit for 3-6 cylinders	With the engine running, no ignition signal is input (except in cases where no ignition signal is input to all the cylinders)	(1) Defective ignition coil (2) Open or short circuit in primary ignition circuit, or connector in loose contact (3) Defective power transistor unit (4) Defective engine control unit	● Unstable idling* ● Poor acceleration* ● Poor startability*

NOTE

* : Failsafe/backup function is in operation.

LIST OF FAIL-SAFE/BACK-UP FUNCTIONS


When the failure of a major sensor is detected by the self diagnosis functions, the preset control logic provides controls to assure safe operation of the vehicle.

Trouble item	Controls to be provided in the event of trouble
Air flow sensor	(1) Injector basic drive timing and basic ignition timing read from the preset map based on the throttle position sensor (TPS) signal and engine speed signal (crank angle sensor signal). (2) Idle speed control servo fixed at predetermined position, and no idling speed control achieved
Intake air temperature sensor	Controls provided on the assumption that intake air temperature is 25°C (77°F)
Throttle position sensor (TPS)	No additional fuel injection provided on the basis of throttle position sensor signal at acceleration
Engine coolant temperature sensor	Controls provided on the assumption that engine coolant temperature is 80°C (176°F) (Even if the sensor signal returns to normal, this control mode is retained until the ignition switch is set to OFF.)
Cam position sensor	(1) Fuel injected into all cylinders simultaneously (Provided that no No. 1 cylinder top dead center has been detected since the ignition switch was placed in the ON position) (2) Fuel cut 4 seconds after a failure was detected (Provided that no No. 1 cylinder top dead center has been detected since the ignition switch was placed in the ON position)
Barometric pressure sensor	Controls provided on the assumption that barometric pressure is 101 kPa (758 mm Hg, 29.8 in. Hg)
Detonation sensor <DOHC>	The ignition timing is switched from the timing for super petrol to the timing for standard petrol.
Ignition coil and power transistor unit	Fuel cut for cylinders whose ignition signal is abnormal
Oxygen sensor	No air-fuel ratio feedback control (closed loop control) achieved

READ OUT OF MALFUNCTION CODE

Precautions for Operation

- (1) When battery voltage is low, no detection of failure is possible. Be sure to check the battery for voltage and other conditions before starting the test.
- (2) Diagnosis item is erased if the battery or the engine control unit connector is disconnected. Do not disconnect the battery before the diagnosis result is completely read.
- (3) Be sure to connect or disconnect the MUT-II with the ignition switch turned off.




WHEN USING THE MUT-II

Caution


Turn off the ignition switch before disconnecting or connecting the MUT-II.

- (1) Connect the MUT-II to the self-diagnosis connector.
- (2) Turn the ignition switch to ON.
- (3) Take a reading of the self-diagnosis output.
- (4) Repair the problem location, referring to the diagnosis chart.
- (5) After turning the ignition switch once to OFF, turn it back to ON.
- (6) Erase the malfunction code.
- (7) Recheck to be sure that the condition is normal.





WHEN USING THE ENGINE WARNING LAMP (CHECK ENGINE LAMP)

- (1) Use the special tool (diagnosis code check harness) to earth the diagnosis test mode control terminal (terminal ①) of the diagnosis control terminal (16 pin).
- (2) Turn the ignition switch to ON.
- (3) Take a reading of a diagnosis output according to how often the engine warning lamp flashes.
- (4) Repair the problem location, referring to the diagnostic chart.
- (5) Erase the diagnostic trouble code by the following procedure.
 - ① Turn the ignition switch to OFF.
 - ② After removing the battery cable from the battery terminals for 10 seconds or more, reconnect the cable.
 - ③ Warm up the engine and let it idle for approx. 15 minutes.
 - ④ Turn the ignition switch to ON and take a reading of the diagnostic output to check if a normal code is output.



DIAGNOSIS RESULT DISPLAY METHOD USING THE CHECK ENGINE/MALFUNCTION INDICATOR LAMP

Example of flashing patterns when diagnosis code outputs	Normal flashing pattern
<p>Diagnostic trouble code No. 24</p>  <p>6FU2060</p>	 <p>6FU2061</p>

NOTE

Other diagnosis items are also output as lamp flashing corresponding to MUT-II diagnosis code numbers.

Diagnosis by DIAGNOSIS 2 MODE

- (1) Using the MUT-II, changeover the diagnosis mode of the engine control unit to DIAGNOSIS 2 MODE.
- (2) Carry out a road test.
- (3) Read the diagnosis code in the same manner as "READ OUT OF MALFUNCTION CODE" and repair the malfunctioning part.
- (4) Turn the ignition switch OFF and then turn it ON again.

NOTE

By turning the ignition switch OFF, the engine control unit will changeover the diagnosis mode from DIAGNOSIS 2 MODE to DIAGNOSIS 1 MODE.

- (5) Erase the malfunction codes.



CHECK CHART CLASSIFIED BY PROBLEM SYMPTOMS

Problem symptoms	Starting		Idling stability		Driving				Stopping		Reference page	
	Will not start	Starting problem	Idling instability (Rough idling)	Incorrect idling speed	Improper idling continuity	Hesitation, sag	Poor acceleration	Stumble	Shock	Surge	Knocking	
Check Items												
Power Supply and Ignition Switch-IG	①①											P.13-79-34
Engine Control Unit Power Earth	②②											P.13-79-37
Fuel Pump	③③	①①		①①	①①	①①						P.13-79-38
Air Flow Sensor				⑪⑪	⑩⑩		⑤⑤	⑤⑤	④④			P.13-79-41
Intake Air Temperature Sensor			⑤		⑥⑥	⑥⑤			②②			P.13-79-46
Barometric Pressure Sensor			⑦		⑨⑨	⑦⑦			③③			P.13-79-49
Engine Coolant Temperature Sensor		③	⑥⑤	①①	⑤⑤	⑧⑧	⑥⑥	④④	③③			P.13-79-51
Throttle Position Sensor						⑦⑦	③③	④④				P.13-79-54
Idle Position Switch			③③	②②	④④							P.13-79-57
Cam Position Sensor	⑤⑤	⑥⑦			⑧⑦			②②				P.13-79-60
Crank Angle Sensor	⑥⑥	⑦⑧			⑨⑧			③③				P.13-79-64
Ignition Switch-ST <M/T>	④④	③④										P.13-79-67
Ignition Switch-ST and Inhibitor Switch <A/T>	④④	③④		⑥								P.13-79-68
Vehicle Speed Sensor					⑥			⑥				P.13-79-70
Power Steering Fluid Pressure Switch				③								P.13-79-72
Air Conditioner Switch and Power Relay				④								P.13-79-74
Detonation Sensor <DOHC>									①①			P.13-79-76
Oxygen Sensor			⑨									P.13-79-80
Injectors	⑧⑧	②②	②②		③③	②②	②②	①①	①①	①①	①	P.13-79-83
Idle Speed Control Servo (Stepper Motor)	④⑤	①①	⑥③	②②				⑧⑥				P.13-79-88
Ignition Coil and Power Transistor	⑦⑦			⑩⑨		⑦⑦		①①		⑥⑤		P.13-79-93, 99
Variable Induction Control Solenoid Valve					④④	④④						P.13-79-103
Purge Solenoid			⑧									P.13-79-105
EGR Control Solenoid Valve					⑥⑤		⑥⑥	④④				P.13-79-107
Anti-skid Brake Signal								⑦				P.13-79-109
Fuel Pressure	⑤⑥	④④		⑦⑥	③③	③③	②②		②②			P.13-79-110, 113

○ : Warm engine (figures inside the ○ indicate the checking sequence.)

□ : Cold engine (figures inside the □ indicate the checking sequence.)

PROBLEM SYMPTOMS TABLE (FOR YOUR INFORMATION)

Item		Symptom	
Starting	Won't start (no initial combustion)	The starter is used to crank the engine, but there is no combustion within the cylinders, and the engine won't start.	
	Starting problem (initial combustion, then stall)	There is combustion within the cylinders, but then the engine soon stalls.	
	(Starting takes a long time.)	Engine won't start quickly.	
Idling stability	Idling instability (Rough idling)	Engine speed doesn't remain constant; changes during idling. Usually, a judgement can be based upon the movement of the tachometer pointer, and the vibration transmitted to the steering wheel, shift lever, body, etc. This is called rough idling.	
	Incorrect idling speed	The engine doesn't idle at the usual correct speed.	
	Improper idling continuity Die out Pass out	This non-continuity of idling includes the following elements. (1) Die out The engine stalls when the foot is taken from the accelerator pedal, regardless of whether the vehicle is moving or not. (2) Pass out The engine stalls when the accelerator pedal is depressed or while it is being used.	
Driving	Hesitation Sag	"Hesitation" is the delay in response of the vehicle speed (engine r/min) that occurs when the accelerator is depressed in order to accelerate from the speed at which the vehicle is now traveling, or a temporary drop in vehicle speed (engine r/min) during such acceleration. Serious hesitation is called "sag".	 <p>Vehicle speed</p> <p>Time</p> <p>1FU0223</p>
	Poor acceleration	Poor acceleration is inability to obtain an acceleration corresponding to the degree of throttle opening, even though acceleration is smooth, or the inability to reach maximum speed.	
	Stumble	Engine r/min response is delayed when the accelerator pedal is initially depressed for acceleration from the stopped condition.	 <p>Vehicle speed</p> <p>Time</p> <p>1FU0224</p>
	Shock	The feeling of a comparatively large impact or vibration when the engine is accelerated or decelerated.	
	Surge	This is repeated surging ahead during constant speed travel or during variable speed travel.	
Stop- ping	Knocking	A sharp sound like a hammer striking the cylinder walls during driving and which adversely affects driving.	
	Run-on (Dieseling)	The engine continues to run even after the switch is turned OFF. This is called dieseling.	

SERVICE ADJUSTMENT PROCEDURES

ACCELERATOR CABLE INSPECTION AND ADJUSTMENT <VEHICLES WITHOUT AUTO-CRUISE CONTROL SYSTEM>

E13FCAZ3

Refer to P.13-14.

For models equipped with the auto-cruise control system, refer to P.13-188.

FUEL FILTER REPLACEMENT

E13FZAM

Refer to P.13-14.

FUEL GAUGE UNIT REPLACEMENT

E13FDAD

Refer to P.13-15.

2-WAY VALVE REPLACEMENT

E13FFAD

Refer to P.13-15.

FUEL PUMP OPERATION CHECK


E13FGCF

Refer to P.13-15.

HOW TO REDUCE THE FUEL LINE INTERNAL PRESSURE

E13HABH

Refer to P.13-16.



THROTTLE BODY (THROTTLE VALVE AREA) CLEANING

- (1) Start the engine and warm it up until the temperature of the engine coolant reaches 80°C (176°F) or higher; then stop the engine.
- (2) Disconnect the air intake hose at the throttle body side.
- (3) Plug the bypass intake port inlet in the throttle body.

Caution

Never let cleaning liquid get into the bypass intake.

- (4) Spray cleaning liquid (from the intake port of the throttle body) onto the valve, and then leave as is for about five minutes.
- (5) Start the engine and race it a few times; then let it run at idle speed for about one minute.


NOTE

The engine idling speed becomes unstable (or the engine stalls) if the by-pass passage is plugged, (or the engine stalls), let the engine run with the throttle valve slightly open.

- (6) If deposits are not removed from the throttle valve, repeat steps (4) and (5).
- (7) Remove the plug from the bypass intake port inlet in the throttle body.
- (8) Connect the air intake hose.
- (9) Using the MUT-II, erase the self-diagnosis code or disconnect the negative battery cable for more than 10 seconds and then connect it again.
- (10) Adjust the basic idle speed. (Refer to P.13-79-24)


NOTE

If hunting of the idling engine occurs after adjusting the basic idling speed, remove the battery (–) cable from the battery terminal for more than 10 seconds, and then idle the engine again.




IDLE POSITION SWITCH AND THROTTLE POSITION SENSOR ADJUSTMENT




- (1) Disconnect the connector of the throttle-position sensor.



- (2) Using jumper wires, connect an ohmmeter across terminal ② (idle position switch) and terminal ① (sensor earth) of the throttle position sensor.



- (3) Insert a 0.65 mm (0.0256 in.) thick thickness gauge between the fixed SAS and throttle lever.



- (4) Loosen the throttle position sensor mounting bolts and turn the throttle position sensor body fully clockwise.
- (5) In this condition, check that there is continuity across terminals ① and ②.

- (6) Slowly turn the throttle position sensor counterclockwise until you find a point at which there is no continuity across terminals ① and ②. Then, tighten the throttle position sensor mounting bolt securely.
- (7) Connect the throttle position sensor connector.

- (8) If the MUT-II is used, connect it to the diagnosis connector.
- (9) If a MUT-II is not used, perform the following operation.


- ① Disconnect the throttle position sensor's connector and make connections between the two disconnected connector valves using the special tool (test harness set).
- ② Connect a digital voltmeter between terminal ③ (sensor output) and terminal ① (sensor earth) of the throttle position sensor.

- (10) Switch ON the ignition switch.
(Do not start the engine.)

- (11) Check the output voltage of the throttle-position sensor. Note, if the MUT-II is used, that item No. 14 should be selected to get the read-out of the throttle-position sensor's output voltage.

Standard value : 400–1,000 mV

- (12) If the voltage is out of specification, check the throttle position sensor and associated harnesses.
- (13) Remove the feeler gauge.
- (14) Turn the ignition switch OFF.



FIXED SAS ADJUSTMENT

NOTE

1. The fixed SAS has been factory-adjusted. Never attempt to move it.
2. Should it be out of proper adjustment, adjust by following the procedure given below.

- (1) Sufficiently slacken the accelerator cable.
- (2) Loosen the lock nut on the fixed SAS.
- (3) Sufficiently loosen the fixed SAS by turning it counterclockwise to fully close the throttle valve.

- (4) Tighten the fixed SAS slowly to find a point at which it contacts the throttle lever (where the throttle valve starts opening). From that point, tighten the fixed SAS further $1\frac{1}{4}$ turns.
- (5) Holding the fixed SAS to prevent it from turning, tighten the lock nut securely.
- (6) Adjust the accelerator cable tension. (Refer to P.13-79-21)
- (7) Adjust the basic idle speed.
- (8) Adjust the idle position switch and throttle position sensor (TPS). (Refer to P.13-79-22)

BASIC IDLE SPEED ADJUSTMENT

NOTE

1. The basic idle speed has been factory-adjusted with the speed adjusting screw (SAS) and does not normally require adjustment.
2. If the adjustment is required, first check that the ignition plug, injector, ISC servo, and compression pressure are normal.

- (1) Before starting the inspection and adjustment procedures, set the vehicle in the following conditions:
 - Engine coolant temperature: 80 to 95°C (176 to 205°F)
 - Lamps, accessories: OFF
 - Transmission: Neutral (P for vehicles with an automatic transmission)




- (2) If the MUT-II is used, connect it to the diagnosis connector.

NOTE


When the MUT-II is connected, the diagnostic control terminal is earthed.

- (3) If the MUT-II is not used, follow the steps below.


- ① Insert a paper clip into the 1-pin connector shown in the figure at the left.
- ② Connect a primary-voltage-detection type of tachometer to the paper clip.



- ③ Use the special tool (diagnosis code check harness) to earth the diagnosis test mode control terminal (terminal (1)) of the diagnosis control terminal (16 pin).



- (4) Remove the water-resistant female connector from the ignition timing adjusting connector.
- (5) Use a jumper wire to earth the terminal for adjustment of ignition timing.



- (6) Start the engine and let it idle.
- (7) Check the standard idling speed.

Standard value: $700 \pm 50 \text{ r/min.}$

NOTE

1. The engine speed may be 20 to 100 r/min. lower than indicated above for a new vehicle (driven approximately 500 km (300 miles) or less), but no adjustment is necessary.
2. If the engine stalls or the r/min. is low even though the vehicle has been driven approximately 500 km (300 miles) or more, it is probable that deposits are adhered to the throttle valve, so clean it. (Refer to P.13-79-21)

- (8) If not within the standard value range, turn the speed adjusting screw (SAS) to make the necessary adjustment.

NOTE

If the idling speed is higher than the standard value range even when the SAS is fully closed, check whether or not there is any indication that the fixed SAS has been moved. If there is an indication that it has been moved, adjust the fixed SAS. If there are no indications that it has been moved, it is possible that there is leakage as a result of deterioration of the fast idle air valve (FIAV), and, if so, the throttle body should be replaced.


- (9) Switch OFF the ignition switch.
- (10) If the MUT-II was not used, disconnect the jumper wire from the diagnosis control terminal.
- (11) Disconnect the jumper wire from the terminal for adjustment of ignition timing, and return the connector to its original condition.
- (12) Start the engine again and let it run at idle speed for about ten minutes; check to be sure that the idling condition is normal.

ON-VEHICLE INSPECTION OF MPI COMPONENTS


COMPONENT LOCATION

<SOHC>











Name	Symbol	Name	Symbol
Air conditioner relay	G	Fuel pump check terminal	A
Air conditioner switch	R	Idle speed control servo	L
Air flow sensor (incorporating intake air temperature sensor and barometric pressure sensor)	N	Ignition coil (power transistor)	I
		Ignition timing adjustment terminal	B
Cam position sensor	H	Inhibitor switch	U
Control relay	T	Injector	D
Crank angle sensor	J	Oxygen sensor	V
Diagnosis connector	O	Power steering fluid pressure switch	M
EGR control solenoid valve	E	Purge control solenoid valve	F
Engine control unit	S	Throttle position sensor (with idle position switch)	C
Engine coolant temperature sensor	K		
Engine warning lamp (check engine lamp)	Q	Vehicle speed sensor	P















7FU1737



7FU1167































<DOHC>

Name	Symbol	Name	Symbol
Air conditioner relay	A	Idle speed control servo	L
Air conditioner switch	B	Ignition coil (power transistor)	M
Air flow sensor (incorporating intake air temperature sensor and barometric pressure sensor)	C	Ignition timing adjustment terminal	N
Cam position sensor	D	Inhibitor switch	O
Crank angle sensor	E	Injector	P
Detonation sensor	F	Oxygen sensor	Q
EGR control solenoid valve	G	Purge control solenoid valve	R
Engine control relay	H	Self-diagnosis connector	S
Engine control unit	I	Throttle position sensor (with idle position switch)	T
Engine coolant temperature sensor	J	Variable induction control solenoid valve	U
Fuel pump check terminal	K	Vehicle-speed sensor (reed switch)	V











COMPONENT INSPECTION PROCEDURE USING MUT-II

- (1) Check by the service data and actuator test function. If any abnormality is found, check the body harness, components, etc. and repair as necessary.
- (2) After repair, check again with the MUT-II to make sure that the input and output signals are now normal.
- (3) Erase the self-diagnosis malfunction code in memory.
- (4) Disconnect the MUT-II.
- (5) Start the engine and perform running test, etc. to make sure that the troubles have been corrected.

POWER SUPPLY (Control relay) AND IGNITION SWITCH-IG



OPERATION






- While the ignition switch is ON, battery power is supplied to the engine control unit, the injector, the air flow sensor, etc.
- When the ignition switch is turned ON, the battery voltage is applied from the ignition switch to the engine control unit, which then turns ON the power transistor to energize the control relay coil. This turns ON the control relay switch and the power is supplied from the battery to the engine control unit through the control relay switch.




INSPECTION

Using MUT-II

Function	Item No.	Data display	Check condition	Standard value
Data reading	16	Engine control unit power voltage	Ignition switch: ON	SV

HARNESS INSPECTION

<p>1</p>  <p>Engine control unit harness side connector</p> <p>01L0427</p>	<p>Measure the ignition switch (IG) terminal input voltage.</p> <ul style="list-style-type: none"> • Engine control unit connector: Disconnected <table border="1" data-bbox="660 358 1101 516"> <thead> <tr> <th>Ignition switch</th><th>Voltage (V)</th></tr> </thead> <tbody> <tr> <td>OFF</td><td>0-1</td></tr> <tr> <td>ON</td><td>SV</td></tr> </tbody> </table>	Ignition switch	Voltage (V)	OFF	0-1	ON	SV	<p>2</p> <p> → Repair the harness. (Ignition switch – 62) or check the ignition switch</p> <p> → or check the ignition switch</p>
Ignition switch	Voltage (V)							
OFF	0-1							
ON	SV							
<p>2</p>  <p>Harness side connector A</p> <p>1FU0808</p>	<p>Measure the power supply voltage of the control relay.</p> <ul style="list-style-type: none"> • Ignition switch: OFF • Control relay connector: Disconnected <table border="1" data-bbox="660 800 1101 895"> <thead> <tr> <th>Voltage (V)</th></tr> </thead> <tbody> <tr> <td>SV</td></tr> </tbody> </table>	Voltage (V)	SV	<p>3</p> <p> → Repair the harness. (Battery – A4, A8)</p> <p> → Repair the harness. (Battery – A4, A8)</p>				
Voltage (V)								
SV								
<p>3</p>  <p>Engine control unit harness side connector</p> <p>1FU0809</p>	<p>Check for an open-circuit, or a short-circuit to earth, between the engine control unit and the control relay.</p> <ul style="list-style-type: none"> • Engine control unit connector: Disconnected • Control relay connector: Disconnected 	<p>4</p> <p> → Repair the harness. (A6 – 38)</p> <p> → Repair the harness. (A6 – 38)</p>						
<p>4</p>  <p>Engine control unit harness side connector</p> <p>6AF0050</p>	<p>Check for an open-circuit, or a short-circuit to earth between the engine control unit and the control relay.</p> <ul style="list-style-type: none"> • Control relay connector: Disconnected • Engine control unit connector: Disconnected 	<p>5</p> <p> → Repair the harness. (A2 – 12, 25)</p> <p> → Repair the harness. (A2 – 12, 25)</p>						
<p>5</p>  <p>Engine control unit harness side connector</p> <p>6AF0051</p>	<p>Measure power voltage to the actuator.</p> <ul style="list-style-type: none"> • Control relay connector: Connected • Engine control unit connector: Connected <table border="1" data-bbox="660 1885 1101 2022"> <thead> <tr> <th>Engine</th><th>Voltage (V)</th></tr> </thead> <tbody> <tr> <td>Cranking</td><td>8V oder higher</td></tr> <tr> <td>Racing</td><td>SV</td></tr> </tbody> </table>	Engine	Voltage (V)	Cranking	8V oder higher	Racing	SV	<p> → STOP</p> <p> → Replace the control relay or defective engine control unit</p>
Engine	Voltage (V)							
Cranking	8V oder higher							
Racing	SV							



CONTROL RELAY INSPECTION

- (1) Remove the control relay.
- (2) Check for continuity between control relay terminals

Terminal No.	Continuity
5 – 7	Conductive
6 – 8	Conductive (only one direction)

- (3) Using jumper wires, connect terminal 7 of control relay to battery \oplus terminal and terminal 5 of control relay to battery \ominus terminal.

Caution

When connecting jumper wires, make sure that it is applied to correct terminal. Otherwise, the relay could be damaged.

- (4) Connecting and disconnecting the jumper wire to battery \ominus terminal, measure the voltage at terminal 1 of the control relay.

Jumper wire	Voltage
Connected	SV
Disconnected	0V


- (5) Using jumper wires, connect terminal 8 of control relay to battery \oplus terminal and terminal 6 of control relay to battery \ominus terminal.

- (6) Connecting and disconnecting the jumper wire to battery \ominus terminal, check the continuity across terminals 2 and 4 (or 3 and 4) of the control relay.


Jumper wire	Continuity across terminals 2 and 4	Continuity across terminals 3 and 4
Connected	Conductive ($0\ \Omega$)	Conductive ($0\ \Omega$)
Disconnected	Nonconductive ($\infty\ \Omega$)	Nonconductive ($\infty\ \Omega$)

- (7) Replace the control relay if any defect is evident.

ENGINE CONTROL UNIT POWER EARTH




Engine control unit



01A0191

Engine control unit connector



9FU0101

OPERATION

Earth the engine control unit.




TROUBLESHOOTING HINTS

If the earth wire of the engine control unit is not connected securely to earth, the unit will not operate correctly.


HARNESS INSPECTION

1 Engine control unit harness side connector 01P0150	Check for continuity of the earth circuit <ul style="list-style-type: none"> • Engine control unit connector: Disconnected 	→ → Repair the harness. (13 – Earth) (26 – Earth)
---	--	--

FUEL PUMP



Engine control unit connector



6AF0159

9FU0101

OPERATION

- The fuel pump is driven when the engine is cranking and while the engine is running.
- When the engine is cranking and while the engine is running, the engine control unit turns the power transistor ON to supply power to the


control relay coil. This causes the control relay switch to turn ON, and current is supplied from the ignition switch via the control relay switch to drive the fuel pump.



INSPECTION

Using MUT-II

Function	Item No.	Drive	Check condition	Check content	Normal state
Actuator test	07	Fuel pump is driven to circulate fuel	<ul style="list-style-type: none"> ● Engine cranking ● Forced drive of fuel pump Check is made for above two conditions.	Hold return hose with fingers to feel pulsation indicating fuel flow	Pulsation is felt
			Listen to pump operating sound near fuel tank	Operating sound is heard	


HARNESS INSPECTION








7

Repair the harness.
(Ⓐ1 – ⓒ1)



8

Repair the harness.
(Ⓐ1 – ⓒ2)





Control relay or engine control unit is defective.


CONTROL RELAY INSPECTION

Refer to P.13-79-36.



AIR FLOW SENSOR



16Z451




Ⓐ Harness side connector



9FU0101

Engine control unit connector



OPERATION

- The air flow sensor located in the air cleaner converts the engine intake air volume into a pulse signal of frequency proportional to the air volume and inputs it to the engine control unit, which then computes the fuel injection rate, etc. based on the input signal.
- The air flow sensor power is supplied from the control relay to the air flow sensor and is earthed in the engine control unit. The air flow sensor generates a pulse signal as it repeatedly opens and closes between the 5 V voltage supplied from the engine control unit and earth.

TROUBLESHOOTING HINTS

Hint 1: If the engine stalls occasionally, crank the engine and shake the air flow sensor harness. If the engine stalls, poor contact of the air flow sensor connector is suspected.

Hint 2: If the air flow sensor output frequency is

other than 0 when the ignition switch is turned on (but not starting the engine), faulty air flow sensor or engine control unit is suspected.

Hint 3: If the engine can be run idle even though the air flow sensor output frequency is out of specification, troubles are often found in other than the air flow sensor itself.

[Examples]

- Disturbed air flow in the air flow sensor (Disconnected air duct, clogged air cleaner element)
- Poor combustion in the cylinder (Faulty ignition plug, ignition coil, injector, incorrect compression pressure, etc.)
- Air leaking into the intake manifold through gap of gasket, etc.
- Loose EGR valve seat

INSPECTION**Using MUT-II****<Air Flow Sensor>**

Function	Item No.	Data display	Check condition	Engine state	Standard value
Data reading	12	Sensor air volume (frequency)	<ul style="list-style-type: none"> • Engine coolant temperature: 80–95°C (176–203°F) • Lamps and accessories: OFF • Transmission: Neutral 	700 r/min (Idle)	25–51 Hz <SOHC> 27–53 Hz <DOHC>
				2500 r/min <SOHC>	74–114 Hz
				2000 r/min <DOHC>	60–100 Hz
				Racing	Frequency increases with racing

NOTE


When the vehicle is new [within initial operation of about 500 km (300 miles)] the air flow sensor output frequency may be about 10% higher.

<Air Flow Sensor Reset Signal>

Function	Item No.	Data display	Check condition	Engine state	Standard value
Data list	34	Reset signal condition	<ul style="list-style-type: none"> • Warm up the engine 	700 r/min (Idle)	ON
				2500 r/min	OFF

<Volumetric Efficiency>

Function	Item No.	Data display	Check condition	Engine state	Standard value
Data list	37	Volumetric efficiency	<ul style="list-style-type: none"> • Engine coolant temperature: 80–95°C (176–203°F) • Lamps, accessory operation: OFF • Transmission: Neutral 	700 r/min (Idle)	15 – 35%
				2500 r/min	15 – 35%
				Sudden racing	Frequency increases with racing




Wave Pattern Inspection Using an Analyzer

Measurement method

- 1) Disconnect the air flow sensor connector, and connect the special tool (test harness: MB991348) in between. (All terminals should be connected.)
- 2) Connect the analyzer special patterns pickup to terminal ③ of the air flow sensor connector.


Standard wave pattern



Observation conditions

Function	Special patterns
Pattern height	Low
Pattern selector	Display
Engine r/min	Idle speed (700 r/min.)

Observation conditions (from conditions on above engine speed is increased by racing.)



7FU0880

Wave pattern observation points

Check that cycle time T becomes shorter and the frequency increases when the engine speed is increased.

Examples of abnormal wave patterns

- Example 1

Cause of problem

Sensor interface malfunction

Wave pattern characteristics

Rectangular wave pattern is output even when the engine is not started.


- Example 2

Cause of problem


Damaged rectifier or vortex generation column

Wave pattern characteristics





Unstable wave pattern with non-uniform frequency. However, when an ignition leak occurs during acceleration, the wave pattern will be distorted temporarily, even if the air flow sensor is normal.



HARNESS INSPECTION



INTAKE AIR TEMPERATURE SENSOR




Ⓐ Equipment side connector
1 2 3 4 5 6 7 8

Air flow sensor connector



Ⓐ Harness side connector
8 7 6 5 4 3 2 1

SEL1803



Intake air temperature sensor

Engine control unit connector



OPERATION

- The intake air temperature sensor converts the engine intake air temperature into a voltage and inputs it to the engine control unit, which then corrects the fuel injection rate, etc. based on the input signal.
- The 5 V power in the engine control unit is supplied via a resistor in the unit to the intake air temperature sensor. Via the sensor which is a kind of resistor, it is earthed in the engine control unit. The intake air temperature sensor resistor has such characteristic that its resistance decreases as the intake air temperature rises.

- The intake air temperature sensor terminal voltage increases or decreases as the sensor resistance increases or decreases. Therefore, the intake air temperature sensor terminal voltage changes with the intake air temperature, decreasing as the temperature rises.




TROUBLESHOOTING HINTS

The intake air temperature sensor senses the intake air temperature in the air cleaner so that it may indicate a temperature different from outside temperature depending on engine operating state.


INSPECTION**Using MUT-II**

Function	Item No.	Data display	Check condition	Intake air temperature °C (°F)	Standard value °C (°F)
Data reading	13	Sensor temperature	Ignition switch: ON or engine running	At -20 (-4)	-20 (-4)
				At 0 (32)	0 (32)
				At 20 (68)	20 (68)
				At 40 (104)	40 (104)
				At 80 (176)	80 (176)


HARNESS INSPECTION

1	<p>(A) Harness side connector</p> 	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Connector: Disconnected 	 → 2		
2	<p>(A) Harness side connector</p> 	<p>Check for open-circuit or short circuit between the intake air temperature sensor and the engine control unit.</p> <ul style="list-style-type: none"> • Air flow sensor connector: Disconnected • Engine control unit connector: Disconnected 	 → 3		
3	<p>(A) Harness side connector</p> 	<p>Measure the power supply voltage.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: ON <table border="1"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>4.5 – 4.9</td> </tr> </table>	Voltage (V)	4.5 – 4.9	 → STOP
Voltage (V)					
4.5 – 4.9					

Air flow sensor side connector



Intake air temperature sensor



SENSOR INSPECTION

- (1) Disconnect the air flow sensor connectors.
- (2) Measure resistance between terminals ⑤ and ⑥.





Temperature °C (°F)	Resistance kΩ
0 (32)	6.0
20 (68)	2.7
80 (176)	0.4

- (3) Measure resistance while heating the sensor using a hair drier.


Temperature	Resistance
Higher	Smaller

- (4) If the value deviates from the standard value or the resistance remains unchanged, replace the air flow sensor assembly.

BAROMETRIC PRESSURE SENSOR



Engine control unit connector



OPERATION

- The barometric pressure sensor converts the barometric pressure into a voltage and inputs it to the engine control unit, which then corrects the fuel injection rate, etc. based on the input signal.
- The 5 V power in the engine control unit is supplied to the barometric pressure sensor.

Through the circuit in the sensor, it is earthed in the engine control unit.

- The barometric pressure sensor output voltage which is proportional to the barometric pressure (absolute pressure) is supplied to the engine control unit.

TROUBLESHOOTING HINTS




Hint 1: If the barometric pressure sensor is faulty, poor driveability is caused at high altitude, in particular.

Hint 2: If the pressure indication of the barometric




pressure sensor drops significantly during high speed driving, check the air cleaner for clogging.

INSPECTION**Using MUT-II**

Function	Item No.	Data display	Check condition	Altitude m (ft.)	Standard value kPa (kg/cm ² , psi)
Data reading	25	Sensor pressure	Ignition switch: ON	At 0 (0)	101 (103, 14.6)
				At 600 (1968.5)	95 (0.97, 13.8)
				At 1,200 (3937.0)	88 (0.90, 12.8)
				At 1,800 (5905.5)	81 (0.83, 11.7)

HARNESS INSPECTION

ENGINE COOLANT TEMPERATURE SENSOR



<DOHC-Up to 1994 model> Coolant temperature sensor

Ⓐ Equipment side connector




<SOHC, DOHC-From 1995 model>


Ⓑ Equipment side connector



Engine control unit



Engine control unit



OPERATION

- The engine coolant temperature sensor converts the engine coolant temperature into a voltage and inputs it to the engine control unit, which then controls the fuel injection rate and fast idle speed when the engine is cold based on the input signal.
- The 5 V power in the engine control unit is supplied via a resistor in the unit to the engine coolant temperature sensor. Through the sensor harness side **ch** is a kind of resistor, it is earthed in the connector. The engine coolant temperature sensor resistor has such characteristic that its resistance decreases as the coolant temperature rises.


- The engine coolant temperature sensor terminal voltage increases or decreases as the sensor resistance increases or decreases. Therefore, the engine coolant temperature sensor terminal voltage changes with the coolant temperature, decreasing as the temperature rises.





TROUBLESHOOTING HINTS

If the fast idle speed is inadequate or the engine emits dark smoke during engine warm up operation, the engine coolant temperature sensor is often faulty.

INSPECTION**Using MUT-II**

Function	Item No.	Data display	Check condition	Coolant temperature °C (°F)	Standard value °C (°F)
Data reading	21	Sensor temperature	Ignition switch: ON or engine operating	At -20 (-4)	-20 (-4)
				At 0 (32)	0 (32)
				At 20 (68)	20 (68)
				At 40 (104)	40 (104)
				At 80 (176)	80 (176)

HARNESS INSPECTION



SENSOR INSPECTION

- (1) Remove engine coolant temperature sensor from the intake manifold.
- (2) With temperature sensing portion of engine coolant temperature sensor immersed in hot water, check resistance.




Temperature °C (°F)	Resistance kΩ
0 (32)	5.8
20 (68)	2.4
40 (104)	1.1
80 (176)	0.3

- (3) If the resistance deviates from the standard value greatly, replace the sensor.


INSTALLATION

- (1) Apply sealant to threaded portion.
Specified sealant: 3M NUT locking Part No. 4171 or equivalent
- (2) Install engine coolant temperature sensor and tighten it to specified torque.
Sensor tightening torque: 29Nm (3.0 kgm, 22 ft.lbs)
- (3) Fasten harness connectors securely.

THROTTLE POSITION SENSOR



182461



9FU0101

OPERATION

- The throttle position sensor converts the throttle position opening into a voltage and inputs it to the engine control unit, which then controls the fuel injection based on the input signal.
- The 5 V power in the engine control unit is supplied to the throttle position sensor. Through the resistor in the sensor, it is earthed in the engine control unit.
- As the throttle valve shaft rotates from the idle position to wide open position, the resistance between the variable resistor terminal of the throttle position sensor and the earth terminal increases. As a result, the voltage at the throttle position sensor variable resistance terminal also increases.

TROUBLESHOOTING HINTS

Hint 1: The throttle position sensor signal is more important in the control of automatic transmission than in the engine control. Shifting shock and other troubles will be caused if this sensor is faulty.




Hint 2: If the output voltage of the throttle position sensor is out of specification, adjust the sensor and check the voltage again. If there is an evidence of disturbed fixed SAS setting, adjust the fixed SAS.


INSPECTION

Using MUT-II

Function	Item No.	Data display	Check conditions	Throttle valve	Standard value	mV
Data reading	14	Sensor voltage	Ignition switch: left ON for 15 seconds or more	Set to idling position.	300 – 1,000	
				Open gradually.	Becomes higher proportionally to valve opening	
				Open fully.	4,500 – 5,500	


HARNESS INSPECTION

1	 <p>Ⓐ Harness side connector 1 2 3 4</p> <p>6FU1241</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> Throttle position sensor connector: Disconnected <p> → 2</p> <p> → Repair the harness. (Ⓐ1 – Ⓜ2)</p>		
2	 <p>Ⓐ Harness side connector 4 3 2 1</p> <p>Engine control unit harness side connector 61 64</p> <p>7FU1270</p>	<p>Check for an open-circuit, or a short-circuit to earth, between the engine control unit and the throttle position sensor.</p> <ul style="list-style-type: none"> Throttle position sensor connector: Disconnected Engine control unit connector: Disconnected Disconnect all other control unit connectors which are connected to the throttle position sensor. <p> → 3</p> <p> → Repair the harness. (Ⓐ3 – Ⓜ6) (Ⓐ4 – Ⓜ6)</p>		
3	 <p>Ⓐ Harness side connector 4 3 2 1</p> <p>7FU1242</p>	<p>Measure the impressed voltage.</p> <ul style="list-style-type: none"> Throttle position sensor connector: Disconnected Engine control unit connector: Connected Ignition switch: ON <table border="1" data-bbox="677 1506 1134 1590"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>4.8 – 5.2</td> </tr> </table> <p> → </p> <p> → Replace the engine control unit.</p>	Voltage (V)	4.8 – 5.2
Voltage (V)				
4.8 – 5.2				




SENSOR INSPECTION

- (1) Disconnect the throttle position sensor connector.



- (2) Measure resistance between terminal ① (sensor earth) and terminal ④ (sensor power).

Standard value: 3.5 – 6.5 kΩ



- (3) Connect a pointer type ohmmeter between terminal ① (sensor earth) and terminal ③ (sensor output).


- (4) Operate the throttle valve slowly from the idle position to the full open position and check that the resistance changes smoothly in proportion with the throttle valve opening angle.

- (5) If the resistance is out of specification, or fails to change smoothly, replace the throttle position sensor.



TPS installation torque: 2.0 Nm (0.2 kgm, 1.5 ft.lbs)

For the idle position switch and throttle position sensor adjusting procedure, refer to P.13-79-22.


IDLE POSITION SWITCH





Engine control unit



7FU0674



01Z092



Engine control unit connector



9FU0101

OPERATION

- The idle position switch senses whether the accelerator pedal is depressed or not, converts it into high/low voltage and inputs the voltage to the engine control unit, which then controls the idle speed control servo based on the input signal.
- The voltage in the engine control unit is applied to the idle position switch through a resistor. When the accelerator pedal is released, the idle position switch is turned on to conduct the

voltage to earth. This causes the idle position switch terminal voltage to go low from high.

TROUBLESHOOTING HINTS

If the idle position switch harness and individual part check results are normal but the idle position switch output is abnormal, the following troubles are suspected.




- Poorly adjusted accelerator cable or auto-cruise control cable
- Poorly adjusted fixed SAS



INSPECTION

Using MUT-II

Function	Item No.	Data display	Check condition	Throttle valve	Normal indication
Data reading	26	Switch state	Ignition switch: ON (check by operating accelerator pedal repeatedly)	At idle position	ON
				Open a little	OFF

HARNESS INSPECTION

1	 <p>Engine control unit harness side connector</p> <p>Ⓐ Harness side connector ④③②①</p> <p>6FU1243</p>	<p>Check for open or short circuit between the idle position switch and the engine control unit.</p> <ul style="list-style-type: none"> • Engine control unit connector: Disconnected • Throttle position sensor connector: Disconnected 		2		
2	 <p>Ⓐ Harness side connector ④③②①</p> <p>7FU0483</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Throttle position sensor connector: Disconnected 		3		
3	 <p>Ⓐ Harness side connector ④③②①</p> <p>7FU0489</p>	<p>Measure the power supply voltage of the idle position switch.</p> <ul style="list-style-type: none"> • Throttle position sensor connector: Disconnected • Engine control unit connector: Connected • Ignition switch: ON <table border="1" data-bbox="670 1203 1111 1287"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>4 or higher</td> </tr> </table>	Voltage (V)	4 or higher		
Voltage (V)						
4 or higher						



SENSOR INSPECTION

- With the accelerator pedal released, check to be sure that the throttle valve lever or the fixed SAS is pushed.

NOTE

If it is not pushed, adjust the fixed SAS (Refer to P.13-79-23.)

- Disconnect the throttle position sensor connector.

- Check the continuity across the throttle position sensor connector terminal ① (Sensor earth) and ② (Idle position switch).

Accelerator pedal	Continuity
Depressed	Non-conductive ($\infty\Omega$)
Released	Conductive (0 Ω)

NOTE








If there is no continuity when the accelerator pedal is returned, loosen the throttle-position sensor installation screw; then, after turning all the way in the clockwise direction, check again.

- Replace the throttle-position sensor (idle-position switch incorporated) if there is a malfunction.


NOTE

For the idle position switch and throttle position sensor adjusting procedure, refer to P.13-79-22.

CAM POSITION SENSOR




Engine control unit connector



6AF0054

OPERATION

- The cam position sensor senses the top dead center on compression stroke, converts it into a pulse signal and inputs it to the engine control unit, which then computes the fuel injection sequence, etc. based on the input signal.
- Power to the cam position sensor is supplied from the control relay and is earthed to the body. The cam position sensor generates a pulse signal as it repeatedly connects and disconnects between 5 V voltage supplied from the engine control unit and earth.

INSPECTION**Waveform inspection with analyzer****TROUBLESHOOTING HINTS**

Hint 1: If the cam position sensor does not function correctly, correct sequential injection is not made so that the engine may stall, run irregularly at idle or fail to accelerate normally.

Hint 2: If the sensor outputs a pulse signal when the ignition switch is turned ON (with the engine no running), a faulty cam position sensor or engine control unit is suspected.


Measuring method

- (1) Disconnect the connector of the cam position sensor, and connect the special tool (test harness: MB991348) across the disconnected connector parts. (Connect the tool to all terminals.)
- (2) Connect the special patterns pick-up of the analyzer to the terminal ② of the cam position sensor connector (in order to inspect the signal waveform of the cam position sensor.)
- (3) Disconnect the connector of the crank angle sensor, and connect the special tool (test harness: MD998478) across the disconnected connector parts.
- (4) Connect the special patterns pick-up of the analyzer to the terminal ② of the crank angle sensor connector (in order to inspect the signal waveform of the crank angle sensor).


Standard waveform

Observation conditions

Function	Special patterns
Pattern height	Low
Pattern selector	Display
Engine speed	Idling speed (700 r/min)

**Waveform observing point**

Confirm that cycle T becomes shorter as the engine speed increases.

**Abnormal waveform example**


- Example 1

Trouble cause

The sensor interface is troubled.

Waveform feature

The engine does not start, but the rectangular waveform is output.



● Example 2

Trouble cause

The timing belt is loose.

The sensor disc is abnormal.






Waveform feature

The waveform fluctuates fore and aft.

HARNESS INSPECTION

<p>1</p> <p>Ⓐ Harness side connector Ⓑ Control relay harness side connector</p> <p>6AF0056</p>	<p>Check for continuity between the cam position sensor and control relay.</p> <ul style="list-style-type: none"> Cam position sensor connector: Disconnected Control relay connector: Disconnected <p>NOTE Touch ohmmeter probes to both ends of the harness.</p>	<p>OK → 2</p> <p>OK → Repair the harness. (Ⓐ 3 – Ⓑ 3)</p>		
<p>2</p> <p>Ⓐ Harness side connector</p> <p>6AF0057</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> Cam position sensor connector: Disconnected 	<p>OK → 3</p> <p>OK → Repair the harness. (Ⓐ 1 – Earth)</p>		
<p>3</p> <p>Ⓐ Harness side connector Ⓑ Engine control unit harness side connector</p> <p>6AF0058</p>	<p>Check for an open-circuit, or a short-circuit to earth between the cam position sensor and the engine control unit.</p> <ul style="list-style-type: none"> Engine control unit connector: Disconnected Cam position sensor connector: Disconnected 	<p>OK → 4</p> <p>OK → Repair the harness. (Ⓐ 2 – 68)</p>		
<p>4</p> <p>Harness side connector</p> <p>6AF0059</p>	<p>Measure the impressed voltage</p> <ul style="list-style-type: none"> Cam position sensor connector: Disconnected Engine control unit connector: Connected Ignition switch: ON <table border="1"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>4.8 – 5.2</td> </tr> </table>	Voltage (V)	4.8 – 5.2	<p>OK → STOP</p> <p>OK → Replace the engine control unit.</p>
Voltage (V)				
4.8 – 5.2				

CRANK ANGLE SENSOR



7FU0682

6AF0060

Engine control unit connector



9FU0101

OPERATION

- The crank angle sensor senses the crank angle (piston position) of each cylinder, converts it into a pulse signal and inputs it to the engine control unit, which then computes the engine speed and controls the fuel injection timing and ignition timing based on the input signal.
- Power to the crank angle sensor is supplied from the control relay and is earthed to the body. The crank angle sensor generates a pulse signal as it repeatedly connects and disconnects between 5 V voltage supplied from the engine control unit and earth.

TROUBLESHOOTING HINTS

Hint 1: If unexpected shocks are felt during driving or the engine stalls suddenly during idling, shake the crank angle sensor harness. If this causes the engine to stall, poor contact of the sensor connector is suspected.

Hint 2: If the crank angle sensor outputs a pulse signal when the ignition switch is turned ON (with the engine not running), a faulty crank angle sensor or engine control unit is suspected.

Hint 3: If the tachometer reads 0 r/min when the engine that has failed to start is cranked, faulty crank angle sensor or broken timing belt is suspected.

Hint 4: If the tachometer reads 0 r/min when the engine that has failed to start is cranked, the primary current of the ignition coil is not turned on and off. Therefore, troubles in the ignition circuit and ignition coil or faulty power transistor is suspected.

Hint 5: If the engine can be run at idle even though the crank angle sensor reading is out of specification, troubles are often in other than the crank angle sensor.

[Examples]

- Faulty engine coolant temperature sensor
- Faulty idle speed control servo
- Poorly adjusted reference idle speed

INSPECTION**Using MUT-II**

Function	Item No.	Data display	Check condition	Check content	Normal state
Data reading	22	Cranking speed	<ul style="list-style-type: none"> Engine cranking Tachometer connected 	Compare cranking speed and MUT-II reading	Indicated speed to agree

NOTE









- The tachometer indicates a third of the actual engine speed. Therefore, 3 times the tachometer indication is the actual engine speed.
- When the tachometer is set to the 2-cylinder range, it indicates actual engine speed.

Function	Item No.	Data display	Check condition	Coolant temperature °C (°F) standard value r/min.	
Data reading	22	Idle speed	<ul style="list-style-type: none"> Engine: Running at idle Idle position switch: ON 	At -20 (-4)	1275-1475
				At 0 (32)	1225-1425
				At 20 (68)	1100-1300
				At 40 (104)	950-1150
				At 80 (176)	600-800

Waveform inspection with analyzer


Refer to cam position sensor section (P.13-79-60.)

HARNESS INSPECTION


1  (B) Control relay harness side connector	 Harness side connector (A)  (2) Harness side connector	<p>Check for continuity between the crank angle sensor and the control relay.</p> <ul style="list-style-type: none"> • Crank angle sensor connector: Disconnected • Control relay connector: Disconnected <p>NOTE Touch ohmmeter probes to both ends of the harness</p>	 OK → 2  OK → Repair the harness. (A) (3) – (B) (3)		
2  (A) Harness side connector	 (A) Harness side connector	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Crank angle sensor connector: Disconnected 	 OK → 3  OK → Repair the harness. (A) (1) – Earth		
3  (A) Harness side connector	 (A) Harness side connector	<p>Check for an open-circuit, or a short-circuit to earth between the crank angle sensor and the engine control unit.</p> <ul style="list-style-type: none"> • Engine control unit connector: Disconnected • Crank angle sensor connector: Disconnected 	 OK → 4  OK → Repair the harness. (A) (2) – (69)		
4  (A) Harness side connector	 (A) Harness side connector	<p>Measure the impressed voltage.</p> <ul style="list-style-type: none"> • Crank angle sensor connector: Disconnected • Engine control unit connector: Connected • Ignition switch: ON <table border="1" data-bbox="644 1601 1077 1685"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>4.8–5.2</td> </tr> </table>	Voltage (V)	4.8–5.2	 OK → STOP  OK → Replace the engine control unit.
Voltage (V)					
4.8–5.2					

IGNITION SWITCH-ST [M/T only]

Engine control unit connector



9FU0101



1FU0638

OPERATION


- The ignition switch-ST inputs a high signal to the engine control unit while the engine is cranking. The engine control unit provides fuel injection control, etc., at engine startup based on this signal.
- When the ignition switch is set to START, the battery voltage at cranking is applied through the ignition switch to the engine control unit, which detects that the engine is cranking.

INSPECTION



Using MUT-II

Function	Item No.	Data display	Check condition	Engine	Normal indication
Data reading	18	Switch state	Ignition switch: ON	Stop	OFF
				Cranking	ON


HARNESS INSPECTION



IGNITION SWITCH-ST AND INHIBITOR SWITCH [A/T only]



Engine control unit connector



OPERATION

- The ignition switch-ST inputs a high signal to the engine control unit while the engine is cranking. The engine control unit provides fuel injection control, etc., at engine startup based on this signal.
- When the ignition switch is set to START, the battery voltage at cranking is applied through the ignition switch and inhibitor switch to the engine control unit, which detects that the engine is cranking. In case the selector lever is in a position other than the P/N range, the battery voltage is not applied to the engine control unit.
- The inhibitor switch converts the selector lever position (whether it is at the P/N range or at others) into high/low voltage and inputs it to the engine control unit, which then controls the idle speed control servo based on this signal.

- The battery voltage in the engine control unit is applied through a resistor to the inhibitor switch. When the selector lever is set to the P/N range, continuity is produced between the inhibitor switch terminal of the engine control unit and earth through the starter motor, thereby making the terminal voltage go low.

TROUBLESHOOTING HINTS




If the inhibitor switch harness and individual part check have resulted normal but the inhibitor switch output is abnormal, poorly adjusted control cable is suspected.

INSPECTION**Using MUT-II****IGNITION SWITCH-ST**

Function	Item No.	Data display	Check condition	Engine	Normal indication
Data reading	18	Switch state	Ignition switch: ON	Stop	OFF
				Cranking	ON

INHIBITOR SWITCH


Function	Item No.	Data display	Check condition	Select lever position	Normal indication
Data reading	29	Shift position	Ignition switch: ON	P or N	P or N
				D, 2, L or R	D, 2, L or R

HARNESS INSPECTION**INHIBITOR SWITCH INSPECTION**


Refer to GROUP 23 – Service Adjustment Procedures.

VEHICLE SPEED SENSOR


Vehicle speed sensor



16W1506




16Z478



16Z451


Engine control unit



Ⓐ Equipment side connector



Vehicle speed sensor (Inside speedometer)



Ⓐ 1


Ⓐ 43

7FU1533

Ⓑ Equipment side connector



Engine control unit connector



9FU0101

OPERATION

- The vehicle-speed sensor is incorporated within the speedometer; it converts vehicle-speed data to pulse signals and inputs those signals to the engine control unit. The engine control unit, based upon those signals, regulates the idle-speed servo, etc.
- The vehicle-speed sensor, by intermitting the flow (to earth) of the approxi-


mately 5V voltage applied from the engine control unit, produces vehicle-speed signals.

TROUBLESHOOTING HINTS

If there is damaged or disconnected wiring, or a short-circuit, of the vehicle-speed sensor signal circuit, the engine may stall when the vehicle speed is reduced and the vehicle is stopped.

HARNESS INSPECTION

1




Engine control unit harness side connector

01A0508

Check the vehicle speed sensor output circuit for continuity.

- Engine control unit connector: Disconnected.
- Move the vehicle.




4



2


REVISED




SENSOR INSPECTION

Refer to GROUP 54 – Meters and Gauges.

POWER STEERING FLUID PRESSURE SWITCH



Engine control unit




37

Power steering fluid pressure switch


Ⓐ Harness side connector

1



01L0435

7FU0536



OPERATION

- The power steering fluid pressure switch converts presence/absence of power steering load into low/high voltage and inputs it to the engine control unit, which then controls the idle speed control servo based on this signal.
- The battery voltage in the engine control unit is applied through a resistor to the power steering



fluid pressure switch. Steering operation causes the power steering fluid pressure to increase, turning the switch on. As a result, continuity is produced between the battery voltage applied and earth. This causes the power steering fluid pressure terminal voltage to go from high to low.

INSPECTION**Using MUT-II**

Function	Item No.	Data display	Check condition	Steering wheel	Normal indication
Data reading	27	Switch state	Engine: Idling	Steering wheel neutral position (wheels straight-ahead direction)	OFF
				Steering wheel half turn	ON



Checking Fluid Pressure

Steering wheel	Fluid pump delivery pressure (ref. value)
Straight forward	kPa (kg/cm ² , psi) 686–1,177 (7–12, 100–171)
Turned	kPa (kg/cm ² , psi) 1,471–1,961 (15–20, 213–284)


HARNESS INSPECTION**SENSOR INSPECTION**

Refer to GROUP 37 – Service Adjustment Procedures.


AIR CONDITIONER SWITCH AND POWER RELAY



Engine control unit connector



9FU0101



7FU0821

OPERATION

- The air conditioner switch applies battery voltage to the engine control unit when the air conditioner is switched ON.
- When the air conditioner signals are input, the engine control unit activates the idle-speed control servo, and also switches ON the power transistor. As a result, current flows to the power relay coil and the relay switch is switched ON; the air conditioner compressor's magnetic clutch is activated.

TROUBLESHOOTING HINTS

If the air conditioner compressor's magnetic clutch is not activated when the air conditioner switch is switched ON during idling, it is probable that the cause is a malfunction of the air conditioner control system.

INSPECTION

Using MUT-II


Air conditioner switch

Function	Item No.	Data display	Check conditions	Air conditioner switch	Normal display
Data reading	28	Switch status	<ul style="list-style-type: none"> • Engine idling (The air conditioner compressor should be activated when the air conditioner switch is switched ON.) 	OFF	OFF
				ON	ON

Air conditioner power relay

Function	Item No.	Data display	Check conditions	Air conditioner switch	Normal display
Data reading	49	Air conditioner power relay status	<ul style="list-style-type: none"> • Engine: idling after warm up 	OFF	OFF (Compressor clutch non-activation)
				ON	ON (Compressor clutch activation)



HARNESS INSPECTION




AIR CONDITIONER INSPECTION

Refer to GROUP 55.

DETONATION SENSOR <DOHC>



Engine control unit connector



9FU0101

OPERATION



The detonation sensor generates a voltage proportional to the magnitude of cylinder block vibration due to knocking and inputs it to the engine control unit. Based on this signal, the engine control unit provides retard control of the ignition timing.

TROUBLESHOOTING HINTS



When knocking occurs while driving under high-load conditions, the following problems are suspected in addition to the detonation sensor itself.

- (1) Inappropriate ignition plug heat range
- (2) Inappropriate gasoline
- (3) Incorrectly adjusted reference ignition timing


HARNESS INSPECTION

1	 <p>Engine control unit harness side connector</p> <p>④ Harness side connector</p> <p>7FU0906</p>	<p>Check for an open-circuit or a short-circuit to earth, between the engine control unit and detonation sensor.</p> <ul style="list-style-type: none"> • Detonation sensor connector: Disconnected • Engine control unit connector: Disconnected 	 <p>OK → 2</p>  <p>OK → Repair the harness. (④ 1 – ⑤ 8)</p>
2	 <p>④ Harness side connector</p> <p>6FU1302</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Connector: Disconnected 	 <p>OK → STOP</p>  <p>OK → Repair the harness. (④ 2 – Earth)</p>

ELECTRICAL LOAD SWITCH <DOHC>




Engine control unit connector



9FU0101

Engine control unit



7FU0688

OPERATION




- The electrical load switch inputs ON/OFF state of the switch of equipment that consumes much power during idling, namely, equipment with a large electrical load, to the engine control unit. Based on this signal, the engine control unit controls the idle-speed control servo.
- When the switch of equipment with a large electrical load is turned ON, the battery voltage is applied to the engine control unit to indicate that the equipment switch is turned ON.

INSPECTION




Using MUT-II

Function	Item No.	Data display	Check condition	Equipment state	Normal display
Data reading	33	Switch state	Operation of equipment: OFF	Lighting switch only: OFF → ON	OFF → ON
				Rear defogger switch only: OFF → ON	OFF → ON
				Brake pedal only: depressed → Released	ON → OFF

HARNESS INSPECTION

<p>1</p>  <p>7FU0689</p>	<p>Measure the input voltage of engine control unit.</p> <ul style="list-style-type: none"> • Engine control unit connector: Disconnected • Lighting switch: ON (Tail lamp relay ON) <table border="1" data-bbox="665 381 1111 486"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>SV</td> </tr> </table>	Voltage (V)	SV	<p>OK → 2</p> <p>OK → Check circuit related to tail lamp relay</p>
Voltage (V)				
SV				
<p>2</p>  <p>7FU0689</p>	<p>Measure the input voltage of engine control unit.</p> <ul style="list-style-type: none"> • Engine control unit connector: Disconnected • Defogger switch: ON (Defogger relay ON) <table border="1" data-bbox="665 760 1111 865"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>SV</td> </tr> </table>	Voltage (V)	SV	<p>OK → 3</p> <p>OK → Check circuit related to defogger relay</p>
Voltage (V)				
SV				
<p>3</p>  <p>7FU0689</p>	<p>Measure the input voltage of engine control unit.</p> <ul style="list-style-type: none"> • Engine control unit connector: Disconnected • Brake pedal: Depressed (Stop lamp switch ON) <table border="1" data-bbox="665 1139 1111 1245"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>SV</td> </tr> </table>	Voltage (V)	SV	<p>OK → STOP</p> <p>OK → Check circuit related to stop lamp relay</p>
Voltage (V)				
SV				

OXYGEN SENSOR



Engine control unit connector



9FU0101

OPERATION

- The oxygen sensor functions to detect the concentration of oxygen in the exhaust gas; it converts those data to voltage, and inputs the resulting signals to the engine control unit.
- If the air/fuel mixture ratio is richer than the theoretical air/fuel mixture ratio (i.e., if the concentration of oxygen in the exhaust gas is sparse), a voltage of approximately 1V is output; if the air/fuel mixture ratio is leaner than the theoretical air/fuel mixture ratio (i.e., if the concentration is dense), a voltage of approximately 0V is output.
- The engine control unit, based upon those signals, regulates the amount of fuel injection so that the air/fuel mixture ratio becomes the theoretical air/fuel mixture ratio.
- Battery power supply is applied, by way of the control relay, to the oxygen sensor heater. As a result, the sensor element is heated by the heater, so that the oxygen sensor shows excellent response even if the temperature of the exhaust gas is low.

TROUBLESHOOTING HINTS

Hint 1: The exhaust gas purification performance will worsen if there is a malfunction of the oxygen sensor.

Hint 2: If the oxygen sensor output voltage deviates from the standard value even though the results of the checking of the oxygen sensor are normal, the cause is probably a malfunction of a component related to air/fuel mixture ratio control.

[Examples]




- (1) Malfunction of an injector.
- (2) Air leakage into the intake manifold from a leaking gasket.
- (3) Malfunction of the air-flow sensor, the intake air temperature sensor, the barometric-pressure sensor, or the engine coolant temperature sensor.

INSPECTION


Using MUT-II

Function	Item No.	Data display	Check conditions	Engine condition r/min.	Standard value mV
Data reading	11	Sensor detection voltage	● Engine: warm-up (Make the mixture lean by engine speed reduction, and rich by racing.)	When sudden deceleration from 4,000	200 or lower
				When engine is suddenly raced	600 – 1,000
			● Engine: warm up using the oxygen sensor signal, check the air/fuel mixture ratio, and also check the condition of control by the engine control unit	700 (Idling)	400 or lower ↓ (changes) 600 – 1,000 2,000


HARNESS INSPECTION



SENSOR INSPECTION



- (1) Disconnect the oxygen sensor connector.
- (2) Check that there is continuity [approx. $20\ \Omega$ at 20°C (68°F)] between oxygen sensor connector terminal ① and terminal ③.
- (3) If there is no continuity, replace the oxygen sensor.



- (4) Warm the engine until the engine coolant temperature reaches 80°C (176°F) or more.
- (5) Use the jumper leads to connect the oxygen sensor terminal ① (connect (+) terminal) and terminal ③ (connect (-) terminal) to the battery (+) and (-) terminals respectively.

Caution

Be careful when connecting the jumper leads, as connecting the terminals incorrectly will damage the oxygen sensor.





- (6) Connect a digital-type voltmeter to terminal ② and terminal ④.
- (7) While repeatedly racing the engine, measure the oxygen sensor output voltage.

Engine	Oxygen sensor output voltage	Notes
When racing the engine	0.6–1.0V	When the air/fuel mixture ratio is enriched by racing the engine repeatedly, a normal oxygen sensor will output a voltage of 0.6–1.0V.


NOTE

For removal and installation of the oxygen sensor, refer to GROUP 15 – Exhaust Pipe, Main Muffler and Catalytic Converter.

INJECTORS



Engine control unit connector



OPERATION

- The injectors are electromagnetic-valve-equipped injection nozzles that function to inject fuel based upon injection signals from the engine control unit.
- Because the surface area of the injection ports is fixed and because the pressure of the fuel relative to the pressure within the manifold is also regulated to a fixed pressure, the amount of fuel injection by injectors is determined by the length

of time that the needle valve is open, or, in other words, by the length of time of current flow to the solenoid coil.

- Battery power supply is supplied, by way of the control relay, to the injectors. When the engine control unit switches ON the power transistor within the unit and current flows to the solenoid coil, the injectors open and fuel is injected.

TROUBLESHOOTING HINTS

Hint 1: If there is a problem with starting while the engine is warm, perform the combustion test and check for leakage of the injectors.

Hint 2: If the engine can't be started, and the injectors are not activated during cranking, the cause is probably a malfunction such as described below, not with the injectors.

- (1) Malfunction of the circuit for supply of power to the engine control unit, or of the earth circuit.
- (2) Malfunction of the control relay.
- (3) Malfunction of the crank-angle sensor and/or the top dead center sensor.

Hint 3: If there is a cylinder for which the idling condition does not change when, during idling, the fuel injection of the injectors is cut off in sequence, check that cylinder as described below.

- (1) Check the injector and harness.
- (2) Check the spark plugs and the high-tension cable.
- (3) Check the compression pressure.

Hint 4: If the injector activation time deviates from the standard value even though the results of the checking of the injector's harness and of the injector itself are normal, the cause may be presumed to be one of the following.

- (1) Incomplete combustion within the cylinder. (Malfunction of the spark plugs, the ignition coil, the compression pressure, etc.)
- (2) Improper adhesion of EGR valve seat.
- (3) Increased engine resistance.

INSPECTION

Using MUT-II

Function	Item No.	Data Display	Check conditions	Engine coolant temperature °C (°F)	Standard value ms
Data reading	41	Activation time* ¹	Engine cranking	When 0* ² (32) 15–18 <DOHC>	15.5–19 <SOHC> 15–18 <DOHC>
				When 20 (68)	38–46.5 <SOHC> 42–51 <DOHC>
				When 80 (176)	10–12 <SOHC> 9–11 <DOHC>

Function	Item No.	Data Display	Check conditions	Engine condition r/min.	Standard value ms
Data reading	41	Activation time* ³	<ul style="list-style-type: none"> ● Engine coolant temperature: 89–95°C (185–205°F) ● Lamps and accessories: OFF ● Transmission: neutral (P range for vehicles with A/T) ● Steering wheel: neutral position 	700 (idling)	2.6–3.8 <SOHC> 2.3–3.5 <DOHC>
				2,500 <SOHC>	2.3–3.5
				2,000 <DOHC>	2.0–3.2
				When raced suddenly	Increases


NOTE

*¹ : Indicates the injector-activation time when the power source voltage is 11V and the cranking speed is 250 r/min or less.

*² : At a coolant temperature of 0°C (32°F), there is synchronous injection for all six cylinders.

*³ : For a new vehicle [driven approximately 500 km (300 miles) or less] the injector-activation may be about ten percent longer than indicated above.

Function	Item No.	Drive content	Check condition	Normal condition
Actuator test	01	No. 1 injector shut off	Engine: Idling after warm-up (Shut off the injectors in sequence during after engine warm-up, check the idling condition)	Idle state to change further (becoming less stable or stalling)
	02	No. 2 injector shut off		
	03	No. 3 injector shut off		
	04	No. 4 injector shut off		
	05	No. 5 injector shut off		
	06	No. 6 injector shut off		




Wave Pattern Inspection Using An Analyzer

- Remove the injector intermediate connector and connect the special tool (harness connector: MD998474).
- Connect the probe of an oscilloscope as follows.

	No. 1 cylinder	No. 2 cylinder	No. 3 cylinder	No. 4 cylinder	No. 5 cylinder	No. 6 cylinder
Male connector terminal No.	3	2	1	7	6	5
Clip colour (lead wire)	Green (Green/black)	White (White)	Blue (Blue)	Yellow (Yellow)	Red (Red)	Black (Black)

Standard wave pattern



Observation conditions


Function	Special patterns
Pattent height	Variable
Variable knob pattern selector	Display
Engine r/min.	Idle speed (700 r/min.)

Wave pattern observation points

(Point A): Height of back electromotive force in the solenoid coil






Contrast with standard wave pattern	Probable cause
Solenoid coil back electromotive force is low or doesn't appear at all.	Short in the injector solenoid

(Point B): Injector drive time



- The injector drive timing will synchronize with the MUT-II display.
- When the engine is suddenly raced, the drive time will be greatly extended at first, but the drive time will soon match the engine speed.

HARNESS INSPECTION



ACTUATOR INSPECTION

Measuring Resistance Between Terminals

(1) Disconnect the injector intermediate harness connector.



(2) Measure resistance value between terminals.

Injector	Terminals	Resistance value
No. 1	8-3	
No. 2	8-2	
No. 3	8-1	
No. 4	8-7	
No. 5	8-6	
No. 6	8-5	
		13 – 16 Ω


(3) Connect the injector intermediate harness connector.

Checking the Injection Condition


- (1) Following the steps below, bleed out the residual pressure within the fuel pipe line to prevent flow of the fuel. (Refer to P.13-79-16.)
- (2) Remove the injector.
- (3) Arrange the special tool (injector test set), adaptor, fuel pressure regulator and clips as shown in the illustration below.



- (4) Connect the battery's negative (-) terminal.
- (5) Apply battery voltage to the fuel pump check terminal and activate the fuel pump.



- (6) Activate the injector and check the atomized spray condition of the fuel. The condition can be considered satisfactory unless it is extremely poor.






- (7) Stop the actuation of the injector, and check for leakage from the injector's nozzle.


Standard value: 1 drop or less per minute

- (8) Activate the injector without activating the fuel pump; then, when the spray emission of fuel from the injector stops, disconnect the special tool and restore it to its original condition.

IDLE SPEED CONTROL SERVO (STEPPER MOTOR TYPE)



Engine control unit connector



9FU0101

OPERATION

- The intake air volume during idling is controlled by opening or closing the servo valve provided in the air path that bypasses the throttle valve.
- The servo valve is opened or closed by operating the stepper motor in the speed control servo in normal or reverse direction.
- The battery power is supplied to the stepper motor through the control relay. As the engine control unit turns on power transistors in the unit one after another, the stepper motor coil is energized and the motor rotates in normal or reverse direction.

TROUBLESHOOTING HINTS

Hint 1: If the stepper motor step increases to 100 to 120 steps or decreases to 0 step, faulty

stepper motor or open circuit in the harness is suspected.

Hint 2: If the idle speed control servo harness and individual part checks have resulted normal but the stepper motor steps are out of specification, the following faults are suspected.


- (1) Poorly adjusted reference idle speed
- (2) Deposit on the throttle valve
- (3) Air leaking into the intake manifold through gasket gap
- (4) Loose EGR valve seat
- (5) Poor combustion in the cylinder (faulty ignition plug, ignition coil, injector, low compression pressure, etc.)

INSPECTION**Using MUT-II**

Function	Item No.	Data display	Check condition	Load state	Standard value
Data reading	45	Stepper motor steps	<ul style="list-style-type: none"> Engine coolant temperature: 80–95°C (176–205°F) Lamps, accessory units: All OFF Transmission: Neutral Idle position switch: ON (compressor clutch to be ON if air conditioner switch is ON) Engine: Idling 	Air conditioner switch: OFF	2–25 steps
				Air conditioner switch: ON	Increase by 10–70 steps

NOTE

When the vehicle is new [within initial operation of about 500 km (300 miles)], the stepper motor steps may be about 30 steps more than standard.




Wave Pattern Inspection Using an Analyzer

Measurement method

- Disconnect the stepper motor connector, and connect the special tool (test harness: MB998463) in between.
- Connect the analyzer special patterns pickup to the stepper motor-side connector terminal ① (red clip on the special tool), terminal ③ (blue clip), terminal ④ (black clip) and terminal ⑥ (yellow clip) respectively.

Standard wave pattern**Observation conditions**

Function	Special patterns
Pattern height	High
Pattern selector	Display
Engine condition	<p>Turn the ignition switch from OFF to ON (without starting the engine).</p> <p>While the engine is idling, turn the air conditioner switch to ON.</p> <p>Immediately after starting the warm engine (approx. 1 minute).</p>



Wave pattern observation points


Check that the standard wave pattern appears when the stepper motor is operating.

(Point A): Presence or absence of induced electromotive force from the motor turning. (Refer to the abnormal wave pattern.)

Contrast with standard wave pattern	Probable cause
Induced electromotive force does not appear or is extremely small.	Motor is malfunctioning

(Point B): Height of coil reverse electromotive force

Contrast with standard wave pattern	Probable cause
Coil reverse electromotive force does not appear or is extremely small.	Short in the coil



Abnormal wave pattern



Cause of problem


Motor is malfunctioning. (Motor is not operating.)

Wave pattern characteristics

Induced electromotive force from the motor turning does not appear.

HARNESS INSPECTION

<p>1</p>  <p>(A) Harness side connector</p> <p>(B) Control relay harness side connector</p> <p>6AF0070</p>	<p>Check for continuity between the idle speed control servo and the control relay.</p> <ul style="list-style-type: none"> • Idle speed control servo connector: Disconnected • Control relay connector: Disconnected <p>NOTE Touch the ohmmeter probes to both ends of the harness.</p>	<p>OK → 2</p> <p>OK → Repair the harness. (A[2] – B[3])</p>
<p>2</p>  <p>(A) Harness side connector</p> <p>01L0397</p>	<p>Check for an open-circuit, or a short-circuit to earth between the engine control unit and the idle speed control servo.</p> <ul style="list-style-type: none"> • Engine control unit connector: Disconnected • Idle speed control servo connector: Disconnected 	<p>OK → STOP</p> <p>OK → Repair the harness. (A[1] – A[4]) (A[3] – A[17]) (A[4] – A[5]) (A[6] – A[18])</p>



ACTUATOR INSPECTION

Checking the Operation Sound

- (1) Check that the operation sound of the stepper motor can be heard after the ignition is switched ON (but without starting the motor).
- (2) If the operation sound cannot be heard, check the stepper motor's activation circuit.
If the circuit is normal, it is probable that there is a malfunction of the stepper motor or of the engine control unit.


Checking the Coil Resistance


- (1) Disconnect the idle speed control servo connector and connect the special tool (test harness).
- (2) Measure the resistance between terminal ② (white clip of the special tool) and either terminal ① (red clip) or terminal ③ (blue clip) of the connector at the idle speed control servo side.

Standard value: 28–33 Ω [at 20°C (68°F)]

- (3) Measure the resistance between terminal ⑤ (green clip of the special tool) and either terminal ⑥ (yellow clip) or terminal ④ (black clip) of the connector at the idle speed control servo side.


Standard value: 28–33 Ω [at 20°C (68°F)]






Operation Check

- (1) Remove the throttle body.
- (2) Remove the stepper motor.



- (3) Connect the special tool (test harness) to the idle speed control servo connector.

- (4) Connect the positive $+$ terminal of a power supply (approx. 6 V) to the white clip and the green clip.




- (5) With the idle speed control servo as shown in the illustration, connect the negative $-$ terminal of the power supply to each clip as described in the following steps, and check whether or not a vibrating feeling (a feeling of very slight vibration of the stepper motor) is generated as a result of the activation of the stepper motor.

- ① Connect the negative $-$ terminal of the power supply to the red and black clip.
- ② Connect the negative $-$ terminal of the power supply to the blue and black clip.
- ③ Connect the negative $-$ terminal of the power supply to the blue and yellow clip.
- ④ Connect the negative $-$ terminal of the power supply to the red and yellow clip.
- ⑤ Connect the negative $-$ terminal of the power supply to the red and black clip.
- ⑥ Repeat the tests in sequence from ⑤ to ①.

- (6) If, as a result of these tests, vibration is detected, the stepper motor can be considered to be normal.

IGNITION COIL AND IGNITION POWER TRANSISTOR <SOHC>





⑧ Equipment side connector




Power transistor unit

Tachometer


Engine control unit



7FU1741



Engine control unit connector



OPERATION

- When the power transistor unit A is turned ON by the signal from the engine control unit, primary current flows to the ignition coil A. When the power transistor unit A is turned OFF, the primary current is shut off and a high voltage is induced in the secondary coil A, causing the ignition plugs of No. 1 and No. 4 cylinders to spark. When the power transistor unit B is turned OFF, the ignition plugs of No. 2 and No. 5 cylinders

spark. In addition, when the power transistor unit C is turned OFF, the ignition plugs of No. 3 and No. 6 cylinders spark.

- When the engine control unit turns OFF the transistor in the unit, the battery voltage in the unit is applied to the power transistor unit to turn it ON. When the engine control unit turns ON the transistor in the unit, the power transistor unit is turned OFF.

INSPECTION**Using MUT-II****<Spark Advance>**


Function	Item No.	Data display	Check condition	Engine state	Standard value
Data reading	44	Ignition advance	<ul style="list-style-type: none"> Engine: Warming up Timing lamp: Set (set timing lamp to check actual ignition timing) 	700 r/min (Idle)	7–23° BTDC
				2,500 r/min	27–47° BTDC

<Ignition Timing Adjustment Mode>

Function	Item No.	Data display	Check condition	Terminal condition	Standard value
Data list	36	Continuity present or not present between ignition timing adjustment terminal and earth	<ul style="list-style-type: none"> Engine: Idling 	Ignition timing adjustment terminal is earthed	ON
				Ignition timing adjustment terminal is disconnected from earth	OFF

<Standard Ignition Timing>

Function	Item No.	Drive	Check condition	Normal condition
Actuator test	17	Set to ignition timing adjustment mode	<ul style="list-style-type: none"> Engine: idling Timing lamp: set 	5° BTDC ± 3°

**Wave Pattern Inspection Using an Analyzer**


- Ignition coil primary signal
Refer to GROUP 16 – Ignition System.
- Power transistor control signal.

<Measurement method>

- Disconnect the power transistor connector, and connect the special tool (test harness: MB991348) in between. (All terminals should be connected.)
- Connect the analyzer special patterns pickup to the connector terminals ① (No.3–No.6), ② (No. 2–No. 5) and ③ (No.1–No. 4) in that order.

Standard wave pattern**Observation conditions**

Function	Special patterns
Pattern height	Low
Pattern selector	Display
Engine revolutions	Approx. 1,200 r/min.




7FU1210

Wave pattern observation points

(Point): Condition of wave pattern build-up and maximum voltage (Refer to abnormal wave pattern examples 1 and 2.)

Condition of wave pattern build-up and maximum voltage	Probable cause
Rise to the right to approximately 4.5V from around 2V.	Normal
Becomes a rectangular wave at approx. 2V	Broken wire in ignition primary circuit
Becomes a rectangular wave at power voltage	Malfunction of the power transistor

**Examples of abnormal wave patterns**

- Example 1


Wave pattern during engine cranking

Cause of problem

Broken wire in ignition primary circuit

Wave pattern characteristics

Top-right part of the build-up section cannot be seen, and voltage value is approximately 2V too low.



- Example 2

Wave pattern during engine cranking

Cause of problem


Malfunction in power transistor

Wave pattern characteristics

Power voltage results when the power transistor is ON.

HARNESS INSPECTION





<p>1</p> <p>④ Harness side connector</p> <p>Ⓐ Harness side connector</p> <p>7FU1723</p>	<p>Check for continuity between the ignition coil and the ignition switch [IG].</p> <ul style="list-style-type: none"> • Ignition switch connector: Disconnected • Ignition coil connector: Disconnected <p>NOTE Touch the ohmmeter probes to both ends of the harness.</p>	<p>OK → 2</p> <p>OK → Repair the harness. (④ – Ⓜ)</p>		
<p>2</p> <p>④ – 2 Harness side connector</p> <p>Ⓐ Harness side connector</p> <p>7FU1724</p>	<p>Check for continuity between the power transistor unit and ignition coil.</p> <ul style="list-style-type: none"> • Ignition coil connector: Disconnected • Power transistor connector: Disconnected 	<p>OK → 3</p> <p>OK → Repair the harness. (④ – Ⓜ)</p>		
<p>3</p> <p>B-1 Harness side connector</p> <p>7FU1729</p>	<p>Measure the power supply voltage of the ignition coil</p> <ul style="list-style-type: none"> • Power transistor connector: Disconnected • Ignition switch: ON <table border="1"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>SV</td> </tr> </table>	Voltage (V)	SV	<p>OK → 4</p> <p>OK → Repair the harness. (④, ⑫, ⑬, ⑭ – Ignition coil)</p>
Voltage (V)				
SV				
<p>4</p> <p>④ – 2 Harness side connector</p> <p>7FU1250</p>	<p>Check for open-circuit or short-circuit to earth between the power transistor and engine control unit.</p> <ul style="list-style-type: none"> • Power transistor connector: Disconnected • Engine control unit connector: Disconnected 	<p>OK → 5</p> <p>OK → Repair the harness. (④ – ⑪) (④ – ⑬) (④ – ⑩) (④ – ⑭)</p>		
<p>5</p> <p>④ – 2 Harness side connector</p> <p>7FU0700</p>	<p>Check for continuity of the earth circuit of the ignition power transistor.</p> <ul style="list-style-type: none"> • Power transistor connector: Disconnected 	<p>OK → 6</p> <p>OK → Repair the harness. (④ – Earth)</p>		



ACTUATOR INSPECTION

Refer to GROUP 16 – Ignition System.

IGNITION COIL AND IGNITION POWER TRANSISTOR <DOHC>



OPERATION

Refer to P.13-79-93.

INSPECTION

Using MUT-II

<Spark Advance>

Function	Item No.	Data display	Check condition	Engine state	Standard value
Data reading	44	Ignition advance	<ul style="list-style-type: none"> ● Engine: Warming up ● Timing lamp: Set (set timing lamp to check actual ignition timing) 	700 r/min (Idle)	2–18° BTDC
				2,000 r/min	18–38° BTDC

<Ignition Timing Adjustment Mode>

Function	Item No.	Data display	Check condition	Terminal condition	Standard value
Data list	36	Continuity present or not present between ignition timing adjustment terminal and earth	<ul style="list-style-type: none"> ● Engine: Idling 	Ignition timing adjustment terminal is earthed	ON
				Ignition timing adjustment terminal is disconnected from earth	OFF






<Standard Ignition Timing>




Function	Item No.	Drive	Check condition	Normal condition
Actuator test	17	Set to ignition timing adjustment mode	<ul style="list-style-type: none"> ● Engine: idling ● Timing lamp: set 	5° BTDC \pm 3°

Wave Pattern Inspection Using an Analyzer

Refer to P.13-79-94.

HARNESS INSPECTION




<p>1</p>  <p>⑤ Harness side connector</p> <table border="1"> <tr><td>3</td><td>2</td><td>1</td></tr> <tr><td>6</td><td>5</td><td>4</td></tr> </table> <p>Ⓐ, Ⓑ, Ⓒ Harness side connector</p> <p>2 1</p> <p>7FU1501</p>	3	2	1	6	5	4	<p>Check for continuity between the ignition coil and the ignition switch [IG].</p> <ul style="list-style-type: none"> • Ignition switch connector: Disconnected • Ignition coil connector: Disconnected <p>NOTE Touch the ohmmeter probes to both ends of the harness.</p>	<p>OK → 2</p> <p>OK → Repair the harness. (Ⓐ2 – Ⓒ4) (Ⓑ2 – Ⓒ4) (Ⓒ2 – Ⓒ4)</p>
3	2	1						
6	5	4						
<p>2</p>  <p>⑥-2 Harness side connector</p> <p>6 5 4 3 2 1</p> <p>Ⓐ, Ⓑ, Ⓒ Harness side connector</p> <p>2 1</p> <p>7FU1502</p>	<p>Check for continuity between the power transistor unit and ignition coil.</p> <ul style="list-style-type: none"> • Ignition coil connector: Disconnected • Power transistor connector: Disconnected 	<p>OK → 3</p> <p>OK → Repair the harness. (Ⓐ2 – Ⓐ6) (Ⓑ2 – Ⓐ6) (Ⓒ2 – Ⓐ6)</p>						
<p>3</p>  <p>⑦-1 Harness side connector</p> <p>13 12 11</p> <p>Ⓐ, Ⓑ, Ⓒ Harness side connector</p> <p>2 1</p> <p>7FU1503</p>	<p>Check for continuity between the power transistor and ignition coil.</p> <ul style="list-style-type: none"> • Ignition coil connector: Disconnected • Power transistor connector: Disconnected 	<p>OK → 4</p> <p>OK → Repair the harness. (Ⓐ2 – Ⓐ6) (Ⓐ2 – Ⓐ6) (Ⓐ2 – Ⓐ6)</p>						
<p>4</p>  <p>Ⓐ, Ⓑ, Ⓒ Harness side connector</p> <p>2 1</p> <p>7FU1504</p>	<p>Check for short-circuit to earth between the power transistor and ignition coil.</p> <ul style="list-style-type: none"> • Ignition coil connector: Disconnected • Power transistor connector: Disconnected 	<p>OK → 5</p> <p>OK → Check the primary circuit of the ignition coil for short-circuit.</p>						
<p>5</p>  <p>⑦-2 Harness side connector</p> <p>6 5 4 3 2 1</p> <p>Engine control unit harness side connector</p> <p>11 23 10 101</p> <p>7FU1250</p>	<p>Check for open-circuit or short-circuit to earth between the power transistor and engine control unit.</p> <ul style="list-style-type: none"> • Power transistor connector: Disconnected • Engine control unit connector: Disconnected 	<p>OK → 6</p> <p>OK → Repair the harness. (⑦1 – 11) (⑦2 – 23) (⑦3 – 10) (⑦5 – 31)</p>						



ACTUATOR INSPECTION

Refer to GROUP 16 – Ignition System.

VARIABLE INDUCTION CONTROL SOLENOID VALVE <DOHC>



OPERATION



- The variable induction control solenoid valve is an ON-OFF type of solenoid valve, and converts the vacuum motor pressure into the intake manifold pressure or atmospheric pressure inside the vacuum tank.
- Battery voltage is supplied to the variable induction control valve via the control relay. When the engine control unit turns the power transistor inside the unit ON, current flows to introduce the intake manifold vacuum into the vacuum motor. This causes the vacuum motor to operate. Thus, the control valve will close.

INSPECTION

Using MUT-II


Function	Item No.	Drive contents	Check condition	Normal condition
Actuator test	11	Solenoid valve is switched from OFF to ON.	• Ignition switch: ON	Operating noise is heard when driven

HARNESS INSPECTION




ACTUATOR INSPECTION


Refer to GROUP 15 – Service Adjustment Procedures.

PURGE SOLENOID


Ⓐ Equipment side connector

Purge solenoid
Ⓐ Harness side connector

Control relay




Engine control unit



01A0324

Engine control unit connector





9FU0101

OPERATION

- The purge solenoid is an ON/OFF type of solenoid valve; it functions to regulate the introduction of purge air from the canister to the intake manifold plenum.
- Battery power supply is supplied, by way of the control relay, to the purge solenoid. When the engine control unit switches ON the ignition power transistor within the unit, current flows to the coil, and purge air is introduced.

INSPECTION**Using MUT-II**



Function	Item No.	Drive contents	Check condition	Normal condition
Actuator test	08	Solenoid valve is switched from OFF to ON.	• Ignition switch: ON	Operating sound is heard when driven



ACTUATOR INSPECTION

Refer to GROUP 17 – Service Adjustment Procedures.

EGR CONTROL SOLENOID VALVE



Engine control unit connector



OPERATION



- The EGR control solenoid valve is a duty control type solenoid valve. It makes control by leaking EGR valve operating negative pressure to the throttle body A port.
- Power supply from the battery is sent through the control relay to the EGR control solenoid valve. When the engine control unit turns off the power transistor inside the unit, current no more flows through the coil and EGR valve operating negative pressure leaks.

TROUBLESHOOTING HINTS

If the results of EGR control solenoid valve on-vehicle and off-vehicle inspections are normal but the self-diagnosis code for EGR system failure is displayed, check the EGR valve, vacuum hose and EGR passage for blocking.


INSPECTION**Using MUT-II**

Function	Item No.	Drive content	Check condition	Normal state
Actuator test	10	Change solenoid valve from OFF to ON state	Ignition switch: ON	Operating sound is heard when driven

HARNESS INSPECTION**ACTUATOR INSPECTION**

Refer to GROUP 17 – Exhaust Gas Recirculation (EGR)System.



ANTI-SKID BRAKE SIGNAL




ABS control unit equipment side connector

1	2	3	4	A	5	6	7	8
9	10	11	12	13	14	15	16	17

18



Engine control unit connector




9FU0101

7FU1137

OPERATION

- The anti-skid braking signal is output by the anti-skid braking system (ABS) control unit to the engine control unit as a signal to indicate whether the motor relay is being driven or not. The engine control unit controls the idle speed control servo by means of this signal, and gives accurate anti-skid braking effectiveness.
- The ABS control unit turns the power transistor ON when the motor relay is being driven, and the output terminal which has battery voltage applied is shorted to the earth. This causes the anti-skid braking signal to change from HIGH to LOW.

HARNESS INSPECTION



FUEL PRESSURE

HOW TO REDUCE THE INTERNAL PRESSURE

Refer to P.13-79-21.

FUEL PUMP OPERATION CHECK


Refer to P.13-79-21.

FUEL PRESSURE TEST <SOHC>


- (1) Reduce the internal pressure of the fuel pipes and hoses.
- (2) Remove the fuel pressure regulator at the delivery pipe side.

Caution

Cover the fuel pressure regulator with rags to prevent splash of fuel that could be caused by some residual pressure in the fuel pipe line.




- (3) Set a fuel pressure gauge on the special tool, placing an adequate O-ring or gasket between the gauge and special tool to prevent fuel leaks.
- (4) Install the special tool set in the step (3) between the delivery pipe and the fuel pressure gauge.



- (5) Connect a jumper wire to the terminal for activation of the fuel pump and to the positive (+) terminal of the battery to activate the fuel pump. With fuel pressure applied, check to be sure that there is no fuel leakage from the fuel pressure gauge and the special tool connection part.
- (6) Disconnect the jumper wire from the terminal for activation of the fuel pump to stop the fuel pump.
- (7) Start the engine and let it idle.
- (8) Measure the fuel pressure during idling.

Standard value: Approx. 270 kPa (38 psi) at curb idle



(9) Disconnect the vacuum hose (blue stripe) from the intake manifold and plug the nipple. Then measure fuel pressure.

Standard value: 330–370 kPa (3.3–3.5 kg/cm², 47–53 psi) at curb idle speed

(10) Check to be sure that the fuel pressure during idling does not decrease even after the engine is raced a few times.

(11) Use a finger to gently press the fuel return hose while repeatedly racing the engine, and check to be sure that there is fuel pressure in the return hose also.

NOTE

There will be no fuel pressure in the return hose if there is insufficient fuel flow.

(12) If the fuel pressure measured in steps (8) to (11) deviates from the standard value range, check for the probable cause by referring to the table below, and then make the appropriate repair.

Condition	Probable cause	Remedy
<ul style="list-style-type: none"> • Fuel pressure is too low. • Fuel pressure drops during racing. • No fuel pressure in fuel return hose. 	Fuel filter is clogged.	Replace the fuel filter.
	Malfunction of the valve seat within the fuel pressure regulator, or fuel leakage to return side caused by spring deterioration.	Replace the fuel pressure regulator.
	Fuel pump low discharge pressure.	Replace the fuel pump.
Fuel pressure is too high	The valve within the fuel pressure regulator is sticking.	Replace the fuel pressure regulator.
	Clogging of the fuel return hose and/or the pipe.	Clean or replace the hose and/or pipe.
No change of the fuel pressure when vacuum hose is connected and when not connected.	Damaged vacuum hose or nipple clogging.	Replace the vacuum hose, or clean the nipple.

(13) Stop the engine and check for a change of the value indicated by the fuel pressure gauge. The condition is normal if there is no decrease of the indicated value within two minutes. If there is a decrease of the indicated value, monitor the speed of the decrease, and, referring to the table below, determine the cause of the problem and make the appropriate repair.

Condition	Probable cause	Remedy
After the engine is stopped, the fuel pressure drops gradually.	Injector leakage.	Replace the injector.
	Leakage at the fuel pressure regulator valve seat.	Replace the fuel pressure regulator.
There is a sudden sharp drop of the fuel pressure immediately after the engine is stopped.	The check valve (within the fuel pump) is not closed.	Replace the fuel pump.

(14) Remove all remaining pressure from inside the fuel pipe. (Refer to P. 13-16.)

(15) Disconnect the fuel pressure gauge and the special tool from the delivery pipe.

Caution

Because there will be a slight amount of remaining pressure in the fuel pipe line, use rags to cover so that fuel doesn't splatter.

(16) Replace the O-ring at the end of the fuel high-pressure hose with a new one.


(17) After connecting the fuel high-pressure hose to the delivery pipe, tighten the installation bolt at the specified torque.

Tightening torque: 5 Nm (0.5 kmg, 3.6 ft.lbs)

(18) Check to be sure that there is no fuel leakage.

① Apply battery voltage to the terminal for activation of the fuel pump so as to activate the fuel pump.

② With fuel pressure applied, check for leakage of the fuel line.




FUEL PRESSURE TEST <DOHC>


- (1) Reduce the internal pressure of the fuel pipes and hoses.
- (2) Remove the intake air plenum.
- (3) Disconnect the fuel high pressure hose at the delivery pipe side.

Caution


Cover the hose connection with rags to prevent splash of fuel that could be caused by some residual pressure in the fuel pipe line.



- (4) Set a fuel pressure gauge on the special tool, placing an adequate O-ring or gasket between the gauge end special tool to prevent fuel leaks.



- (5) Attach the special tool set in step (3) to the delivery pipe.



- (6) Connect a jumper wire to the terminal for activation of the fuel pump and to the positive (+) terminal of the battery to activate the fuel pump. With fuel pressure applied, check to be sure that there is no fuel leakage from the fuel pressure gauge and the special tool connection part.

- (7) Measure the fuel pressure.

Standard value: 324–343 kPa (3.3–3.5 kg/cm², 47–50 psi)

- (8) If the fuel pressure measured in step (7) deviates from the standard value range, check for the probable cause by referring to the table on the next page, and then make the appropriate repair.

Condition	Probable cause	Remedy
Fuel pressure is too low.	Fuel filter is clogged.	Replace the fuel filter.
	Malfunction of the valve seat within the fuel pressure regulator, or fuel leakage to return side caused by spring deterioration.	Replace the fuel pressure regulator.
	Fuel pump low discharge pressure.	Replace the fuel pump.
Fuel pressure is too high.	The valve within the fuel pressure regulator is sticking	Replace the fuel pressure regulator.
	Clogging of the fuel return hose and/or the pipe.	Clean or replace the hose and/or pipe.

(9) Disconnect the lead wire from the fuel pump activating terminal (black) to stop the fuel pump and check for a change of the value indicated by the fuel pressure gauge. The condition is normal if there is no decrease of the indicated value within two minutes. If there is a decrease of the indicated value, monitor the speed of the decrease, and, referring to the table below, determine the cause of the problem and make the appropriate repair.

Condition	Probable cause	Remedy
After the fuel pump is stopped, the fuel pressure drops gradually.	Injector leakage.	Replace the injector.
	Leakage at the fuel pressure regulator valve seat.	Replace the fuel pressure regulator.
There is a sudden sharp drop of the fuel pressure immediately after the fuel pump is stopped.	The check valve (within the fuel pump) is not closed.	Replace the fuel pump.

(10) Connect a hand vacuum pump to the fuel pressure regulator and apply vacuum of 80 kPa (600 mmHg, 23.6 in.Hg) to remove all remaining pressure from inside the fuel line.
 (11) Disconnect the fuel pressure gauge and the special tool from the delivery pipe.

Caution

Because there will be a slight amount of remaining pressure in the fuel pipe line, use rags to cover so that fuel doesn't splatter.

(12) Replace the O-ring at the end of the fuel high-pressure hose with a new one.
 (13) After connecting the fuel high-pressure hose to the delivery pipe, tighten the installation bolt at the specified torque.

Tightening torque: 5 Nm (0.5 kgm, 3.6 ft.lbs.)



(14) Check to be sure that there is no fuel leakage.
 ① Apply battery voltage to the terminal for activation of the fuel pump so as to activate the fuel pump.
 ② With fuel pressure applied, check for leakage of the fuel line.
 (15) Install the intake air plenum.

FUEL SYSTEM <4G64 Engine>

GENERAL INFORMATION

E13BBAH

MULTI POINT INJECTION SYSTEM DIAGRAM



SPECIFICATIONS**GENERAL SPECIFICATIONS**

E13CA-B

Items	Specifications	
Fuel		
Tank capacity	dm ³ (U.S.gal., Imp.gal.)	75 (19.8, 16.5) 92 (24.3, 20.2)
Standard Wheelbase		
Long Wheelbase		
Fuel pump		Electrical, in-tank type
Type		Electric motor
Driven by		
Throttle body		
Throttle bore	mm (in.)	50 (1.968)
Throttle position sensor		Variable resistor type
Idle speed control servo		Electric motor
Idle position switch		Contact type, within throttle position sensor
Motor position sensor		Variable resistor type
Engine control unit		
Identification model No.		E2T37771
Input sensor		
Air flow sensor		Karman vortex type
Barometric pressure sensor		Semiconductor type
Intake air temperature sensor		Thermistor type
Engine coolant temperature sensor		Thermistor type
Oxygen sensor		Zirconia type
Vehicle speed sensor		Reed switch type
No. 1 cylinder top dead center sensor		Photo interruptor type
Crank angle sensor		Photo interruptor type
Actuators		
Control relay type		Contact switch type
Injector type and number		Electromagnetic 4
Purge control solenoid valve		ON/OFF type solenoid valve
Fuel pressure regulator		
Regulated pressure	kPa (kg/cm ² , psi)	335 (3.35, 47.6)

SERVICE SPECIFICATIONS

E13CB-B

Items	Specifications
Standard value	
Accelerator cable play	mm (in.)
Basic ignition timing	
Curb idle speed	r/min.
Idle speed when air conditioner ON	r/min.
Basic idle speed	r/min.
Throttle position sensor output voltage	V
Throttle position sensor resistance	kΩ
Idle speed control servo coil resistance [at 20°C (68°F)]	Ω
Motor position sensor resistance	kΩ
Intake air temperature sensor resistance [at 20°C (68°F)]	kΩ
Engine coolant temperature sensor resistance	kΩ
20°C (68°F)	
80°C (176°F)	
Fuel pressure regulator pressure	kPa (kg/cm ² , psi)
Vacuum hose disconnection	
Vacuum hose connection	
Injector coil resistance [at 20°C (68°F)]	Ω


SEALANT






E13CE-B

Items	Specified sealant	Quantity
Engine coolant temperature sensor threaded portion	3M Nut locking Part No. 4171 or equivalent	As required

SPECIAL TOOLS

E13DA-B

Tool	Number	Name	Use
	MB991341	Multi-use tester assembly	<ul style="list-style-type: none"> • Reading diagnosis code • MPI system inspection
	MB991419	ROM pack (for multi-use tester)	<ul style="list-style-type: none"> • Reading diagnosis code • MPI system inspection
	MB991348	Test harness set	<ul style="list-style-type: none"> • Adjustment of throttle position sensor • Inspection with oscilloscope

Tool	Number	Name	Use
	MD998706	Injector test set	<ul style="list-style-type: none"> • Checking injection condition of injector
	MD998740	Injector test adaptor	
	MD998746	Clip	
	MD998464	Harness connector (4P, square)	<ul style="list-style-type: none"> • Inspection with oscilloscope
	MD998700	Hose adapter	<ul style="list-style-type: none"> • Measurement of fuel pressure
Red harness (for DLI) 	MB991223	Inspection harness set connector	<ul style="list-style-type: none"> • Measurement of terminal voltages
White harness (for LC) 		<ul style="list-style-type: none"> • Pin contact pressure inspection harness • Marketing tester connection probe (for general connectors) 	

TROUBLESHOOTING


E13EFAK

EXPLANATION OF TROUBLESHOOTING PROCEDURES

Refer to P.13-7.

EXPLANATION AND PRECAUTION RELATED TO HARNESS CHECKING

Refer to P.13-8.

**ENGINE WARNING LAMP (CHECK ENGINE LAMP)**

Among the self-diagnosis items, a engine warning lamp comes on to notify the driver of the emission control items when an irregularity is detected.

However, when an irregular signal returns to normal and the engine control unit judges that it has returned to normal, the engine warning lamp goes out.

Moreover, when the ignition switch is turned off, the lamp goes out. Even if the ignition switch is turned on again, the lamp does not come on until the irregularity is detected.

Here, immediately after the ignition switch is turn on, the lamp engine warning lamp is lit for 5 seconds to indicated that the engine warning lamp operates normally.

Item indicated by the lightening engine warning lamp

Engine control unit	Crank angle sensor
Oxygen sensor	No. 1 cylinder top dead center sensor
Air flow sensor	Barometric pressure sensor
Engine coolant temperature sensor	Ignition timing adjustment signal
Intake air temperature sensor	Injector
Throttle position sensor	Fuel pump

Caution

Engine warning lamp will come on when the line of terminal for ignition timing adjustment is short-circuited. Therefore, the lamp will come on even when the terminal for ignition timing adjustment is earthed at the time of adjusting ignition timing. In this case, however, it is not abnormal.

ENGINE WARNING LAMP INSPECTION

Refer to P.13-10.

SELF-DIAGNOSIS

The engine control unit monitors the input/output signals (some signals at all times and the others under specified conditions) of the engine control unit.

When it is noticed that an irregularity has continued for a specified time or longer from when the irregular signal is initially monitored, passing a certain number, the engine control unit judges that an irregularity has occurred, memorizes the malfunction code, and outputs the signal to the self-diagnosis output terminals.

There are 15 diagnosis items, including the normal state, and the diagnosis results can be read out with a multi-use tester.

Moreover, since memorization of the malfunction codes is backed up directly by the battery, the diagnosis results are memorized even if the ignition key is turned off. The malfunction codes will, however, be erased when the battery terminal or the engine control unit connector is disconnected.

The malfunction codes are also erased by setting the ignition switch to the "ON" position and then sending the malfunction-code-erase signal from the multi-use tester to the engine control unit.

Caution

If the sensor connector is disconnected while the ignition switch is ON, the malfunction code is memorized. In this instance, either send the malfunction-code-erase signal from the multi-use tester to the engine control unit, the diagnosis memory will be erased.

The 15 diagnosis items are provided as follows, and if plural items are activated, they are all indicated sequentially from the smallest code number.

Caution

Ignition timing adjustment signal malfunction code is output when the ignition timing adjustment terminal line is short-circuited to the earth. Therefore, the malfunction code is output when the ignition timing adjustment terminal is earthed, however, this is not a malfunction.

DIAGNOSIS CHART

Output preference order	Diagnosis item	Diagnosis code		Check item (Remedy)
		No.	Memory	
1	Engine control unit	–	–	(Replace engine control unit)
2	Oxygen sensor	11	Retained	<ul style="list-style-type: none"> • Harness and connector • Oxygen sensor • Fuel pressure • Injectors (Replace if defective.) • Intake air leaks
3	Air flow sensor	12	Retained	<ul style="list-style-type: none"> • Harness and connector (If harness and connector are normal, replace air flow sensor assembly)
4	Intake air temperature sensor	13	Retained	<ul style="list-style-type: none"> • Harness and connector • Intake air temperature sensor
5	Throttle position sensor	14	Retained	<ul style="list-style-type: none"> • Harness and connector • Throttle position sensor • Idle position switch

Output preference order	Diagnosis item	Diagnosis code		Check item (Remedy)
		No.	Memory	
6	Engine coolant temperature sensor	21	Retained	<ul style="list-style-type: none"> • Harness and connector • Engine coolant temperature sensor
7	Crank angle sensor	22	Retained	<ul style="list-style-type: none"> • Harness and connector (If harness and connector are normal, replace distributor assembly.)
8	Top dead center sensor (No. 1 cylinder)	23	Retained	<ul style="list-style-type: none"> • Harness and connector (If harness and connector are normal, replace distributor assembly.)
9	Vehicle speed sensor (reed switch)	24	Retained	<ul style="list-style-type: none"> • Harness and connector • Vehicle speed sensor (reed switch)
10	Barometric pressure sensor	25	Retained	<ul style="list-style-type: none"> • Harness and connector (If harness and connector are normal, replace barometric pressure sensor assembly.)
11	Ignition timing adjustment signal	36	-	<ul style="list-style-type: none"> • Harness and connector
12	Injector	41	Retained	<ul style="list-style-type: none"> • Harness and connector • Injector coil resistance
13	Fuel pump	42	Retained	<ul style="list-style-type: none"> • Harness and connector • Control relay
14	Servo valve position sensor	55	Retained	<ul style="list-style-type: none"> • Harness and connector • ISC servo (If harness and connector are normal, replace ISC servo assembly.)
15	Normal state	-	-	-

NOTE

Replace the engine control unit if a malfunction code is output although the inspection reveals that there is no problem with the check items.

READ OUT OF MALFUNCTION CODE

Refer to P.13-11.

CHECK CHART CLASSIFIED BY PROBLEM SYMPTOMS



Problem symptoms	Starting	Idling stability		Driving				Stop- ping	Reference page		
	Will not start	Starting problem	Idling instability (Rough idling)	Incorrect idling speed	Improper idling continuity	Hesitation, sag	Poor acceleration				
Check Items											
Power Supply	① ①								P.13- 98		
Engine Control Unit Power Earth	② ②								P.13-100		
Fuel Pump	③ ③	① ①		① ①	① ①	① ①			P.13-101		
Air Flow Sensor				⑫	⑧ ⑧		⑥ ⑤	⑥ ⑥	③ ③	P.13-104	
Intake Air Temperature Sensor			⑥		④ ④	④ ④			① ①	P.13-108	
Barometric Pressure Sensor			⑧		⑦ ⑦	⑥ ⑥			② ②	P.13-110	
Engine Coolant Temperature Sensor		③ ⑦ ⑥	① ①	⑥ ⑥	⑥ ⑥	⑤ ⑤	④ ④	③ ③		P.13-111	
Throttle Position Sensor					⑥ ⑤		③ ③	④ ④		P.13-112	
Idle Position Switch			④ ④	② ②	⑥ ⑤					P.13-114	
Servo Valve Position Sensor			③ ③	④ ③	④ ④			⑤ ⑤		P.13-116	
Top Dead Center Sensor	⑤ ⑤	⑥ ⑦		⑨ ⑨				② ②		P.13-118	
Crank Angle Sensor	⑥ ⑥	⑦ ⑧		⑩ ⑨				③ ③		P.13-121	
Ignition Switch - ST	④ ④	③ ④								P.13-123	
Vehicle Speed Sensor				⑦				⑦		P.13-123	
Air Conditioner Switch and Power Relay				③						P.13-123	
Oxygen Sensor			⑩							P.13-124	
Injectors	⑧ ⑧	② ②	② ②		③ ③	② ②	② ②	① ①	① ①	①	P.13-126
Idle Speed Control Servo (DC Motor)		④ ⑤	① ①	⑥ ④	② ②			⑧ ⑦			P.13-131
Ignition Coil and Power Transistor	⑦ ⑦			⑪ ⑩		⑦ ⑦		① ①	④ ④		P.13-133
Purge Control Solenoid Valve			⑨								P.13-137
Fuel Pressure		⑤ ⑥	⑤ ⑤		⑥ ⑦	③ ③	③ ③	② ②	② ②		P.13-138

○: Warm engine (figures inside the ○ indicate the checking sequence.)


□: Cold engine (figures inside the □ indicate the checking sequence.)

PROBLEM SYMPTOMS TABLE (FOR YOUR INFORMATION)

Item	Symptom	
Starting	Won't start (no initial combustion)	The starter is used to crank the engine, but there is no combustion within the cylinders, and the engine won't start.
	Starting problem (initial combustion, then stall) (Starting takes a long time.)	There is combustion within the cylinders, but then the engine soon stalls. Engine won't start quickly.
	Idling instability (Rough idling)	Engine speed doesn't remain constant; changes during idling. Usually, a judgement can be based upon the movement of the tachometer pointer, and the vibration transmitted to the steering wheel, shift lever, body, etc. This is called rough idling.
Idling Stability	Incorrect idling speed	The engine doesn't idle at the usual correct speed.
	Improper idling continuity Die out Pass out	This non-continuity of idling includes the following elements. (1) Die out The engine stalls when the foot is taken from the accelerator pedal, regardless of whether the vehicle is moving or not. (2) Pass out The engine stalls when the accelerator pedal is depressed or while it is being used.
	Hesitation Sag	"Hesitation" is the delay in response of the vehicle speed (engine r/min.) that occurs when the accelerator is depressed in order to accelerate from the speed at which the vehicle is now traveling, or a temporary drop in vehicle speed (engine r/min.) during such acceleration. Serious hesitation is called "sag".
Driving	Poor acceleration	Poor acceleration is inability to obtain an acceleration corresponding to the degree of throttle opening, even though acceleration is smooth, or the inability to reach maximum speed.
	Stumble	Engine r/min. response is delayed when the accelerator pedal is initially depressed for acceleration from the stopped condition.
	Shock	The feeling of a comparatively large impact or vibration when the engine is accelerated or decelerated.
	Surge	This is repeated surging ahead during constant speed travel or during variable speed travel.
	Knocking	A sharp sound like a hammer striking the cylinder walls during driving and which adversely affects driving.



Item		Symptom
Driving	Surge	This is repeated surging ahead during constant speed travel or during variable speed travel.
	Knocking	A sharp sound like a hammer striking the cylinder walls during driving and which adversely affects driving.
Stopping	Run-on (Dieseling)	The engine continues to run even after the switch is turned OFF. This is called dieseling.



SERVICE ADJUSTMENT PROCEDURES


ACCELERATOR CABLE INSPECTION AND ADJUSTMENT

E13FCAZZ

- (1) Check that there are no sharp bends in the accelerator cable.
- (2) Check that the engine idling speed is at the normal value.
- (3) Turn the ignition switch to OFF to stop the engine.

- (4) Check that the throttle link is touching the fixed SAS stopper.
- (5) Move the plate so that the inner cable play is at the standard value, and tighten the adjusting bolt.

Standard value: 1–2 mm (0.04–0.08 in.)



FUEL FILTER REPLACEMENT

E13FZAM

Refer to P.13-14.

FUEL GAUGE UNIT REPLACEMENT

E13FDAD

Refer to P.13-15.

2-WAY VALVE REPLACEMENT

E13FFAD

Refer to P.13-15.

FUEL PUMP OPERATION CHECK


E13FGCF

Refer to P.13-15.

HOW TO REDUCE THE FUEL LINE INTERNAL PRESSURE

E13HABH

Refer to P.13-16.



THROTTLE BODY (THROTTLE VALVE AREA) CLEANING

E13HAJB2

- (1) Start the engine and warm it up until the temperature of the engine coolant reaches 80°C (176°F) or higher; then stop the engine.
- (2) Disconnect the air intake hose at the throttle body side.
- (3) Plug the bypass intake port inlet in the throttle body.

Caution

Never let cleaning liquid get into the bypass intake.

- (4) Spray cleaning liquid (from the intake port of the throttle body) onto the valve, and then leave as is for about five minutes.
- (5) Start the engine and race it a few times; then let it run at idle speed for about one minute.


NOTE

The engine idling speed is unstable (or the engine stalls), let the engine run with the throttle valve slightly open.

- (6) If deposits are not removed from the throttle valve, repeat steps (4) and (5).
- (7) Remove the plug from the bypass intake port inlet in the throttle body.
- (8) Connect the air intake hose.
- (9) Using the multi-use tester, erase the self-diagnosis code.
- (10) Adjust the basic idle speed. (Refer to P.13-93.)

NOTE


If hunting of the idling engine occurs after adjusting the basic idling speed, remove the battery (-) cable from the battery terminal for more than 10 seconds, and then idle the engine again.




IDLE POSITION SWITCH AND THROTTLE POSITION SENSOR ADJUSTMENT

E13HAKD2


- Disconnect the connector of the throttle position sensor.




- Using jumper wires, connect an ohmmeter across terminal ③ (idle position switch) and terminal ④ (sensor earth) of the throttle position sensor.



- Insert a 0.65 mm (0.0256 in.) thick feeler gauge between the fixed SAS and throttle lever.



- Loosen the throttle position sensor mounting bolts and turn the throttle position sensor body fully counterclockwise.
- In this condition, check that there is continuity across terminals ③ and ④.




- Slowly turn the throttle position sensor clockwise until you find a point at which there is no continuity across terminals ③ and ④. Then, tighten the throttle position sensor mounting bolt securely.
- Connect the throttle position sensor connector.

- (8) Connect the multi use tester (MUT) to the diagnosis connector.
- (9) Turn the ignition switch ON (but do not start the engine).
- (10) Using the MUT, select item No. 14 and read the throttle position sensor output voltage.

Standard value: 400–1,000 mV

- (11) If the voltage is out of specification, check the throttle position sensor and associated harnesses.
- (12) Remove the feeler gauge.
- (13) Turn the ignition switch OFF.



FIXED SAS ADJUSTMENT

E13HAMC2

NOTE

1. The fixed SAS has been factory-adjusted. Never attempt to move it.
2. Should it be out of proper adjustment, adjust by following the procedure given below.

- (1) Sufficiently slacken the accelerator cable.
- (2) Loosen the lock nut on the fixed SAS.
- (3) Sufficiently loosen the fixed SAS by turning it counterclockwise to fully close the throttle valve.
- (4) Tighten the fixed SAS slowly to find a point at which it contacts the throttle lever (where the throttle valve starts opening). From that point, tighten the fixed SAS further 1 1/4 turns.
- (5) Holding the fixed SAS to prevent it from turning, tighten the lock nut securely.
- (6) Adjust the accelerator cable tension. (Refer to P.13-89.)
- (7) Adjust the basic idle speed. (Refer to P.13-93.)
- (8) Adjust the idle position switch and throttle position sensor (TPS). (Refer to P.13-91.)

BASIC IDLE SPEED ADJUSTMENT

E13HANE



NOTE

1. The basic idle speed has been factory-adjusted with the speed adjusting screw (SAS) and does not normally require adjustment.
2. If the adjustment is required, first check that the ignition plug, injector, ISC servo, and compression pressure are normal.
- (1) Before starting the inspection and adjustment procedures, set the vehicle in the following conditions:
 - Engine coolant temperature: 80 to 95°C (176 to 203°F)
 - Lights, electric cooling fan, accessories: OFF
 - Transmission: Neutral
 - Steering wheel: Straightforward position

- (2) Connect the multi use tester (MUT) to the diagnosis connector.

NOTE

When the multi-use tester is connected, the diagnosis control terminal will be earthed.



- (3) Remove the waterproof female connector from the ignition timing adjusting connector (brown).

- (4) Using a jumper wire, earth the ignition timing adjusting terminal.

- (5) Start the engine and run at idle.

- (6) Check the basic idle speed.


Using the MUT, select item No. 22 and read the idle speed.

Standard value: 750 ± 50 r/min.

NOTE

1. The engine speed may be low by 20 to 100 r/min. while the vehicle is new [distance driven approx. 500 km (300 miles) or less], but no adjustment is necessary.
2. If the engine stalls or speed is low despite a sufficient distance driven [approx. 500 km (300 miles) or more], it is probably due to deposits on the throttle valve. In this case, clean the throttle valve. (Refer to P.13-90.)

13-94 FUEL SYSTEM <4G64 Engine> – Service Adjustment Procedures



(7) If the basic idle speed is out of specification, adjust by turning the speed adjusting screw (SAS).


NOTE

If the idle speed is higher than the standard value even with SAS fully tightened, check to see if there is evidence of the fixed SAS being moved. If the fixed SAS seems to have been moved, adjust it. If it does not seem to have been moved, there may be a leak caused by deteriorated fast idle air valve (FIAV). In such a case, replace the throttle body.


(8) Turn the ignition switch OFF.
(9) Remove the jumper wire from the ignition timing adjusting terminal and replace the connector back again.
(10) Start the engine again and run at idle for 10 minutes to make sure that the engine runs at proper idle speed.

ON-VEHICLE INSPECTION OF MPI COMPONENTS

COMPONENT LOCATION













6FU1704










7FU1167

Name	Symbol	Name	Symbol
Air conditioner relay	A	Ignition timing adjustment terminal	Q
Air conditioner switch	M	Injector	J
Air flow-sensor (incorporating intake air temperature sensor and barometric pressure sensor)	B	Idle speed control servo (incorporating servo, valve position sensor)	C
Crank angle sensor and No. 1 cylinder top dead center sensor	G	Oxygen sensor	K
Engine control relay	L	Purge control solenoid valve	I
Engine control unit	O	Self-diagnosis connector	P
Engine coolant temperature sensor	E	Throttle position sensor (incorporating idle position switch)	D
Fuel pump check terminal	H	Vehicle-speed sensor (reed switch)	N
Ignition coil (power transistor)	F		

13-96 FUEL SYSTEM <4G64 Engine> – On-Vehicle Inspection of MPI Components







COMPONENT INSPECTION PROCEDURE USING MULTI USE TESTER


Refer to P.13-22.

POWER SUPPLY



01A0344

Engine control unit connector



01L0838

OPERATION

- While the ignition switch is ON, battery power supply is supplied to the engine control unit, injectors, air-flow sensor, etc.
- Turning the ignition switch to the ON position causes current to flow from the ignition switch through the control relay coil to earth. This turns the control relay switch on and supplies power from the battery to the engine control unit via the control relay switch.




INSPECTION

Using Multi-use tester (MUT)

Function	Item No.	Data display	Check conditions	Standard value
Data reading	16	Engine control unit power-supply voltage	Ignition switch:ON	SV

HARNESS INSPECTION

<p>1</p> <p>Ⓐ Harness side connector</p> <p>01A0521</p>	<p>Measure the power supply voltage of the engine control relay.</p> <ul style="list-style-type: none"> • Engine control relay: Disconnected • Ignition switch: ON <table border="1" data-bbox="677 326 1052 474"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>SV</td> </tr> </table>	Voltage (V)	SV	<p>OK → 2</p> <p>OK → Repair the harness. (Ignition switch — Ⓢ [8])</p>
Voltage (V)				
SV				
<p>2</p> <p>Ⓐ Harness side connector</p> <p>01A0369</p>	<p>Check for continuity of the earth circuit</p> <ul style="list-style-type: none"> • Engine control relay connector: Disconnected 	<p>OK → 3</p> <p>OK → Repair the harness. (Ⓐ [6] — Earth)</p>		
<p>3</p> <p>Ⓐ Harness side connector</p> <p>01A0361</p>	<p>Measure the power supply voltage of the engine control relay.</p> <ul style="list-style-type: none"> • Engine control relay connector: Disconnected <table border="1" data-bbox="677 1053 1052 1200"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>SV</td> </tr> </table>	Voltage (V)	SV	<p>OK → 4</p> <p>OK → Repair the harness. (Battery — Ⓢ [4])</p>
Voltage (V)				
SV				
<p>4</p> <p>Engine control unit harness side connector</p> <p>01A0374</p>	<p>Check for open-circuit, or short-circuit to earth, between the engine control unit and the engine control relay.</p> <ul style="list-style-type: none"> • Engine control unit connector: Disconnected • Engine control relay connector: Disconnected. 	<p>OK → STOP</p> <p>OK → Repair the harness (102 — Ⓢ [3]) (107 — Ⓢ [3])</p>		



ENGINE CONTROL RELAY INSPECTION

Caution

When applying battery voltage directly, make sure that it is applied to correct terminal. Otherwise, the relay could be damaged.

- (1) Check the continuity of the engine control relay coil.

Measured Terminals	Continuity
③ – ⑤	Yes (approx. 95Ω)
② – ⑤	
⑥ – ⑦	Yes (approx. 35Ω)
⑥ – ⑧	Yes One direction only

- (2) Check the continuity between terminals 1 and 4 of the engine control relay contacts.

Relay Coil (Between terminals ⑥–⑦)	Continuity
When not energized	No ($\infty\Omega$)
When energized	Yes (0Ω)

- (3) Check the continuity between terminals 2 and 4 of the engine control relay contacts.




Relay Coil (Between terminals ⑧–⑥)	Continuity
When not energized	No ($\infty\Omega$)
When energized	Yes (0Ω)

- (4) If the control relay is faulty, replace it.


ENGINE CONTROL UNIT POWER EARTH

Refer to P.13-26.

FUEL PUMP



6FU1720



01L0838

OPERATION




- Activates the fuel pump during engine cranking and while the engine is running.
- When the ignition switch is set to the START position, current flows, by way of the control relay coil, from the ignition switch to earth. As a result, the control relay switch is switched ON, and the power for activation of the fuel pump is supplied, by way of the control relay switch, from the battery to the fuel pump.
- While the engine is running, the engine control unit switches ON the power transistor, after which current flows to the control relay coil, and the power for activation of the fuel pump is supplied to the fuel pump.
- When the control relay switch is switched ON, battery voltage is also applied to the engine control unit, and so the engine control unit detects the fact that the power for activation of the fuel pump is being supplied to the fuel pump.






INSPECTION

Using Multi-use tester (MUT)

Function	Item No.	Activation	Check conditions	Check description	Normal condition
Actuator test	07	Activates fuel pump and circulates fuel.	<ul style="list-style-type: none"> Engine cranking Fuel pump forced activation <p>Make the check under both of the above conditions.</p>	<p>Pinch the return hose and feel the pulsations of the fuel flow.</p>	Pulsations can be felt.
				<p>Listen (close to the fuel tank) for pump sounds.</p>	Sounds can be heard.

HARNESS INSPECTION

	<p>Check the fuel pump.</p> <ul style="list-style-type: none"> Apply battery voltage to the checking terminal and operate the pump. <div style="display: flex; justify-content: space-around;">  → 4  → 2 </div>
	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> Fuel pump connector: Disconnected <div style="display: flex; justify-content: space-around;">  → 3  → Repair the harness. (② – Earth) </div>
	<p>Check for continuity between the fuel pump and the checking terminal.</p> <ul style="list-style-type: none"> Fuel pump connector: Disconnected <div style="display: flex; justify-content: space-around;">  → 4  → Repair the harness. (② – ①) </div>

<p>4</p>  <p>Ⓐ Harness side connector</p> <p>8FU0308</p>	<p>Check for continuity between the checking terminal; and between the engine control relay terminals.</p> <ul style="list-style-type: none"> • Engine control relay connector: Disconnected • Fuel pump connector: Disconnected 	<p>OK → 5</p> <p>Repair the harness. (Ⓐ 1 – Ⓐ 5 – (Ⓐ 1 – 109)</p> <p>OK → 5</p>		
<p>5</p>  <p>Ⓐ Harness side connector</p> <p>01A0504</p>	<p>Measure the power supply voltage of the engine control relay.</p> <ul style="list-style-type: none"> • Engine control relay connector: Disconnected • Ignition switch: START (when checking Ⓐ 7) <table border="1" data-bbox="693 705 1064 853"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>8 or higher</td> </tr> </table>	Voltage (V)	8 or higher	<p>OK → 6</p> <p>Repair the harness. (Ⓐ 4 – Battery) (Ⓐ 7 – Ignition switch)</p> <p>OK → 6</p>
Voltage (V)				
8 or higher				
<p>6</p>  <p>Engine control unit harness side connector</p> <p>Harness side connector</p> <p>01A0354</p>	<p>Check for an open-circuit, or a short-circuit to earth between the engine control relay and the engine control unit.</p> <ul style="list-style-type: none"> • Engine control relay connector: Disconnected • Engine control unit connector: Disconnected 	<p>OK → 7</p> <p>Repair the harness. (Ⓐ 5 – 56)</p> <p>OK → 7</p>		
<p>7</p>  <p>Harness side connector</p> <p>01A0351</p>	<p>Check for continuity, of the earth circuit.</p> <ul style="list-style-type: none"> • Engine control relay connector: Disconnected. 	<p>OK → 8</p> <p>Repair the harness. (Ⓐ 6 – Earth)</p> <p>OK → 8</p>		
<p>8</p>  <p>Ⓑ Harness side connector</p> <p>1FU0472</p>	<p>Check for an open-circuit, or a short-circuit to earth between the engine control relay and the fuel pump.</p> <ul style="list-style-type: none"> • Engine control relay connector: Disconnected • Fuel pump connector: Disconnected 	<p>OK → STOP</p> <p>Repair the harness. (Ⓐ 1 – Ⓑ 2)</p> <p>OK → STOP</p>		

FUEL PUMP INSPECTION




Refer to P.13-15.

ENGINE CONTROL RELAY INSPECTION

Refer to P.13-100.

AIR FLOW SENSOR

M13YFAA1



OPERATION

- The air-flow sensor is incorporated within the cleaner; it functions to convert the amount of engine air intake to pulse signals of a frequency proportional to the amount of engine air intake, and to input those signals to the engine control unit. The engine control unit then, based upon those signals, calculates the amount of fuel injection, etc.
- The power for the air flow sensor is supplied from the control relay to the air flow sensor, and is earthed at the engine control unit. The air flow sensor, by intermitting the flow of the 5V voltage applied from the engine control unit produces pulse signals.

Hint 1:

If the engine sometimes stalls, try starting the engine and shaking the air flow sensor harness.

If the engine then stalls, incorrect or improper contact of the air flow sensor connector is the probable cause.

Hint 2:

If, when the ignition switch is switched ON (but the engine is not started), the air flow sensor output frequency is any value other than zero, a malfunction of the air flow sensor or of the engine control unit is the probable cause.

Hint 3:

If idling is possible even though the air flow sensor output frequency is deviated from the standard value, the cause is usually a malfunction other than of the air flow sensor.

[Examples]


- The flow of air within the air flow sensor is disturbed. (Air duct disconnection or clogged air cleaner element.)
- Incomplete combustion within a cylinder. (Malfunction of spark plugs, ignition coil, injectors, compression pressure, etc.)
- Air is taken into the intake manifold through a leaking gasket, etc.
- EGR valve
Improper adhesion of valve sheet.

INSPECTION
Using Multi-use tester (MUT)


Function	Item No.	Data display	Check conditions	Engine conditions r/min.	Standard value Hz
Data reading	12	Sensor detection air flow (frequency)	<ul style="list-style-type: none"> Engine coolant temperature: 80–95°C (176–205°F) Lights and accessories: OFF Transmission: neutral Steering wheel: neutral position 	750 (idling) 2,000 Racing	37–63 75–115 Frequency increases by racing.

NOTE

When the vehicle is new [driven approximately 500 km (300 miles) or less], the air-flow sensor output frequency may be approximately 10% higher than indicated above.


Wave Pattern Inspection Using an Analyzer
Measurement Method


- Disconnect the air flow sensor connector, and connect the special tool (test harness: MB991348) in between. (All terminals should be connected.)
- Connect the analyzer special patterns pickup to terminal ③ of the air flow sensor connector.

Standard wave pattern

Observation conditions

Function	Special patterns
Pattern height	Low
Pattern selector	Display
Engine r/min.	Idle r/min. (750/min.)


Observation conditions

(from conditions on previous page, engine speed is increased by racing.)



Wave pattern observation points

Check that cycle time T becomes shorter and the frequency increases when the engine speed is increased.



Examples of abnormal wave patterns

- Example 1

Cause of problem

Sensor interface malfunction

Wave pattern characteristics

Short wave pattern is output even when the engine is not started.

- Example 2



Cause of problem



Damaged rectifier or vortex generation column

Wave pattern characteristics





Unstable wave pattern with non-uniform frequency. However, when an ignition leak occurs during acceleration, the wave pattern will be distorted temporarily, even if the air flow sensor is normal.

HARNESS INSPECTION






<p>3</p> <p>Ⓐ Harness side connector</p>  <p>7FU0657</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Connector: Disconnected 	<p>OK → 4</p> <p>OKX → Repair the harness. (Ⓐ5 – 17, 24)</p>
<p>4</p> <p>Ⓐ Harness side connector</p>  <p>7FU0745</p>	<p>Check for continuity between the air flow sensor and the engine control unit.</p> <ul style="list-style-type: none"> • Air-flow sensor connector: Disconnected • Engine control unit connector: Disconnected 	<p>OK → STOP</p> <p>OKX → Repair the harness. (Ⓐ7 – 57)</p>

INTAKE AIR TEMPERATURE SENSOR



Ⓐ Equipment side connector

Air flow sensor connector





OPERATION

TROUBLESHOOTING HINTS

INSPECTION

Using Multi-use tester (MUT)

FUEL SYSTEM <6G72 Engine> – Refer to Intake Air Temperature Sensor (P.13-34).


<p>1</p> <p>Ⓐ Harness side connector</p>  <p>7FU0657</p>	<p>Check for continuity of the earth circuit.</p>	 → 2  → Repair the harness. (Ⓐ 5 – 17, 24)		
<p>2</p> <p>Ⓐ Harness side connector</p>  <p>7FU0660</p>	<p>Measure the power supply voltage.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: ON <table border="1" data-bbox="685 684 1052 832"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>4.5 – 4.9</td> </tr> </table>	Voltage (V)	4.5 – 4.9	 → STOP  → Repair the harness. (Ⓐ 6 – 8)
Voltage (V)				
4.5 – 4.9				

SENSOR INSPECTION

FUEL SYSTEM <6G72 Engine> – Refer to Intake Air Temperature Sensor (P.13-35).

BAROMETRIC PRESSURE SENSOR


M13YHAA1




Ⓐ Equipment side connector




Air flow
sensor
connector



- Ⓐ Harness side connector




SEL180




Engine control unit connector

6FU1610



1



01L0838

OPERATION

TROUBLESHOOTING HINTS

INSPECTION


Using Multi-use tester (MUT)

FUEL SYSTEM <6G72 Engine> - Refer to Barometric Pressure Sensor (P.13-36).

HARNESS INSPECTION

<p>1</p> <p>Ⓐ Harness side connector</p> <p>7FU0657</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Connector: Disconnected 	<p>OK → 2</p> <p>OK → Repair the harness. (Ⓐ 5 – 17, 24)</p>		
<p>2</p> <p>Ⓐ Harness side connector</p> <p>7FU0665</p>	<p>Measure the power supply voltage of the barometric pressure sensor.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: ON <table border="1" data-bbox="677 726 1044 863"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>4.8 – 5.2</td> </tr> </table>	Voltage (V)	4.8 – 5.2	<p>OK → 3</p> <p>OK → Repair the harness. (Ⓐ 1 – 13, 23)</p>
Voltage (V)				
4.8 – 5.2				
<p>3</p> <p>Engine control unit harness side connector</p> <p>7FU0666</p>	<p>Check for an open-circuit or a short-circuit to earth, between the engine control unit and the barometric pressure sensor.</p> <ul style="list-style-type: none"> • Air flow sensor connector: Disconnected • Engine control unit connector: Disconnected 	<p>OK → STOP</p> <p>OK → Repair the harness. (Ⓐ 2 – 16)</p>		

ENGINE COOLANT TEMPERATURE SENSOR



OPERATION

TROUBLESHOOTING HINTS

INSPECTION




Using Multi-use tester (MUT)

HARNESS INSPECTION


SENSOR INSPECTION

FUEL SYSTEM <6G72 Engine> – Refer to Engine Coolant Temperature Sensor (P.13-38, 39).

HARNESS INSPECTION

<p>1</p>  <p>6FU1241</p>	<p>Measure the power supply voltage of the throttle position sensor.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: ON <table border="1" data-bbox="693 347 1052 484"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>4.8 – 5.2</td> </tr> </table>	Voltage (V)	4.8 – 5.2	<p>OK → 2</p> <p>OK → Repair the harness. (Ⓐ 4 – 17, 24)</p>
Voltage (V)				
4.8 – 5.2				
<p>2</p>  <p>6FU1242</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Connector: Disconnected 	<p>OK → 3</p> <p>OK → Repair the harness. (Ⓐ 4 – 17, 24)</p>		
<p>3</p>  <p>6FU1243</p>	<p>Check for an open-circuit, or a short-circuit to earth, between the engine control unit and the throttle position sensor.</p> <ul style="list-style-type: none"> • Throttle position sensor connector: Disconnected • Engine control unit connector: Disconnected 	<p>OK → STOP</p> <p>OK → Repair the harness. (Ⓐ 2 – 19)</p>		

SENSOR INSPECTION








- (1) Disconnect the throttle position sensor connector.
- (2) Measure resistance between terminal ④ (sensor earth) and terminal ① (sensor power).

Standard value: 3.5–6.5 kΩ

- (3) Connect a pointer type ohmmeter between terminal ④ (sensor earth) and terminal ② (sensor output).
- (4) Operate the throttle, valve slowly from the idle position to the full open position and check that the resistance changes smoothly in proportion with the throttle valve opening angle.
- (5) If the resistance is out of specification, or fails to change smoothly, replace the throttle position sensor.

TPS installation torque: 2.0 Nm (0.2 kgm, 1.5 ft.lbs.)

IDLE POSITION SWITCH



7FU0488

OPERATION



TROUBLESHOOTING HINTS


INSPECTION

Using Multi-use tester (MUT)

FUEL SYSTEM <6G72 Engine> – Refer to Idle Position Switch (P.13-43).


HARNESS INSPECTION





SENSOR INSPECTION

(1) Disconnect the throttle position sensor connector.



(2) Check the continuity between the throttle position sensor connector terminal ③ and terminal ④.



Accelerator pedal	Continuity
Depressed	No continuity
Released	Continuity

(3) If there is a malfunction, replace the throttle position sensor.

NOTE

- After replacement, the idle position switch and throttle position sensor should be adjusted. (Refer to P.13-91.)

SERVO VALVE POSITION SENSOR



OPERATION

- The servo valve position sensor converts the changes (increase or decrease) in the valve position of the engine idling speed control servo (ISC) into pulse signals and inputs these signals to the engine control unit. The engine control unit determines the valve position from these signals, and controls the engine idling speed control servo.
- 5V power is supplied to the servo valve position sensor from the engine control unit, and the earth connection is made from the engine control unit.
- 5V power is applied to the two servo valve position sensor output terminals. When the servo valve position is changed (increased or decreased) by the DC motor inside the servo, the servo valve position sensor generates a signal from the opening and closing between the output terminal and the earth.

TROUBLESHOOTING

The servo valve position sensor is the most important sensor for controlling the engine idling speed. If a malfunction develops when the engine is idling and the electrical load is varied by turning the air conditioner switch to ON and OFF, etc., this sensor is probably defective.

INSPECTION










Using Multi-use tester (MUT)

Function	Item No.	Data display	Check conditions	Load conditions	Standard value
Data reading	55	Servo valve position steps	<ul style="list-style-type: none"> • Engine coolant temperature: 80–95°C (176–203°F) • Lights and accessories: OFF • Transmission: neutral • Steering wheel: neutral position • Idle-position switch: ON (The compressor clutch should be actived when the air conditioner switch is switched ON.) • Engine: idling 	<ul style="list-style-type: none"> • Air conditioner switch: OFF 	2–20 STP
				<ul style="list-style-type: none"> • Air conditioner switch: ON 	8–50 STP Increases





NOTE

When the vehicle is new [driven approximately 500 km (300 miles) or less] the number of steps may be about 30 steps greater than the standard value indicated above.

HARNESS INSPECTION

1  <p>Ⓐ Harness side connector  6FU1881</p>	<p>Measure the power supply voltage of the air intake control valve position sensor.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: ON <table border="1" data-bbox="693 1085 1068 1190"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>4.8–5.2</td> </tr> </table>	Voltage (V)	4.8–5.2	 2  <p>Ⓐ Harness side connector  6FU1250</p>
Voltage (V)				
4.8–5.2				
2  <p>Ⓐ Harness side connector  6FU1250</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Connector: Disconnected 	 3  <p>Ⓐ Harness side connector  6FU1882</p>		
3  <p>Ⓐ Harness side connector  6FU1882</p>	<p>Measure the terminal voltage.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: ON <table border="1" data-bbox="693 1801 1068 1906"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>4.8–5.2</td> </tr> </table>	Voltage (V)	4.8–5.2	  STOP  <p>Repair the harness. (Ⓐ2 – 67) (Ⓐ4 – 68)</p>
Voltage (V)				
4.8–5.2				

TOP DEAD CENTER SENSOR




OPERATION

TROUBLESHOOTING HINTS

FUEL SYSTEM <6G72 Engine> – Top Dead Center Sensor (P.13-44).

INSPECTION

Wave Pattern Inspection Using an Analyzer




Measurement method

- 1) Disconnect the crankshaft angle sensor connector and connect the special tool (test harness: MB998464) in between.
- 2) Connect the analyzer special patterns pickup to terminal ④ (white clip) of the crankshaft angle sensor connector. (When inspecting the TDC sensor signal wave pattern.)
- 3) Connect the analyzer special patterns pickup to terminal ① (red clip) of the crankshaft angle sensor connector. (When inspecting the crankshaft angle sensor signal wave pattern.)

Standard wave pattern

Observation conditions


Function	Special patterns
Pattern height	Low
Pattern selector	Display
Engine r/min.	Idle r/min. (750 r/min.)



6FU1727

Wave pattern observation points

Check that cycle time T becomes shorter and the frequency increases when the engine speed is increased.



Examples of abnormal wave patterns


- Example 1

Cause of problem

Sensor interface malfunction

Wave pattern characteristics

Short wave pattern is output even when the engine is not started.



- Example 2

Cause of problem

Loose timing belt

Abnormality in sensor disk





Wave pattern characteristics

Wave pattern is displaced to the left or right.

HARNESS INSPECTION

<p>1</p> <p>Ⓐ Harness side connector</p> <p>01L0411</p>	<p>Measure the power supply voltage.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: ON <table border="1" data-bbox="718 1064 1085 1211"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>SV</td> </tr> </table>	Voltage (V)	SV	<p>OK → 2</p> <p>OK → Repair the harness. (Ⓐ3 – ignition switch)</p>
Voltage (V)				
SV				
<p>2</p> <p>Ⓐ Harness side connector</p> <p>01A0270</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Connector: Disconnected 	<p>OK → 3</p> <p>OK → Repair the harness. (Ⓐ2 – Earth)</p>		
<p>3</p> <p>Ⓐ Harness side connector</p> <p>01L0407</p>	<p>Check the voltage of the output circuit.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: ON <table border="1" data-bbox="718 1843 1085 1991"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>4.8–5.2</td> </tr> </table>	Voltage (V)	4.8–5.2	<p>OK → STOP</p> <p>OK → Repair the harness. (Ⓐ4 – ②)</p>
Voltage (V)				
4.8–5.2				

CRANK ANGLE SENSOR



OPERATION

TROUBLESHOOTING HINTS

FUEL SYSTEM <6G72 Engine> – Refer to Crank Angle Sensor (P.13-48.)

13-122 FUEL SYSTEM <4G64 Engine> – On-Vehicle Inspection of MPI Components

INSPECTION

Using Multi-use tester


Function	Item No.	Data display	Check conditions	Check description	Normal condition
Data reading	22	Cranking r/min.	<ul style="list-style-type: none"> • Engine is being cranked. • Tachometer connected. (The tachometer is used to check the intermittent pulsation of the ignition coil's primary current.) 	Compare the cranking rpm and the rpm indicated by the multi-use tester.	Both agree.


Function	Item No.	Data display	Check conditions	Engine coolant temperature °C (°F)	Standard value r/min.
Data reading	22	Idling r/min.	<ul style="list-style-type: none"> • Engine: idling • Idle-position switch: ON 	When -20 (-4)	1,300–1,500
				When 0 (32)	1,300–1,500
				When 20 (68)	1,150–1,350
				When 40 (104)	950–1,150
				When 80 (176)	650–850


Wave Pattern Inspection Using an Analyzer

Refer to the top dead center sensor section (P.13-118).

HARNESS INSPECTION

1  <p>④ Harness side connector</p>	<p>Measure the power supply voltage.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: ON <table border="1"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>SV</td> </tr> </table>	Voltage (V)	SV	 2 <p>Repair the harness. (④ – ignition switch)</p>
Voltage (V)				
SV				

2  <p>④ Harness side connector</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Connector: Disconnected 	 3 <p>Repair the harness. (④ – Earth)</p>
---	---	--



IGNITION SWITCH – ST

Refer to P.13-50.




VEHICLE SPEED SENSOR

Refer to P.13-54.


AIR CONDITIONER SWITCH AND POWER RELAY

Refer to P.13-56.

OXYGEN SENSOR



Engine control unit connector



OPERATION

- The oxygen sensor functions to detect the concentration of oxygen in the exhaust gas; it converts those data to voltage, and inputs the resulting signals to the engine control unit.
- If the air/fuel mixture ratio is richer than the theoretical air/fuel mixture ratio (i.e., if the concentration of oxygen in the exhaust gas is sparse), a voltage of approximately 1V is output; if the air/fuel mixture ratio is leaner than the theoretical air/fuel mixture ratio (i.e., if the concentration is dense), a voltage of approximately 0V is output.
- The engine control unit, based upon those signals, regulates the amount of fuel injection so that the air/fuel mixture ratio becomes the theoretical air/fuel mixture ratio.

TROUBLESHOOTING HINTS

Hint 1:

The exhaust gas purification performance will worsen if there is a malfunction of the oxygen sensor.

Hint 2:

If the oxygen sensor output voltage deviates from the standard value even though the results of the checking of the oxygen sensor are normal, the cause is probably a malfunction of a component related to air/fuel mixture ratio control.

[Examples]

- Malfunction of an injector.
- Air leakage into the intake manifold from a leaking gasket.
- Malfunction of the air-flow sensor, the intake air temperature sensor, the barometric-pressure sensor, or the Engine coolant temperature sensor.

INSPECTION

Using Multi-use tester (MUT)

Function	Item No.	Data display	Check conditions	Engine condition r/min.	Standard value mV
Data reading	11	Sensor detection voltage	<ul style="list-style-type: none"> Engine: warm-up (Make the mixture lean by engine speed reduction, and rich by racing.) 	When sudden deceleration from 4,000	200 or lower
				When engine is suddenly raced	600 – 1,000
			<ul style="list-style-type: none"> Engine: warm up using the oxygen sensor signal, check the air/fuel mixture ratio, and also check the condition of control by the engine control unit 	750 (Idling)	400 or lower ↓ 600 – 1,000
				2,000	

HARNESS INSPECTION

<p>1</p> <p>Ⓐ Harness side connector</p> <p>6FU1730</p>	<p>Check for an open-circuit or a short-circuit to earth, between the engine control unit and the oxygen sensor.</p> <ul style="list-style-type: none"> Oxygen sensor connector: Disconnected Engine control unit connector: Disconnected 	<p>OK → 2</p> <p>Repair the harness. (Ⓐ 1 – 4)</p>
--	---	--

<p>2</p> <p>Ⓐ Harness side connector</p> <p>6FU1731</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> Connector: Disconnected 	<p>OK → STOP</p> <p>Repair the harness. (Ⓐ 2 – Earth)</p>
--	---	---


SENSOR INSPECTION

Caution

- Before checking, warm up the engine until engine coolant temperature reaches 80 to 95°C (176 to 205°F).
- Use an accurate digital voltmeter.

- Disconnect the oxygen sensor connector and connect a voltmeter to the oxygen sensor connector.
- While repeating engine racing, measure the oxygen sensor output voltage.



Engine	Oxygen sensor output voltage	Remarks
Race	0.6 – 1.0 V	Make air-fuel mixture rich by accelerator operation




NOTE

For removal and installation of the oxygen sensor, refer to GROUP 15 – Exhaust Manifold.

INJECTORS



M13YTAB



OPERATION

- The injectors are electromagnetic-valve-equipped injection nozzles that function to inject fuel based upon injection signals from the engine control unit.
- Because the surface area of the injection ports is fixed and because the pressure of the fuel relative to the pressure within the manifold is also regulates to a fixed pressure, the amount of fuel injection by injectors is determined by the length of time that the needle valve is open, or, in other words, by the length of time of current flow to the solenoid coil.
- Battery power supply is supplied, by way of the control relay, to the injectors. When the engine control unit switches ON the power transistor within the unit and current flows to the solenoid coil, the injectors open and fuel is injected.

TROUBLESHOOTING HINTS

Hint 1:

If there is a problem with starting while the engine is warm, perform the combustion test and check for leakage of the injectors.

Hint 2:

If the engine can't be started, and the injectors are not activated during cranking, the cause is probably a malfunction such as described below, not with the injectors.

- Malfunction of the circuit for supply of power to the engine control unit, or of the earth circuit.
- Malfunction of the control relay.
- Malfunction of the crank-angle sensor and/or the top dead center sensor.

Hint 3:

If there is a cylinder for which the idling condition does not change when, during idling, the fuel injection of the injectors is cut off in sequence, check that cylinder as described below.

- Check the injector and harness.
- Check the spark plugs and the high-tension cable.
- Check the compression pressure.

Hint 4:

If the injector activation time deviates from the standard value even though the results of the checking of the injector's harness and of the injector itself are normal, the cause may be presumed to be one of the following.

- (1) Incomplete combustion within the cylinder.
(Malfunction of the spark plugs, the ignition coil, the compression pressure, etc.)
- (2) Improper adhesion of EGR valve sheet.
- (3) Increased engine resistance.

INSPECTION
Using Multi-use tester

Function	Item No.	Data display	Check conditions	Engine coolant temperature °C (°F)	Standard value ms
Data reading	41	Activation time* ¹	Engine cranking	When 0 (32)* ²	Approx. 20
				When 20 (68)	Approx. 41
				When 80 (176)	Approx. 10

Function	Item No.	Data display	Check conditions	Engine condition r/min.	Standard value ms
Data reading	41	Activation time * ³	<ul style="list-style-type: none"> • Engine coolant temp: 80–95°C (176–203°F) • Lights and accessories: OFF • Transmission: neutral • Steering wheel: neutral position 	750 (idling)	2.9–4.1
				2,000	2.0–3.2
				When raced suddenly	Increases.

NOTE

*¹: Indicates the injector-activation time when the power source voltage is 11V and the cranking speed is 250 rpm or less.


*²: At a coolant temperature of 0°C (32°F), there is synchronous injection for all four cylinders.

*³: For a new vehicle [driven approximately 500 km (300 miles) or less] the injector-activation may be about ten percent longer than indicated above.


Function	Item No.	Activation description	Check conditions	Normal condition
Actuator test	01	No. 1 injector shut-off	<ul style="list-style-type: none"> • Engine: idling after warm-up (shut off the injectors in sequence during after engine warm-up, check the idling condition) 	Idling condition changes more (Becomes more unstable, or the engine stalls.)
	02	No. 2 injector shut-off		
	03	No. 3 injector shut-off		
	04	No. 4 injector shut-off		

Wave Pattern Inspection Using an Analyzer
Measurement method

- (1) Disconnect the injector connector, and connect the special tool (test harness: MB991348) in between. (The power side and the ECU side terminals should both be connected.)
- (2) Connect the analyzer special patterns pickup to the ECU test harness clip.



Standard wave pattern




7FU1202

Wave pattern observation points

(Point A): Height of back electromotive force in the solenoid coil



Contrast with standard wave pattern	Probable cause
Solenoid coil back electromotive force is low or doesn't appear at all.	Short in the injector solenoid



(Point B): Injector drive time

- The injector drive timing will synchronize with the multi-use tester display.
- When the engine is suddenly raced, the drive time will be greatly extended at first, but the drive time will soon match the engine speed.

HARNESS INSPECTION



ACTUATOR INSPECTION

Checking Operation Sound


Using a sound scope, check the operation sound ("chi-chi-chi") of injectors during idling or during cranking. Check that as the rotating speed increases, the frequency of the operating sound also increases.

Caution

Note that even if the injector you are checking is not operating, you will hear the operating sound of the other injectors.

NOTE

If no operating sound is heard from the injector that is being checked, check the injector drive circuit. If there is nothing wrong with the circuit, a defective injector or engine control unit is suspected.



Measuring Resistance Between Terminals



- (1) Remove the injector connector.
- (2) Measure the resistance between the terminals.

Standard value: 13–16 Ω [at 20°C (68°F)]


- (3) Install the injector connector.

Checking the Injection Condition


- (1) Following the steps below, bleed out the residual pressure within the fuel pipe line to prevent flow of the fuel. (Refer to P.13-89.)
- (2) Remove the injector.
- (3) Arrange the special tool (injector test set), adaptor, fuel pressure regulator and clips as shown in the illustration below.



- (4) Connect the battery's negative (-) terminal.
- (5) Apply battery voltage to the fuel pump check terminal and activate the fuel pump.



- (6) Activate the injector and check the atomized spray condition of the fuel. The condition can be considered satisfactory unless it is extremely poor.






- (7) Stop the actuation of the injector, and check for leakage from the injector's nozzle.

Standard value: 1 drop or less per minute

- (8) Activate the injector without activating the fuel pump; then, when the spray emission of fuel from the injector stops, disconnect the special tool and restore it to its original condition.

IDLE SPEED CONTROL SERVO (DC MOTOR)





TROUBLESHOOTING HINTS

Hint 1: While the engine is idling, if the engine idling speed and servo valve position (step) change when the air conditioner switch is turned to ON and OFF, it can be assumed that the engine idling speed control servo and the servo valve position sensor are operating normally.

Hint 2: If the servo valve position (step) is outside the standard position, the malfunction is probably one of the following:

- (1) Basic engine idling speed adjustment is wrong.
- (2) Some deposit is adhering to the throttle valve.
- (3) Air is being drawn into the air intake manifold through a defective gasket seal.
- (4) Fuel injection malfunction inside a cylinder.
(Spark plug, ignition coil, injector or compression pressure is defective.)

HARNESS INSPECTION

1  <p>④ Harness side connector ⑥ ⑤ ④ ③ ② ①</p> <p>6FU1735</p>	Engine control unit harness side connector  <p>59 58</p>	<p>Check for an open-circuit, or a short-circuit to earth, between the engine control unit and the idle speed control servo.</p>	   <p>Repair the harness. ④ ⑤ — ⑥ ④ ⑥ — ⑤</p>
---	--	--	--



ACTUATOR INSPECTION

Use a sound scope to check if the sound of the ISC servo operating can be heard immediately after the ignition switch is turned to "ON".

NOTE

If the sound of the servo operating cannot be heard, inspect the motor drive circuit and the ISC servo motor.

IGNITION COIL AND POWER TRANSISTOR



6FU1736


OPERATION

FUEL SYSTEM <6G72 Engine> – Refer to Ignition Coil and Power Transistor (P.13-71).

INSPECTION

Using Multi-use tester

Function	Item No.	Data display	Check conditions	Engine condition r/min.	Standard value °BTDC
Data reading	44	Spark advance	<ul style="list-style-type: none"> • Engine: warm • Timing light: set (The timing light is set so as to check the actual ignition timing.) 	750 (Idling)	2-16
				2,000	30-50



Wave Pattern Inspection Using an Analyzer

- Ignition coil primary signal
Refer to GROUP 16 – Ignition System.
- Power transistor control signal


<Measurement method>

- (1) Disconnect the power transistor connector, and connect the special tool (test harness: MB991348) in between. (All terminals should be connected.)
- (2) Connect the analyzer special patterns pickup to the power transistor connector terminal (3).


<Standard wave pattern>

Observation conditions

Function	Special patterns
Pattern height	Low
Pattern selector	Display
Engine r/min.	Approx. 2,000 r/min.



6FU1884



Wave pattern observation points

(Point): Condition of wave pattern build-up and maximum voltage (Refer to abnormal wave pattern examples 1 and 2.)

Examples of abnormal wave patterns

- Example 1

Wave pattern during engine cranking

Cause of problem

Broken wire in ignition primary circuit

Wave pattern characteristics

Top-right part of the build-up section cannot be seen, and voltage value is approximately 2V too low.

- Example 2


Wave pattern during engine cranking

Cause of problem


Malfunction in power transistor





Wave pattern characteristics

Power voltage results when the power transistor is ON.



HARNESS INSPECTION





<p>2</p> <p>Ⓐ Harness side connector Ⓑ Harness side connector</p>  <p>6FU1739</p>	<p>Check for an open-circuit, or a short-circuit to earth, between the power transistor and ignition coil.</p> <ul style="list-style-type: none"> • Ignition coil connector: Disconnected • Power transistor connector: Disconnected <p>OK → 3</p> <p>OK → Repair the harness. (Ⓐ2 – Ⓑ3)</p>		
<p>3</p> <p>Ⓐ Harness side connector</p>  <p>7FU0837</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> • Connector: Disconnected <p>OK → 4</p> <p>OK → Repair the harness. (Ⓑ2 – Earth)</p>		
<p>4</p> <p>Ⓐ Harness side connector</p>  <p>7FU0838</p>	<p>Measure the voltage of the control signal circuit of the power transistor.</p> <ul style="list-style-type: none"> • Connector: Disconnected • Ignition switch: START <table border="1" data-bbox="718 1095 1077 1243"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>2–6</td> </tr> </table> <p>OK → 5</p> <p>OK → Repair the harness. (Ⓑ1 – Ⓛ4)</p>	Voltage (V)	2–6
Voltage (V)			
2–6			
<p>5</p> <p>Ⓐ Ignition timing adjustment connector</p>  <p>7FU1060</p>	<p>Measure the voltage of the ignition timing adjustment terminal.</p> <ul style="list-style-type: none"> • Ignition switch: ON <table border="1" data-bbox="718 1432 1077 1580"> <tr> <td>Voltage (V)</td> </tr> <tr> <td>4.0–5.2</td> </tr> </table> <p>OK → STOP</p> <p>OK → Repair the harness. (Ⓐ1 – Ⓛ2)</p>	Voltage (V)	4.0–5.2
Voltage (V)			
4.0–5.2			

ACTUATOR INSPECTION


Refer to GROUP 16.

PURGE CONTROL SOLENOID VALVE



01A0324

Engine control unit connector



01L0838

OPERATION


- The purge-control solenoid valve is an ON/OFF type of solenoid valve; it functions to regulate the introduction of purge air from the canister to the intake air plenum.
- Battery power is supplied, by way of the control relay, to the purge-control solenoid valve. When the engine control unit switches ON the power transistor within the unit, current flows to the coil, and purge air is introduced.

INSPECTION

Using Multi-use tester

Function	Item No.	Activation	Check conditions	Normal condition
Actuator test	08	Solenoid valve is switched from OFF to ON.	• Ignition switch: ON	Operating sound is heard when driven.

HARNESS INSPECTION



ACTUATOR INSPECTION

Refer to GROUP 17.

FUEL PRESSURE


M13YXAE

HOW TO REDUCE THE FUEL LINE INTERNAL PRESSURE

Refer to P.13-89.

FUEL PUMP OPERATION CHECK

Refer to P.13-89.




FUEL PRESSURE TEST


- (1) Remove all remaining pressure from inside the fuel pipe line to prevent splash of fuel. (Refer to P.13-89.)
- (2) Disconnect the fuel high pressure hose at the delivery pipe side.

Caution


Cover the hose connection with shop towel to prevent splash of fuel that could be caused by some residual pressure in the fuel pipe line.




- (3) Set a fuel pressure gauge on the special tool, placing an adequate O-ring or gasket between the gauge end special tool prevent fuel leaks.



- (4) Attach pressure gauge set in step (3) to the delivery pipe.
- (5) Connect the (–) battery terminal.




- (6) Connect a jumper wire to the terminal for activation of the fuel pump and to the positive (+) terminal of the battery to activate the fuel pump. With fuel pressure applied, check to be sure that there is no fuel leakage from the fuel pressure gauge and the special tool connection part.
- (7) Disconnect the jumper wire (from the terminal for activation of the fuel pump) to stop the fuel pump.
- (8) Start the engine and let it idle.



- (9) Measure the fuel pressure during idling.

Standard value: Approx. 270 kPa (2.7 kg/cm², 38 psi) at curb idle



- (10) Disconnect the vacuum hose from the fuel pressure regulator, and then measure the fuel pressure while using a finger to plug the end of the hose.

Standard value: 330–350 kPa (3.3–3.5 kg/cm², 47–50 psi) at curb idle speed

- (11) Check to be sure that the fuel pressure during idling does not decrease even after the engine is raced a few times.

- (12) Use a finger to gently press the fuel return hose while repeatedly racing the engine, and check to be sure that there is fuel pressure in the return hose also.

NOTE

There will be no fuel pressure in the return hose if there is insufficient fuel flow.

13-140 FUEL SYSTEM <4G64 Engine> — On-Vehicle Inspection of MPI Components

(13) If the fuel pressure measured in steps (9) to (12) deviates from the standard value range, check for the probable cause by referring to the table below, and then make the appropriate repair.

Condition	Probable cause	Remedy
<ul style="list-style-type: none"> • Fuel pressure is too low. • Fuel pressure drops during racing. • No fuel pressure in fuel return hose. 	Fuel filter is clogged.	Replace the fuel filter.
	Malfunction of the valve seat within the fuel pressure regulator, or fuel leakage to return side caused by spring deterioration.	Replace the fuel pressure regulator.
	Fuel pump low discharge pressure.	Replace the fuel pump.
Fuel pressure is too high.	The valve within the fuel pressure regulator is sticking.	Replace the fuel pressure regulator.
	Clogging of the fuel return hose and/or the pipe.	Clean or replace the hose and/or pipe.
No change of the fuel pressure when vacuum hose is connected and when not connected.	Damaged vacuum hose or nipple clogging.	Replace the vacuum hose, or clean the nipple.

(14) Stop the engine and check for a change of the value indicated by the fuel pressure gauge. The condition is normal if there is no decrease of the indicated value within two minutes. If there is a decrease of the indicated value, monitor the speed of the decrease, and, referring to the table below, determine the cause of the problem and make the appropriate repair.

Condition	Probable cause	Remedy
After the engine is stopped, the fuel pressure drops gradually.	Injector leakage.	Replace the injector.
	Leakage at the fuel pressure regulator valve seat.	Replace the fuel pressure regulator.
There is a sudden sharp drop of the fuel pressure immediately after the engine is stopped.	The check valve (within the fuel pump) is not closed.	Replace the fuel pump.

(15) Remove all remaining pressure from inside the fuel pipe.
(Refer to P.13-89.)

(16) Disconnect the fuel pressure gauge and the special tool from the delivery pipe.

Caution

Because there will be a slight amount of remaining pressure in the fuel pipe line, use rags to cover so that fuel doesn't splatter.

- (17) Replace the O-ring at the end of the fuel high-pressure hose with a new one.
- (18) After connecting the fuel high-pressure hose to the delivery pipe, tighten the installation bolt at the specified torque.

Tightening torque: 5 Nm (0.5 kgm, 3.6 ft.lbs.)

- (19) Check to be sure that there is no fuel leakage.

- ① Apply battery voltage to the terminal for activation of the fuel pump so as to activate the fuel pump.
- ② With fuel pressure applied, check for leakage of the fuel line.

FUEL SYSTEM <4D56 Engine>

SPECIFICATIONS

GENERAL SPECIFICATIONS

E13CA-C

Items	Specifications
Fuel	
Tank capacity Standard Wheelbase Long Wheelbase	dm ³ (U.S. gal., Imp. gal.) 75 (19.8, 16.5) 92 (24.3, 20.2)
Fuel injection pump	
Type Governor type Feed pump type	Distribution type Half all speeds Vane type
Injection nozzle	
Nozzle type Holder type	Throttle type Screwed-in type

SERVICE SPECIFICATIONS

E13CB-C

Items	Specifications
Standard value.	
Accelerator cable play	mm (in.)
Fuel cut solenoid valve coil resistance	Ω
Injection pressure	kPa (kg/cm ² , psi)

SPECIAL TOOL

E13DA-C

Tool	Number	Name	Use
	MD998388	Injection pump sprocket puller	Removal of sprocket from drive shaft of injection pump

SERVICE ADJUSTMENT PROCEDURES**FUEL INJECTION TIMING INSPECTION AND ADJUSTMENT**

E13FKAD

Refer to GROUP 11 – Service Adjustment Procedures.

ENGINE IDLING SPEED INSPECTION AND ADJUSTMENT

E13HBAA

Refer to GROUP 11 – Service Adjustment Procedures.

ACCELERATOR CABLE INSPECTION AND ADJUSTMENT <VEHICLES WITHOUT AUTO-CRUISE CONTROL SYSTEM>



E13FCAZ3

For models equipped with the auto-cruise control system, refer to P.13-188.

- (1) Turn the air conditioner and all lights OFF so that there is no electrical load when inspecting.
- (2) Warm the engine until the engine idling speed becomes stable.
- (3) Check that the engine idling speed is at the specified value.
- (4) Stop the engine and turn the ignition switch to OFF.
- (5) Check that there are no sharp bends in the accelerator cable.
- (6) Check the amount of play in the inner cable.
- (7) If there is excessive play in the inner cable, or if there is no play, adjust by the following procedure.
 - ① Loosen the adjusting nut and fully close the throttle lever.
 - ② Tighten the adjusting nut so that the inner cable play is at the standard value, and fix it with the lock nut.

Standard value: 0–1 mm (0–0.04 in.)

- ③ After adjusting, check that the throttle lever is touching the idle adjusting screw (stopper).


**FUEL FILTER REPLACEMENT**

E13FZAN


- (1) Remove the intercooler. (Refer to GROUP 15 – Intercooler.)
- (2) Remove the fuel tank cap to release the pressure inside the tank.
- (3) Disconnect the water level sensor connector.
- (4) Remove the fuel hose and then remove the fuel filter.

Caution**Cover with a rag to prevent fuel from spraying out.**

13-144 FUEL SYSTEM <4D56 Engine> – Service Adjustment Procedures




- (5) Secure the fuel filter pump in a vise, and use an oil filter wrench to remove the fuel filter cartridge.
- (6) Secure the water level sensor in a vise and turn the fuel filter cartridge with both hands to remove the water filter sensor.
- (7) After installing a new fuel filter, bleed all air from the fuel line.
- (8) Start the engine, and check that there are no fuel leakages.



EVACUATION OF WATER FROM FUEL FILTER E13FVAB

Water is in the filter when fuel filter indicator lights. Evacuate water by the following procedures.

- (1) Loosen drain plug.
- (2) Drain water with hand pump. Finger-tighten drain plug.





EVACUATION OF AIR FROM FUEL LINE

E13FSAB

Evacuate air after following services.

- When fuel is drained and re-filled for service.
- When fuel filter is replaced.
- When main fuel line is removed.


- (1) Loosen fuel filter air plug.
- (2) Place rags around air plug hole. Operate hand pump repeatedly until no bubbles come from plug hole. Tighten air plug.
- (3) Repeat until hand pump operation becomes stiff.




FUEL GAUGE UNIT REPLACEMENT

E13FDAC2

- (1) Take out the carpet in the cargo compartment and remove the floor cover.



- (2) Disconnect the connector from the fuel gauge unit, and remove the fuel gauge unit.
- (3) Install the fuel gauge unit so that the packing stoppers (2 places) match the hole in the fuel gauge unit.
- (4) Install the floor cover packing and the floor cover.




2-WAY VALVE REPLACEMENT

E13FFAC2

- (1) Remove the filler neck protector inside the rear left bumper.
- (2) Replace the 2-way valve.

Caution
Be careful not to mistake the direction of the 2-way valve.

- (3) Install the filler neck protector.




FUEL INJECTION PUMP INSPECTION

E13FMAB

1. INSPECTION OF FUEL CUT SOLENOID VALVE OPERATION


- (1) When a sound scope is held against the fuel cut solenoid valve and the ignition switch is turned to "ON", check that the sound of the valve operating can be heard.



2. INSPECTION OF FUEL CUT SOLENOID VALVE COIL RESISTANCE


- (1) Measure the resistance between the fuel cut solenoid valve terminal and the ignition pump and body.

Standard value: 8–10 Ω



3. BOOST COMPENSATOR INSPECTION

- (1) Connect a hand pump (pressure pump type) to the boost compensator nipple.
- (2) Apply positive pressure of 30 kPa (0.3 kg/cm², 4.3 psi.) and check that pressure is maintained.



4. ENGINE SPEED SENSOR INSPECTION

- (1) Disconnect the engine speed sensor.
- (2) Measure the resistance between the engine speed sensor terminals.


Standard value: 1.3–1.9 kΩ

INJECTION NOZZLE INSPECTION AND ADJUSTMENT

E13FOAG

Caution

Never touch the injection spray that is injected from the nozzle.



1. FUEL INJECTION INITIAL PRESSURE INSPECTION

- (1) Install the injection nozzle to a nozzle tester.
- (2) Move the lever of the nozzle tester 2–3 times to inject fuel and to bleed the air.
- (3) Gently press down the lever of the nozzle tester, and take a reading of the indication value on the pressure gauge at the point where the needle slowly rises and then suddenly drops.




Standard value:

<Vehicles without EGR system built up to 1994>
11,770–12,750 kPa
(120–130 kg/cm², 1,707–1,849 psi.)
<Vehicles with EGR system built up to 1994, Vehicles built from 1995>
14,750–15,690 kPa
150–160 kg/cm², 2133–2276 psi.)

- (4) If the fuel injection initial pressure is outside the standard value, disassemble the nozzle holder to clean it, and then change the thickness of the shim to adjust the fuel injection initial pressure.

NOTE

- For disassembly and reassembly of the nozzle holder, refer to the engine workshop manual.
- There are 10 shims for adjustment, with thicknesses in the range 0.10–0.80 mm (0.0039–0.0315 in.).
- When the shim thickness is increased by 0.1 mm (0.0039 in.), the fuel injection initial pressure increases by 2350 kPa (24 kg/cm², 341 psi.).



2. INJECTION SPRAY INSPECTION

- (1) Move the lever of the nozzle tester rapidly (4–6 times per second) to eject the fuel continuously. Check that the injection spray comes out evenly in a straight, thin line (angle of spray is zero). The injection spray patterns shown in the illustration at left are wrong.


- (2) Check that no fuel drips after injection is completed.
- (3) If there are any drips, disassemble the nozzle, clean it and re-inspect, or replace the nozzle.

3. NOZZLE FUEL TIGHT INSPECTION

- (1) Gently raise the lever of the nozzle tester until the pressure inside the nozzle becomes 9,810–10,790 kPa (100–110 kg/cm², 1,422–1,565 psi.) <Vehicles without EGR system built up to 1994, vehicles built from 1995> or 12,750–13,730 kPa (130–140 kg/cm², 1,850–1,990 psi.) <Vehicles with EGR system built from 1995>, and after holding this pressure for approximately 10 seconds, check that there are no fuel leaks from the nozzle.
- (2) If there are any leaks, disassemble the nozzle, clean it and re-inspect, or replace the nozzle.


<Vehicles built up to May, 1994>

(TYPE 1)



14E0223


(TYPE 2)



14E0222


<Vehicles built from June, 1994>

(TYPE 1)



14E0224

Accelerator opener solenoid valve No. 2




Battery

DFU0081

ACCELERATOR LEVER CONTROL CHECK DURING ANTI-SKID BRAKE (ABS) OPERATION ACCELERATOR OPENER SOLENOID VALVE OPERATION CHECK

- (1) Disconnect the No. 2 connector of the accelerator opener solenoid valve.
- (2) Start the engine and run it at idle.

- (3) When the solenoid valve terminals and the battery terminals are connected by jumper leads, check that the accelerator opener operates and that the engine r/min increases.



20E0097





ACCELERATOR OPENER SOLENOID VALVE NO. 1 (FOR AIR CONDITIONER) CHECK

- (1) Remove the vacuum hose from the idle-up solenoid valve.

NOTE

When installing the vacuum hose, be careful not to confuse the connection ends.

- (2) Remove the idle-up solenoid valve connection.



- (3) Connect the vacuum pump (Mighty Vac) to nipple "A".
- (4) Check the air flow with the vacuum pump (Mighty Vac) when battery voltage is applied between the idle-up solenoid valve terminals, and when battery voltage is removed.

Battery voltage	Nipple "B"	Vacuum condition
Applied	Open	Vacuum leaks from nipple "B"
	Covered with a finger* ¹	Vacuum is maintained
Not applied	Open	
	Covered with a finger* ²	Vacuum is maintained

NOTE

At *¹, negative pressure can be felt, but at *², negative pressure cannot be felt.

- (5) Measure the resistance between the idle-up solenoid valve terminals.

Standard value: approx. 40 Ω

ACCELERATOR OPENER SOLENOID VALVE NO. 2 (FOR ANTI-LOCK BRAKE) CHECK

NOTE


When disconnecting the vacuum hose, always make a mark so that the hose can be connected at the original position.

1. Remove the idle-up solenoid valve from the hydraulic unit.
2. Measure the resistance between the solenoid valve terminals.

**Standard value: <TYPE 1> 33–39 Ω
<TYPE 2> 37–44 Ω**


13-150 FUEL SYSTEM <4D56 Engine> – Service Adjustment Procedures

TYPE 1



14E0088


TYPE 2



14E0095

3. Connect a hand vacuum pump to the nipple "A".
4. Check airtightness by applying a vacuum with voltage applied directly from the battery to the solenoid valve terminal and without applying voltage.

Battery voltage	Solenoid valve nipple "B"	Normal condition
Applied	Open	Vacuum leaks
	Blocked with finger	Vacuum maintained
Not applied	Open	Vacuum maintained



VEHICLE SPEED SENSOR CHECK

- (1) With the vehicle speed relay connector connected, connect an analog voltmeter to terminal (3).
- (2) Turn the ignition switch to "ON".
- (3) When the vehicle is moving slowly forward, check that the voltage repeatedly changes from 0 V to 5 V and back.

VEHICLE SPEED RELAY CHECK

With the vehicle speed relay connector connected, check the continuity between the vehicle speed relay terminals (1) and (4).

NOTE

When checking the continuity, use an analog circuit tester, and connect the (–) probe to terminal (1).

Vehicle speed	Continuity between terminals (1)–(4)
15 km/h (9 mph) or less	No continuity
35 km/h (21 mph) or more	Continuity

FUEL SYSTEM <4M40 Engine>

SPECIFICATIONS


GENERAL SPECIFICATIONS

Items	Specifications
Fuel	
Tank capacity	dm ³ (U.S. gal., Imp gab.)
Standard wheelbase	75 (19.8, 16.5)
Long wheelbase	92 (24.3, 20.2)
Fuel injection pump	
Type	Distribution type
Governor type	Half all speeds
Feed pump type	Vane type
Injection nozzle	
Nozzle type	Throttle type
Holder type	Screwed-in type

SERVICE SPECIFICATIONS

Items	Specifications
Standard value	
Accelerator cable play	mm (in.)
Fuel cut solenoid valve coil resistance	Ω
Injection pressure	kPa (kg/cm ² , psi)
	0–1 (0–0.04)
	8–10
	14,710–15,690 (150–160, 2,133–2,276)

SPECIAL TOOL

Tool	Number	Name	Use
	MH062464	Injection pump sprocket puller	Removal of sprocket from drive shaft of injection pump

SERVICE ADJUSTMENT PROCEDURES

FUEL INJECTION TIMING INSPECTION AND ADJUSTMENT

E13FKAD

Refer to GROUP 11 – Service Adjustment Procedures.

ENGINE IDLING SPEED INSPECTION AND ADJUSTMENT

E13HBAA

Refer to GROUP 11 – Service Adjustment Procedures.

ACCELERATOR CABLE INSPECTION AND ADJUSTMENT <VEHICLES WITHOUT AUTO-CRUISE CONTROL SYSTEM>

E13FCAZ3

Refer to P.13-143.

For models equipped with the auto-cruise control system, refer to P.13-188.

FUEL FILTER REPLACEMENT

E13FZAM

Refer to P.13-143.

EVACUATION OF WATER FROM FUEL FILTER

E13FVAB

Refer to P.13-144.

EVACUATION OF AIR FROM FUEL LINE

E13FSAB

Refer to P.13-144.

FUEL GAUGE UNIT REPLACEMENT

E13FDAD

Refer to P.13-144.


2-WAY VALVE REPLACEMENT

E13FFAD

Refer to P.13-145.

ACCELERATOR LEVER CONTROL CHECK DURING ANTI-SKID BRAKE (ABS) OPERATION


Refer to P.13-148



FUEL INJECTION PUMP INSPECTION

INSPECTION OF FUEL CUT SOLENOID VALVE OPERATION


When a sound scope is held against the fuel cut solenoid valve and the ignition switch is turned to "ON", check that the sound of the valve operating can be heard.



INSPECTION OF FUEL CUT SOLENOID VALVE COIL RESISTANCE

Measure the resistance between the fuel cut solenoid valve terminal ① and ⑤.

Standard value: 8–10 Ω




BOOST COMPENSATOR INSPECTION

- (1) Connect a hand pump (pressure pump type) to the boost compensator nipple.
- (2) Apply positive pressure of 29.4 kPa (0.3 kg/cm², 4.3 psi.), and check that pressure is maintained.

INJECTION NOZZLE INSPECTION AND ADJUSTMENT

Caution

Never touch the injection spray that is injected from the nozzle.



FUEL INJECTION INITIAL PRESSURE INSPECTION

- (1) Install the injection nozzle to a nozzle tester.
- (2) Apply positive pressure of 29.4 kPa (0.3 kg/cm², 4.3 psi.), and check that pressure is maintained.
- (3) Gently press down the lever of the nozzle tester, and take a reading of the indication value on the pressure gauge at the point where the needle slowly rises and then suddenly drops.

Standard value: 14,710–15,690 kPa (150–160 kg/cm², 2,133–2,276 psi)


- (4) If the fuel injection initial pressure is outside the standard value, disassemble the nozzle holder to clean it, and then change the thickness of the shim to adjust the fuel injection initial pressure.

NOTE


- For disassembly, reassembly and adjustment of the nozzle holder, refer to the engine workshop manual.
- When the shim thickness is increased by 0.1 mm (0.004 in.), the fuel injection initial pressure increases by approx. 1,177–2,157 kPa (12–22 kg/cm², 171–313 psi).

13-150-4 FUEL SYSTEM <4M40 Engine> – Service Adjustment Procedures

A. Injection angle is large B. Bias



C. Intermittent fuel injection



DFU100


- (2) Check that no fuel drips after injection is completed.
- (3) If there are any drips, disassemble the nozzle, clean it and re-inspect, or replace the nozzle.




01R0531

NOZZLE FUEL TIGHT INSPECTION

- (1) Gently raise the lever of the nozzle tester until the pressure inside the nozzle becomes 12,749–13,729 kPa (130–140 kg/cm², 1,849–1,991 psi.). Check that no fuel leaks from the nozzle within approx. 10 seconds.
- (2) If there are any leaks, disassemble the nozzle, clean it and re-inspect, or replace the nozzle.




DFU0073




**ACCELERATOR LEVER CONTROL CHECK
DURING ANTI-SKID BRAKE (ABS) OPERATION
ACCELERATOR OPENER SOLENOID VALVE OPERATION
CHECK**

- (1) Disconnect the No. 2 connector of the accelerator opener solenoid valve.
- (2) Start the engine and run it at idle.





- (3) When the solenoid valve terminals and the battery terminals are connected by jumper leads, check that the accelerator opener operates and that the engine r/min increases.



ACCELERATOR OPENER SOLENOID VALVE NO. 1 (FOR AIR CONDITIONER) CHECK


- (1) Remove the vacuum hose from the idle-up solenoid valve.
- NOTE
When installing the vacuum hose, be careful not to confuse the connection ends.
- (2) Remove the idle-up solenoid valve connection.
- (3) Connect the vacuum pump (Mighty Vac) to nipple "A".
- (4) Check the air flow with the vacuum pump (Mighty Vac) when battery voltage is applied between the idle-up solenoid valve terminals, and when battery voltage is removed.

Battery voltage	Nipple "B"	Vacuum condition
Applied	Open	Vacuum leaks from nipple "B"
	Covered with a finger* ¹	Vacuum is maintained
Not applied	Open	
	Covered with a finger* ²	Vacuum is maintained




NOTE

At *¹, negative pressure can be felt, but at *², negative pressure cannot be felt.



(5) Measure the resistance between the idle-up solenoid valve terminals.

Standard value: approx. 40 Ω



ACCELERATOR OPENER SOLENOID VALVE NO. 2 (FOR ANTI-LOCK BRAKE) CHECK


NOTE

When disconnecting the vacuum hose, always make a mark so that the hose can be connected at the original position.

1. Remove the idle-up solenoid valve from the hydraulic unit.

2. Measure the resistance between the solenoid valve terminals.

**Standard value: <L.H. drive vehicles> 38–44 Ω
<R.H. drive vehicles> 33–39 Ω**



3. Connect a hand vacuum pump to the nipple "A".

4. Check airtightness by applying a vacuum with voltage applied directly from the battery to the solenoid valve terminal and without applying voltage.

Battery voltage	Solenoid valve nipple "B"	Normal condition
Applied	Open	Vacuum leaks
	Blocked with finger	Vacuum maintained
Not applied	Open	Vacuum maintained


FUEL PUMP <4G64, 6G72, 6G74>

REMOVAL AND INSTALLATION

E13LA--


Pre-removal and Post-installation Operation

- Drain and Filling of Fuel
- Removal and Installation of the Floor Carpet



Removal steps

1. Floor cover
2. Packing
3. Fuel pump connector
4. Fuel high pressure hose
5. Fuel return hose connection
6. Fuel pump and filter assembly
7. Filter
8. Fuel pump assembly



SERVICE POINT OF REMOVAL AND INSTALLATION

E13LDAB

4. REMOVAL AND INSTALLATION OF FUEL HIGH PRESSURE HOSE

- (1) After disconnecting the high-pressure fuel pipe at the body-side main pipe connection, disconnect the pump-side connection.
- (2) To install, carry out the removal procedure in reverse.

INJECTION NOZZLE <4D56, 4M40>

REMOVAL AND INSTALLATION


E13NA-

Pre-removal Operation

- Removal of Intercooler
(Refer to GROUP15 – Intercooler)

Post-installation Operation


- Installation of Intercooler
(Refer to GROUP 15 – Intercooler)
- Adjustment of Accelerator Cable
(Refer to P.13-14, 89.)
- Adjustment of Throttle Control Cable
(Refer to GROUP 23 – Service Adjustment Procedures)



Removal steps

- Accelerator cable connection
- Throttle control cable connection < A/T >
- Injection pipe clamp
- Injection pipe
- Fuel return hose
- Nut

↔ 7. Fuel return pipe
↔ 8. Fuel return pipe gasket
↔ 9. Nozzle holder
10. Holder gasket
11. Nozzle gasket




SERVICE POINTS OF REMOVAL

E13NBAB

4. DISCONNECTION OF INJECTION PIPE

When loosening nuts at both ends of injection pipe, hold the other side (pump side-delivery holder, nozzle side-nozzle holder) with wrench and loosen nut.




7. DISCONNECTION OF FUEL RETURN PIPE

Hold fuel return line hexagon nut with wrench and remove nut.

Caution


Loosening nut without holding fuel return line may damage the line. Be sure to hold line.



9. REMOVAL OF NOZZLE HOLDER

Caution

Label cylinder No. on removed injection nozzle holder to ensure correct nozzle to cylinder reassembly.



SERVICE POINTS OF INSTALLATION

E13NDAB

9. INSTALLATION OF NOZZLE HOLDER

- (1) Clean cylinder head injection nozzle aperture and install new gasket.

Caution

A defective gasket can cause improper idle rpm.

- (2) Tighten to specified torque with deep socket wrench.

INJECTION PUMP <4D56>

REMOVAL AND INSTALLATION


E13MA-

Pre-removal Operation

- Draining of Engine Coolant
<Vehicles with CSD>
- Removal of the Timing Belt
(Refer to GROUP 11 – Timing Belt.)

Post-installation Operation


- Supplying of Engine Coolant
<Vehicles with CSD>
- Installation of the Timing Belt
(Refer to GROUP 11 – Timing Belt.)
- Adjustment of Injection Timing
(Refer to GROUP 11 – Service Adjustment Procedures.)
- Adjustment of Accelerator Cable
(Refer to P.13-143)
- Adjustment of Throttle Control Cable
(Refer to GROUP 23 – Service Adjustment Procedures.)
- Adjustment of Lever Position Switch
(Refer to GROUP 55 – Lever Position Switch.)



03G0236

Removal steps

1. Fuel injection pump wiring harness
2. Water hose connection <Vehicles with CSD>
3. Fuel hoses
4. Lever position switch <A/T – A/C>
5. Accelerator cable connection
6. Throttle control cable connection <A/T>
7. Boost hose connection
8. Fuel injection pipe
9. Fuel injection pump sprocket
10. Fuel injection pump




SERVICE POINT OF REMOVAL

E13MBAG

8. REMOVAL OF INJECTION PIPE

Loosen the nuts at the end of the injection pipe with the corresponding holders (delivery holder for pump side and nozzle holder for nozzle side) retained by a spanner, etc..




9. REMOVAL OF FUEL INJECTION PUMP SPROCKET

Remove sprocket installing nut and remove sprocket from pump drive shaft with special tool.

Caution

1. Do not hit pump drive shaft with hammer, etc.
2. When holding injection pump, do not allow to dangle by holding accelerator lever or fast idle lever.

Do not remove these levers. Removal will cause injection pump malfunction.



SERVICE POINT OF INSTALLATION

E13MDAF

8. INSTALLATION OF INJECTION PIPE

Tighten the nuts at the end of the injection pipe to the specified value with the corresponding holders (delivery holder for pump side and nozzle holder for nozzle side) retained by a spanner, etc..

INJECTION PUMP <4M40>


REMOVAL AND INSTALLATION

Pre-removal Operation

- Draining of Engine Coolant
- Removal of Intercooler
(Refer to GROUP 15 – Intercooler.)
- Removal of Starter Motor


Post-installation Operation


- Adjustment of Injection Timing
(Refer to GROUP 11 – Service Adjustment Procedures.)
- Installation of Starter Motor
- Adjustment of Accelerator Cable
(Refer to P.13-150-2.)
- Adjustment of Throttle Control Cable
- Supplying of Engine Coolant
(Refer to GROUP 14 – Service Adjustment Procedures.)
- Air Bleeding of Fuel Line
- Installation of Intercooler
(Refer to GROUP 15 – Intercooler)



Removal steps

1. Throttle position sensor connector
2. Fuel injection pump wiring harness connector
3. Fuel hoses connection
4. Accelerator cable connection
5. Throttle control cable connection
6. Boost hose connection
7. Water hoses connection
8. Fuel injection pipe
9. Fuel injection pump
10. O-ring






SERVICE POINTS OF REMOVAL


8. REMOVAL OF INJECTION PIPE

Loosen the nuts at the end of the injection pipe with the corresponding holders (delivery holder for pump side and nozzle holder for nozzle side) retained by a spanner, etc..




9. REMOVAL OF FUEL INJECTION PUMP

Align the notch of the crankshaft pulley with the "0" timing mark to set the No. 1 cylinder to the compression top dead centre position.



NOTE


If the protrusion on the camshaft is pointing directly upwards when the filler cap is removed, the No. 1 cylinder will be at the compression top dead centre position.



SERVICE POINTS OF INSTALLATION

9. INSTALLATION OF INJECTION PUMP


Check that the No. 1 cylinder is at the compression top dead centre position and aligning the notch of the injection pump gear with the "T" mating mark on the flange plate, and then install the injection pump to the timing gear case.



8. INSTALLATION OF INJECTION PIPE



Tighten the nuts at the end of the injection pipe to the specified value with the corresponding holders (delivery holder for pump side and nozzle holder for nozzle side) retained by a spanner, etc..

DISASSEMBLY AND ASSEMBLY



Disassembly steps

- 1. Injection pump gear
- 2. Flange plate
- 3. O ring
- 4. Key
- 5. Injection pump



SERVICE POINTS OF REMOVAL

1. REMOVAL OF INJECTION PUMP GEAR

Use the special tool to remove the injection pump gear.

NOTES


FUEL TANK

REMOVAL AND INSTALLATION

[Vehicles built up to May, 1994]


E13GA--

<Standard Wheelbase>



<Long Wheelbase>

<4G64, 6G72, 6G74>



Removal steps


- 1. Vapour hoses
- 2. Fuel check valve
- 3. 2-way valve
- 4. Separator tank
- 5. Fuel high pressure hose <4G64, 6G72, 6G74>
- 6. Fuel main hose <4D56, 4M40>
- 7. Fuel return hose
- 8. Fuel pump connector
- 9. Fuel gauge unit connector
- 10. Bolt
- 11. Fuel tank assembly
- 12. Fuel tank cap
- 13. Fuel filler hose
- 14. Fuel filler neck and vapour hose assembly
- 15. Packing
- 16. Vapour hose
- 17. Fuel filler neck
- 18. Fuel tank
- 19. Separator tank
- 20. Vapour hoses
- 21. Fuel pump assembly <4G64, 6G72, 6G74>
- 22. Filter
- 23. Pipe assembly <4D56, 4M40>
- 24. Fuel gauge unit
- 25. Fuel tank protector
- 26. Plate
- 27. Drain plug
- 28. Fuel tank

03E0082

[Vehicles built from June, 1994]

<Standard Wheelbase>



<6G72, 6G74>



Pre-removal and Post-installation Operation

- Draining and Filling of Fuel
- Removal and Installation of the Filler Neck Protector
- Removal and Installation of the Floor Carpet
- Removal and Installation of the Floor Cover

<4D56, 4M40>



03E0151


Removal steps

1. Vapour hoses
2. 2-way valve
3. High pressure fuel hose <6G72, 6G74>
4. Fuel main hose <4D56, 4M40>
5. Fuel return hose
6. Fuel pump connector <6G72, 6G74>
7. Fuel gauge unit connector
8. Fuel tank protector
9. Fuel tank assembly
10. Fuel tank cap
11. Fuel filler hose
12. Fuel filler neck and vapour hose assembly
13. Packing
14. Vapour hose
15. Fuel filler neck

16. 20. Vapour hoses
17. Fuel pump assembly <6G72, 6G74>
18. Filter
19. Pipe assembly <4D56, 4M40>
20. Fuel gauge unit
21. Plate
22. Drain plug
23. Fuel tank
24. Fuel cut off valve

<Long Wheelbase>

<6G72, 6G74>




03E0152

Removal steps

1. Vapour hoses
 2. 2-way valve
 3. High pressure fuel hose <6G72, 6G74>
 4. Fuel main hose <4D56, 4M40>
 5. Fuel return hose
 6. Fuel pump connector
 7. Fuel gauge unit connector
 8. Fuel tank assembly
 9. Fuel tank cap
 10. Fuel filler hose
 11. Fuel filler neck and vapour hose assembly
 12. Packing
 13. Vapour hose
 14. Fuel filler neck

15. 20. Vapour hoses
 16. Fuel pump assembly } <6G72, 6G74>
 17. Filter
 18. Pipe assembly <4D56, 4M40>
 19. Fuel gauge unit
 20. Fuel tank protector
 21. Plate
 22. Drain plug
 23. Fuel tank
 24. Fuel cut off valve



SERVICE POINTS OF REMOVAL

E13GBAN

5. REMOVAL OF HIGH PRESSURE FUEL HOSE

<4G64, 6G72, 6G74>

After disconnecting the high-pressure fuel hose at the body-side main pipe connection, disconnect the pump-side connection.

Caution

The fuel line has some residual pressure, so cover it with a rag.

12. REMOVAL OF FUEL TANK ASSEMBLY

<Standard Wheelbase>

- (1) Support the fuel tank with the transmission jack or similar tool.
- (2) Remove the fuel tank installation nut and lower the fuel tank.
- (3) Disconnect the fuel filler hose and the vapour hose connector of the fuel tank side, and then disconnect the fuel tank.

INSPECTION

E13GCAM

- Check the hoses and the pipes for crack or damage.
- Check the fuel tank cap for malfunction
- Check the fuel tank for deformation, corrosion or crack.
- Check the fuel tank for dust or foreign material.

NOTE


If the inside of the fuel tank is to be cleaned, use any one of the following:

- (1) Kerosene
- (2) Trichloroethylene
- (3) A neutral emulsion type detergent

- Check the in-tank fuel filter for damage or clogging.
- Check the check valve for malfunction.

FUEL CUT OFF VALVE INSPECTION


If the sound of the float valve moving (knocking sound) can be heard when the valve assembly is gently shaken up and down, then the valve is okay.



03T0038


CHECKING 2-WAY VALVE

Attach a clean rubber hose, and check the operation of the 2-way valve.



03N0078

Inspection procedure	Normal condition
Blow lightly from the inlet side (fuel tank side).	Air passes through after a slight resistance is felt.
Blow lightly from the outlet side (canister side).	Air passes through.



SERVICE POINTS OF INSTALLATION


E13GDAZ

20. INSTALLATION OF VAPOUR HOSES/19./4. SEPARATOR TANK <Vehicle built up to May, 1994>

Connect the vapour hoses with the corresponding numbers as shown in the illustration.


Caution

Connect the vapour hose with the identification mark (yellow tape) between (1)-(1), with the mark towards the separator tank side.




5. INSTALLATION OF FUEL HIGH PRESSURE HOSE <4G64, 6G72, 6G74>

After tightening the high pressure fuel hose at the pump side, tighten the connection at the body-side main pipe.



3. INSTALLATION OF 2-WAY VALVE

Install the 2-way valve, being careful not to mistake the direction.



2. INSTALLATION OF FUEL CHECK VALVE

Install the fuel check valve as shown in the illustration, being careful not to mistake the direction.

FUEL LINE AND VAPOUR LINE <4G64, 6G72, 6G74>



REMOVAL AND INSTALLATION

E13KA-A


<4G64>

Pre-removal Operation

- Release of Residual Pressure from High Pressure Fuel Hose (Refer to P.13-16, 89.)



Engine oil





03E0091


Removal steps

➡➡ 1. High pressure fuel hose	➡➡ 12. High pressure fuel hose
➡➡ 2. Fuel return hose	➡➡ 13. Fuel return hose
➡➡ 5. Fuel vapour hose	14. Fuel main pipe (front)
➡➡ 6. Fuel vapour hose	15. Fuel return pipe (front)
➡➡ 7. Fuel vapour hose	➡➡ 16. Fuel return hose
8. Canister	17. Fuel main pipe (rear)
9. High pressure fuel hose	18. Fuel return pipe (rear)
10. Joint assembly	19. Fuel vapour pipe
11. Fuel filter	

<6G72 – 12 VALVE built up to October, 1993>



<Standard Wheelbase>





<Long Wheelbase>

03E0066

Removal steps


- ➡ 1. High pressure fuel hose
- ➡ 2. Fuel return hose
- ➡ 5. Fuel vapour hose
- ➡ 6. Fuel vapour hose
- ➡ 7. Fuel vapour hose
- ➡ 8. Canister
- ➡ 9. High pressure fuel hose
- ➡ 10. Joint assembly
- ➡ 11. Fuel filter
- ➡ 12. High pressure fuel hose
- ➡ 13. Fuel return hose
- ➡ 14. Fuel main pipe (front)
- ➡ 15. Fuel return pipe (front)
- ➡ 16. Fuel return hose
- ➡ 17. Fuel main pipe (rear)
- ➡ 18. Fuel return pipe (rear)
- ➡ 19. Fuel vapour pipe

<6G72 – 24VALVE>



<6G72 – 12VALVE
Built from November, 1994>

<Standard wheelbase>



03E0167



Removal steps

- ◆ 1. High pressure fuel hose
- ◆ 2. Fuel return hose
- ◆ 3. Fuel return pipe
- ◆ 4. Fuel return hose
- ◆ 5. Fuel vapour hose
- ◆ 6. Fuel vapour hose
- ◆ 7. Fuel vapour hose
- ◆ 8. Canister
- ◆ 9. High pressure fuel hose
- ◆ 10. Joint assembly


<Long Wheelbase>

- ◆ 11. Fuel filter
- ◆ 12. High pressure fuel hose
- ◆ 13. Fuel return hose
- ◆ 14. Fuel main pipe (front)
- ◆ 15. Fuel return pipe (front)
- ◆ 16. Fuel return hose
- ◆ 17. Fuel main pipe (rear)
- ◆ 18. Fuel return pipe (rear)
- ◆ 19. Fuel vapour pipe

<6G74>



<Standard wheelbase>



<Long wheelbase>

Removal steps

- ◆ ◆ 1. High pressure fuel hose
- ◆ ◆ 2. Fuel return hose
- ◆ ◆ 3. Fuel return pipe
- ◆ ◆ 4. Fuel return hose
- ◆ ◆ 5. Fuel vapour hose
- ◆ ◆ 6. Fuel vapour hose
- ◆ ◆ 7. Fuel vapour hose
- ◆ ◆ 8. Canister
- ◆ ◆ 9. High pressure fuel hose
- ◆ ◆ 10. Joint assembly
- ◆ ◆ 11. Fuel filter
- ◆ ◆ 12. High pressure fuel hose
- ◆ ◆ 13. Fuel return hose
- ◆ ◆ 14. Fuel main pipe (front)
- ◆ ◆ 15. Fuel return pipe (front)
- ◆ ◆ 16. Fuel return hose
- ◆ ◆ 17. Fuel main pipe (rear)
- ◆ ◆ 18. Fuel return pipe (rear)
- ◆ ◆ 19. Fuel vapour pipe


SERVICE POINTS OF REMOVAL

E13KBAN

1. REMOVAL OF HIGH PRESSURE FUEL HOSE


Caution

Cover the high pressure hose connection with rags to prevent splash of fuel that could be caused by some residual pressure in the fuel pipe line.



9. REMOVAL OF HIGH PRESSURE FUEL HOSE/10. JOINT ASSEMBLY

Hold fuel filter with a wrench and remove eye bolt retaining high pressure fuel hose joint assembly with an eye wrench.




12. REMOVAL OF HIGH PRESSURE FUEL HOSE

After disconnecting the high-pressure fuel hose at the body-side main pipe connection, disconnect the pump-side connection.

INSPECTION

E13KCAM

- Check the fuel hoses and pipes for cracks, bend, deformation, deterioration or clogging.
- Check the fuel filter for clogging or damage.
- Check the canister for clogging or damage.



SERVICE POINTS OF INSTALLATION

E13KDBA

16./13./4./2. INSTALLATION OF FUEL RETURN HOSE/7./6./5. FUEL VAPOUR HOSE

Insert each hose approximately 25–30 mm (1.0–1.2 in.) into the corresponding pipe.

1. INSTALLATION OF HIGH PRESSURE FUEL HOSE (DELIVERY PIPE SIDE)

Insert the hose, being careful not to damage the O-ring, and tighten securely.

FUEL LINE <4D56, 4M40>

REMOVAL AND INSTALLATION

E13KA-B

Pre-removal Operation


- Removal of the Intercooler
(Refer to GROUP 15 – Intercooler)

Post-installation Operation



- Installation of the Intercooler
(Refer to GROUP 15 – Intercooler)
- Air Bleeding of Fuel Line
(Refer to P.13-144.)

<4D56>

<Vehicles with fuel line heater>



<Vehicles without fuel line heater>



03E0068

<Long Wheelbase>


Removal steps

- ➡➡➡ 1. Fuel return hose
- ➡➡➡ 2. Fuel main hose
- 3. Fuel filter assembly
- 4. Drain plug
- 5. Fuel filter cartridge
- 6. Water level sensor


- 7. Air plug
- 8. Fuel filter pump body
- ➡➡ 9. Fuel main hose
- ➡➡ 10. Fuel return hose
- 11. Fuel main pipe
- 12. Fuel return pipe

<4M40>


<Vehicles with line heater>



<Vehicles without line heater>



<Standard Wheelbase>



03E0168

<Long Wheelbase>

Removal steps


- ◆◆◆ 1. Fuel return hose
- ◆◆◆ 2. Fuel main hose
- ◆◆◆ 3. Fuel filter assembly
- ◆◆◆ 4. Drain plug
- ◆◆◆ 5. Fuel filter cartridge
- ◆◆◆ 6. Water level sensor

- 7. Air plug
- 8. Fuel filter pump body
- ◆◆◆ 9. Fuel main hose
- ◆◆◆ 10. Fuel return hose
- 11. Fuel main pipe
- 12. Fuel return pipe

SERVICE POINTS OF REMOVAL


E13KBAO

1. REMOVAL OF FUEL RETURN HOSE/2. FUEL MAIN HOSE**Caution****Cover with a rag to prevent fuel from spraying out.**




5. REMOVAL OF FUEL FILTER CARTRIDGE

Hold fuel filter pump in vice. Remove fuel filter cartridge with oil filter wrench.



6. REMOVAL OF WATER LEVEL SENSOR

Hold water level sensor in vice. Remove fuel filter cartridge by hand.




INSPECTION

E13KCAN

- Check hoses and line for cracks, bends, deterioration or clogging.
- Check fuel filter for clogging or damage.

WATER LEVEL SENSOR OPERATION


Connect circuit tester to water level sensor connector. Water level sensor is operating correctly if there is continuity when float is raised and no continuity when lowered.



HEATER <Vehicles with fuel line heater>

Measure resistance between terminals ② and ④ of the heater connector.

Standard value: $1.3 \pm 0.2 \Omega$




FUEL TEMPERATURE SENSOR <Vehicles with fuel line heater>

- (1) Immerse the fuel temperature sensor in warm water as shown in the illustration.
- (2) Check the continuity between terminals ① and ③ with a circuit tester as the temperature of the liquid changes.

Standard value:


Temperature	°C (°F)	0 (32)	10 (50)	20 (68)
Resistance	kΩ	1.85–2.5	3.3–4.6	6.0–8.0

**SERVICE POINTS OF INSTALLATION**

E13KDBB

10. INSTALLATION OF FUEL RETURN HOSE/9. FUEL MAIN HOSE

Insert each hose securely as far as the stepped section on the pipes.

**2. INSTALLATION OF FUEL MAIN HOSE/1. FUEL RETURN HOSE**



Insert each hose 25–30 mm (1.0–1.2 in.). If the pipe side is too short, insert the hose as far as possible.

ACCELERATOR CABLE AND PEDAL

REMOVAL AND INSTALLATION



<6G72 – 12VALVE, 6G74>

(L.H. drive vehicles)






<4G64>

(R.H. drive vehicles)



<6G72 – 24VALVE>

(L.H. drive vehicles)




Removal steps of accelerator cable

- Adjustment of accelerator cable
(Refer to P.13-14, 89.)
- 1. Accelerator cable adjusting nuts
- 2. Accelerator cable adjusting bolts
- 3. Accelerator cable mounting bolts
- 4. Accelerator cable


Removal steps of accelerator pedal

6. Accelerator arm bracket mounting bolts
7. Accelerator pedal assembly
8. Pedal
9. Spring
10. Split pin
11. Accelerator arm
12. Return spring
13. Accelerator arm bracket
14. Stopper


<4D56, 4M40>
(R.H. drive vehicles)



(L.H. drive vehicles)



10 Nm
1.0 kgm
7 ft.lbs.



Removal steps of accelerator pedal

- 5. Nob } (Vehicles built from June 1991)
- 6. Nut }
- 7. Idle control cable
- 8. Accelerator arm bracket mounting bolts
- 9. Accelerator pedal assembly
- 10. Pedal
- 11. Spring
- 12. Split pin
- 13. Accelerator arm
- 14. Return spring
- 15. Accelerator arm bracket
- 16. Stopper


Removal steps of accelerator cable

- Intercooler
(Refer to GROUP 15 – Intercooler)
- Adjustment of accelerator cable
(Refer to P.13-143, 150-2.)
- 1. Accelerator cable adjusting nuts
- 3. Accelerator cable mounting bolts
- 4. Accelerator cable

INSPECTION

E130CAM

- Check inner cable for damage.
- Check outer cable for damage.
- Check sliding condition of cable.
- Check accelerator arm bend.
- Check return spring for wear.
- Check connection of inner cable and end metal fittings.



SERVICE POINTS OF INSTALLATION

E130DAP


7. INSTALLATION OF IDLE CONTROL CABLE

- (1) With the idle control knob pushed in fully, move the adjuster until there is no play in the idle control cable, and then tighten the cable.

Caution

Check that there is no tension on the accelerator arm from the idle control cable.

- (2) Adjust the holder cap so that when the idle control knob is pulled out by hand fully and then released, the knob moves back no more than 10 mm (0.4 in.).
(Vehicles built up to May 1991)



AUTO-CRUISE CONTROL SYSTEM

SPECIFICATIONS

GENERAL SPECIFICATIONS

E13CA--

Items	Specifications	
Main switch		
Rated load	A	1
Voltage drop	V	0.15 or less
Control switch		
Rated load	A	
SET		0.1
RESUME		0.1
CANCEL		1.2
Voltage drop	V	0.2 or less
Auto-cruise control unit		
Set error	km/h (mph)	0 ⁰ –1.0 (0 ⁰ –0.6)
Range of speed control	km/h (mph)	40–200 (25–125)
Actuator		
Drive system		Vacuum type
Stroke	mm (in.)	38–42 (1.5–1.7)
Motor-driven vacuum pump		
Rated load	A	0.4 or less


SERVICE SPECIFICATIONS


E13CB--

Items	Specifications	
Accelerator cable play	mm (in.)	0–1 (0–0.04)
Throttle cable play	mm (in.)	1–2 (0.04–0.08)
Auto-cruise control cable play	mm (in.)	1–2 (0.04–0.08)
Control valve, release valve resistance	Ω	50–60

SPECIAL TOOLS

E13DA--

Tool	Number	Name	Use
	MB991341	Multi-use tester assembly	Vehicles built up to October, 1993 • Checking of the self-diagnosis output
	MB991419	ROM pack	

Tool	Number	Name	Use
	MB991502	MUT-II	All models • Checking of the diagnostic output
		ROM pack	

NOTES

TROUBLESHOOTING <AUTO-CRUISE CONTROL SYSTEM>

E13EDACa

Before commencing troubleshooting, carry out each of the following inspections, and make repairs if necessary.


1. Check that the motor-driven vacuum pump assembly, actuator, intermediate link, each cable and the vacuum hose are all installed correctly, and that each cable and vacuum hose circuit is correct.

2. Check that the movement of the intermediate link and each cable is smooth.
3. Check that there is not too much play or tension in each cable.

TROUBLESHOOTING QUICK-REFERENCE CHART

**Auto-cruise control system is canceled when cancellation not wanted.
Or, the auto-cruise control system cannot be set after an automatic cancellation.**


ECU: Electronic control unit



Auto-cruise control system cannot be set.

NOTE

This chart is to be used, then, for troubleshooting if it is not possible to use the self-diagnosis for checking.




Trouble symptom	Probable cause	Check chart No.	Remedy
<ul style="list-style-type: none"> • The set vehicle speed varies greatly upward or downward. • "Hunching" (repeated alternating acceleration and deceleration) occurs after setting is made. 	Malfunction of the vehicle speed sensor circuit	No. 5	Repair the vehicle speed sensor system, or replace the part.
	Malfunction of the speedometer cable or speedometer drive gear		
	Motor-driven vacuum pump circuit poor contact	No. 6	Repair the motor-driven vacuum pump or replace the part.
	Malfunction of the motor-driven vacuum pump		
	Malfunction of the ECU	—	Replace the ECU.
The auto-cruise control system is not canceled when the brake pedal is depressed.	Damaged or disconnected wiring of the stop lamp switch input circuit or stop lamp switch (for auto-cruise control) poor contact (short-circuit)	If the input check code No. 23 indicates a malfunction, see the check chart No. 7	Repair the harness or replace the stop lamp switch.
	Motor-driven vacuum pump drive circuit short-circuit	No. 6	Repair the harness or replace the motor-driven vacuum pump.
	Malfunction of the ECU	—	Replace the ECU.
The auto-cruise control system is not canceled when the clutch pedal is depressed. <M/T> (It is canceled, however, when the brake pedal is depressed.)	Damaged or disconnected wiring of clutch switch input circuit	If the input check code No. 23 indicates a malfunction, see the check chart No. 8	Repair the harness, or repair or replace the clutch switch.
	Clutch switch improper installation (won't switch ON)		
	Malfunction of the ECU	—	Replace the ECU.
The auto-cruise control system is not canceled when the selector lever is moved to the "N" position. <A/T> (It is canceled, however, when the brake pedal is depressed.)	Damaged or disconnected wiring of inhibitor switch input circuit	If the input check code No. 23 indicates a malfunction, see the check chart No. 9	Repair the harness, or repair or replace the inhibitor switch.
	Improper adjustment of inhibitor switch		
	Malfunction of the ECU	—	Replace the ECU.

Trouble symptom	Probable cause	Check chart No.	Remedy
Cannot decelerate by using the SET switch	Temporary damaged or disconnected wiring of SET switch input circuit	No. 2	Repair the harness or replace the control switch.
	Motor-driven vacuum pump circuit poor contact	No. 6	Repair the harness or replace the motor-driven vacuum pump.
	Malfunction of the auto-cruise actuator		
	Malfunction of the ECU	—	Replace the ECU.
Cannot accelerate or resume speed by using the RESUME switch.	Damaged or disconnected wiring, or short-circuit, of RESUME switch input circuit	No. 3	Repair the harness or replace the control switch.
	Motor-driven vacuum pump circuit poor contact	No. 6	Repair the harness or replace the motor-driven vacuum pump.
	Malfunction of the motor-driven vacuum pump		
	Malfunction of the ECU	—	Replace the ECU.
Auto-cruise control system can be set while traveling at a vehicle speed of less than 40 km/h (25 mph), or there is no automatic cancellation at that speed.	Malfunction of the vehicle-speed sensor circuit	No. 5	Repair the vehicle-speed sensor system, or replace the part.
	Malfunction of the speedometer cable or the speedometer drive gear		
	Malfunction of the ECU	—	Replace the ECU.
The indicator lamp of the main switch does not illuminate. (But auto-cruise control system is normal.)	Damaged or disconnected bulb of indicator lamp or malfunction of the main switch	—	Repair the harness or replace the main switch.
	Harness damaged or disconnected		
Overdrive is not canceled during fixed speed driving. <3000-A/T>	Malfunction of circuit related to overdrive cancelation, or malfunction of ECU	No. 10	Repair the harness or replace the part.
No shift to overdrive during manual driving. <3000-A/T>			

CHECK CHART

1. CHECKING THE CONTROL UNIT POWER SUPPLY CIRCUIT



03E0022

Description of operation

When the main switch is switched ON while the ignition switch is ON, current flows to the ignition switch (IG₁), to fuse No. 11 of the junction block,

and to the main switch, the control unit, and to earth. When the ignition switch is turned off, the main switch is also turned off.


Troubleshooting hint

ECU terminal voltage

Terminal No.	Signal	Conditions	Terminal voltage
2	Control unit power supply	When the main switch is switched ON	System voltage
8	Control unit earth	At all times	0 V


2. CHECKING THE SET SWITCH CIRCUIT

<Vehicles built up to October, 1993>



03E0021

<Vehicles built from November, 1993>



Remarks
 □ : Vehicles without SRS
 △ : Vehicles with SRS

*1: L.H. drive vehicles
 *2: R.H. drive vehicles

03E0139

Description of operation

When driving at the desired speed [40–200 km/h (25–125 mph) and the main switch of the auto-cruise control system is pressed to ON, by turning the control switch to SET, the vehicle speed at this time will become the constant driving speed. Also, during constant speed driving, if the control switch is held continuously in the SET

position, the vehicle speed will gradually decrease (COAST), and when the control switch is released, the speed at that time will be the constant driving speed. Current flows to fuse No. 4 of the junction block, to the control switch (SET) and to the control unit.

Troubleshooting hint


Diagnosis-No. 15 (automatically cancelled)

ECU terminal voltage

Terminal No.	Signal	Conditions	Terminal voltage
18	SET switch	When the control switch is turned to the SET position	3 V
		When the control switch is turned to the off position	0 V


3. CHECKING THE RESUME SWITCH CIRCUIT

<Vehicles built up to October, 1993>



03E0021

<Vehicles built from November, 1993>



Remarks
 □ : Vehicles without SRS
 △ : Vehicles with SRS

*1: L.H. drive vehicles
 *2: R.H. drive vehicles

03E0139

Description of operation

The set speed (before cancellation) resumes when the control switch is turned to RESUME position, even if the constant-speed control has been cancelled.

That speed will not resume, however, even if the control switch is turned to RESUME position, if the main switch is switched OFF and if the vehicle speed decreases to 40 km/h (25 mph) or lower.

Troubleshooting hint


Diagnosis-No. 5 (automatically cancelled)

ECU terminal voltage

Terminal No.	Signal	Conditions	Terminal voltage
18	RESUME switch	When the control switch is turned to the RESUME position	6 V
		When the control switch is turned to the off position	0 V


4. CHECKING THE CANCEL SWITCH CIRCUIT

<Vehicles built up to October, 1993>



03E0021

<Vehicles built from November, 1993>



Remarks
 : Vehicles without SRS
 : Vehicles with SRS

*1: L.H. drive vehicles
 *2: R.H. drive vehicles

03E0139

Description of operation

During constant speed driving, when the control switch is turned to the CANCEL position, a cancel signal is sent to the control unit, the current to the motor-driven vacuum pump is stopped, and

constant speed driving is cancelled. Current flows to the fuse No. 4 of the junction block, to the control switch (CANCEL) and to the control unit.

Troubleshooting hint




Diagnosis-No. 15 (automatically cancelled)

ECU terminal voltage

Terminal No.	Signal	Conditions	Terminal voltage
18	CANCEL switch	When the control switch is turned to the CANCEL position	System voltage
		When the control switch is turned to the off position	0 V

5. CHECKING THE VEHICLE-SPEED SENSOR CIRCUIT

<Vehicles built up to October, 1993>

<Vehicles built from November, 1993
(L.H. drive vehicles)><Vehicles built from November, 1993
(R.H. drive vehicles)>

Description of operation

The vehicle-speed sensor is installed within the speedometer; it sends to the control unit pulse signals that are proportional to the rotation speed (i.e., the vehicle speed) of the transmission's

output gear.

This vehicle-speed sensor is the reed switch type of sensor; it generates four pulse signals for each rotation of the speedometer's driven gear.


Troubleshooting hint**Diagnosis–No. 12 (automatically cancelled)****ECU terminal voltage**

Terminal No.	Signal	Conditions	Terminal voltage
19	Vehicle-speed sensor	Set the shift lever to the 1st range <M/T> or the selector lever to D-range <A/T>, move the vehicle forward slowly.	0 V – 0.6 V ← Flashing → 2 V or higher

NOTES

6. CHECKING THE MOTOR-DRIVEN VACUUM PUMP CIRCUIT

<Vehicles built up to October, 1993>



03E0020

Description of operation**HOLD MODE**

When driving at 40 km/h (25 mph) and the main switch is pressed to ON and the control switch is turned to the SET position, the control unit receives a "set" signal. The control unit stops current from flowing to the motor-driven vacuum pump, and makes current flow to the solenoid

coils in the control valve and the release valve to close both valves together.

Also, after reaching the desired speed, the motor-driven vacuum pump and the control valve turn ON and OFF repeatedly according to the driving conditions.

ACCELERATION MODE

When the control switch is moved to the RESUME position, the control unit receives a "resume" signal. The control unit controls current flow to the motor-driven vacuum pump, and controls current flow to the solenoid coils in the control valve and the release valve to close both valves together.

DECELERATION MODE

When the control switch is moved to the SET position, the control unit receives a "set" signal. The control unit stops current from flowing to the motor-driven vacuum pump, and stops current

from flowing to the solenoid coil in the control valve to open the valve. At the same time, the current flowing to the solenoid coil in the release valve is stopped, closing the valve.

RELEASE MODE


When the control switch is moved to the CANCEL position, the control unit receives a "cancel" signal. The control unit stops current from flowing to the motor-driven vacuum pump, and stops current from flowing to the solenoid coils in the control valve and the release valve to open both valves together.

Troubleshooting hint**Diagnosis-No. 11 (automatically cancelled)****ECU terminal voltage**

Terminal No.	Signal	Mode/Terminal voltage (V)			
		Hold	Acceleration	Deceleration	Release
26	Motor-driven vacuum pump drive	System voltage	0	System voltage	System voltage
13	Control valve open/close		0	System voltage	System voltage
12	Release valve open/close		0	0	System voltage

6. CHECKING THE MOTOR-DRIVEN VACUUM PUMP CIRCUIT

<Vehicles built from November, 1993>



Remarks

□ : Vehicles without SRS

△ : Vehicles with SRS

*1: L.H. drive vehicles

*2: R.H. drive vehicles

03E0137

Description of operation

HOLD MODE

When driving at 40 km/h (25 mph) and the main switch is pressed to ON and the control switch is turned to the SET position, the control unit receives a "set" signal. The control unit stops current from flowing to the motor-driven vacuum pump, and makes current flow to the solenoid

coils in the control valve and the release valve to close both valves together.

Also, after reaching the desired speed, the motor-driven vacuum pump and the control valve turn ON and OFF repeatedly according to the driving conditions.

ACCELERATION MODE

When the control switch is moved to the RESUME position, the control unit receives a "resume" signal. The control unit controls current flow to the motor-driven vacuum pump, and controls current flow to the solenoid coils in the control valve and the release valve to close both valves together.

DECELERATION MODE


When the control switch is moved to the SET position, the control unit receives a "set" signal. The control unit stops current from flowing to the motor-driven vacuum pump, and stops current

Troubleshooting hint**Diagnosis–No. 11 (automatically cancelled)****ECU terminal voltage**

Terminal No.	Signal	Mode/Terminal voltage (V)			
		Hold	Acceleration	Deceleration	Release
26	Motor-driven vacuum pump drive	System voltage	0	System voltage	System voltage
13	Control valve open/close		0	System voltage	System voltage
12	Release valve open/close		0	0	System voltage


7. CHECKING THE STOP LAMP SWITCH CIRCUIT

<Vehicles built up to October, 1993>



03E0017

<Vehicles built from November, 1993>



03E0140

NOTE

(1) NC: ON at all times
 (2) NO: OFF at all times

Remarks

*1: L.H. drive vehicles
 *2: R.H. drive vehicles

Description of operation

When the brake pedal is depressed during constant-speed travel, the stop lamp switch's (NC) contacts for the auto-cruise control system open, with the result that the current to the motor-driven vacuum pump is interrupted, thus cancelling the constant-speed travel.

At the same time, moreover, the closing of the (NO) contacts for the stop lamp results in the sending of the cancel signal to the control unit, so that the motor-driven vacuum pump current is discontinued within the control unit, thereby cancelling the constant-speed travel.

Troubleshooting hint


ECU terminal voltage

Terminal No.	Signal	Conditions	Terminal voltage
15	Stop lamp switch (load side)	When the brake pedal is depressed	System voltage
		When the brake pedal is not depressed	0 V


8. CHECKING THE CLUTCH SWITCH CIRCUIT <M/T>

<Vehicles built up to October, 1993>

<Vehicles built from November, 1993>



03E0018



Remarks
 *1: L.H. drive vehicles
 *2: R.H. drive vehicles

03E0141

Description of operation

If the clutch pedal is pressed when driving at a constant speed, the clutch switch is turned ON and a cancel signal is input to the control unit and


the determined driving speed is canceled, because the current flows to the control unit, to the clutch switch and to the earth.

Troubleshooting hint**ECU terminal voltage**


Terminal No.	Signal	Conditions	Terminal voltage
1	Clutch switch	When the clutch pedal is depressed	System voltage
		When the clutch pedal is not depressed	0 V

9. CHECKING THE INHIBITOR SWITCH CIRCUIT <A/T>

<Vehicles built up to October, 1993>



<Vehicles built from November, 1993>



Remarks
 *1: L.H. drive vehicles
 *2: R.H. drive vehicles
 *3: 6G72 engine
 *4: 6G74, 4M40 engine

Description of operation

The inhibitor switch also functions as the switch for the starter.

If the selector lever is moved to the "N" position during constant-speed travel, current flows to the

control unit, inhibitor switch, starter motor, and to earth; the cancel signal is therefore input to the control unit, thus canceling the constant-speed travel.

Troubleshooting hint


ECU terminal voltage

Terminal No.	Signal	Conditions	Terminal voltage
1	Inhibitor switch	Neutral	System voltage


10. CHECKING THE CIRCUIT RELATED TO THE OVERDRIVE-CANCELLATION FUNCTION

<3000-A/T, 3500-A/T>

<Vehicles built up to October, 1993>



<Vehicles built from November, 1993>



Remarks
 *1: L.H. drive vehicles
 *2: R.H. drive vehicles

Description of operation

This is a function that cancels the overdrive function for a certain fixed period of time, if during constant-speed travel in overdrive, the actual vehicle speed decreases to less than the vehicle speed retained in the memory, and then after a short time causes the vehicle speed to return to the vehicle speed retained in the memory.

Overdrive will be cancelled in the following cases:

- If the control switch is turned to the RESUME position.

- If the actual vehicle speed decreases to 7 km/h (4.4 mph) or more below the constant driving speed.

In these case, the OD-ON signal output from the control unit turns the transistor Tr off, and so the current flowing through the overdrive switch is stopped at the transistor Tr, and is then controlled by the 3-speed automatic transmission.



Troubleshooting hint

ECU terminal voltage

Terminal No.	Signal	Conditions	Terminal voltage
11	OD switch	When the OD switch is switched ON	System voltage

11.CHECKING THE THROTTLE POSITION SENSOR AND IDLE SWITCH CIRCUIT <3000, 3500>

<Vehicles built up to October, 1993>



03E0028

Description of operation

The throttle position sensor and idle switch are mounted in the throttle body and are sensors in the MPI system.

The throttle position sensor converts the opening position of the throttle valve to a voltage value, and inputs it to the control unit. The control unit

compares this signal with the vehicle speed signal and changes the amount of actuator control accordingly. The idle switch turns ON and OFF depending on the voltage value from the throttle position sensor to compensate for fluctuations or deviations in the voltage.


Diagnosis-No. 17 (automatically cancelled)

ECU terminal voltage

Terminal No.	Signal	Conditions	Terminal voltage
4	Idle switch	When accelerator pedal is pressed	4.5–5.5 V
		When accelerator pedal is released	0 V
5	Throttle position sensor	When accelerator pedal is pressed all the way down	4.0–5.5 V
		When accelerator pedal is released	0.5–0.7 V

11.CHECKING THE THROTTLE POSITION SENSOR AND IDLE SWITCH CIRCUIT <3000, 3500>

<Vehicles built from November, 1993>



Remarks

*1: 6G72 engine
 *2: 6G74 engine

03E0144

Description of operation

The throttle position sensor and idle switch are mounted in the throttle body and are sensors in the MPI system.

The throttle position sensor converts the opening position of the throttle valve to a voltage value, and inputs it to the control unit. The control unit


compares this signal with the vehicle speed signal and changes the amount of actuator control accordingly. The idle switch turns ON and OFF depending on the voltage value from the throttle position sensor to compensate for fluctuations or deviations in the voltage.

Diagnosis-No. 17 (automatically cancelled)

ECU terminal voltage

Terminal No.	Signal	Conditions	Terminal voltage
4	Idle switch	When accelerator pedal is pressed	4.5–5.5 V
		When accelerator pedal is released	0 V
5	Throttle position sensor	When accelerator pedal is pressed all the way down	4.0–5.5 V
		When accelerator pedal is released	0.5–0.7 V

NOTES



SELF-DIAGNOSIS CHECKING

Self-diagnosis checking is performed when there has been an automatic cancellation, without cancel switch operation.

- (1) Note that the diagnosis check connector is located under the driver's side instrument panel.

Connect the multi-use tester's or MUT-II's socket and connector to the accessories socket and the self-diagnosis check connector, and set the tester.

Caution

The ignition switch should always be turned off when connecting or disconnecting the tester.

Use the multi-use tester or MUT-II according to its operation instructions; display the diagnosis code number and then check.

- (2) When diagnosis code No. is displayed, check by referring to the check chart applicable to that number.

ERASURE OF DIAGNOSIS CODE

Diagnosis codes are memorized until battery power source is disconnected. It, however, can be erased without removing battery terminal by the following procedure.

1. Turn the ignition switch to ON.
2. With the control switch in the SET position, press the main switch to ON, and within 1 second, turn the control switch to RESUME.
3. Turn the control switch back to the SET position, and turn the stop lamp switch to ON for a continuous period of 5 seconds or more.
4. Check the self-diagnosis code, and check that the abnormal code is erased and a normal code is output.

DIAGNOSIS DISPLAY PATTERNS AND CODES

Code No.	Probable cause	Check chart No.
11	Abnormal condition of motor-driven vacuum pump system	No. 6
12	Abnormal condition of vehicle-speed signal system	No. 5
15	Control switch malfunction (when SET and RESUME switches switched ON simultaneously.)	No. 2, 3
16	Abnormal condition of ECU	No. 7, 8, 9
17	Abnormal condition of throttle position sensor <3000, 3500> Abnormal condition of idle switch <3000, 3500>	No. 11

NOTE


1. These diagnosis codes are displayed when not driving at continuous speed with the main switch at ON.
2. After the diagnosis codes in the memory are erased, if (when the power supply of the control unit is switched ON once again) the power supply of the control unit is normal, the diagnosis output code display will be normal, regardless of whether the system condition is normal or not.

INPUT CHECKING

Input checks should be made when the auto-cruise control system cannot be set and when it is necessary to check (when a malfunction related to the auto-cruise control system occurs) whether or not the input signals are normal.

NOTE

1. Self-diagnosis terminal outputs display patterns.
2. Display codes are displayed only if the circuit is normal according to the conditions shown in the "Input Check Table".



Carry out input checking by the following procedure:

- (1) The setting of the multi-use tester or the MUT-II is the same as for self-diagnosis check.
- (2) Turn the ignition switch to ON.
- (3) When the control switch is moved to the SET position, press the main switch to ON, and within 1 second, turn the control switch to RESUME to display the results of input checking.

- (4) Perform each input operation according to the Input Check Table and read the codes.

NOTE

1. If two or more input operations are performed at the same time, the codes will be output in order starting from the lowest number.
2. Each code will be displayed in order of priority beginning from No. 1.
If there is no display, it is possible that there is a malfunction of the ECU power-supply circuit or the SET and/or RESUME switch (control switch), so check according to check chart 1, 2 and 3.

INPUT CHECK TABLE

Check No.	Input operation	Code No.	Check results
1	SET switch ON	21	SET switch circuit normal
2	RESUME switch ON	22	RESUME switch circuit normal
3	Stop lamp switch (brake pedal depressed)	23	Stop lamp switch normal
4	Driving at approximately to 40 km/h (25 mph) or higher	24	When both No. 4 and No. 5 can be confirmed, vehicle-speed sensor circuit normal.
5	Driving at less than approximately 40 km/h (25 mph)	25	
6	1. Clutch switch ON (clutch pedal depressed) <M/T> 2. Inhibitor switch ON (selector lever to "N" range) <A/T>	26	Clutch switch or inhibitor switch normal
7	CANCEL switch ON	28	CANCEL switch circuit normal
8	Throttle position sensor output (when the accelerator pedal is pressed more than half way) <3000, 3500>	28	Throttle position sensor normal
9	Idle switch OFF (accelerator pedal depressed) <3000, 3500>	29	Idle switch normal


SERVICE ADJUSTMENT PROCEDURES

CONTROL CABLES INSPECTION AND ADJUSTMENT


E13FYAEc

<L.H. drive vehicles>


<Petrol-powered vehicles>



<Diesel-powered vehicles>



<R.H. drive vehicles>




03E0046

- (1) Remove the link protector. (Refer to P.13-195.)
- (2) Check if there is any flexion in the inner cables of the accelerator cable, auto-cruise control cable and throttle cable.

If there is excessive flexion or no play in one of the inner cables, loosen the adjusting bolts and nuts of the throttle lever and each link to release each link from the throttle lever.


(Do not remove the adjusting bolts or nuts.)

<L.H. drive vehicles with petrol engine>




03E0052

<L.H. drive vehicles with diesel engine>




03E0055

<R.H. drive vehicles>




03E0053

<L.H. drive vehicles with petrol engine>



03E0052

<L.H. drive vehicles with diesel engine>



03E0055

Accelerator Cable

- While holding link (C) so that it is touching the stopper, adjust the play of the accelerator cable with the adjusting nut so that the cable play is at the standard value.

Standard value: 0–1 mm (0–0.04 in.)


- After adjusting, fix the cable with the lock nut.

Throttle Cable


- While holding link (B) so that it is touching link (C), adjust the play of the throttle cable with the adjusting nut and adjusting bolts so that the cable play is at the standard value.

Standard value: 1–2 mm (0.04–0.08 in.)


- After adjusting, fix the cable with the lock nut.




<L.H. drive vehicles with petrol engine>



<L.H. drive vehicles with diesel engine>




<R.H. drive vehicles>




Auto-cruise Control Cable

- (1) While holding link (A) so that it is touching link (B), adjust the play of the auto-cruise control cable with the adjusting nut so that the cable play is at the standard value.
Standard value: 1-2 mm (0.04-0.08 in.)
- (2) After adjusting, fix the cable with the lock nut.



AUTO-CRUISE CONTROL MAIN SWITCH INSPECTION

- (1) Turn the ignition key to ON.
- (2) Check to be sure that the indicator lamp within the switch illuminates when the main switch is switched ON.




AUTO-CRUISE CONTROL SWITCH INSPECTION

Auto-cruise Control Setting Check

- (1) Switch ON the main switch.
- (2) Drive at the desired speed within the range of approximately 40–200 km/h (25–125 mph).
- (3) Turn the control switch to the SET position.
- (4) Check to be sure that when the switch is released the speed is the desired constant speed.

NOTE

If the vehicle speed decreases to approximately 15 km/h (9 mph) below the set speed, because of climbing a hill for example, the auto-cruise control will be cancelled.




Speed-increase Setting Check

- (1) Set to the desired speed.
- (2) Turn the control switch to RESUME position.
- (3) Check to be sure that acceleration continues while the switch is held, and that when it is released the constant speed at the time when it was released becomes the driving speed.

NOTE

Even if, during acceleration, the vehicle speed reaches or exceeds the high limit [approximately 200 km/h (125 mph)], acceleration will continue, however, when the switch is released, the set speed ("memorized speed") will become the high limit of the vehicle speed.



Speed Reduction Setting Check


- (1) Set to the desired speed.
- (2) Turn the control switch to the SET position.
- (3) Check to be sure that deceleration continues while the switch is pressed, and that when it is released the constant speed at the time when it was released becomes the driving speed.

NOTE


When the vehicle speed reaches the low limit [approximately 40 km/h (25 mph)] during deceleration, the automatic speed control will be cancelled.

Auto-cruise Control Cancellation Check and Check of Return to the Set Speed before Cancellation


- (1) Set the auto-cruise speed control.
- (2) Check to be sure that there is a return to ordinary driving when either of the operations below is performed.



- ① The auto-cruise control switch is turned to the CAN-CEL position.
- ② The brake pedal is depressed.
- ③ The clutch pedal is depressed. <M/T>
- ④ The selector lever is moved to the "N" range. <A/T>



- (3) Turn the control switch to RESUME position while driving at a vehicle speed of approximately 40 km/h (25 mph) or higher, and check to be sure that there is a return to the auto-cruise control speed before it will be cancelled and the vehicle will travel at the constant speed.
- (4) When driving at constant speed and the main switch is turned to OFF, check that the vehicle returns to normal driving conditions.



INDIVIDUAL PARTS INSPECTION


E13HAEEC

Stop Lamp Switch/Brake Switch Inspection

- (1) Disconnect the connector.
- (2) Check for continuity between the terminals of the switch.


: continuity

Measurement conditions	Switch Terminal	Brake switch		Stop lamp switch	
		1	4	2	3
When brake pedal depressed.					
When brake pedal not depressed.					



Clutch Switch Inspection <M/T>

- (1) Disconnect the connector.
- (2) Check to be sure that there is continuity between connector terminals when the clutch pedal is depressed.



Inhibitor Switch ("N" position) Inspection <A/T>

<Vehicles built up to October, 1993>

- (1) Disconnect the connector.
- (2) Check to be sure that there is continuity between connector terminals (7) and (12) when the selector lever is moved to the "N" range.

<Vehicles built from November, 1993>

- (1) Disconnect the connector
- (2) Check to be sure that there is continuity between connector terminals (5) and (6) when the selector lever is moved to the "N" range.

Throttle Position Sensor Inspection <3000, 3500>

Refer to P.13-17.

Idle Switch Inspection <3000, 3500>

Refer to P.13-17.

Vehicle-speed Sensor Inspection

Refer to GROUP 54 – Meters and Gauges.

Auto-cruise Vacuum Pump Inspection

<Solenoid valve (Control valve, Release valve)>


- (1) Remove the auto-cruise vacuum pump connector.
- (2) Measure the resistance value between terminals (1)–(2) and between (1)–(3).

Standard value: 50–60 Ω

- (3) Check that the solenoid valve makes an operating noise when battery voltage is impressed between terminals (1)–(2) and between (1)–(3).
- (4) If there is a malfunction of the solenoid valve, replace the auto-cruise vacuum pump assembly.


<Motor>

- (1) Remove the auto-cruise vacuum pump connector.
- (2) Check that the motor revolves when battery voltage is impressed between terminals (1)–(4).



Actuator Inspection

- (1) Remove the actuator.
- (2) Apply negative pressure to the actuator with the vacuum pump and check that the holder moves more than 35 mm (1.38 in.). In addition, check that there is no change in the position of the holder when negative pressure is maintained in that condition.
- (3) First install the actuator and then inspect and adjust the auto-cruise control cable. (Refer to P.13-188.)



AUTO-CRUISE CONTROL


REMOVAL AND INSTALLATION <LINK AND ACTUATOR>

E13SA--

<L.H. drive vehicles>

Post-installation Operation
 • Control Cables Adjustment
 (Refer to P.13-188.)

<Petrol-powered vehicles>



03E0034

Removal steps of intermediate link


1. Link protector
2. Connection for accelerator cable and link
3. Connection for throttle cable and link
4. Connection for auto-cruise control cable and link
5. Intermediate link
6. Link bracket

Removal steps of actuator

4. Connection for auto-cruise control cable and link
7. Wiring connector
8. Vacuum pump
9. Pump bracket
10. Actuator
11. Actuator bracket

<Diesel-powered vehicles>

Post-installation Operation
 • Control Cables Adjustment
 (Refer to P.13-188.)



03E0035

Removal steps of intermediate link


1. Link protector
2. Connection for accelerator cable and link
3. Connection for throttle cable and link
4. Connection for auto-cruise control cable and link
5. Intermediate link
6. Link bracket

Removal steps of actuator

4. Connection for auto-cruise control cable and link
7. Wiring connector
8. Vacuum pump
9. Pump bracket
10. Actuator
11. Actuator bracket

<R.H. drive vehicles>

Post-installation Operation
 • Control Cables Adjustment
 (Refer to P.13-189.)



03E0014

Removal steps of intermediate link


1. Link protector
2. Connection for accelerator cable and link
3. Connection for throttle cable and link
4. Connection for auto-cruise control cable and link
5. Intermediate link
6. Link bracket

Removal steps of actuator

4. Connection for auto-cruise control cable and link
7. Wiring connector
8. Vacuum pump
9. Pump bracket
10. Actuator
11. Actuator bracket

REMOVAL AND INSTALLATION <SWITCHES, CONTROL UNIT AND SENSORS>


E13SA-A



Removal steps of switches


CAUTION: SRS
 Before removal of air bag module, refer to GROUP 52B – SRS Service Precautions and Air Bag Module and Clock Spring.

12. Main switch	switches
13. Steering column lower trim	
14. Wiring connectors	<Vehicles built up to October, 1993>
16. Control switch	
15. Air bag module (Refer to GROUP 52B – Air Bag Module and Clock Spring.)	<Vehicles built from November, 1993>
16. Control switch	




03E0128

<L.H. drive vehicles>




03E0057


<R.H. drive vehicles>



03E0011



03E0033



03E0004

Removal steps of sensors

19. Vehicle speed sensor (reed switch)
(Refer to GROUP 54 – Meters and Gauges.)
20. Stop lamp switch
21. Clutch switch <M/T>
22. Inhibitor switch <A/T>
23. TPS (Throttle position sensor) <3000, 3500>

NOTES