

COOLING

CONTENTS

E14AA--

SPECIFICATIONS	2 THERMOSTAT AND WATER PUMP	
General Specifications	<4D56>	10
Service Specifications	2 WATER PUMP <4G64>	12
Lubricants	3 WATER PUMP <6G72-12 VALVE>	13
Sealant	3 WATER PUMP <6G74>	13-1
SERVICE ADJUSTMENT PROCEDURES	3 WATER PUMP <4M40>	13-2
Coolant Leaks Checking	4 WATER PUMP <6G72-24 VALVE>	13-3
Radiator Cap Valve Opening Pressure Checking	4 RADIATOR *	14
Coolant Replacement	5 THERMO SWITCH, ENGINE	
Concentration Measurement	5 COOLANT TEMPERATURE GAUGE	
Coolant Inspection	6 UNIT, ENGINE COOLANT TEMPERATURE	
COOLING FAN	6 SENSOR AND ENGINE COOLANT	
THERMOSTAT <4G64, 6G72, 6G74, 4M40>	TEMPERATURE SWITCH	16
	8	

SUPPLEMENTAL RESTRAINT SYSTEM (SRS) - AIR BAG

- (1) An SRS air bag for the driver's side seat is optional equipment in this vehicle.
- (2) The SRS includes the following components: impact sensors, SRS diagnosis unit: SRS warning lamp, air bag module, clock spring, interconnecting wiring. Other SRS-related components (that may have to be removed/installed in connection with SRS service or maintenance) are indicated in the table of contents by an asterisk (*).

WARNING!

- (1) Improper service or maintenance of any component of the SRS, or any SRS-related component, can lead to personal injury or death to service personnel (from inadvertent firing of the air bag) or to the driver (from rendering the SRS inoperative).
- (2) Service or maintenance of any SRS component or SRS-related component must be performed only at an authorized MITSUBISHI dealer.
- (3) MITSUBISHI dealer personnel must thoroughly review this manual, and especially its GROUP 52B - Supplemental Restraint System (SRS), before beginning any service or maintenance of any component of the SRS or any SRS-related component.

SPECIFICATIONS

E14CA--

GENERAL SPECIFICATIONS

Items	Specifications
Cooling method	Water-cooled pressurized, forced circulation
Radiator	Pressurized corrugated fin type
Type	
Performance	J/h (kcal/h, BTU/h)
<6G72 A/T, 4G64>	$193,396 \times 10^3$ (46,200, 183,333)
<6G72 M/T>	$182,093 \times 10^3$ (43,500, 172,619)
<6G74>	$200,930 \times 10^3$ (48,000, 190,476)
<4D56>	$221,861 \times 10^3$ (53,000, 210,317)
<4M40>	$274,186 \times 10^3$ (65,500, 259,920)
Automatic transmission oil cooler <Vehicles with A/T>	
Performance	J/h (kcal/h, BTU/h)
<6G72, 6G74>	$6,195 \times 10^3$ (1,480, 5,873)
<4D56>	$4,814 \times 10^3$ (1,150, 4,563)
<4M40>	$6,279 \times 10^3$ (1,500, 5,952)
Thermostat	
Type	Wax type with jiggle valve
Fan clutch	
Type	Thermo type with spiral type bimetal
Water pump	
Type	Impeller of centrifugal type

SERVICE SPECIFICATIONS

E14CB--

Items	Specifications
Standard value	
Radiator cap	
High pressure valve opening pressure	kPa(kg/cm ² , psi)
Vacuum valve opening pressure	kPa(kg/cm ² , psi)
Range of coolant antifreeze concentration	%
Thermostat	
<4G64, 6G72-12 VALVE>	
Valve opening temperature of thermostat	°C (°F)
Full-opening temperature of thermostat	°C (°F)
<6G74, 6G72-24 VALVE>	
Valve opening temperature of thermostat	°C (°F)
Full-opening temperature of thermostat	°C (°F)
<4D56, 4M40>	
Valve opening temperature of thermostat	°C (°F)
Full-opening temperature of thermostat	°C (°F)
Engine coolant temperature gauge unit	
<4G64, 6G72, 6G74>	
Resistance	
At 70°C (158°F)	Ω
	104 ± 13.5

Items	Specifications	
Engine coolant temperature sensor <4G64, 6G72, 6G74>		
Resistance		
At 20°C (68°F)	kΩ	2.37 ± 0.24
At 80°C (176°F)	Ω	290 ± 32
Thermo switch <6G72-A/T, 6G74-A/T> (always opened type)		
OFF → ON operating temperature	°C (°F)	More than 50 (122)
Engine coolant temperature gauge unit and sensor <4D56, 4M40>		
Resistance of terminal A		
At 70°C (158°F)	Ω	104 ± 13.5
Resistance of terminal B		
At 20°C (68°F)	Ω	3.25 ± 0.33
At 80°C (176°F)	Ω	300
Limit		
Opening pressure of radiator cap high pressure valve	kPa (kg/cm ² , psi)	65 (0.65, 9.2)

LUBRICANTS

E14CD--

Items	Recommended antifreeze	Engine	Quantity		
			dm ³	U.S.qts.	Imp.qts.
Engine coolant	HIGH QUALITY ETHYLENE GLYCOL ANTIFREEZE COOLANT	4G64 6G72, 6G74, 4D56, 4M40	8.0 (9.0) 9.5 (10.5)	8.5 (9.5) 10.0 (11.1)	7.0 (7.9) 8.4 (9.3)

NOTE

() indicates figures with rear heater.

SEALANT

E14CE--

Items	Specified sealant adhesive	Remarks
Cylinder block drain plug Engine coolant temperature sensor <4G64, 6G72, 6G74> Engine coolant temperature gauge unit and sensor <4D56, 4M40> Engine coolant temperature gauge unit <4G64, 6G72, 6G74> Thermo switch <6G72-A/T, 6G74-A/T>	3M Nut Locking Part No. 4171 or equivalent	Drying sealant
	3M ATD Part No. 8660 or equivalent	Semi-drying sealant

SERVICE ADJUSTMENT PROCEDURES

E14FAAA


COOLANT LEAKS CHECKING


1. Confirm that the coolant level is up to the filler neck. Install a radiator cap tester and apply 160 kPa (1.6 kg/cm², 23 psi) pressure, and then check for leakage from the radiator hose or connections.

Caution

1. Be sure to completely clean away any moisture from the places checked.
2. When the tester is taken out, be careful not to spill any coolant from it.
3. Be careful, when installing and removing the tester and when testing, not to deform the filler neck of the radiator.

2. If there is leakage, repair or replace the appropriate part.





RADIATOR CAP VALVE OPENING PRESSURE CHECKING

E14FBAE

1. Use an Adapter to attach the cap to the tester.
2. Increase the pressure until the indicator of the gage stops moving.

Limit: 65 kPa (0.65 kg/cm², 9.2 psi)


Standard value: 75–105 kPa

(0.75–1.05 kg/cm², 11–15 psi)

3. Replace the radiator cap if the reading does not remain at or above the limit.

NOTE

Be sure that the cap is clean before testing, since rust or other foreign material on the cap seal will cause an improper indication.



COOLANT REPLACEMENT

E14FCAS

1. Drain the engine coolant by removing the drain plug and then the radiator cap.

2. Remove the cylinder block drain plugs to drain the engine coolant. <6G72, 6G74, 4D56, 4M40>

NOTE

For the 6G72 and 6G74, the drain plugs are on the left and right bank and for the 4D56 and 4M40, the drain plugs are on the right side.

3. Remove the reserve tank to drain the engine coolant.
4. When the engine coolant has drained out, pour in water from the radiator cap to clean the engine coolant line.
5. Coat the thread of the cylinder block drain plug with specified sealant, and tighten to the specified torque.
6. Securely tighten the radiator drain plug.
7. Install the reserve tank.
8. Slowly pour the engine coolant into the mouth of the radiator until the radiator is full, and pour also into the reserve tank up to the FULL line.

Recommended antifreeze:

HIGH QUALITY ETHYLENE GLYCOL ANTIFREEZE COOLANT

Quantity dm³(U.S.qts., Imp.qts.)

<4G64> 8.0 (8.5, 7.0)

*9.0 (9.5, 7.9)


<6G72, 6G74, 4D56, 4M40> 9.5 (10.0, 8.4)


*10.5 (11.1, 9.2)

NOTE


1. (*) indicates vehicles with rear heater.

2. For Norway, the non-amine type of antifreeze should be used.





- (9) Install the radiator cap securely.
- (10) Start the engine and warm the engine until the thermostat opens.
- (11) After racing the engine several times, stop the engine.
- (12) When the engine has cooled down, remove the radiator cap and once again add engine coolant until the radiator is full, and also refill the reserve tank up to the FULL line.



CONCENTRATION MEASUREMENT

E14FDAC

Measure the temperature and specific gravity of the engine coolant to check the antifreeze concentration.

Standard value: 30%–60% (allowable concentration range)

RECOMMENDED ANTIFREEZE


Antifreeze	Allowable concentration
HIGH QUALITY ETHYLENE GLYCOL ANTIFREEZE COOLANT	30–60 %

Caution

If the concentration of the antifreeze is below 30 %, the anti-corrosion property will be adversely affected.

In addition, if the concentration is above 60 %,

both the anti-freezing and engine cooling properties will decrease, affecting the engine adversely. For these reasons, be sure to maintain the concentration level within the specified range.



COOLANT INSPECTION

E14FHAB

1. Check that the coolant level in the reserve tank is within FULL and LOW limits.
2. Check for presence of oil in the coolant.

COOLING FAN


E14JA--

REMOVAL AND INSTALLATION


Pre-removal and Post-installation Operation

- Draining and Supplying of the Engine Coolant <4G64>


<4G64>



<6G72-12 VALVE>



<6G72-24 VALVE, 6G74>



Removal steps


1. Radiator upper hose connection
2. Shroud
3. Drive belt (Power steering)
4. Drive belt (Air conditioner)
5. Drive belt (Alternator)

<6G64, 6G72-12 VALVE>

6. Drive belt (Alternator)
7. Drive belt (Air conditioner)
11. Cooling fan and fan clutch assembly
12. Pulley
13. Fan clutch
14. Cooling fan


<4G72-24 VALVE, 6G74>

<4D56>




04E0033

<4M40 (L.H. drive vehicles)>



04E0065

<4M40 (R.H. drive vehicles)>




04E0057

Removal steps

- Intcooler
(Refer to GROUP 15 - Intcooler)
- 8. Drive belt (Air conditioner)
- 9. Drive belt (Power steering)
- 10. Drive belt (Alternator)
- 11. Cooling fan and fan clutch assembly

12. Pulley
13. Fan clutch
14. Cooling fan






SERVICE POINT OF REMOVAL

E14JBAB

11. REMOVAL OF COOLING FAN AND FAN CLUTCH ASSEMBLY <4D56, 4M40>

Remove the shroud mounting bolt, and remove the cooling fan and fan clutch assembly through the gap between the shroud and the radiator.




INSPECTION

E14JCAD

COOLING FAN

- Check blades for damage and cracks.
- Check for cracks and damage around bolt holes in fan hub.
- If any portion of fan is damaged or cracked, replace cooling fan.



FAN CLUTCH


- Check to ensure that fluid in fan clutch is not leaking at case joint and seals. If fluid quantity decreases due to leakage, fan speed will decrease and engine overheating might result.
- When a fan attached to an engine is turned by hand, it should give a sense of some resistance. If fan turns lightly, it is faulty.
- Check bimetal strip for damage.

NOTES

THERMOSTAT <4G64, 6G72, 6G74, 4M40>**REMOVAL AND INSTALLATION**


E14GA--

<4G64>



04B0062

<6G72-24 VALVE, 6G74>




01E0110

Pre-removal and Post-installation Operation


- Draining and Supplying of Engine Coolant

<6G72-12 VALVE>



04W578

<4M40>




04E0056

Removal steps

1. Radiator upper hose connection
2. Radiator lower hose connection
3. Water inlet hose connection
4. Water inlet fitting
5. Water outlet fitting
6. Water outlet fitting gasket
7. Thermostat





INSPECTION

E14GCAT

- Check that valve closes tightly at room temperature.
- Check for defects or damage.
- Check for rust or encrustation on valve. Remove if any.
- Immerse the thermostat in water. Stir to raise water temperature and check that thermostat valve opening temperature and the temperature at which valve fully opens valve lift amount [8 mm (0.31 in.) <4G64, 6G72-12 VALVE>], [8.5 mm (0.33 in.) <4M40>], [10 mm (0.39 in.) <6G72-24 VALVE, 6G74>] are at the standard value.

Standard value:

<4G64, 6G72-12 VALVE>



Valve opening temperature 88°C (190°F)
 Temperature at which the valve fully opens 100°C (212°F) or more

<4M40>

Valve opening temperature 76.5°C (170°F)
 Temperature at which the valve fully opens 90°C (194°F) or more

<6G72-24 VALVE, 6G74>

Valve opening temperature 82°C (180°F)
 Temperature at which the valve fully opens 95°C (203°F) or more



NOTE

Measure valve height when fully closed. Calculate lift by measuring the height when fully open.

SERVICE POINTS OF INSTALLATION

E14GDAJ

7. INSTALLATION OF THERMOSTAT

<4G64>

Caution



Check to ensure that the thermostat flange is correctly seated in the thermostat housing socket. If thermostat is installed in the wrong direction, the bottom of the thermostat will touch the rib inside the intake manifold, making it impossible to seat the flange in position.

<6G72-12 VALVE>

Install the thermostat to the intake manifold as illustrated.

Caution

The thermostat flange fits over the manifold seat; ensure that the thermostat is not installed at an angle.



<6G72-24 VALVE, 6G74, 4M40>

Install the thermostat so that the jiggle valve is facing straight up and is aligned with the mark on the thermostat case as shown in the illustration.

Caution


Make absolutely sure that no oil is adhering to the rubber ring of the thermostat. In addition, be careful not to fold over or scratch the rubber ring when inserting.

THERMOSTAT AND WATER PUMP <4D56> REMOVAL AND INSTALLATION

E14HA-

Pre-removal and Post-installation Operation

- Draining and Supplying of the Engine Coolant
- Removal and Installation of the Air Intake Hose



Removal steps of water pump

- Timing belt – Timing belt "B" (Refer to GROUP 11 – Timing Belt Timing Belt "B")

1. Radiator lower hose
2. Power steering oil pump

3. Power steering oil pump bracket
4. Water pump with thermostat

5. Water pump gasket
6. O-ring

7. Water inlet fitting
8. Thermostat

9. Thermostat housing

10. Thermostat housing gasket

11. Water pump

Removal steps of thermostat

1. Radiator lower hose
7. Water inlet fitting

8. Thermostat



1. Radiator lower hose
2. Power steering oil pump

3. Power steering oil pump bracket
4. Water pump with thermostat



5. Water pump gasket
6. O-ring

7. Water inlet fitting
8. Thermostat

9. Thermostat housing

10. Thermostat housing gasket

11. Water pump


No.	Hardness category (Head mark)	$d \times l$ mm (in.)	Remark
1	4T	8×25 (0.31×0.98)	
2	4T	8×40 (0.31×1.57)	
3	7T	8×70 (0.31×2.76)	 

SERVICE POINTS OF REMOVAL

E14HBAA

2. REMOVAL OF POWER STEERING OIL PUMP

- (1) Remove the power steering oil pump from the bracket with the hose still attached.
- (2) Place the power steering oil pump somewhere where it will not be a hindrance to working, being careful not to put too much strain on the hose.



INSPECTION

E14HCAA

THERMOSTAT




- Check that valve closes tightly at room temperature.
- Check for defects or damage.
- Check for rust or encrustation on valve. Remove if any.
- Immerse thermostat in container of water. Stir to raise water temperature and check that thermostat opening valve temperature and the temperature with valve fully open [valve lift-over 8 mm (0.32 in.)] are at the standard value.

Standard value:

Opening valve temperature 76.5°C (170°F)
Full-open 90°C (194°F) or more

NOTE

NOTE Measure valve height when fully closed. Calculate lift by measuring the height when fully open.



WATER PUMP


- Check each part for cracks, damage or wear, and replace the water pump assembly if necessary.
- Check the bearing for damage, abnormal noise and sluggish rotation, and replace the water pump assembly if necessary.
- Check the seal unit for leaks, and replace the water pump assembly if necessary.
- Check for water leakage. If water leaks from hole "A" seal unit is defective. Replace as an assembly.

SERVICE POINTS OF INSTALLATION

E14HRAA

8. INSTALLATION OF THERMOSTAT

Install the thermostat as shown in the illustration.



4. INSTALLATION OF WATER PUMP WITH THERMOSTAT

Rinse the mounting location of the O-ring and water pipe with water, and install the O-ring and water pipe.

Caution

1. Do not apply oil and grease to water pipe O-ring.
2. Keep the water pipe connections free of sand, dust, etc.
3. Insert water pipe until its end bottoms.


WATER PUMP <4G64>

REMOVAL AND INSTALLATION

E14MA-

Pre-removal and Post-installation Operation


- Draining and Supplying of the Engine Coolant
- Removal and Installation of Timing Belt, Timing Belt (B) (Refer to GROUP 11 – Timing Belt)




04E0024

Removal steps

1. Radiator lower hose
2. Alternator brace
3. Water pump
4. Water pump gasket
5. O-ring

No.	Hardness category (Head mark)	$d \times \ell$ mm (in.)	Remark
1	4T	8×20 (0.31×0.79)	
2	4T	8×30 (0.31×1.18)	
3	7T	8×65 (0.31×2.26)	
4	4T	8×40 (0.31×1.57)	

04U0025




INSPECTION

WATER PUMP

E14MCAP

- Check each part for cracks, damage or wear, and replace the water pump assembly if necessary.
- Check the bearing for damage, abnormal noise and sluggish rotation, and replace the water pump assembly if necessary.
- Check the seal unit for leaks, and replace the water pump assembly if necessary.
- Check for water leakage. If water leaks from hole "A" seal unit is faulty. Replace as an assembly.



SERVICE POINTS OF INSTALLATION

E14MDBC

3. INSTALLATION OF WATER PUMP

Rinse the mounting location of the O-ring and water pipe with water, and install the O-ring and water pipe.

Caution


1. Do not apply oil and grease to water pipe O-ring.
2. Keep the water pipe connections free of sand, dust, etc.
3. Insert water pipe until its end bottoms.

WATER PUMP <6G72-12 VALVE>

REMOVAL AND INSTALLATION

Pre-removal and Post-installation Operation

- Draining and Supplying of the Engine Coolant
- Removal and Installation of Timing Belt
(Refer to GROUP 11 – Timing Belt)




04E0039

Removal steps

1. Water bypass hose
2. Radiator lower hose
3. Water inlet fitting
4. Water inlet fitting gasket

5. Cooling fan stay
6. Water pump
7. Water pump gasket
8. O-ring



04W577

INSPECTION

E14MCAP

WATER PUMP

- Check each part for cracks, damage or wear, and replace the water pump assembly if necessary.
- Check the bearing for damage, abnormal noise and sluggish rotation, and replace the water pump assembly if necessary.
- Check the seal unit for leaks, and replace the water pump assembly if necessary.
- Check for water leakage if water leaks from hole "A" seal unit is faulty. Replace as an assembly.

SERVICE POINTS OF INSTALLATION


E14MDBC

6. INSTALLATION OF WATER PUMP

Rinse the mounting location of the O-ring and water pipe with water, and install the O-ring and water pipe.

Caution

1. Do not apply oil and grease to water pipe O-ring.
2. Keep the water pipe connections free of sand, dust, etc.
3. Insert water pipe until its end bottoms.




01L0217

WATER PUMP <6G74>**REMOVAL AND INSTALLATION****Pre-removal and Post-installation Operation**

- Draining and Supplying of the Engine Coolant
- Removal and Installation of Timing Belt
(Refer to GROUP 11 - Timing Belt)
- Removal and Installation of Thermostat (Refer to P. 14-8)

17-20 Nm
1.7-2.0 kgm
12-14 ft.lbs.



04E0059

Removal steps


- 1. Radiator hose
- 2. Water outlet fitting
- 3. O-ring
- 4. Gasket
- 5. Thermostat case
- 6. Gasket
- 7. Water pump fitting
- 8. Gasket
- 9. Water pump
- 10. Gasket
- 11. O-ring

INSPECTION


M14MDAP

WATER PUMP

- Check each part for cracks, damage or wear, and replace the water pump assembly if necessary.
- Check the bearing for damage, abnormal noise and sluggish rotation, and replace the water pump assembly if necessary.
- Check the seal unit for leaks, and replace the water pump assembly if necessary.
- Check for water leakage if water leaks from hole "A" seal unit is faulty. Replace as an assembly.



04E0062



01L0217

SERVICE POINTS OF INSTALLATION**11.3/ INSTALLATION OF O-RINGS**

Rinse the mounting location of the O-ring and water pipe with water, and install the O-ring and water pipe.

Caution

1. Do not apply oil and grease to water pipe O-ring.
2. Keep the water pipe connections free of sand, dust, etc.
3. Insert water pipe until its end bottoms.


WATER PUMP <4M40>

REMOVAL AND INSTALLATION


Pre-removal and Post-installation Operation

- Draining and Supplying of the Engine Coolant
- Removal and Installation of Cooling Fan (Refer to P. 14-7.)

<R.H. drive vehicles>



<L.H. drive vehicles>



04E0066

Removal steps

1. Drive belt
2. Coupling plate
3. Water pump pulley
4. Water pump
5. O-ring



INSPECTION

WATER PUMP

- Check each part for cracks, damage or wear, and replace the water pump assembly if necessary.
- Check the bearing for damage, abnormal noise and sluggish rotation, and replace the water pump assembly if necessary.
- Check the seal unit for leaks, and replace the water pump assembly if necessary.

SERVICE POINTS OF INSTALLATION

4. INSTALLATION OF WATER PUMP

Rinse the mounting location of the O-ring and water pipe with water, and install the O-ring and water pipe.

Caution

1. Do not apply oil and grease to water pipe O-ring.
2. Keep the water pipe connections free of sand, dust, etc.
3. Insert water pipe until its end bottoms.

WATER PUMP <6G72-24 VALVE>


REMOVAL AND INSTALLATION

Pre-removal and Post-installation Operation

- Draining and Supplying of the Engine Coolant
- Removal and Installation of Timing Belt (Refer to GROUP 11 – Timing Belt)
- Removal and Installation of Thermostat (Refer to P.14-8)

Removal steps

1. Radiator hose
2. Water hose
3. Water outlet fitting bracket
4. Water outlet fitting
5. O-ring
6. Gasket
7. Thermostat case
8. Gasket
9. Water pump bracket
10. Water pump
11. Water pump gasket
12. O-ring




04E0071




INSPECTION

WATER PUMP

- Check each part for cracks, damage or wear, and replace the water pump assembly if necessary.
- Check the bearing for damage, abnormal noise and sluggish rotation, and replace the water pump assembly if necessary.
- Check the seal unit for leaks, and replace the water pump assembly if necessary.
- Check for the water leakage if water leaks from hole "A" seal unit is faulty. Replace as an assembly.



04E0062



01L0217

SERVICE POINTS OF INSTALLATION

12.5. INSTALLATION OF O-RINGS

Rinse the mounting location of the O-ring and water pipe with water, and install the O-ring and water pipe.

Caution

1. Do not apply oil and grease to water pipe O-ring.
2. Keep the water pipe connections free of sand, dust, etc.
3. Insert water pipe until its end bottoms.

NOTES

RADIATOR

E14QA--


REMOVAL AND INSTALLATION

Pre-removal Operation


- Draining of the Engine Coolant
- Removal of the Intercooler <4D56> (Refer to GROUP 15 – Intercooler)
- Removal of the Cooling Fan <4G64, 4D56> (Refer to P.14-6.)
- Removal of the Under Cover <A/T>

<4G64, 4D56>

Vehicles built up to March 1991




Vehicles built from April 1991




<6G72, 6G74>

Vehicles built up to March 1991




Vehicles built from April 1991

**Removal steps**

1. Automatic transmission oil cooler hose connection <AVT>
2. Radiator upper hose
5. Radiator shroud
6. Overflow hose
7. Reserve tank

9. Radiator and radiator lower hose
10. Radiator
11. Radiator lower hose

<4M40>



01E0127

Removal steps

1. Automatic transmission oil cooler hose connection <AT>	7. Reserve tank
2. Radiator upper hose	8. Upper insulator
3. Corner	9. Radiator and radiator lower hose
4. Cover	10. Radiator
5. Radiator shroud	11. Radiator lower hose
6. Overflow hose	12. Lower insulator

INSPECTION


E14QCAL

- Check for foreign material between radiator fins.
- Check the radiator fins for bend or damage.
- Check the radiator for corrosion, damage, rust or scale.
- Check the radiator hoses for cracks, damage or deterioration.
- Check the reserve tank for damage.
- Check the spring of radiator cap for deterioration.
- Check the packing of radiator cap for damage or cracks.

11. INSTALLATION OF RADIATOR LOWER HOSE

<6G74>

The radiator hose should be inserted just as far as the stepped section and then secured with the clamp.



04E0068

NOTES

THERMO SWITCH, ENGINE COOLANT TEMPERATURE GAUGE UNIT, ENGINE COOLANT TEMPERATURE SENSOR AND ENGINE COOLANT TEMPERATURE SWITCH


E14UA--

REMOVAL AND INSTALLATION



Pre-removal and Post-installation Operation

- Draining and Supplying of the Engine Coolant
- Removal and Installation of the Intercooler <4D56, 4M40> (Refer to group 15 – Intercooler)


<4G64>




<6G72-12 VALVE>



<6G74>




<4D56>



04E0026


<6G72-24 VALVE>

8 Nm
0.8 kgm
6 ft.lbs.

04E0070

4 10-12 Nm
1.0-1.2 kgm
7-9 ft.lbs.

<4M40>



04E0067

2 35 Nm
3.5 kgm
25 ft.lbs.

1. Thermo switch <6G72-A/T, 6G74-A/T>
2. Engine coolant temperature switch <A/C>
3. Engine coolant temperature sensor <4G64, 6G72, 6G74>
4. Engine coolant temperature gauge unit <4G64, 6G72, 6G74>
5. Engine coolant temperature gauge unit and sensor <4D56, 4M40>

INSPECTION

E14UCAO

THERMO SWITCH <6G72-A/T, 6G74-A/T>


Raise the water temperature and check continuity when it reaches the specified temperature.

Standard value:


<6G72-12 VALVE, 6G74>

50°C (122°F) or more
50°C (122°F) dimmerContinuity
No continuity

<6G72-24 VALVE>

35°C (95°F) or more
35°C (95°F) dimmerContinuity
No continuity

04W590




04A0020

ENGINE COOLANT TEMPERATURE SENSOR <4G64, 6G72, 6G74>

Raise the water temperature and measure the resistance if within the standard value.

Standard value:


2.37 ± 0.24 kΩ [at 20°C (68°F)]
290 ± 32Ω [at 80°C (176°F)]



ENGINE COOLANT TEMPERATURE GAUGE UNIT <4G64, 6G72, 6G74>

Immerse the gauge unit in hot water at 70°C (158°F) and measure the resistance value with an ohmmeter.

Standard value: $104 \pm 13.5\Omega$ [at 70°C (158°F)]



ENGINE COOLANT TEMPERATURE GAUGE UNIT AND SENSOR

<4D56, 4M40>

Raise the water temperature and measure the resistance if within the standard value.

Standard value:

Terminal A	$104 \pm 13.5\Omega$ [at 70°C (158°F)]
Terminal B	$3.25 \pm 0.33k\Omega$ [at 20°C (68°F)]
	300Ω [at 80°C (176°F)]

NOTE

Terminal A is for engine coolant temperature gauge. Terminal B is for glow and EGR control.

ENGINE COOLANT TEMPERATURE SWITCH <A/C>

Refer to GROUP 55-Engine Coolant Temperature Switch.