





# Workshop Manual

SUPPLEMENT

## PAJERO 2001



Pub. No. PWJE0001-A (PHJE0001-A)

# PAJERO

WORKSHOP MANUAL .....

## FOREWORD

ELECTRICAL WIRING .....

This manual integrates the WORKSHOP  
MANUAL(chassis), ELECTRICAL WIRING.

“GDI” is a registered trade mark of Mitsubishi  
Motors Corporation.

 **mitsubishi MOTORS CORPORATION**

# PAJERO

## WORKSHOP MANUAL SUPPLEMENT

General .....

00

Fuel .....

13

### FOREWORD

This manual outlines changes in servicing procedures related to the chassis including vehicle inspections and adjustments in the newly added equipment MITSUBISHI STABILITY CONTROL(MITSUBISHI SC). Please read this manual carefully so that it will be of assistance for your service activities. Use the following manuals in combination with this manual as required.

TECHNICAL INFORMATION MANUAL  
PYJE0001

WORKSHOP MANUAL  
ENGINE GROUP PWEE\_\_\_\_  
(Looseleaf edition)

CHASSIS GROUP PWJT0008R  
(CD-ROM)

ELECTRICAL WIRING PHJE0001

BODY REPAIR MANUAL PBJE0001

PARTS CATALOGUE B603H601A□

All information, illustrations and product descriptions contained in this manual are current as at the time of publication. We, however, reserve the right to make changes at any time without prior notice or obligation.

## GROUP 00

## GENERAL

### OUTLINE OF CHANGES

The following models are equipped with Mitsubishi Stability Control (MITSUBISHI SC) system.

### VEHICLE IDENTIFICATION

#### MODELS

#### <Short wheelbase>

| Model code |        | Engine model                           | Transmission model | Fuel supply system                                        |
|------------|--------|----------------------------------------|--------------------|-----------------------------------------------------------|
| V68W       | MNDFL6 | 4M41-DOHC Intercooler Turbo (3,200 mL) | V5M31 <5M/T>       | Electronically-controlled high pressure fuel distribution |
|            | MNHFL6 |                                        |                    |                                                           |
|            | MNHFR6 |                                        |                    |                                                           |
|            | MYHFL6 |                                        | V5A51 <5A/T>       |                                                           |
|            | MYHFR6 |                                        |                    |                                                           |
|            | MNXFL6 |                                        | V5M31 <5M/T>       |                                                           |
|            | MNXFR6 |                                        |                    |                                                           |
|            | MYXFL6 |                                        | V5A51 <5A/T>       |                                                           |
|            | MYXFR6 |                                        |                    |                                                           |
| V65W       | MNHCL6 | 6G74GDI (3,496 mL)                     | V5M31 <5M/T>       | GDI                                                       |
|            | MNHCR6 |                                        |                    |                                                           |
|            | MYHCL6 |                                        | V5A51 <5A/T>       |                                                           |
|            | MYHCR6 |                                        |                    |                                                           |
|            | MNXCL6 |                                        | V5M31 <5M/T>       |                                                           |
|            | MNXCR6 |                                        |                    |                                                           |
|            | MYXCL6 |                                        | V5A51 <5A/T>       |                                                           |
|            | MYXCR6 |                                        |                    |                                                           |

## &lt;Long wheelbase&gt;

| Model code |        | Engine model                           | Transmission model | Fuel supply system                                        |
|------------|--------|----------------------------------------|--------------------|-----------------------------------------------------------|
| V78W       | LNDFL6 | 4M41-DOHC Intercooler Turbo (3,200 mL) | V5M31 <5M/T>       | Electronically-controlled high pressure fuel distribution |
|            | LNHFL6 |                                        |                    |                                                           |
|            | LNHFR6 |                                        |                    |                                                           |
|            | LYHFL6 |                                        | V5A51 <5A/T>       |                                                           |
|            | LYHFR6 |                                        |                    |                                                           |
|            | LNXFL6 |                                        | V5M31 <5M/T>       |                                                           |
|            | LNXFR6 |                                        |                    |                                                           |
|            | LYXFL6 |                                        | V5A51 <5A/T>       |                                                           |
|            | LYXFR6 |                                        |                    |                                                           |
| V75W       | LNHCL6 | 6G74GDI (3,496 mL)                     | V5M31 <5M/T>       | GDI                                                       |
|            | LNHCR6 |                                        |                    |                                                           |
|            | LYHCL6 |                                        | V5A51 <5A/T>       |                                                           |
|            | LYHCR6 |                                        |                    |                                                           |
|            | LNXCL6 |                                        | V5M31 <5M/T>       |                                                           |
|            | LNXCR6 |                                        |                    |                                                           |
|            | LYXCL6 |                                        | V5A51 <5A/T>       |                                                           |
|            | LYXCR6 |                                        |                    |                                                           |

# FUEL

## CONTENTS

|                                                    |     |
|----------------------------------------------------|-----|
| GDI (GASOLINE DIRECT INJECTION) .....              | 13A |
| MITSUBISHI STABILITY CONTROL (MITSUBISHI SC) ..... | 13E |

---

# GASOLINE DIRECT INJECTION (GDI)

## CONTENTS

|                         |          |                                  |          |
|-------------------------|----------|----------------------------------|----------|
| <b>GENERAL .....</b>    | <b>3</b> | <b>GENERAL INFORMATION .....</b> | <b>3</b> |
| Outline of Change ..... | 3        | General Specifications .....     | 3        |

---

## GENERAL

### OUTLINE OF CHANGE

The engine-ECU <M/T> and engine-A/T-ECU <A/T>, which feature communication port with stability control system, have been introduced. The service procedures for these ECUs are the same as before.

## GENERAL INFORMATION

### GENERAL SPECIFICATIONS

| Items                |                    | Specifications                   |
|----------------------|--------------------|----------------------------------|
| Engine-ECU <M/T>     | Identification No. | E2T79275 <LHD><br>E2T79276 <RHD> |
| Engine-A/T-ECU <A/T> | Identification No. | E2T76290 <LHD><br>E2T76291 <RHD> |



# MITSUBISHI STABILITY CONTROL (MITSUBISHI SC)

## CONTENTS

|                                       |    |                                      |    |
|---------------------------------------|----|--------------------------------------|----|
| <b>GENERAL INFORMATION</b> .....      | 2  | Wheel Speed Sensor (FR) Check .....  | 18 |
| <b>SERVICE SPECIFICATIONS</b> .....   | 4  | Vehicle Speed Sensor Check .....     | 18 |
| <b>SPECIAL TOOLS</b> .....            | 4  | <b>SC-ECU*</b> .....                 | 19 |
| <b>TROUBLESHOOTING</b> .....          | 5  | <b>G SENSOR</b> .....                | 20 |
| <b>ON-VEHICLE SERVICE</b> .....       | 18 | <b>WHEEL SPEED SENSOR (FR)</b> ..... | 20 |
| Operation Test of MITSUBISHI SC ..... | 18 | <b>VEHICLE SPEED SENSOR</b> .....    | 20 |

### WARNINGS REGARDING SERVICING OF SUPPLEMENTAL RESTRAINT SYSTEM (SRS) EQUIPPED VEHICLES

#### WARNING!

- (1) Improper service or maintenance of any component of the SRS, or any SRS-related component, can lead to personal injury or death to service personnel (from inadvertent firing of the air bag) or to the driver and passenger (from rendering the SRS inoperative).
- (2) Service or maintenance of any SRS component or SRS-related component must be performed only at an authorized MITSUBISHI dealer.
- (3) MITSUBISHI dealer personnel must thoroughly review this manual, and especially its GROUP 52B – Supplemental Restraint System (SRS) before beginning any service or maintenance of any component of the SRS or any SRS-related component.

#### NOTE

The SRS includes the following components: front impact sensors, SRS-ECU, SRS warning lamp, air bag module, clock spring and interconnecting wiring. Other SRS-related components (that may have to be removed/installed in connection with SRS service or maintenance) are indicated in the table of contents by an asterisk (\*).


## GENERAL INFORMATION

The MITSUBISHI Stability Control (MITSUBISHI SC) system, which compensates for an unsafe driving by controlling the engine output (i.e., traction control), has been introduced.




The MITSUBISHI SC judges that the vehicle is unstable via the lateral gravity sensor.

Then the system will control the engine output, based on the vehicle speed and the throttle opening angle.


In addition, if the system fails, the SC warning lamp inside the combination meter will illuminate or flash to warn the driver.



## System Diagram



System Circuit Diagram



Y0587CA



## MAJOR COMPONENT REFERENCE TABLE

| Components                   | Functions                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SC-ECU                       | Receives signals from various sensors, and transmits an engine output control signal to the engine-ECU or engine-A/T-ECU, based on the information.                                                                                                                                                                                                                                                                                                   |
| Engine-ECU<br><M/T, 4M4-A/T> | Transmits the engine information (such as APS signal and engine speed), which is required for control the Mitsubishi SC, to the SC-ECU.<br><br>Compensate for the engine output according to the current engine condition on request from the SC-ECU.                                                                                                                                                                                                 |
| Engine-A/T-ECU <6G7-A/T>     | <ul style="list-style-type: none"> <li>Transmits the engine information (such as APS signal and engine speed), which is required for controlling the Mitsubishi SC, to the SC-ECU.</li> <li>Transmits the transmission information (such as shift position), which is required for controlling the Mitsubishi SC, to the SC-ECU.</li> </ul><br>Compensate for the engine output according to the current engine condition on request from the SC-ECU. |
| A/T-ECU <4M4-A/T>            | Transmits the transmission information (such as shift position), which is required for controlling the Mitsubishi SC, to the SC-ECU.                                                                                                                                                                                                                                                                                                                  |
| ABS-ECU                      | Transmits the wheel speed sensor (FR) signal to the SC-ECU.                                                                                                                                                                                                                                                                                                                                                                                           |
| G sensor                     | Measures the vehicle lateral gravity, and transmit the information to the SC-ECU as a voltage signal.                                                                                                                                                                                                                                                                                                                                                 |
| Vehicle speed sensor         | Transmits the vehicle speed (transmission output gear speed) signal to the SC-ECU.                                                                                                                                                                                                                                                                                                                                                                    |
| SC warning lamp              | Illuminates or flashes when the SC-ECU transmits a signal indicating the system error.                                                                                                                                                                                                                                                                                                                                                                |
| Diagnosis connector          | When a diagnosis code is set, the MUT-II communicates with the system via this connector.                                                                                                                                                                                                                                                                                                                                                             |

## SERVICE SPECIFICATIONS

| Items                     | Standard value                                     |
|---------------------------|----------------------------------------------------|
| G sensor output voltage V | When the vehicle is stationary                     |
|                           | When an arrow on the G sensor label is facing down |
|                           | 2.35 – 2.65                                        |
|                           | 3.3 – 3.7                                          |


## SPECIAL TOOLS

| Tools                                                                                       | No.      | Name                | Application                                                     |
|---------------------------------------------------------------------------------------------|----------|---------------------|-----------------------------------------------------------------|
|  8991502 | MB991502 | MUT-II sub assembly | Checking the MITSUBISHI SC (Diagnosis display using the MUT-II) |
|  8991348 | MB991348 | Test harness set    | Checking the G sensor                                           |

## TROUBLESHOOTING

### STANDARD FLOW OF DIAGNOSTIC TROUBLESHOOTING


Refer to Basic Manual GROUP 00 – How to Use Troubleshooting/Inspection Service Points.



### SC WARNING LAMP INSPECTION

Check that the SC warning lamp illuminates as follows.

1. When the ignition key is turned to "ON", the SC warning lamp will illuminate.
2. When the engine is started, the SC warning lamp will be switched off.
3. If the illumination is other than the above, check the diagnosis codes.



### DIAGNOSIS FUNCTION


#### METHOD OF READING DIAGNOSIS CODES

##### WHEN USING THE MUT-II

Connect the MUT-II to the diagnosis connector and take a reading of the diagnosis codes.

##### Caution

Turn the ignition switch to "LOCK" (OFF) position before connecting or disconnecting the MUT-II.



##### WHEN USING THE WARNING LAMP

1. Use the special tool to earth No.1 terminal (diagnosis control terminal) of the diagnosis connector.
2. Turn on the ignition switch.
3. Read out a diagnosis code by observing how the warning lamp flashes.  
(Refer to Basic Manual GROUP 00 – How to Use Troubleshooting/Inspection Service Points.)

### ERASING DIAGNOSIS CODES

Connect the MUT-II to the diagnosis connector and erase the diagnosis codes.

##### Caution

Turn the ignition switch to "LOCK" (OFF) position before connecting or disconnecting the MUT-II.

**INSPECTION CHART FOR DIAGNOSIS CODES**

| Diagnosis code No. | Diagnosis item                                                             | SC warning lamp | Reference page |
|--------------------|----------------------------------------------------------------------------|-----------------|----------------|
| 27* <sup>1</sup>   | SC-ECU power supply system (abnormal voltage drop)                         | Flashes         | 13E-6          |
| 51* <sup>2</sup>   | Vehicle speed sensor wheel speed sensor system (output signal abnormality) | Flashes         | 13E-7          |
| 52                 | Vehicle speed sensor system (open circuit or short-circuit)                | Flashes         | 13E-8          |
| 53* <sup>2</sup>   | Wheel speed sensor system (open circuit or short-circuit)                  | Flashes         | 13E-8          |
| 55* <sup>2</sup>   | G sensor system                                                            | Flashes         | 13E-9          |
| 71                 | Communication line between the engine-ECU or engine-A/T-ECU and the system | Flashes         | 13E-10         |
| 72                 | Engine-ECU or Engine-A/T-ECU system                                        | Illuminates     | 13E-10         |
| 74* <sup>2</sup>   | Communication line between the A/T-ECU and the system <4M4-A/T>            | Flashes         | 13E-11         |
| 81* <sup>1</sup>   | The SC-ECU is controlling the system too long                              | Flashes         | 13E-11         |

**NOTE**

\*1: Code No.27 and 81 are erased from the memory if the condition returns to normal.


\*2: For code Nos.51, 53, 55 and 74, a diagnosis code will be set in ten seconds after a failure is detected..

**INSPECTION PROCEDURE FOR DIAGNOSIS CODE**

| Code No. 27 SC-ECU power supply system (abnormal voltage drop)                                  | Probable cause                                                                                                                                                 |
|-------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| This diagnosis code will be set if the SC-ECU power supply voltage drops below a certain level. | <ul style="list-style-type: none"> <li>● Malfunction of battery</li> <li>● Malfunction of harness or connector</li> <li>● Malfunction of the SC-ECU</li> </ul> |

**Caution**

If the system voltage drops during inspection, this code will be output to indicate a current problem. And correct problem diagnosis will not be possible. Before carrying out the following procedure, check the battery and recharge it if necessary.




### Code No. 51 Vehicle speed sensor system


This diagnosis code will be set when the vehicle speed signal from the vehicle speed sensor is not the same as that from the wheel speed sensor (FR).

### Probable cause


- Malfunction of vehicle speed sensor system
- Malfunction of wheel speed sensor system
- Malfunction of the SC-ECU



| Code No. 52 Vehicle speed sensor system (open circuit or short-circuit)                                         | Probable cause                                                                                                                                                              |
|-----------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| This diagnosis code will be set when the vehicle speed sensor does not send vehicle speed signal to the SC-ECU. | <ul style="list-style-type: none"> <li>• Malfunction of vehicle speed sensor</li> <li>• Malfunction of harness or connector</li> <li>• Malfunction of the SC-ECU</li> </ul> |



| Code No. 53 Wheel speed sensor system (open circuit or short-circuit)                                                                                                                                                                                                               | Probable cause                                                                                                                                                             |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| This code is output when the open circuit or short-circuit detection carried out by the ABS-ECU hardware circuit detects that there is an open circuit or short-circuit in the (+) or (–) wire in one of the four wheel speed sensors and signals are consequently not being input. | <ul style="list-style-type: none"> <li>• Malfunction of wheel speed sensor</li> <li>• Malfunction of harness or connector</li> <li>• Malfunction of the ABS-ECU</li> </ul> |





| Code No. 55 G sensor system                                                                                                                                                                                                                                                                                            | Probable cause                                                                                                                                            |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>This code is output at the following cases:</p> <ul style="list-style-type: none"> <li>When the G sensor output is lower than 0.5 V or higher than 4.5 V (Open circuit or short-circuit in G sensor circuit)</li> <li>When there is no variation in the G sensor output voltage (G sensor output seized)</li> </ul> | <ul style="list-style-type: none"> <li>Malfunction of G sensor</li> <li>Malfunction of harness or connector</li> <li>Malfunction of the SC-ECU</li> </ul> |


Measure at G sensor connector E-123.

- Disconnect the connector and measure at the harness side.

(1) Voltage between terminal 1 and body earth (Ignition switch: ON)  
**OK:** System voltage

(2) Continuity between terminal 3 and body earth  
**OK:** Continuity

OK



- Remove the G sensor (Refer to P.13E-19).
- Connect the special tool between the G sensor harness-side connector E-123 and the G sensor.
- Ignition switch: ON
- Voltage between terminal 2 and body earth when the G sensor is placed on a level surface  
**OK:** 2.35 – 2.65 V
- Voltage between terminal 2 and body earth when the G sensor is placed so that the label is facing straight up  
**OK:** 3.3 – 3.7 V

OK

Check the following connectors: E-123, E-113, E-122, E-121

OK

Check the trouble symptoms.

NG

Check the harness wire between the G sensor and SC-ECU

OK

Check the trouble symptoms.

NG

Replace the SC-ECU.

(1)NG

Check the following connectors: D-208, D-213, D-32, E-115, E-123

OK

NG

Check the trouble symptoms.

NG

Check the harness wire, and repair if necessary.

- Between ignition switch and G sensor

Repair

Check the following connectors: E-123

OK

NG

Check the trouble symptoms.

NG

Check the harness wire, and repair if necessary.

- Between the G sensor and body earth

Repair

NG

Replace the G sensor.


NG

Repair

NG

Repair


| Code No. 71 Communication line between the engine-ECU or engine-A/T-ECU and the system                                                                                                                                                    | Probable cause                                                                                                                                                                        |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| This diagnosis code will be set when an error takes place due to the open or short circuit in the serial communication line between the SC-ECU and the engine-ECU or engine-A/T-ECU, internal failure in the ECU or improper shield line. | <ul style="list-style-type: none"> <li>• Malfunction of harness or connector</li> <li>• Malfunction of engine-ECU or engine - A/T-ECU</li> <li>• Malfunction of the SC-ECU</li> </ul> |




| Code No. 72 Engine-ECU or Engine-A/T-ECU system                                                                                                                                                                                                                             | Probable cause                                                                                                                                     |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| This diagnosis code will be set when the engine-ECU or engine-A/T-ECU detects a system failure. On the GDI system <6G7> or diesel fuel system <4M4>, the system failure is transmitted from the engine-ECU or engine-A/T-ECU via a serial communication line to the SC-ECU. | <ul style="list-style-type: none"> <li>• Malfunction of GDI system &lt;6G7&gt;</li> <li>• Malfunction of diesel fuel system &lt;4M4&gt;</li> </ul> |

- Carry out the troubleshooting regarding the GDI system. <6G7> (Refer to Basic Manual GROUP 13A – Troubleshooting.)
- Carry out the troubleshooting regarding the diesel fuel system. <4M4> (Refer to Basic Manual GROUP 13C – Troubleshooting.)

| Code No. 74 Communication line between the A/T-ECU and the system <4M4-A/T>                                                                                                                                          | Probable cause                                                                                                                                                 |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| This diagnosis code will be set when an error takes place due to the open or short circuit in the serial communication line between the SC-ECU and the A/T-ECU, internal failure in the ECU or improper shield line. | <ul style="list-style-type: none"> <li>• Malfunction of harness or connector</li> <li>• Malfunction of A/T-ECU</li> <li>• Malfunction of the SC-ECU</li> </ul> |



| Code No. 81 The SC-ECU is controlling the system too long                                         | Probable cause                                                                                               |
|---------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|
| This diagnosis code will be set when the SC-ECU is controlling the system for 20 seconds or more. | <ul style="list-style-type: none"> <li>• Malfunction of G sensor</li> <li>• Malfunction of SC-ECU</li> </ul> |




## INSPECTION CHART FOR TROUBLE SYMPTOMS

| Trouble Symptom                                                                                 | Inspection procedure No. | Reference page |
|-------------------------------------------------------------------------------------------------|--------------------------|----------------|
| Communication with MUT-II is not possible.                                                      | 1                        | 13E-12         |
| Communication with MUT-II and the SC-ECU is not possible.                                       | 2                        | 13E-13         |
| The SC warning lamp does not illuminate when the ignition key is turned to ON (engine stopped). | 3                        | 13E-14         |
| The SC warning lamp remains illuminated after the engine has started.                           | 4                        | 13E-14         |

## INSPECTION PROCEDURES FOR TROUBLE SYMPTOMS


## Inspection procedure 1

| Communication with MUT-II is not possible.                                                            | Probable cause                                                                                                                        |
|-------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|
| The cause is probably a malfunction of the diagnosis connector power supply circuit or earth circuit. | <ul style="list-style-type: none"> <li>• Malfunction of diagnosis connector</li> <li>• Malfunction of harness or connector</li> </ul> |




Inspection procedure 2

| Communication with MUT-II and the SC-ECU is not possible.                                                                    | Probable cause                                                                                                           |
|------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|
| The cause is probably an open circuit in the SC-ECU power supply circuit or an open circuit in the diagnosis output circuit. | <ul style="list-style-type: none"> <li>Malfunction of harness or connector</li> <li>Malfunction of the SC-ECU</li> </ul> |



## Inspection procedure 3

| The SC warning lamp does not illuminate when the ignition key is turned to ON (engine stopped).                                                                                                                                                                                                                                                                                                                           | Probable cause                                                                                                                                                                                                                       |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| When the ignition switch is turned on, the SC-ECU starts to communicate with the engine-ECU or engine-A/T-ECU. Then the SC-ECU will illuminate the SC warning lamp if the engine speed is 350 rpm or less. If the SC warning lamp does not illuminate, the case is probably an open circuit in the SC warning lamp power supply circuit, a blown lamp bulb or an open circuit between the SC warning lamp and the SC-ECU. | <ul style="list-style-type: none"> <li>• Blown fuse</li> <li>• Blown SC warning lamp bulb</li> <li>• Malfunction of harness or connector</li> <li>• Malfunction of combination meter</li> <li>• Malfunction of the SC-ECU</li> </ul> |




## Inspection procedure 4

| The SC warning lamp remains illuminated after the engine has started.              | Probable cause                                                                                                                                                              |
|------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The cause is probably a short-circuit in the SC warning lamp illumination circuit. | <ul style="list-style-type: none"> <li>• Malfunction of combination meter</li> <li>• Malfunction of harness (short-circuit)</li> <li>• Malfunction of the SC-ECU</li> </ul> |

## NOTE

This trouble symptom is limited to cases where communication with the MUT-II is possible(SC-ECU power supply is normal) and the diagnosis code is a normal diagnosis code.



# DATA LIST REFERENCE TABLE

The following ECU input data items can be read using the MUT-II.

| Item No. | Check item                                      | Inspection conditions                    |                                               | Normal condition                                      |
|----------|-------------------------------------------------|------------------------------------------|-----------------------------------------------|-------------------------------------------------------|
| 10       | Vehicle speed                                   | When vehicle is being driven             |                                               | Speedometer display and MUT-II display are identical. |
| 11       | Accelerator pedal position sensor               | Ignition switch: ON                      | Release the accelerator pedal.                | 0.9 – 1.1 V                                           |
|          |                                                 |                                          | Depress the accelerator pedal gradually.      | Increases in response to pedal depression stroke.     |
|          |                                                 |                                          | Depress the accelerator pedal fully           | 4.0 V or more                                         |
| 18       | Power supply voltage                            | Ignition switch: ON                      |                                               | System voltage                                        |
| 19       | Accelerator pedal position switch (Idle switch) | Ignition switch: ON                      | Release the accelerator pedal                 | ON                                                    |
|          |                                                 |                                          | Depress the accelerator pedal slightly.       | OFF                                                   |
| 20       | Ignition switch                                 | Ignition switch: ON                      |                                               | ON                                                    |
|          |                                                 | Ignition switch: OFF                     |                                               | OFF                                                   |
| 22       | Front-right wheel speed                         | When vehicle is being driven             |                                               | Speedometer display and MUT-II display are identical. |
| 28       | Engine type                                     | Vehicles with the 6G74 engine            |                                               | 6G74                                                  |
|          |                                                 | Vehicles with the 4M41 engine            |                                               | 4M41                                                  |
| 30       | Trace control                                   | SC system control is active              |                                               | ON                                                    |
|          |                                                 | SC system control is not active          |                                               | OFF                                                   |
| 31       | Engine specification 1                          | Vehicles with the 6G74 engine            |                                               | DOHC                                                  |
|          |                                                 | Vehicles with the 4M41 engine            |                                               | –                                                     |
| 32       | Engine specification 2                          | Vehicles with the 6G74 engine            |                                               | N/A                                                   |
|          |                                                 | Vehicles with the 4M41 engine            |                                               | –                                                     |
| 33       | Engine specification 3                          | Vehicles with the 6G74 engine            |                                               | MIVEC/ETV                                             |
|          |                                                 | Vehicles with the 4M41 engine            |                                               | –                                                     |
| 35       | Destination                                     | –                                        |                                               | EC                                                    |
| 40       | Engine speed                                    | Depress the accelerator pedal gradually. |                                               | Tachometer display and MUT-II display are identical.  |
| 51       | Inhibitor switch                                | Ignition switch: ON<br>Engine: stopped   | Selector lever position: P                    | P                                                     |
|          |                                                 |                                          | Selector lever position: R                    | R                                                     |
|          |                                                 |                                          | Selector lever position: N                    | N                                                     |
|          |                                                 |                                          | Selector lever position: D                    | D                                                     |
| 52       | Shift position                                  | Selector lever position: sports mode     | Driving at a constant speed of 10 km/h in 1st | 1st                                                   |
|          |                                                 |                                          | Driving at a constant speed of 30 km/h in 2nd | 2nd                                                   |
|          |                                                 |                                          | Driving at a constant speed of 50 km/h in 3rd | 3rd                                                   |
|          |                                                 |                                          | Driving at a constant speed of 50 km/h in 4th | 4th                                                   |
|          |                                                 |                                          | Driving at a constant speed of 70 km/h in 5th | 5th                                                   |

| Item No. | Check item | Inspection conditions                                                                                             | Normal condition |
|----------|------------|-------------------------------------------------------------------------------------------------------------------|------------------|
| 63       | G sensor   | <ul style="list-style-type: none"> <li>Ignition switch: ON</li> <li>When vehicle is stationary (level)</li> </ul> | 2.35 – 2.65 V    |
|          |            | When vehicle is being driven                                                                                      | 1.0 – 4.0 V      |

## ACTUATOR TEST TABLE


The following actuators can be force-driven using the MUT-II.

### NOTE

1. Actuator tests cannot be carried out when the operation of the SC-ECU has been stopped by the fail-safe function.
2. Actuator tests can only be carried out while the vehicle is stopped.

## ACTUATOR TEST SPECIFICATIONS

| Item No. | Check item                      | Drive Contents                                                                                                                |
|----------|---------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| 05       | Operation Test of MITSUBISHI SC | Transmits the signal, which requests no torque and wide open throttle, to the engine-ECU or engine-A/T-ECU for three seconds. |



### SC-ECU side connector

|    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 | 13 |
| 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 |

|    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|
| 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 |
| 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 |

Y0583CA


## CHECK AT SC-ECU TERMINAL

### TERMINAL VOLTAGE TABLE

1. Measure the voltages between the respective terminal and earth.
2. The terminal layout is shown in the illustration.



| Terminal No. | Check item                                              | Inspection conditions                                  |                           | Normal condition                     |
|--------------|---------------------------------------------------------|--------------------------------------------------------|---------------------------|--------------------------------------|
| 1            | Diagnosis select input                                  | When the MUT-II is connected                           |                           | 1 V or less                          |
|              |                                                         | When the MUT-II is not connected                       |                           | Approx. 5 V                          |
| 14           | MUT-II                                                  | When the MUT-II is connected                           |                           | Serial communication with the MUT-II |
|              |                                                         | When the MUT-II is not connected                       |                           | 1 V or less                          |
| 15, 16       | A/T-ECU <4M41-A/T>                                      | Ignition switch: ON                                    |                           | Serial communication with the SC-ECU |
|              |                                                         | Ignition switch: OFF                                   |                           | 0 V                                  |
| 17, 18       | Engine-ECU <M/T, 6G74-M/T> or Engine-A/T-ECU <6G74-A/T> | Ignition switch: ON                                    |                           | Serial communication with the SC-ECU |
|              |                                                         | Ignition switch: OFF                                   |                           | 0 V                                  |
| 19           | G sensor input                                          | Ignition switch: ON<br>Vehicle horizontal position     |                           | 2.4 – 2.6 V                          |
| 21           | ABS-ECU [wheel speed sensor (FR)] input                 | Ignition switch: ON<br>Move the vehicle slowly forward |                           | 0 V and 5 V alternates               |
| 23           | Vehicle speed sensor input                              | Ignition switch: ON<br>Move the vehicle slowly forward |                           | 0 V and 8 – 12 V alternates          |
| 25           | SC-ECU power supply                                     | Ignition switch: ON                                    |                           | System voltage                       |
|              |                                                         | Ignition switch: OFF                                   |                           | 0 V                                  |
| 39           | SC-ECU backup power supply                              | At all time                                            |                           | System voltage                       |
| 45           | SC warning lamp output                                  | Ignition switch: ON                                    | When lamp is switched off | System voltage                       |
|              |                                                         |                                                        | When lamp is illuminated  | 2 V or less                          |



### CHECK CHART FOR RESISTANCE AND CONTINUITY BETWEEN TERMINALS

1. Turn the ignition switch to the LOCK (OFF) position.
2. Check the resistances and continuity with the SC-ECU connector disconnected.
3. Check the resistances and continuity between the terminals listed in the table below.
4. The terminal layout is shown in the illustration.

| Terminal No.                       | Signal name | Normal condition |
|------------------------------------|-------------|------------------|
| Between terminal 13 and body earth | Earth       | Continuity       |
| Between terminal 26 and body earth | Earth       |                  |
| Between terminal 31 and body earth | Earth       |                  |

## ON-VEHICLE SERVICE

### OPERATION TEST OF MITSUBISHI SC

1. Connect the MUT-II to the 16-pin diagnosis connector.

#### Caution

**Turn the ignition switch to the LOCK (OFF) position when connecting and disconnecting the MUT-II.**

2. Move the shift lever to the neutral <M/T>, or the selector lever to the P range.
3. Start the engine.
4. Use the MUT-II to activate the Actuator Test (item No.05) while depressing the accelerator pedal fully. Check that the engine speed should decrease gradually.

#### Caution

**Activate the Actuator Test for three seconds. Release the accelerator pedal immediately after the Actuator Test is complete, or the engine speed will rise.**

#### NOTE

During the Actuator Test, the SC-ECU transmits the signal, which requests no torque and wide open throttle, to the engine-ECU or engine-A/T-ECU for three seconds.

### WHEEL SPEED SENSOR (FR) CHECK

Refer to Basic Manual GROUP 35B – On-vehicle service.

### VEHICLE SPEED SENSOR CHECK

Refer to Basic Manual GROUP 54A – Combination Meter.

# SC-ECU


## REMOVAL AND INSTALLATION

### Caution

When removing and installing the SC-ECU, do not let it bump against the SRS-ECU.

#### Pre-removal and Post-installation Operations


Front floor console removal and installation  
(Refer to Basic Manual GROUP 52A.)



**G SENSOR****REMOVAL AND INSTALLATION****Caution**

Do not drop the G sensor or subject it to any shocks.

**Pre-removal and Post-installation Operations**  
Rear floor console removal and installation  
(Refer to Basic Manual GROUP 52A.)



AY0586CA

**Removal steps**

1. G sensor (for SC) connector and harness clamp
2. G sensor (for SC)
3. G sensor (for ABS) connector
4. G sensor (for ABS)
5. Harness clamp <L.H.D>
6. G sensor bracket

**WHEEL SPEED SENSOR (FR)**

Refer to Basic Manual GROUP 35B – Wheel Speed Sensor.

**VEHICLE SPEED SENSOR**

Refer to Basic Manual GROUP 54A – Combination Meter.