

GENERAL INFORMATION

The heater system uses a two-way-flow full-air-mix system that features high performance and low operating noise, and includes an independent face air blowing function and a cool air bypass function. The A/C refrigerant system is basically the same as conventional systems and R134a refrigerant has been adopted as a response to restrictions on the use of chlorofluorocarbons.

For the air conditioning switch, push-button controls have been adopted for air flow control, air conditioning mode switching and blower speed. When the button is depressed, the air flow direction, air condi-

tioning mode and blower speed are indicated on a graphic display. A rotary control is used for setting cabin temperature. When the knob is rotated, the desired temperature is indicated on the graphic display.

On vehicles with manual air conditioning a belt lock controller is used to compare compressor rpm to engine rpm to determine if the drive belt is slipping or the compressor has seized. If the speed difference between the engine and compressor indicates the belt slipping, the belt lock controller will de-energise the magnetic clutch.

| Items | Specifications | |
|----------------------------|-----------------------------------|----------------------------------|
| Heater unit | Type | Two-way-flow full-air-mix system |
| Heater control assembly | Push button type | |
| Compressor | Type | Scroll |
| Dual pressure switch | High pressure switch | OFF: 3,140, ON: 2,550 |
| | Low pressure switch | OFF: 200, ON: 220 |
| Refrigerant and quantity g | R-134a(HFC-134a), Approx. 630–670 | |

SAFETY PRECAUTIONS

Because R-134a refrigerant is a hydrofluorocarbon (HFC) which contains hydrogen atoms in place of chlorine atoms, it will not cause damage to the ozone layer.

Ozone filters out harmful radiation from the sun. To assist in protecting the ozone layer, the use of a R-134a refrigerant recycling device is recommended.

Refrigerant R-134a is transparent and colourless in both the liquid and vapour state. Since it has a boiling point of -29.8°C , at atmospheric pressure, it will be a vapour at all normal temperatures and pressures. The vapour is heavier than air, non-flammable, and non-explosive. The following precautions must be observed when handling R-134a.

Caution

Wear safety goggles when servicing the refrigeration system.

R-134a evaporates so rapidly at normal atmospheric pressures and temperatures that it tends to freeze anything it contacts. For this reason, extreme care must be taken to prevent any liquid refrigerant from contacting the skin and especially the eyes. Always wear safety goggles when servicing the refrigeration part of the A/C system. Keep a bottle of sterile mineral oil handy when working on the refrigeration system. Should any liquid refrigerant get into the eyes, use a few drops of mineral oil to wash them out. R-134a is rapidly absorbed by the oil. Next splash the eyes with plenty of cool water. Call your doctor immediately even if irritation has ceased after treatment.

Caution**Do not heat R-134a above 40°C**

In most instances, moderate heat is required to bring the pressure of the refrigerant in its container above the pressure of the system when charging or adding refrigerant.

A bucket or large pan of hot water not over 40°C is all the heat required for this purpose. Do not heat the refrigerant container with a blow torch or any other means that would raise temperature and pressure above this temperature. Do not weld or steam clean on or near the system components or refrigerant lines.

Caution**Keep R-134a containers upright when charging the system.**

When adding R-134a into the refrigeration system keep the supply tank or cans in an upright position. If the refrigerant container is on its side or upside down, liquid refrigerant will enter the system and damage the compressor.

Caution

1. A leak detector designed for R-134a should be used to check for refrigerant gas leaks.
2. Do not allow liquid refrigerant to touch bright metal.

Refrigerant will tarnish bright metal and chrome surfaces, and in combination with moisture can severely corrode all metal surfaces.



SERVICE SPECIFICATIONS


| Items | Standard value | |
|---|----------------|------|
| Idle speed r/min (N or P RANGE) | 700±50 | |
| Idle up speed r/min | 900 | |
| Air gap mm (Magnetic clutch) mm | 0.4–0.65 | |
| Resistance of air mix damper potentiometer kΩ | MAX, HOT | 4.82 |
| | MAX COOL | 0.18 |
| Resistance of mode selector damper potentiometer kΩ | DEF position | 0.18 |
| | FACE position | 4.82 |
| Revolution pickup sensor resistance (at 20°C) Ω | 405±35 | |

LUBRICANTS

| Items | Specified lubricants | Quantity |
|---|----------------------|-------------|
| Each connection of refrigerant line Lip seal of the compressor | SUN PAG 56 | As required |
| Compressor refrigerant unit lubricant, ml. | SUN PAG 56 | 170–190 |

SPECIAL TOOLS

| Tool | Tool number and name | Supersession | Application |
|---|--|--------------|---|
|  | MB991367 Special spanner | – | Armature mounting nut of compressor removal and installation |
|  | MB991386 Pin | – | Armature mounting nut of compressor removal and installation |
|  | MB991502 MUT-II | – | Checking the full automatic air conditioning |
|  | ROM pack | – | |
|  | MB991529 Diagnosis code check harness | – | Checking the full automatic air conditioning when using a voltmeter |



AUTOMATIC AIR CONDITIONING TROUBLESHOOTING

DIAGNOSIS FUNCTION


DIAGNOSIS CODE CHECK

With the MUT-II

Connect the MUT-II to the diagnosis connector then check diagnosis trouble codes.

Caution

Turn the ignition switch off before connecting or disconnecting the MUT-II.



Using a Voltmeter

1. Turn OFF the ignition switch.
2. Connect an analog voltmeter across the diagnosis output terminal 11 and terminal 4 or 5 (ground terminal) of the diagnosis connector.
3. Turn ON the ignition switch.
4. According to the voltmeter pointer deflection, read the diagnosis test mode pattern.
5. Referring to the diagnosis chart, repair the faulty item.
6. Turn OFF the ignition switch.
7. Disconnect the battery cable from the battery terminal and leave it disconnected for 10 seconds or more then reconnect the cable.
8. Turn ON the ignition switch and read the diagnosis code to check that the normal condition code is being output.

ERASING DIAGNOSIS CODES

With the MUT-II

Connect the MUT-II to the diagnosis connector then erase the diagnosis codes.

Without the MUT-II

Remove the battery cable from the negative battery terminal for 10 seconds or more then reconnect the cable.

INSPECTION CHART FOR DIAGNOSIS CODES

| Item No. | Diagnosis Item |
|----------|--|
| 11 | Passenger compartment temperature sensor (open circuit) |
| 12 | Passenger compartment temperature sensor (short circuit) |
| 13 | Outside air temperature sensor system (open circuit) |
| 14 | Outside air temperature sensor system (short circuit) |
| 15 | Heater water temperature sensor system (open circuit) |
| 16 | Heater water temperature sensor system (short circuit) |
| 21 | Air thermo sensor system (open circuit) |
| 22 | Air thermo sensor system (short circuit) |
| 31 | Potentiometer system for air mix damper motor |
| 32 | Potentiometer system for mode selector damper motor |
| 41 | Driving system for air mix damper motor |
| 42 | Driving system for mode selector damper motor |

INSPECTION PROCEDURE FOR DIAGNOSIS CODES

| Code No. 11 Passenger compartment temperature sensor (open circuit) | Probable cause |
|--|---|
| This code is output when there is an open circuit in the power supply wiring or input wiring in the passenger compartment temperature sensor in the A/C-ECU, and there is no input from the passenger compartment temperature sensor to the A/C-ECU. | <ul style="list-style-type: none"> • A/C-ECU fault |

Replace A/C-ECU

| Code No. 12 Passenger compartment temperature sensor (short circuit) | Probable cause |
|--|---|
| This code is output when there is a short circuit in the power supply wiring and output wiring in the passenger compartment temperature sensor in the A/C-ECU, and the power supply voltage is input from the passenger compartment temperature sensor to the A/C-ECU. | <ul style="list-style-type: none"> • A/C-ECU fault |


Replace A/C-ECU

Code No. 13 Outside air temperature sensor system (open circuit)

This code is output when there is an open circuit in the outside air temperature sensor power supply or input wiring, and there is no input from the outside air temperature sensor in the A/C-ECU.

Probable cause

- Outside air temperature sensor fault
- Connector or harness fault
- A/C-ECU fault




Code No. 14 Outside air temperature sensor system (short circuit)

This code is output when there is a short circuit in the outside air temperature sensor power supply and input wiring, and the outside air temperature sensor power supply voltage is output to the A/C-ECU.

Probable cause


- Outside air temperature sensor fault
- Connector or harness fault
- A/C-ECU fault



Code No. 15 Heater water temperature sensor system (open circuit)**Probable cause**


This code is output when there is an open circuit in the heater water temperature sensor power supply or input wiring, and there is no input from the heater water temperature sensor into the A/C-ECU.

- Heater water temperature sensor fault
- Harness or connector fault
- A/C-ECU fault

**Code No. 16 Heater water temperature sensor system (short circuit)****Probable cause**

This code is output when the heater water temperature sensor power supply and output wires are shorted and the heater water temperature sensor power supply voltage has been input into the A/C-ECU.

- Heater water temperature sensor fault
- Harness or connector fault
- A/C-ECU fault




Code No. 21 Air thermo sensor system (open circuit)

Probable cause

This code is output when there is an open circuit in the air thermo sensor power supply or input wiring, and there is no input from the air thermo sensor to the A/C-ECU.

- Air thermo sensor fault
- Harness or connector fault
- A/C-ECU fault




Code No. 22 Air thermo sensor system (short circuit)


Probable cause

This code is output when the air thermo sensor power supply and output wires are shorted, and the air thermo sensor power supply voltage has been input into the A/C-ECU.

- Air thermo sensor fault
- Harness or connector fault
- A/C-ECU fault



| Code No. 31 Potentiometer system for air mix damper | Probable cause |
|--|---|
| <p>This code is output when there is no input from the air mix damper potentiometer to the A/C-ECU due to an open or short circuit in the harness.</p> | <ul style="list-style-type: none"> • Air mix damper potentiometer fault • Harness or connector fault • A/C-ECU fault |




Code No. 32 Potentiometer system for mode selector damper

This code is output when there is no input from the mode selector damper potentiometer to the A/C-ECU due to an open or short circuit in the harness.

Probable cause

- Mode selector damper potentiometer fault
- Harness or connector fault
- A/C-ECU fault




Code No. 41 Driving system for air mix damper motor


This code is output when the air mix damper cannot be rotated to the set opening angle.

Probable cause

- Air mix damper motor fault
- Harness or connector fault
- A/C-ECU fault



| Code No. 42 Driving system for mode selector damper motor | Probable cause |
|---|---|
| This code is output when the mode selector damper cannot be rotated to the set opening angle. | <ul style="list-style-type: none"> • Mode selector damper motor fault • Harness or connector fault • A/C-ECU fault |




INSPECTION CHART BY TROUBLE SYMPTOM

| Trouble symptom | Inspection Procedure No. |
|---|--------------------------|
| Cannot communicate with MUT-II | 1 |
| Air conditioning does not operate | 2 |
| Graphical air conditioning display in control unit does not display | 3 |
| Cannot set the temperature | 4 |
| The air conditioning blower air temperature does not rise | 5 |
| The air conditioning blower air temperature does not fall | 6 |
| The blower does not operate | 7 |
| The blower does not operate on HI | 8 |
| Cannot change blower air volume | 9 |
| Cannot switch mode selector | 10 |
| Cannot switch air inlet selector | 11 |
| Defroster function does not operate | 12 |
| Condenser fan does not operate | 13 |
| Rear defogger does not operate | 14 |
| Check A/C-ECU power supply circuit | 15 |
| Check A/C compressor control circuit | 16 |

INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS

INSPECTION PROCEDURE 1

| Cannot communicate with MUT-II | Probable cause |
|---|----------------|
| <p>In the event that communication is impossible with all systems, it is highly likely that there is a diagnosis line fault. If communication is impossible with the air conditioning system only, possible causes include a diagnosis line fault or an A/C-ECU power supply system (ground) fault.</p> | |




INSPECTION PROCEDURE 2

Air conditioning does not operate

If the air conditioning does not operate even when the temperature setting is turned to 17°C with the A/C switch ON, possible causes include a blower operation fault or a magnetic clutch power supply system fault.

Probable cause

- Blower system fault
- Insufficient refrigerant volume
- Magnetic clutch fault
- Air thermo sensor fault
- Compressor relay fault
- Refrigerant temperature switch fault
- Dual pressure switch fault
- Heater water temperature sensor fault
- Harness or connector fault
- A/C-ECU fault



INSPECTION PROCEDURE 3

| Graphical air conditioning display in control unit does not display | Probable cause |
|--|---|
| It is possible there is a fault in the A/C-ECU power supply system (including the ground). | <ul style="list-style-type: none"> • Harness or connector fault • A/C-ECU fault |


**INSPECTION PROCEDURE 4**

| Cannot set the temperature | Probable cause |
|---|---|
| It is possible that there is a fault in the input or output systems for the temperature setting signal. | <ul style="list-style-type: none"> • Harness or connector fault • A/C-ECU fault |

[Trouble Symptom Inspection Procedure 15](#)

INSPECTION PROCEDURE 5

| The air conditioning blower air temperature does not rise | Probable cause |
|--|---|
| If the blower air temperature does not rise even though the set temperature has been raised, possible causes include a fault in one of the sensors, or an operating fault in the air mix damper. In such a case, the breakdown causes can be verified for each system using the MUT-II to check the diagnosis trouble codes. | <ul style="list-style-type: none"> • Air mix damper potentiometer fault • Air mix damper motor fault • Air mix damper fault • Harness or connector fault • Thermostat fault • A/C-ECU fault |




INSPECTION PROCEDURE 6

The air conditioning blower air temperature does not fall

If the room temperature does not fall even though the set temperature has been lowered, possible causes include mis-detections in sensors causing an air conditioning operation fault or an air mix damper operation fault. In such a case, the breakdown causes can be verified for each system using the MUT-II to check the diagnosis codes.


Probable cause

- Outside air temperature sensor fault
- Air mix damper potentiometer fault
- Air mix damper motor fault
- Air thermo sensor fault
- Harness or connector fault
- Air mix damper fault
- A/C-ECU fault




INSPECTION PROCEDURE 7


| The blower does not operate | Probable cause |
|---|---|
| If no air is blown although the blower switch is ON, it is possible that there is a fault in the blower motor relay circuit system. | <ul style="list-style-type: none"> • Blower motor relay fault • Blower motor fault • Harness or connector fault • A/C-ECU fault |




INSPECTION PROCEDURE 8




INSPECTION PROCEDURE 9




INSPECTION PROCEDURE 10



INSPECTION PROCEDURE 11




INSPECTION PROCEDURE 12



INSPECTION PROCEDURE 13

| Condenser fan does not operate | Probable cause |
|---|--|
| <p>If the condenser fan does not rotate when the air conditioning is operated, it is possible that there is a fault in the condenser fan motor operation circuit. In such a case, this will be a cause of reduced cooling performance when the vehicle is not moving.</p> | <ul style="list-style-type: none"> ● Condenser fan motor fault ● Condenser fan motor relay fault ● Harness or connector fault |



INSPECTION PROCEDURE 14


| Rear defogger does not operate | Probable cause |
|--|---|
| If the rear defogger does not operate even when the switch is ON (12 min. timer operates), it is possible that there is a fault in the A/C-ECU power supply system (including ground). | <ul style="list-style-type: none"> • Harness or connector fault • A/C-ECU fault |

Is there an actuation sound when the rear de-mister switch is operated? No

↓


Replace the A/C-ECU

INSPECTION PROCEDURE 15



INSPECTION PROCEDURE 16

Check A/C compressor control circuit





SERVICE DATA REFERENCE TABLE

| Item No. | Inspection item | Inspection condition | Normal condition |
|----------|---|----------------------|--|
| 11 | Passenger compartment temperature sensor | Ignition switch ON | Ambient temperature at sensor and MUT-II indicated value agree |
| 13 | Outside air temperature sensor | Ignition switch ON | Outside temperature and MUT-II indicated value agree |
| 15 | Heater water temperature sensor | Ignition switch ON | Temperature at heater core wall surface and MUT-II indicated value agree |
| 21 | Air thermo sensor | Ignition switch ON | Evaporator outlet temperature and MUT-II indicated value agree |
| 25 | Photo sensor | Ignition switch ON | Voltage displayed on MUT-II is proportional to sunlight intensity |
| 31 | Air mix damper potentiometer | Ignition switch ON | Damper position |
| | | | MAX HOT |
| | | | MAX COOL |
| 32 | Air outlet mode selector damper potentiometer | Ignition switch ON | Damper position |
| | | | FACE |
| | | | FOOT |
| | | | FOOT/DEF |
| | | | DEF |

ACTUATOR TEST REFERENCE TABLE

| Item No. | Actuator test item | Item No. | Actuator test item |
|----------|--------------------|--------------|--------------------|
| 01 | Blower fan motor | OFF command | 08 |
| 02 | | Drive Low | 09 |
| 03 | | Drive Medium | 10 |
| 04 | | Drive High | 11 |
| 05 | Air mix damper | Drive 0% | 12 |
| 06 | | Drive 50% | 13 |
| 07 | | Drive 100% | 14 |

CHECK AT THE A/C-ECU TERMINALS



Figures in brackets () in the Normal condition column are reference values.

| Terminal No. | Checking items | Checking conditions | Normal condition |
|--------------|---|---|-------------------------------------|
| 1 | Blower HI control circuit | Blower switch OFF | Battery voltage |
| | | Blower switch HI | Small voltage (0V) |
| 2 | Front power transistor base output | Blower switch OFF | 0V |
| | | Blower switch LO | Approx. 1.3V |
| | | Blower switch HI | Approx. 2.5V |
| 3 | Backup power supply | At all times | Battery voltage |
| 4 | Heater water temperature sensor input | Sensor temperature 25°C (4kΩ) | 2.3–2.9V |
| 5 | Air mix damper potentiometer input | Damper moved to MAX. HOT position | 4.7–5.0V |
| 6 | Air outlet mode selector damper potentiometer input | Damper moved to Defroster position | 4.8–5.2V |
| 7 | Outside air temperature sensor input | Sensor temperature 25°C (4kΩ) | 2.3–2.9V |
| 8 | Fin Thermo sensor input | Sensor temperature 25°C (4kΩ) | 2.3–2.9V |
| 9 | Photo sensor (-) | Illumination 0 lux Illumination 100 000 lux or above | 0V –0.1–0.2 |
| 10 | Sensor power supply | Full-time | 4.8–5.2V |
| 13 | Compressor operating signal | Compressor operating | Battery voltage |
| 14 | Engine speed signal input | Ignition switch: ON | 5V (approx) |
| 16 | Rear defogger | Rear defogger switch ON | 1.5V or greater |
| | | Rear defogger switch OFF | Battery voltage |
| 17 | Diagnosis output | Ignition switch: ON | Needle oscillates between 0 and 12V |
| 18 | Diagnosis control output | Ignition switch: ON | Battery voltage–2V |
| 19 | Photo sensor (+) | At all times | 0V |
| 20 | Sensor ground | At all times | 0V |
| 21 | Air outlet mode selector damper motor (FACE) | Damper moved to FACE position | 10V |
| | | Damper moved to DEFROSTER position | Small voltage (0.5V) |
| 22 | Air mix damper motor (MAX. COOL) | Damper moved to MAX. COOL position | 10V |
| | | Damper moved to MAX. HOT position | Small voltage (0.5V) |
| 23 | Air inlet mode selector damper motor (RECIRC) | Selector switch on RECIRC | Small voltage (0.5V) |
| | | Selector switch on Outside Air Intake | 10V |

| Terminal No. | Checking items | Checking conditions | Normal condition |
|--------------|--|--|-----------------------------|
| 24 | Air outlet mode selector damper motor | Damper moved to FACE position (DEFROSTER) | Small voltage (0.5V) |
| | | Damper moved to DEFROSTER position | 10V |
| 25 | Air mix damper motor (MAX. HOT) | Damper moved to MAX. COOL position | Small voltage (0.5V) |
| | | Damper moved to MAX. HOT | 10V |
| 26 | Air inlet mode selector damper motor (OUTSIDE AIR) | Selector switch on RECIRC Selector switch on Outside Air Intake | 10V Small voltage (0.5V) |
| 27 | Ground | Full-time | Continuity exists |
| 28 | IG2 power supply | Ignition switch: ON | Battery voltage |
| 29 | Illumination circuit ground (rheostat) | Full-time | Continuity exists |
| 30 | Illumination power supply | Lighting switch ON | Battery voltage |
| 31* | Revolution pick-up sensor | Compressor: ON | 0.2V AC |
| 32* | Revolution pick-up sensor | Compressor: ON | 0.2V AC |
| 35 | Ground | Full-time | Continuity exists |
| 36 | Air conditioning output | Air conditioning: OFF | 0V |
| | | Air conditioning: ON | Battery voltage |


NOTE: *The voltage shown is the pulse signal voltage

MANUAL AIR CONDITIONING

TROUBLESHOOTING PROCEDURES

| Trouble Symptom | Problem cause | Remedy |
|--|--|--|
| When the engine is running the A/C does not operate | Fuse is defective | Replace the fuse |
| | Harness or connector is defective | Repair the harness or connector |
| | A/C compressor relay is defective | Replace the A/C compressor relay |
| | A/C compressor magnetic clutch is defective | Replace the armature plate, rotor or clutch coil |
| | Refrigerant leak or overfilling of refrigerant | Replenish the refrigerant, repair the leak or take out some of the refrigerant |
| | Dual pressure switch is defective | Replace the dual pressure switch |
| | A/C switch is defective | Replace the A/C switch assembly |
| | Blower switch is defective | Replace the blower switch assembly |
| | Engine-ECU is defective | Replace the engine-ECU |
| When the A/C is operating, temperature inside the passenger compartment doesn't decrease (cool air is not emitted) | Refrigerant leak | Replenish the refrigerant and repair the leak |
| | Dual pressure switch is defective | Replace the dual pressure switch |
| | Engine-ECU is defective | Replace the engine-ECU |
| | Thermostat is defective | Replace the thermostat |
| | Fin thermo sensor is defective | Replace the fin thermo sensor |
| Blower fan and motor do not turn | Fuse is defective | Replace the fuse |
| | Harness or connector is defective | Repair the harness or connector |
| | Blower relay is defective | Replace the blower relay |
| | Blower fan and motor are defective | Replace the blower fan and motor |
| | Blower switch is defective | Replace the blower switch assembly |
| Blower fan and motor do not stop turning | Harness or connector is defective | Repair the harness or connector |
| | Blower switch is defective | Replace the blower switch assembly |
| | Blower relay is defective | Replace the blower relay |

| Trouble Symptom | Problem cause | Remedy |
|---|---|---------------------------------|
| When the A/C is operating the condenser fan or radiator fan does not turn | Fuse is defective | Replace the fuse |
| | Harness or connector is defective | Repair the harness or connector |
| | Condenser fan motor is defective | Replace the condenser fan motor |
| | Radiator fan motor is defective | Replace the radiator fan motor |
| | Engine-ECU is defective | Replace the engine-ECU |




ON-VEHICLE SERVICE

SIGHT GLASS REFRIGERANT LEVEL TEST

The sight glass is a refrigerant level indicator. To check the refrigerant level, clean the sight glass and start the vehicle engine and hold engine speed at 1500 rpm. Push the A/C button to operate the compressor, place the blower switch to high and move the temperature control lever to max cool. After operating for a few minutes in this manner, check the sight glass.

1. If bubbles are visible occasionally in the sight glass and disappear when engine speed is raised, the magnetic clutch is engaged, the compressor discharge line is warm and the compressor inlet line is cool; the system may be overcharged.
2. If the sight glass is clear, the magnetic clutch is engaged and there is no significant temperature difference between compressor inlet and discharge lines; the system has most of its refrigerant charge.
3. If the sight glass shows foam or bubbles, the system could be low on refrigerant or the receiver drier is restricted. The system has to be tested, leak checked then recharged with refrigerant.



MAGNETIC CLUTCH TEST



1. Disconnect the connector (1P) to the magnetic clutch.
2. Connect battery (-) to compressor body.
3. Connect battery (+) voltage directly to the connector for the magnetic clutch.
4. If the magnetic clutch is normal, there will be a "click". If the pulley and armature do not make contact ('click'), there is a malfunction.

RECEIVER DRIER TEST

Operate the unit and check the piping temperature by touching the receiver drier outlet and inlet.

If there is a difference in the temperatures, the receiver drier is restricted.

Replace the receiver drier.

High-/Low
pressure side

00000189


DUAL PRESSURE SWITCH CHECK

1. Remove the dual pressure switch connector and connect the high/low pressure side terminals located on the harness side as shown in the illustration.
2. Install a gauge manifold to the high pressure side service valve of the refrigerant line. (Refer to [Performance Test](#).)
3. When the high/low pressure sides of the dual pressure switch are at operation pressure (ON) and there is continuity between the respective terminals, then the condition is normal. If there is no continuity, replace the switch.

Unit: kPa

| Items | Switch position | |
|--------------------|-----------------|-----------|
| | OFF to ON | ON to OFF |
| Low-pressure side | 220 | 200 |
| High-pressure side | 2,550 | 3,140 |

COMPRESSOR DRIVE BELT ADJUSTMENTRefer [Group 11A](#).



CHARGING

- With the handles turned back all the way (valve closed), install the adaptor valve to the low-pressure side of the gauge manifold.
- Connect the charging hose (blue) to the adaptor valve.
- Connect the quick joint (for low pressure) to the charging hose (blue).
- Connect the quick joint (for low pressure) to the low pressure service valve.

NOTE

The low-pressure service valve should be connected to the low pressure hose.

Caution

- Use tools that are designed for R-134a.
- To install the quick joint, press section A firmly against the service valve until a click is heard. When connecting, run your hand along the hose while pressing to ensure that there are no bends in the hose.

- Close the high and low pressure valves of the gauge manifold.
- Install the vacuum pump adaptor to the vacuum pump.
- Connect the vacuum pump plug to the vacuum pump adaptor.
- Connect the charging hose (yellow) to the R-134a connection port of the vacuum pump adaptor.
- Tighten the adaptor valve handle (valve open).
- Open the low pressure valve of the gauge manifold.
- Turn the power switch of the vacuum pump to the ON position.

NOTE

Even if the vacuum pump power switch is turned ON, the vacuum pump will not operate because of the power supply connection in step (7).

- Turn the vacuum pump adaptor switch to the R-134a side to start the vacuum pump.

Caution

Do not operate the A/C compressor during evacuation.

- Evacuate to a vacuum reading of 100 kPa or higher (takes approx. 10 minutes).
- Turn the vacuum pump adaptor switch OFF and allow to stand it for 5 minutes.


Caution



Do not operate the compressor in the vacuum condition; damage may occur.

- Carry out a leak test. (Good if the negative pressure does not drop.)

Caution

If the negative pressure (vacuum) is lost, check for loose connections. Then, repeat the evacuation procedure from step (12).





16. With the handle turned out all the way (valve open), install the charging valve to the service can.
17. Turn the handle of the adaptor valve back all the way (valve closed), remove it from the gauge manifold and install the service can.
18. Tighten the handle of the charging valve (valve closed) to puncture the service can.

19. Turn the handle of the charging valve back (valve open) and tighten the handle of the adaptor valve (valve open) to charge the system with refrigerant.

Caution

If the service can is inverted, liquid refrigerant may be drawn into the compressor damaging it by liquid compression. Keep the service can upright to ensure that refrigerant is charged in gas state.

20. If the refrigerant is not drawn in, turn the handle of the adaptor valve back all the way (valve closed).
21. Check for gas leaks using a leak detector. If a gas leak is detected, re-tighten the connections, and then repeat the charging procedure from evacuation in step (12).

Caution

A leak detector designed for R-134a should be used.

22. Start the engine.
23. Operate the A/C and set to the lowest temperature (MAX. COOL).
24. Fix the engine speed at 1,500 rpm.
25. Tighten the handle of the adaptor valve (valve open) to charge the required volume of refrigerant.


Caution

If the service can is inverted, liquid refrigerant may be drawn into the compressor damaging it by liquid compression. Keep the service can upright to ensure that refrigerant is charged in gas state.

26. After charging with refrigerant, turn the handle of the adaptor valve back all the way (valve closed).
27. Tighten the charging valve handle (valve closed). Remove the quick joint (for low pressure) from the low-pressure service valve.


NOTE

If the service can is not emptied completely, keep the handles of the charging valve and adaptor valve closed for the next charging.



CORRECTING LOW REFRIGERANT LEVEL IN CASE THE SERVICE CAN IS USED


1. Install the charge valve with the handle turned all the way out (valve open) of the service can.
2. Install the adaptor valve with the handle turned all the way back (valve close) to the charging valve.
3. Connect the charging hose (blue) to the adaptor valve.
4. Connect the charging hose (blue) to the quick joint (for low pressure).
5. Tighten the handle of the charge valve (valve close), and pierce the service can.
6. Turn the handle of the adaptor valve to bleed the air.



7. Install the quick joint (for low pressure) to the low pressure service valve.

NOTE

The low-pressure service valve should be connected to the low-pressure hose.



8. Start the engine.
9. Operate the air conditioner and set at the lowest temperature (MAX. COOL).
10. Fix the engine speed at 1,500 rpm.
11. Tighten the handle of the adaptor valve (valve open), and replenish refrigerant checking the quantity through the sight glass.


Caution

If the service can is inverted, liquid refrigerant may be drawn into the compressor damaging it by liquid compression. Keep the service can upright to ensure that refrigerant is charged in gas state.

12. After replenishing is completed, turn the handle of the adaptor valve all the way back (valve close), and remove the quick joint.

NOTE

If any refrigerant is remaining in the service can, close the adaptor valve and save the refrigerant for another vehicle. Do not release into the atmosphere.



DISCHARGING SYSTEM

1. Run the engine at an engine speed of 1,200–1,500 r/min for approximately 5 minutes with the A/C operating to return the oil.

NOTE

Returning the oil will be more effective if it is done while driving.

2. Stop the engine.
3. Connect the charging hose (blue) to the adaptor valve with its handle turned back all the way (valve closed).
4. Connect the quick joint to the charging hose (blue).
5. Install the quick joint to the low pressure service valve.

NOTE

The low pressure service valve should be connected to the suction hose.

Caution

To connect the quick joint, press section "A" firmly against the service valve until a click is heard. When connecting, run your hand along the hose while pressing to ensure that there are no bends in the hose.

6. Place the adaptor valve inside the container and discharge the refrigerant by opening the handle gradually so that the oil does not gush out.

NOTE

Any oil remaining in the container should be returned to the A/C system.

REFILLING OF OIL IN THE A/C SYSTEM

Too little oil will provide inadequate compressor lubrication and cause a compressor failure. Too much oil will increase discharge air temperature.


When a compressor is installed at the factory, it contains 170 ml. of refrigerant oil. While the A/C system is in operation, the oil is carried through the entire system by the refrigerant. Some of this oil will be trapped and retained in various parts of the system.

When the following system components are changed, it is necessary to add oil to the system to replace the oil being removed with the component.

Compressor oil: SUN PAG 56

Quantity:

Evaporator: 60 ml.
Condenser: 15 ml.
Suction hose: 10 ml.
Receiver: 10 ml.



PERFORMANCE TEST

1. The vehicles to be tested should be in a place that is not in direct sunlight.
2. Close the high and low pressure valve of the gauge manifold.
3. Connect the charging hose (blue) to the low pressure valve and connect the charging hose (red) to the high pressure valve of the gauge manifold.
4. Install the quick joint (for low pressure) to the charging hose (blue), and connect the quick joint (for high pressure) to the charging hose (red).
5. Connect the quick joint (for low pressure) to the low-pressure service valve and connect the quick joint (for high pressure) to the high-pressure service valve.

NOTE

The high-pressure service valve is on high-pressure pipe B, and the low-pressure service valve is on the low-pressure hose.

Caution


To connect the quick joint, press section A firmly against the service valve until a click is heard.

When connecting, run your hand along the hose while pressing to ensure that there are no bends in the hose.

6. Start the engine.
7. Set the A/C controls as follows:
A/C switch: A/C – ON position
Mode selection: Face position
Temperature control: Max. cooling position
Air selection: Recirculation position
Blower switch: HI (Fast) position
8. Adjust engine speed to 1500 rpm with A/C clutch engaged.
9. Engine should be warmed up with doors and windows closed.
10. Insert a thermometer in the left centre A/C outlet and operate the engine for 20 minutes.
11. Note the discharge air temperature.

NOTE

If the clutch cycles, take the reading before the clutch disengages.



Performance Temperature Chart

| | | | | |
|-------------------------------|---------|---------|----------|-----------|
| Garage ambient temperature °C | 21 | 26.7 | 32.2 | 37.8 |
| Discharge air temperature °C | 0.0–3.0 | 0.0–3.0 | 0.0–4.0 | 0.0–4.0 |
| Compressor high pressure kPa | 650–700 | 740–790 | 980–1020 | 1650–1200 |
| Compressor low pressure kPa | 130–140 | 130–190 | 130–190 | 130–190 |

REFRIGERANT LEAK REPAIR

LOST CHARGE

If the system has lost all charge due to a leak:

1. Evacuate the system. (See procedure.)
2. Charge the system with approximately 450 g, of refrigerant.
3. Check for leaks.
4. Discharge the system.
5. Repair leaks.
6. Replace receiver drier.

Caution

Replacement filter-drier units must be sealed while in storage. The drier used in these units will absorb water/water vapour water quickly upon exposure to the atmosphere. When installing a drier, have all tools and supplies ready for quick reassembly to avoid keeping the system open any longer than necessary.

7. Evacuate and charge system.

LOW CHARGE

If the system has not lost all of its refrigerant charge; locate and repair all leaks. If it is necessary to increase the system pressure to find the leak (because of an especially low charge) add refrigerant. If it is possible to repair the leak without discharging the refrigerant system, use the procedure for correcting low refrigerant level.

COMPRESSOR NOISE CHECK

You must first know the conditions when the noise occurs. These conditions are: weather, vehicle speed, in gear or neutral, engine temperature or any other special conditions.

Noises that develop during A/C operation can often be misleading. For example: what sounds like a failed front bearing or connecting rod, may be caused by loose bolts, nuts, mounting brackets, or a loose clutch assembly. Verify accessory drive belt tension (power steering or alternator).

Improper accessory drive belt tension can cause a misleading noise when the compressor is engaged and little or no noise when the compressor is disengaged.

Drive belts are speed-sensitive. That is, at different engine speeds, and depending upon belt tension, belts can develop unusual noises that are often mistaken for mechanical problems within the compressor.

HANDLING TUBING AND FITTINGS

Kinks in the refrigerant tubing or sharp bends in the refrigerant hose lines will greatly reduce the capacity of the entire system. High pressures are produced in the system when it is operating. Extreme care must be exercised to make sure that all connections are pressure tight. Dirt and moisture can enter the system when it is opened for repair or replacement of lines or components. The following precautions must be observed. The system must be completely discharged before opening any fitting or connection in the refrigeration system. Open fittings with caution even after the system has been discharged. If any pressure is noticed as a fitting is loosened, allow trapped pressure to bleed off very slowly.





Never attempt to rebend formed lines to fit. Use the correct line for the installation you are servicing. A good rule for the flexible hose lines is keep the radius of all bends at least 10 times the diameter of the hose.

Sharper bends will reduce the flow of refrigerant. The flexible hose lines should be routed so that they are at least 80 mm from the exhaust manifold. It is good practice to inspect all flexible hose lines at least once a year to make sure they are in good condition and properly routed.

O-rings used on connections are not reusable.

ADJUSTMENT

1. Select a quiet area for testing. Duplicate conditions as much as possible. Switch compressor on and off several times to clearly identify compressor noise. To duplicate high ambient conditions (high head pressure), restrict air flow through condenser. Install manifold gauge set to make sure discharge pressure doesn't exceed 2,070 kPa.
2. Tighten all compressor mounting bolts, clutch mounting bolt, and compressor drive belt. Check to assure clutch coil is tight (no rotation or wobble).
3. Check refrigerant hoses for rubbing or interference that can cause unusual noises.
4. Check [refrigerant charge](#).
5. Recheck compressor noise as in Step 1.
6. If noise still exists, loosen compressor mounting bolts and retorque. Repeat Step 1.
7. If noise continues, replace compressor and repeat Step 1.

20Z0002
25AE012N04Z0001
25AE013N

POWER RELAY CHECK

BLOWER RELAY CONTINUITY CHECK

| Battery voltage | Terminal No. | | | |
|-----------------|--------------|-------|---|---|
| | 1 | 2 | 3 | 4 |
| Not supplied | ○ | | ○ | |
| Supplied | ⊖ | ----- | ⊕ | |

A/C COMPRESSOR CLUTCH RELAY, CONDENSER FAN RELAY (LO) AND (HI) CONTINUITY CHECK

| Battery voltage | Terminal No. | | | |
|-----------------|--------------|-------|---|---|
| | 1 | 3 | 4 | 5 |
| Not supplied | ○ | ○ | | |
| Supplied | ⊕ | ----- | ⊖ | ○ |

IDLE-UP OPERATION CHECK

1. Before inspection and adjustment, set vehicle in the following condition:
 - Engine coolant temperature: 80–90°C
 - Lights, electric cooling fan and accessories: Set to OFF
 - Transmission: N or P
 - Steering wheel: Straightahead
2. Check whether or not the idling speed is the standard value.

Standard value: 700 ± 50 rpm

3. When the A/C is running after turning the A/C switch to ON, and the blower switch to the MED or HI position, check to be sure that the idle speed is at the standard value.

Standard value: 900 ± 50 rpm

NOTE

Idle speed is controlled by the ISC system and is not adjustable. If, idle speed is not within specifications, check the [ISC system](#).

MANUAL AIR CONDITIONING, HEATER UNIT, HEATER CORE, BLOWER ASSEMBLY AND COOLING UNIT


REMOVAL AND INSTALLATION

Pre-removal and Post-installation procedures

- Remove or install instrument panel and floor console box, Refer [Group 52A](#).
- Evacuate or recharge the [refrigerant system](#) (only when removing the cooling unit).
- Remove or install the air cleaner cover and hose, refer [Group 15](#).
- Drain or add coolant (only when removing the heater unit) refer [Group 14](#).

CAUTION: SRS

- (1) Before removing the passenger seat airbag module, ensure that you refer to [Group 52B–Servicing Cautions](#) and the section on the Airbag Module.
- (2) When removing or installing the instrument panel or engine control module, do not apply bump to the SRS-ECU.



Heater Unit removal steps

1. Floor carpet front reinforcement
2. ECU bracket
3. Centre stay assembly
4. Heater hose connection
5. Centre duct assembly
6. Foot distribution duct
7. Suction pipe, liquid pipe B and cooling unit connection
8. Drain hose
9. Cooling unit
10. Engine and A/T ECU
11. Heater unit
12. Heater core support
13. Heater core

Blower assembly removal steps

7. Suction pipe, liquid pipe B and cooling unit connection
8. Drain hose
9. Cooling unit
14. Blower assembly

Cooling unit removal steps

1. Suction pipe, liquid pipe B and cooling unit connection
3. Centre stay assembly
7. Suction pipe, liquid pipe B and cooling unit connection
8. Drain hose
9. Cooling unit




REMOVAL SERVICE POINTS**◀A▶ DISCONNECTING THE SUCTION PIPE, LIQUID
PIPE B AND THE COOLING UNIT**

1. To prevent the entry of dust and other contaminants, insert plugs in the disconnected pipes and the cooling unit nipples.

Caution

Because the compressor oil and receiver are strongly hygroscopic, use plugs that do not allow air to pass.

**INSPECTION****AIR THERMO SENSOR (IN EVAPORATOR)**

- When the resistance between the terminals is measured under two or more sets of temperature conditions, the resistance values should approximately satisfy the illustrated values.

NOTE


The temperature conditions when carrying out the check should not exceed the range in the characteristic diagram.

BLOWER MOTOR ASSEMBLY

REMOVAL AND INSTALLATION

Pre-removal and Post-installation procedures


- Remove or install the undercover assembly, glove box assembly and glove box outer case, Refer group 52A.



20P0036

Blower removal steps

1. A/C belt lock controller (Magna only)
2. Blower motor assembly



INSPECTION

BLOWER MOTOR


- Confirm that the motor rotates when the battery voltage is applied to the terminals and that no abnormal noises are emitted from the motor.

AIR CONDITIONING CONTROLS

REMOVAL AND INSTALLATION

Pre-removal and Post-installation procedures

- Remove or install the floor console panel (refer Group 52A.)
- Remove or install the centre air outlet assembly and ashtray, (refer Group 52A.)

**Air conditioning controls removal steps**

1. Mode selection switch
2. Air selection control wire

3. Temperature control wire
4. Fan speed switch wiring
5. Wiring from A/C switch

AUTOMATIC AIR CONDITIONING, HEATER UNIT, HEATER CORE, BLOWER ASSEMBLY AND COOLING UNIT


REMOVAL AND INSTALLATION

Pre-removal and Post-installation procedures


- Remove or install instrument panel and floor console box, refer [Group 52A](#).
- Evacuate or recharge the [refrigerant system](#) (only when removing the cooling unit).
- Remove or install the [air cleaner cover and hose](#).
- Drain or add coolant (only when removing the heater unit) refer [group 14](#).

CAUTION: SRS

- (1) Before removing the passenger seat airbag module, ensure that you refer to [Group 52B](#)[Group 52B–Servicing Cautions](#) and the section on the Airbag Module.
- (2) When removing or installing the instrument panel or engine control module, do not apply bump to the SRS-ECU.



Piping joints



20W0230

A/C compressor oil:
SUN PAG 56

Heater Unit removal steps

1. Floor carpet front reinforcement
2. ECU bracket
3. Centre stay assembly
4. Heater hose connection
5. Centre duct assembly
6. Foot distribution duct
7. Aspirator hose
8. Suction pipe, liquid pipe B and cooling unit connection
9. Drain hose
10. Cooling unit
11. Engine and A/T ECU
12. Heater unit
13. Heater core support
14. Heater core



Blower assembly removal steps

8. Suction pipe, liquid pipe B and cooling unit connection
9. Drain hose
10. Cooling unit
15. Blower assembly

Cooling unit removal steps

1. Floor carpet front reinforcement
2. ECU bracket
3. Centre stay assembly
8. Suction pipe, liquid pipe B and cooling unit connection
9. Drain hose
10. Cooling unit




REMOVAL SERVICE POINTS**◀A▶ DISCONNECTING THE SUCTION PIPE, LIQUID
PIPE B AND THE COOLING UNIT**

1. To prevent the entry of dust and other contaminants, insert plugs in the disconnected pipes and the cooling unit nipples.

Caution

Because the compressor oil and receiver are strongly hygroscopic, use plugs that do not allow air to pass.

**INSPECTION****AIR THERMO SENSOR (IN EVAPORATOR)**

- When the resistance between the terminals is measured under two or more sets of temperature conditions, the resistance values should approximately satisfy the illustrated values.

NOTE


The temperature conditions when carrying out the check should not exceed the range in the characteristic diagram.

BLOWER MOTOR ASSEMBLY

REMOVAL AND INSTALLATION

Pre-removal and Post-installation procedures

- Undercover Assembly, Glove Box Assembly, Glove Box Assembly, Glove Box Outer Case Removal and Installation (Refer to [group 52A](#).)



25TH037A

Removal steps


1. Blower motor assembly

AIR CONDITIONING CONTROL UNIT ASSEMBLY

REMOVAL AND INSTALLATION

Pre-removal and Post-installation Operations


- Floor Console Panel Removal and Installation (Refer Group 52A.)
- Centre Air Outlet and Ashtray Removal and Installation (Refer Group 52A)



20P0038

Removal steps

1. Audio panel
2. Air control panel assembly and radio/tape player
3. Harness connector and breather hose
4. A/C control assembly




INSPECTION

BLOWER FAN AND MOTOR

When battery voltage is applied between the terminals, check to be sure that the motor operates. Also, check to be sure that there is no abnormal noise.

DAMPER CONTROL MOTOR ASSEMBLY AND POWER TRANSISTOR REMOVAL AND INSTALLATION



20P0022

Air inlet mode selector damper motor removal steps

- Undercover assembly, glove box assembly, glove box frame (Refer group 52A.)

1. Linkage connection
2. Air inlet mode selector damper motor

Air outlet mode selector damper motor removal steps

- Instrument panel lower cover assembly (Refer group 52A.)

3. Linkage connection
4. Air outlet mode selector damper motor

Air mix damper motor removal steps


- Undercover assembly, glove box assembly, glove box outer case, console side cover assembly (Refer group 52A.)

5. Linkage connection
6. Air mix damper motor

Power transistor removal steps

- Undercover assembly, glove box assembly, glove box frame (Refer Group 52A.)

7. Power transistor




INSPECTION

AIR INLET MODE SELECTOR DAMPER MOTOR OPERATION CHECK

Check that the lever moves when battery voltage is applied across terminals 1 and 3 of motor assembly side connector. Check also that the lever moves in the opposite direction when polarity is reversed.

Caution

1. Remove the voltage when the damper is at the inside air position or outside air position.
2. Remove the voltage if the motor does not turn when battery voltage is applied.



AIR MIX DAMPER MOTOR OPERATION CHECK

Check that the lever moves when battery voltage is applied across terminals 1 and 3 of motor assembly side connector. Check also that the lever moves in the opposite direction when polarity is reversed.


Caution

1. Remove the voltage when the damper is at the inside air position or outside air position.
2. Remove the voltage if the motor does not turn when battery voltage is applied.

AIR MIX DAMPER MOTOR POTENTIOMETER CHECK

During motor operation check, confirm that the resistance value between motor connector terminals 2 and 5 and 5 and 6 changes gradually in the range of the standard value.

Standard value: 0.18–4.82 kΩ



AIR OUTLET MODE SELECTOR DAMPER MOTOR OPERATION CHECK

Check that the lever moves when battery voltage is applied across terminals 1 and 3 of motor assembly side connector. Check also that the lever moves in the opposite direction when polarity is reversed.

Caution

1. Remove the voltage when the damper is at the inside air position or outside air position.
2. Remove the voltage if the motor does not turn when battery voltage is applied.

**AIR OUTLET MODE SELECTOR DAMPER MOTOR
POTENTIOMETER CHECK**

During motor operation check, confirm that the resistance value between motor connector terminals 2 and 5 and 5 and 6 changes gradually in the range of the standard value.



Standard value: 0.18–4.82 kΩ

COMPRESSOR AND TENSION PULLEY

REMOVAL AND INSTALLATION

Pre-removal and Post-installation Operation

- Refrigerant Discharging and Charging.
- Compressor Drive Belt Adjustment



Compressor oil: SUN
PAG 56

25TJ043A


Removal steps

◀A▶

1. Alternator and A/C compressor drive belt
2. Harness connector

◀B▶ ▶A◀

3. Suction hose connection
4. Discharge hose connection
5. Compressor
6. Compressor bracket



REMOVAL SERVICE POINTS

◀A▶ COMPRESSOR DRIVE BELT REMOVAL

1. Loosen nut "A" for holding the tension pulley.
2. Loosen bolt "B" for adjustment.
3. Remove the alternator and compressor drive belt.

◀B▶ COMPRESSOR REMOVAL

When doing this work, be careful not to spill the compressor oil.

INSTALLATION SERVICE POINT

▶A◀ COMPRESSOR INSTALLATION

If a new compressor is installed, first adjust the amount of oil according to the procedures described below, and then install the compressor.

1. Measure the amount {X ml.} of oil within the removed compressor.
2. Drain (from the new compressor) the amount of oil calculated according to the following formula, and then install the new compressor.

New compressor oil amount
170–190 ml. – X ml. = Y ml.

NOTE

- (1) Y ml. indicates the amount of oil in the refrigerant line, the condenser, the evaporator etc.
- (2) When replacing A/C system parts with new ones, recharge the compressor oil the equivalent amount that was in the component.

Quantity:

Evaporator: 60 ml.

Condenser: 15 ml.


Suction hose: 10 ml.

Receiver: 10 ml.

INSPECTION

- Checking for heat damage of the tension pulley.
- Check for excessive play or deflection of the tension pulley.
- Check for unusual wear of the tension pulley.
- Check for hardening of the compressor drive belt.
- Check for unusual wear or abrasion of the compressor drive belt.

DISASSEMBLY AND REASSEMBLY




Disassembly steps

◀A▶ **D**◀C◀

1. Bolt
2. Pulley
3. Self-locking nut
4. Armature






▶B◀ **B**◀A◀

5. Shim
6. Snap ring
7. Rotor
8. Field core



DISASSEMBLY SERVICE POINTS

◀A▶ NUT REMOVAL



REASSEMBLY SERVICE POINTS

►A◀ CLUTCH COIL INSTALLATION

When installing the clutch coil to the A/C compressor body, install so that the pin hole of the A/C compressor body and the clutch coil projection are aligned.

►B◀ SNAP RING INSTALLATION

Install the snap ring so that the tapered surface is at the outer side.

►C◀ ARMATURE PLATE INSTALLATION

Align the mating mark of the crankshaft spline and the mating mark of the armature plate, and then fit them together.

►D◀ NUT INSTALLATION

1. Install the nut.



2. Check whether or not the air gap of the clutch is within the standard value.

Standard value: 0.4–0.65 mm

NOTE

If there is a deviation of the air gap from the standard value, make the necessary adjustment by adjusting the number of shims.

View A



20P0028

INSPECTION

- Check the surface of the armature for scoring or bluing.
- Check the surface of the rotor for scoring or bluing.
- Check the sealing surfaces for cracks, scratches and deformation.
- Check the front housing for cracks or scoring on the sealing surfaces.
- Check the compressor shaft for scoring.

REFRIGERANT-TEMPERATURE SWITCH

Check that there is continuity between connector terminals 1 and 2.

REVOLUTION PICK UP SENSOR CHECK

Check that the resistance between connector terminals 3 and 4 is in the standard value range.



Standard value: $405 \pm 35 \Omega$ (at 20°C)

REFRIGERANT LINE

REMOVAL AND INSTALLATION

Pre-removal and Post-installation Operation

- [Discharge and Charging of Refrigerant](#)
- [Battery and Battery Tray Removal and Installation](#)
- [Air Cleaner Removal and Installation](#)



Removal steps

- 1. Clamp
- 2. Liquid pipe B
- 3. Suction pipe
- 4. Liquid pipe A
- 5. Receiver



- 6. Dual pressure switch
- 7. Receiver bracket
- 8. Clamp
- 9. Suction hose
- 10. Discharge hose



INSTALLATION SERVICE POINT

►A◀ SUCTION HOSE, RECEIVER ASSEMBLY INSTALLATION

When replacing the suction hose, or the receiver assembly with new ones, refill them with a specified amount of compressor oil, and then install each of them.

Compressor oil: SUN PAG 56

Quantity:

Suction hose: 10 ml.


Receiver: 10 ml.

CONDENSER AND CONDENSER FAN MOTOR

REMOVAL AND INSTALLATION

Pre-removal and Post-installation Operation

- Discharge and Charging of Refrigerant

20P0032
25AE026N

Condenser fan motor removal steps

1. Condenser fan motor and shroud assembly
2. Condenser fan
3. Condenser fan motor

4. Spacer
5. Shroud

Condenser removal steps

6. Discharge pipe
7. Condenser


►A◀

INSTALLATION SERVICE POINT**►A◀CONDENSER INSTALLATION**


When replacing the condenser with a new one, refill the condenser with a specified amount of compressor oil and install it (to the vehicle).

Compressor oil: SUN PAG 56

Quantity: 15 ml.

**INSPECTION****CONDENSER FAN MOTOR**

1. Check to be sure that the condenser fan motor operates when battery voltage (+) is applied to terminal 1 and terminal 2 is grounded (-).
2. In this same condition, apply battery (+) voltage to terminal 3 and ground terminal 4. Check to be sure that the condenser fan motor operates faster at this time.



SENSORS



PHOTO SENSORS

REMOVAL AND INSTALLATION

1. Remove the [centre air outlet assembly](#).
2. Remove the [centre message display](#)
3. Remove the photo sensor.

INSPECTION

With the fully automatic air conditioning operating (during summer in daylight), cover the light-sensitive part of the photo sensor with the hand – if the blower speed drops, it is normal. If it does not drop, replace the photo sensor.



OUTSIDE AIR TEMPERATURE SENSOR

REMOVAL AND INSTALLATION

1. Remove the radiator grille. (Refer [Group 51.](#))
2. Remove the outside air temperature sensor.

INSPECTION

When the resistance between the sensor terminals is measured under two or more temperature conditions, the resistance should approximately satisfy the illustrated values.

NOTE

The temperature conditions when checking should not exceed the range shown in the diagram.

HEATER WATER TEMPERATURE SENSOR


REMOVAL AND INSTALLATION

Pre-removal and Post-installation Operation

- Instrument Panel Lower Cover Assembly, Under-cover Assembly, Console Side Cover Assembly, and Floor Carpet Front Reinforcement, [Removal and Installation.](#)
- Engine-ECU, Transmission ECU and A/T Control Relay [Removal and Installation](#)


Caution: SRS

- (1) Before removing the passenger seat airbag module, ensure that you refer to [Group 52B –Servicing Cautions](#) and the section on the Airbag Module.
- (2) When removing or fitting the engine control module, do not let it knock against the SRS-ECU.



Removal steps

1. Heater water temperature sensor clip
 2. Heater water temperature sensor



REMOVAL SERVICE POINTS

►A► HEATER WATER TEMPERATURE SENSOR CLIP/HEATER WATER TEMPERATURE SENSOR REMOVAL

Pull out the heater water temperature sensor clip from the base of the heater unit, and remove the heater water temperature sensor from the heater unit.

INSTALLATION SERVICE POINT

►A► HEATER WATER TEMPERATURE SENSOR/HEATER WATER TEMPERATURE SENSOR CLIP INSTALLATION


Insert the heater water temperature sensor into the mounting hole at the base of the heater unit, and secure by plugging in the heater water temperature sensor clip.

INSPECTION

Check using the same procedure as in [checking the outside air temperature sensor](#).

VENTILATORS

REMOVAL AND INSTALLATION



20P0016


**Defroster nozzle and distribution
duct removal steps**

1. Side air outlet assembly
 - Instrument panel (Refer [Group 52A.](#).)
2. Defroster nozzle
3. Side defroster hose
4. Distribution duct
5. Defroster garnish

6. Centre duct**Rear heater duct removal steps**

- Front seat (Refer [Group 52A.](#))
- Instrument Panel, centre stay assembly (Refer [Group 52A.](#))
- 7. Rear heater duct
- 8. Rear heater nozzle
- 9. Distribution duct

VENTILATORS (AIR OUTLET) REMOVAL AND INSTALLATION



Removal steps

1. Rear bumper (Refer [Group 51](#))
2. Rear ventilation duct