

SECTION **BL**

BODY, LOCK & SECURITY SYSTEM

CONTENTS

PRECAUTIONS	4	OUTLINE	19	F
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	4	Schematic	20	
Precautions for work	4	Wiring Diagram -D/LOCK-	21	
Wiring Diagnosis and Trouble Diagnosis	4	FIG. 1	21	G
PREPARATION	5	FIG. 2	22	
Special service tool	5	FIG. 3	23	
Commercial Service Tool	5	FIG. 4	24	H
SQUEAK AND RATTLE TROUBLE DIAGNOSIS	6	Terminals and Reference Value for BCM	25	
Work Flow	6	Work Flow	25	
CUSTOMER INTERVIEW	6	CONSULT-II Function	25	
DUPLICATE THE NOISE AND TEST DRIVE	7	CONSULT-II BASIC OPERATION PROCEDURE	26	BL
CHECK RELATED SERVICE BULLETINS	7	DATA MONITOR	26	
LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE	7	ACTIVE TEST	27	J
REPAIR THE CAUSE	7	Trouble Diagnoses Symptom Chart	27	
CONFIRM THE REPAIR	8	BCM Power Supply and Ground Circuit Check	27	
Generic Squeak and Rattle Troubleshooting	8	Door Switch Check	29	K
INSTRUMENT PANEL	8	Key Switch (Insert) Check	31	
CENTER CONSOLE	8	Door Lock/Unlock Switch Check	32	
DOORS	8	Door Lock Actuator Check (Front LH)	34	
TRUNK	9	Door Lock Actuator Check (Front RH and Rear LH/ RH)	35	L
SUNROOF/HEADLINER	9	Front Door Key Cylinder Switch LH Check	36	
SEATS	9	REMOTE KEYLESS ENTRY SYSTEM	37	M
UNDERHOOD	9	Component Parts and Harness Connector Location	37	
Diagnostic Worksheet	10	System Description	38	
HOOD	12	INPUTS	38	
Fitting Adjustment	12	OPERATED PROCEDURE	38	
FRONT END HEIGHT ADJUSTMENT AND LATERAL/LONGITUDINAL CLEARANCE ADJUSTMENT	12	CAN Communication System Description	40	
Removal and Installation of Hood Assembly	13	Schematic	41	
Removal and Installation of Hood Lock Control	14	Wiring Diagram — KEYLES —	42	
REMOVAL	15	FIG. 1	42	
INSTALLATION	15	FIG. 2	43	
Hood Lock Control Inspection	15	FIG. 3	44	
POWER DOOR LOCK SYSTEM	17	Terminals and Reference Value for BCM	45	
Component Parts and Harness Connector Location	17	Terminals and Reference Value for IPDM E/R	46	
System Description	18	CONSULT-II Function	46	
		CONSULT-II Inspection Procedure	46	
		"MULTI REMOTE ENT"	46	
		CONSULT-II Application Items	47	

“MULTI REMOTE CONT SYS”	47	POWER SUPPLY	80
Trouble Diagnosis Procedure	49	INITIAL CONDITION TO ACTIVATE THE SYS-	
Pre-Diagnosis Inspection	49	TEM	81
BCMPowerSupplyAndGroundCircuit		VEHICLE SECURITY SYSTEM ALARM OPER-	
INSPECTION	49	ATION	81
Trouble Diagnoses	50	VEHICLE SECURITY SYSTEM DEACTIVATION..	81
SYMPTOM CHART	50	PANIC ALARM OPERATION	81
Key Fob Battery and Function Check	52	CAN Communication System Description	82
ACC Power Check	54	Schematic	83
IPDM E/R Operation Check	54	Wiring Diagram -VEHSEC-	84
Door Switch Check	56	FIG. 1	84
Key Switch Check	58	FIG. 2	85
Trunk Lamp Switch and Trunk Release Solenoid		FIG. 3	86
Check	58	FIG. 4	87
Check Hazard Function	60	FIG. 5	88
Check Horn Function	60	CONSULT-II Function	89
Check Headlamp Function	60	CONSULT-II INSPECTION PROCEDURE	89
Check Map Lamp and Ignition Key Illumination		CONSULT-II APPLICATION ITEM	89
Function	60	Trouble Diagnosis	91
ID Code Entry Procedure	61	WORK FLOW	91
KEY FOB ID SET UP WITH CONSULT-II	61	Preliminary Check	92
KEY FOB ID SET UP WITHOUT CONSULT-II	63	Symptom Chart	93
Key Fob Battery Replacement	64	Diagnostic Procedure 1	94
DOOR	65	Diagnostic Procedure 2	97
Fitting Adjustment	65	Diagnostic Procedure 3	98
FRONT DOOR	65	Diagnostic Procedure 4	98
REAR DOOR	65	Diagnostic Procedure 5	98
STRIKER ADJUSTMENT	65	Diagnostic Procedure 6	98
Removal and Installation	66	NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-	
Door Weatherstrip	67	NATS)	99
FRONT DOOR LOCK	68	Component Parts and Harness Connector Location..	99
Component Structure	68	System Description	100
Removal and Installation	68	System Composition	100
REMOVAL	68	ECM Re-communicating Function	101
INSTALLATION	70	Wiring Diagram — NATS —	102
Disassembly and Assembly	71	Terminals and Reference Value for BCM	103
DOOR KEY CYLINDER ASSEMBLY	71	CONSULT-II	103
REAR DOOR LOCK	72	CONSULT-II INSPECTION PROCEDURE	103
Component Structure	72	CONSULT-II DIAGNOSTIC TEST MODE FUNC-	
Removal and Installation	72	TION	104
REMOVAL	72	HOW TO READ SELF-DIAGNOSTIC RESULTS..	105
INSTALLATION	74	NVIS (NATS) SELF-DIAGNOSTIC RESULTS	
TRUNK LID AND FUEL FILLER LID OPENER	75	ITEM CHART	105
Wiring Diagram -TLID-	75	Work Flow	106
Terminals and Reference Value for BCM	76	Trouble Diagnoses	107
Fitting Adjustment	76	SYMPTOM MATRIX CHART 1	107
LONGITUDINAL AND LATERAL CLEARANCE		SYMPTOM MATRIX CHART 2	108
ADJUSTMENT	76	DIAGNOSTIC SYSTEM DIAGRAM	108
SURFACE HEIGHT ADJUSTMENT	76	Diagnostic Procedure 1	109
Removal and Installation of Trunk Lid Assembly	77	Diagnostic Procedure 2	110
Removal and Installation of Trunk Lid Lock	77	Diagnostic Procedure 3	111
LOCK REMOVAL	77	Diagnostic Procedure 4	112
STRIKER REMOVAL	78	Diagnostic Procedure 5	113
LOCK AND STRIKER INSTALLATION	78	Diagnostic Procedure 6	116
Removal and Installation of Trunk Lid Weatherstrip..	78	How to Replace NATS Antenna Amp.	117
VEHICLE SECURITY (THEFT WARNING) SYSTEM..	79	INTEGRATED HOMELINK TRANSMITTER	118
Component Parts and Harness Connector Location..	79	Wiring Diagram — TRNSCV —	118
System Description	80	Trouble Diagnoses	119
DESCRIPTION	80	DIAGNOSTIC PROCEDURE	119

BODY REPAIR	121	Handling Precautions for Plastics	144	
Body Exterior Paint Color	121	HANDLING PRECAUTIONS FOR PLASTICS ..	144	A
Body Component Parts	122	LOCATION OF PLASTIC PARTS	145	
UNDERBODY COMPONENT PARTS	122	Precautions in Repairing High Strength Steel	147	
BODY COMPONENT PARTS	124	HIGH STRENGTH STEEL (HSS) USED IN NIS-		B
Corrosion Protection	126	SAN VEHICLES	147	
DESCRIPTION	126	Replacement Operations	150	
ANTI-CORROSIVE WAX	127	DESCRIPTION	150	C
UNDERCOATING	128	HOODLEDGE	153	
Body Sealing	129	HOODLEDGE (PARTIAL REPLACEMENT)	154	
DESCRIPTION	129	FRONT SIDE MEMBER	155	
Body Construction	132	FRONT SIDE MEMBER (PARTIAL REPLACE-		D
BODY CONSTRUCTION	132	MENT)	156	
Body Alignment	133	FRONT PILLAR	157	
BODY CENTER MARKS	133	CENTER PILLAR	161	E
PANEL PARTS MATCHING MARKS	134	OUTER SILL	163	
DESCRIPTION	135	REAR FENDER	164	
ENGINE COMPARTMENT	136	REAR PANEL	165	F
UNDERBODY	138	REAR FLOOR REAR	166	
PASSENGER COMPARTMENT	140	REAR SIDE MEMBER EXTENSION	167	
REAR BODY	142			G

BL

J

K

L

M

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EIS001FJ

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.

Precautions for work

EIS001FK

- After removing and installing the opening/closing parts, be sure to carry out fitting adjustments to check their operation.
- Check the lubrication level, damage, and wear of each part. If necessary, grease or replace it.

Wiring Diagnosis and Trouble Diagnosis

EIS001FL

When you read wiring diagrams, refer to the following:

- [GI-12, "How to Read Wiring Diagrams"](#)
- [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#)

When you perform trouble diagnosis, refer to the following:

- [GI-10, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#)
- [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#)
Check for any Service bulletins before servicing the vehicle.

PREPARATION



PREPARATION

PFP:00002

Special service tool


EIS001FM

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
(J-39570) Chassis ear  SIIA0993E	Locating the noise
(J-43980) NISSAN Squeak and Rattle Kit  SIIA0994E	Repairing the cause of noise
(J-43241) Remote Keyless Entry Tester  LEL946A	Used to test key fobs

Commercial Service Tool

EIS001FN

Tool name	Description
Engine ear  SIIA0995E	Locating the noise


SQUEAK AND RATTLE TROUBLE DIAGNOSIS

SQUEAK AND RATTLE TROUBLE DIAGNOSIS

PFP:00000

Work Flow

EIS001FO



CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer [BL-10, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces=higher pitch noise/softer surfaces=lower pitch noises/edge to surface=chirping
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

SQUEAK AND RATTLE TROUBLE DIAGNOSIS

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on A/T model).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear and mechanic's stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.
Refer to [BL-8, "Generic Squeak and Rattle Troubleshooting"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through your authorized Nissan Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100×135 mm (3.94×5.31 in)/76884-71L01: 60×85 mm (2.36×3.35 in)/76884-71L02: 15×25 mm (0.59×0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50×50 mm (1.97×1.97 in)/73982-50Y00: 10 mm (0.39 in) thick, 50×50 mm (1.97×1.97 in)

INSULATOR (Light foam block)

SQUEAK AND RATTLE TROUBLE DIAGNOSIS

80845-71L00: 30 mm (1.18 in) thick, 30×50 mm (1.18×1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15×25 mm (0.59×0.98 in) pad/**68239-13E00:** 5 mm (0.20 in) wide tape roll The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that will be visible or not fit.

Note: Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Generic Squeak and Rattle Troubleshooting

EIS001FP

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicone spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSIS

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner. In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINER

Noises in the sunroof/headliner area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sun visor shaft shaking in the holder
3. Front or rear windshield touching headliner and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noise can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

A

B

C

D

E

F

G

H

BL

J

K

L

M

SQUEAK AND RATTLE TROUBLE DIAGNOSIS

Diagnostic Worksheet

EIS001FQ




SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Nissan Customer:

We are concerned about your satisfaction with your Nissan vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Nissan right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to the back of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

ABT468

SQUEAK AND RATTLE TROUBLE DIAGNOSIS

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET- page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (check the boxes that apply)

- | | |
|--|---|
| ☐ anytime | ☐ after sitting out in the sun |
| ☐ 1 st time in the morning | ☐ when it is raining or wet |
| ☐ only when it is cold outside | ☐ dry or dusty conditions |
| ☐ only when it is hot outside | ☐ other: _____ |

III. WHEN DRIVING:

- ☐ through driveways
- ☐ over rough roads
- ☐ over speed bumps
- ☐ only at about _____ mph
- ☐ on acceleration
- ☐ coming to a stop
- ☐ on turns : left, right or either (circle)
- ☐ with passengers or cargo
- ☐ other: _____
- ☐ after driving _____ miles or _____ minutes

IV. WHAT TYPE OF NOISE?

- ☐ squeak (like tennis shoes on a clean floor)
- ☐ creak (like walking on an old wooden floor)
- ☐ rattle (like shaking a baby rattle)
- ☐ knock (like a knock on a door)
- ☐ tick (like a clock second hand)
- ☐ thump (heavy, muffled knock noise)
- ☐ buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	☐	☐	_____
- Noise verified on test drive	☐	☐	_____
- Noise source located and repaired	☐	☐	_____
- Follow up test drive performed to confirm repair	☐	☐	_____

VIN: _____ Customer Name: _____

W.O. #: _____ Date: _____

SBT844

This form must be attached to Work Order


HOOD

HOOD

PFP:F5100

Fitting Adjustment

EIS001FR



FRONT END HEIGHT ADJUSTMENT AND LATERAL/LONGITUDINAL CLEARANCE ADJUSTMENT.

1. Remove the radiator grille. Refer to [EI-18, "Removal and Installation"](#).
2. Install the hood lock temporarily, and align the hood striker and lock so that the centers of striker and lock become vertical viewed from the front, by moving the hood lock laterally.


HOOD

3. Check that the secondary latch is properly engaged with the secondary striker with hood's own weight by dropping it from approx. 200 mm (7.87 in) height or by pressing it lightly approx. 3 kg (29 N).

CAUTION:


Do not drop the hood from 300 mm (11.81 in) height or higher.

4. Move the hood lock up and down so that the striker and lock are engaged firmly with the hood closed.
5. Tighten the lock mounting bolts to the specified torque.
6. Install the radiator grille. Refer to [EI-18, "Removal and Installation"](#).



Removal and Installation of Hood Assembly

E/S001FS



1. Remove the hinge mounting nuts on the hood to remove the hood assembly.

HOOD



Install in the reverse order of removal.

NOTE:

Align the hood. Refer to [BL-12, "Fitting Adjustment"](#) .

Removal and Installation of Hood Lock Control

EIS001FT



LIA0303E


HOOD

REMOVAL

1. Disconnect the hood lock cable from the hood lock, and un-clip it from the radiator core upper support and hoodledge.
2. Remove the mounting screws, and remove the hood opener.
3. Remove the grommet on the instrument panel, and pull the hood lock cable toward the passenger compartment.


CAUTION:

While pulling, be careful not to damage (peeling) the outside of the hood lock cable.




INSTALLATION

1. Pull the hood lock cable through the panel hole to the engine compartment. Be careful not to bend the cable too much, keeping the radius 100 mm (3.94 in) or more.
2. Check that the cable is not offset from the positioning grommet, and push the grommet into the panel hole securely.
3. Apply the sealant to the grommet (at * mark) properly.



4. Install the cable securely to the lock.
5. After installing, check the hood lock adjustment and hood opener operation.




Hood Lock Control Inspection

CAUTION:


If the hood lock cable is bent or deformed, replace it.

1. Check that the secondary latch is properly engaged with the secondary striker with hood's own weight by dropping it from approx. 200 mm (7.87 in) height.
2. While operating the hood opener, carefully check that the front end of the hood is raised by approx. 20 mm (0.79 in). Also check that the hood opener returns to the original position.



HOOD

3. Check the hood lock lubrication condition. If necessary, apply "body grease" to the points shown in the figure.




POWER DOOR LOCK SYSTEM

POWER DOOR LOCK SYSTEM

PFP:24814

Component Parts and Harness Connector Location

EIS001FV



LIA0505E

POWER DOOR LOCK SYSTEM

EIS001FW

System Description

Power is supplied at all times

- to BCM terminal 55
- through 50A fusible link (letter **f**, located in the fuse and fusible link box)
- through 10A fuse [No. 21, located in the fuse block (J/B)]
- to key switch and keylock solenoid terminal 2
- to BCM terminal 42.

With ignition key inserted, power is supplied

- through key switch and keylock solenoid terminal 1
- to BCM terminal 37.

Ground is supplied to terminals 49 and 52 of BCM through body grounds M57, M61 and M79.

When the door is locked or unlocked with main power window and door lock/unlock switch, ground is supplied

- to CPU of main power window and door lock/unlock switch
- through main power window and door lock/unlock switch terminal 17
- through grounds M57, M61 and M79.

Then main power window and door lock/unlock switch operation signal is supplied.

- to BCM terminal 22
- through main power window and door lock/unlock switch terminal 14.

When the door is locked or unlocked with front power window switch RH, ground is supplied

- to CPU of front power window switch RH
- through front power window switch RH terminal 11
- through grounds M57, M61 and M79.

Then front power window switch RH operation signal is supplied

- to BCM terminal 22
- through front power window switch RH terminal 16.

When the door is locked with front door key cylinder switch LH, ground is supplied

- to main power window and door lock/unlock switch terminal 4
- through key cylinder switch terminals 1 and 5
- through grounds M57, M61 and M79.

Then key cylinder switch operation signal is supplied

- to BCM terminal 22
- through main power window and door lock/unlock switch terminal 14.

When the door is unlocked with front door key cylinder switch LH, ground is supplied

- to main power window and door lock/unlock switch terminal 6
- through key cylinder switch terminals 6 and 5
- through grounds M57, M61 and M79.

Then key cylinder switch operation signal is supplied

- to BCM terminal 22
- through main power window and door lock/unlock switch terminal 14.

BCM is connected to main power window and door lock/unlock switch and front power window switch RH through a serial link.

When the front door switch LH is ON (door is open), ground is supplied

- to BCM terminal 62
- through front door switch LH terminal 2
- through front door switch LH case ground.

When the front door switch RH is ON (door is open), ground is supplied

- to BCM terminal 12
- through front door switch RH terminal 2
- through front door switch RH case ground.

POWER DOOR LOCK SYSTEM

When the rear door switch LH is ON (door is open), ground is supplied

- to BCM terminal 63
- through rear door switch LH terminal 1
- through rear door switch LH case ground.

When the rear door switch RH is ON (door is open), ground is supplied

- to BCM terminal 13
- through rear door switch RH terminal 1
- through rear door switch RH case ground.

OUTLINE

Functions available by operating the door lock and unlock switches on driver's door and passenger's door

- Interlocked with the locking operation of door lock and unlock switch, door lock actuators of all doors are locked.
- Interlocked with the unlocking operation of door lock and unlock switch, door lock actuators of all doors are unlocked.

Functions available by operating the key cylinder switch on driver's door

- Interlocked with the locking operation of door key cylinder, door lock actuators of all doors are locked.
- When door key cylinder is unlocked, front door lock actuator LH is unlocked.
- When door key cylinder is unlocked for the second time within 5 seconds after the first operation, door lock actuators on all doors are unlocked.

Key reminder door system

When door lock and unlock switch is operated to lock doors with ignition key put in key cylinder and any door open, all door lock actuators are locked and then unlocked.

A

B

C

D

E

F

G

H

BL

J

K


L

M

POWER DOOR LOCK SYSTEM

Schematic

EIS001FX






LIWA0098E

POWER DOOR LOCK SYSTEM

Wiring Diagram -D/LOCK- FIG. 1

EIS001FY



BL-D/LOCK-01



POWER DOOR LOCK SYSTEM

FIG. 2



BL-D/LOCK-02



POWER DOOR LOCK SYSTEM

FIG. 3



BL-D/LOCK-03



POWER DOOR LOCK SYSTEM

FIG. 4


BL-D/LOCK-04



POWER DOOR LOCK SYSTEM

Terminals and Reference Value for BCM

E/S001FZ

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)
12	BR/W	Front door switch RH	Door open (ON) → Door close (OFF)	0 → Battery voltage
13	L/R	Rear door switch RH	Door open (ON) → Door close (OFF)	0 → Battery voltage
22	Y	Anti-pinch serial link	When ignition switch is ON or power window timer operates	 PIIA2344E
37	B/R	Key switch (insert)	Key inserted in IGN key cylinder (ON) → Key removed from IGN key cylinder (OFF)	Battery voltage → 0
39	L	CAN-H	—	—
40	Y	CAN-L	—	—
42	Y/R	Battery power supply	—	Battery voltage
44	G	Front door lock actuator LH (unlock)	Driver door lock knob (locked → unlocked)	0 → Battery voltage
49	B	Ground	—	—
50	GR	All door lock actuator (lock)	Driver door lock knob (neutral → lock)	0 → Battery voltage
51	G/Y	Front door lock actuator RH and Rear door lock actuators LH/RH (unlock)	Door lock and unlock switch (locked → unlocked)	0 → Battery voltage
52	B	Ground	—	—
55	W/B	BAT power supply	—	Battery voltage
62	SB	Front door switch LH	Door open (ON) → Door close (OFF)	0 → Battery voltage
63	R/B	Rear door switch LH	Door open (ON) → Door close (OFF)	0 → Battery voltage

Work Flow

E/S001G0

1. Check the symptom and customer's requests.
2. Understand the outline of system. Refer to [BL-18, "System Description"](#) .
3. According to the trouble diagnosis chart, repair or replace the cause of the malfunction. Refer to [BL-27, "Trouble Diagnoses Symptom Chart"](#) .
4. Does power door lock system operate normally? OK: GO TO 5, NG: GO TO 3.
5. INSPECTION END.

CONSULT-II Function

E/S001G2


Power door lock system check with data monitor and active test can be executed by combining data reception and command transmission via communication line from BCM.

BCM diagnosis part	Inspection item, self-diagnosis mode	Content
Door lock	Data monitor	Displays BCM input data on real-time basis.
	Active test	Sends drive signals to door lock actuator to perform operation check.


POWER DOOR LOCK SYSTEM

CONSULT-II BASIC OPERATION PROCEDURE


1. With ignition switch OFF, connect CONSULT-II to data link connector on vehicle, and turn ON ignition switch.
2. Touch "START".



3. Touch "BCM" on "SELECT SYSTEM" screen.



4. Select item to be diagnosed on "SELECT TEST ITEM" screen.



DATA MONITOR

Monitor item "OPERATION"		Content
KEY ON SW	"ON/OFF"	Indicates [ON/OFF] condition of key switch.
LOCK SW DR/AS	"ON/OFF"	Indicates [ON/OFF] condition of lock signal from lock/unlock switch LH and RH.
UNLK SW DR/AS	"ON/OFF"	Indicates [ON/OFF] condition of unlock signal from lock/unlock switch LH and RH.
KEY CYL LK-SW	"ON/OFF"	Indicates [ON/OFF] condition of lock signal from key cylinder.
KEY CYL UN-SW	"ON/OFF"	Indicates [ON/OFF] condition of unlock signal from key cylinder.
LK BUTTON/SIG	"ON/OFF"	Indicates [ON/OFF] condition of lock signal from key fob.
UN BUTTON/SIG	"ON/OFF"	Indicates [ON/OFF] condition of unlock signal from key fob.
IGN ON SW	"ON/OFF"	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-DR	"ON/OFF"	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	"ON/OFF"	Indicates [ON/OFF] condition of front door switch RH.
DOOR SW-RR	"ON/OFF"	Indicates [ON/OFF] condition of rear door switch RH.
DOOR SW-RL	"ON/OFF"	Indicates [ON/OFF] condition of rear door switch LH.

POWER DOOR LOCK SYSTEM

ACTIVE TEST

Test item	Content
ALL D/LK MTR	This test is able to check all door lock actuators lock operation. These actuators lock when "ON" on CONSULT-II screen is touched.
DR D/UN MTR	This test is able to check front door lock actuator LH unlock operation. These actuators lock when "ON" on CONSULT-II screen is touched.
NON DR D/UN	This test is able to check door lock actuators (except front door lock actuator LH) unlock operation. These actuators unlock when "ON" on CONSULT-II screen is touched.

Trouble Diagnoses Symptom Chart

EIS001G3

Symptom	Repair order	Refer to page
Key reminder door system does not operate properly.	1. Door switch check	BL-29, "Door Switch Check"
	2. Key switch (Insert) check	BL-31, "Key Switch (Insert) Check"
	3. Replace BCM.	BCS-19, "Removal and Installation of BCM"
Power door lock does not operate with door lock and unlock switch on main power window and door lock/unlock switch or front power window switch RH	1. Door lock/unlock switch check	BL-32, "Door Lock/Unlock Switch Check"
Front door lock actuator LH does not operate.	1. Door lock actuator check (Front LH)	BL-34, "Door Lock Actuator Check (Front LH)"
Specific door lock actuator does not operate.	1. Door lock actuator check (Front RH, Rear LH/RH)	BL-35, "Door Lock Actuator Check (Front RH and Rear LH/RH)"
Power door lock does not operate with front door key cylinder LH operation.	1. Front door key cylinder switch LH check	BL-36, "Front Door Key Cylinder Switch LH Check"
	2. Replace BCM.	BCS-19, "Removal and Installation of BCM"
Power door lock does not operate.	1. BCM power supply and ground circuit check	BL-27, "BCM Power Supply and Ground Circuit Check"
	2. Door lock/unlock switch check	BL-32, "Door Lock/Unlock Switch Check"

BCM Power Supply and Ground Circuit Check

EIS001G1

1. CHECK FUSE

- Check the following BCM fuse and fusible link.

Component Parts	Terminal No. (SIGNAL)	Ampere	No.	Location
BCM	21 (BAT power supply)	15A	21	Fuse block (J/B)
BCM	55 (BAT power supply)	50A	f	Fuse and fusible link box

NOTE:

Refer to [BL-17, "Component Parts and Harness Connector Location"](#).

OK or NG

OK >> GO TO 2

NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse, refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).

POWER DOOR LOCK SYSTEM

2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BCM.
3. Check voltage between BCM connector M19 terminals 42, 55 and ground.

Connector	Terminals (Wire color)		Voltage (V) (Approx.)
	(+)	(-)	
M19	42 (Y/R)	Ground	Battery voltage
	55 (W/B)		

OK or NG

OK >> GO TO 3

NG >> Repair or replace harness.



3. CHECK GROUND CIRCUIT


Check continuity between BCM connector M19 terminals 49, 52 and ground.

Connector	Terminals (Wire color)		Continuity
	(+)	(-)	
M19	49 (B)	Ground	YES
	52 (B)		

OK or NG

OK >> Power supply and ground circuit is OK.

NG >> Repair or replace harness.



POWER DOOR LOCK SYSTEM

Door Switch Check

EIS001G4

1. CHECK DOOR SWITCHES INPUT SIGNAL

 With CONSULT-II

Check door switches ("DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RL", "DOOR SW-RR") in DATA MONITOR mode with CONSULT-II. Refer to [BL-26, "DATA MONITOR"](#).

- When any doors are open :

DOOR SW-DR :ON
DOOR SW-AS :ON
DOOR SW-RL :ON
DOOR SW-RR :ON

- When any doors are closed :

DOOR SW-DR :OFF
DOOR SW-AS :OFF
DOOR SW-RL :OFF
DOOR SW-RR :OFF

DATA MONITOR	
MONITOR	
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RL	OFF
DOOR SW-RR	OFF

PIIA6469E


 Without CONSULT-II

Check voltage between BCM connector M18 or M20 terminals 12, 13, 62, 63 and ground.

Connector	Item	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
		(+)	(-)		
M20	Front door switch LH	62 (SB)	Ground	Open ↓ Closed	0 ↓ Battery voltage
	Rear door switch LH	63 (R/B)			
M18	Front door switch RH	12 (BR/W)	Ground	Open ↓ Closed	0 ↓ Battery voltage
	Rear door switch RH	13 (L/R)			

OK or NG

OK >> System is OK.
NG >> GO TO 2



POWER DOOR LOCK SYSTEM


2. CHECK DOOR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door switch and BCM.
3. Check continuity between door switch connector B8 (Front LH) or B108 (Front RH) terminal 2, B18 (Rear LH) or B116 (Rear RH) terminal 1 and BCM connector M18, M20 terminals 12, 13, 62 and 63

2 (SB) - 62 (SB) :Continuity should exist
2 (BR/W) - 12 (BR/W) :Continuity should exist
1 (R/B) - 63 (R/B) :Continuity should exist
1 (L/R) - 13 (L/R) :Continuity should exist

4. Check continuity between door switch connector B8 (Front LH) or B108 (Front RH) terminal 2, B18 (Rear LH) or B116 (Rear RH) terminal 1 and ground.

2 (SB or BR/W) - Ground :Continuity should not exist
1 (R/B or L/R) - Ground :Continuity should not exist



OK or NG

OK >> GO TO 3
 NG >> Repair or replace harness.


3. CHECK DOOR SWITCHES

- Disconnect door switch harness.
- Check continuity between door switch connector terminals.

	Terminals (Wire color)	Condition	Continuity
Front door switch LH/RH	2 – Ground	Open	Yes
		Closed	No
Rear door switch LH/RH	1 – Ground	Open	Yes
		Closed	No

OK or NG

OK >> Check door switch case ground condition.
 NG >> Replace door switch.



POWER DOOR LOCK SYSTEM

Key Switch (Insert) Check


E/S001G5

1. CHECK KEY SWITCH INPUT SIGNAL

 With CONSULT-II

Check key switch "KEY ON SW" in DATA MONITOR mode with CONSULT-II. Refer to [BL-26, "DATA MONITOR"](#).

- When key is inserted to ignition key cylinder :
KEY ON SW :ON
- When key is removed from ignition key cylinder :
KEY ON SW :OFF




 Without CONSULT-II

Check voltage between BCM connector M18 terminal 37 and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V)
	(+)	(-)		
M18	37	Ground	Key is inserted.	Battery voltage
			Key is removed.	0

OK or NG

- OK >> System is OK.
- NG >> GO TO 2




2. CHECK KEY SWITCH (INSERT)

Check continuity between key switch connector terminals.

Terminals	Condition	Continuity
1 - 2	Key is inserted.	Yes
	Key is removed.	No

OK or NG

- OK >> Repair or replace harness.
- NG >> Replace key switch.



POWER DOOR LOCK SYSTEM

EIS001G6

Door Lock/Unlock Switch Check

1. CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

With CONSULT-II

Check door lock/unlock switch ("CDL LOCK SW", "CDL UNLOCK SW") in DATA MONITOR mode in CONSULT-II. Refer to [BL-26, "DATA MONITOR"](#)

- When door lock/unlock switch is turned to LOCK :

CDL LOCK SW :ON

- When door lock/unlock switch is turned to UNLOCK :


CDL UNLOCK SW :ON

DATA MONITOR	
MONITOR	
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF


PIIA6538E

Without CONSULT-II

- Remove key from ignition key cylinder.
- Check the signal between BCM connector M18 terminal 22 and ground with oscilloscope when door lock/unlock switch is turned to LOCK or UNLOCK.
- Make sure the signals which are shown in the figure below can be detected during 10 seconds just after the door lock/unlock switch is turned to LOCK or UNLOCK.

Connector	Terminal (Wire color)		Voltage (V)
	(+)	(-)	
M18	22 (Y)	Ground	

PIIA1297E



OK or NG

- OK >> Door lock and unlock switch circuit is OK.
- NG >> GO TO 2

2. CHECK BCM OUTPUT SIGNAL

Check ("POWER WINDOW DOWN") in ACTIVE TEST mode for "REMOTE KEYLESS ENTRY SYSTEM" with CONSULT-II. Refer to [BL-48, "Active Test"](#).

When "ACTIVE TEST" is performed, are the front windows lowered?

OK or NG

- OK >> GO TO 3
- NG >> Replace BCM.

ACTIVE TEST	
POWER WINDOW DOWN	OFF
ON	


PIIA3080E

POWER DOOR LOCK SYSTEM

3. CHECK DOOR LOCK/UNLOCK SWITCH GROUND HARNESS

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch or front power window switch RH
3. Check continuity between main power window and door lock/unlock switch connector D8 terminal 17 and ground.

17 (B) - Ground : Continuity should exist.




4. Check continuity between front power window switch RH connector D105 terminal 11 and ground

11 (B) - Ground : Continuity should exist.

OK or NG


- OK >> GO TO 4
NG >> Repair or replace harness.



4. CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Disconnect BCM.
2. Check continuity between BCM connector M18 terminal 22 and main power window and door lock/unlock switch connector D7 terminal 14.

22 (Y) - 14 (Y) : Continuity should exist.




3. Check continuity between BCM connector M18 terminal 22 and front power window switch RH connector D105 terminal 16.

22 (Y) - 16 (Y) : Continuity should exist.

OK or NG

- OK >> Replace main power window and door lock/unlock switch or front power window switch RH
NG >> Repair or replace harness.



POWER DOOR LOCK SYSTEM


EIS001G8

Door Lock Actuator Check (Front LH)

1. CHECK DOOR LOCK ACTUATOR SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between BCM connector M19 terminals 44, 50 and ground.

Con- nec- tor	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M19	44 (G)	Ground	Driver door lock/unlock switch is turned to UNLOCK	0 → Battery voltage
	50 (GR)		Driver door lock/unlock switch is turned to LOCK	0 → Battery voltage



OK or NG

- OK >> GO TO 2
NG >> Replace BCM.


2. CHECK DOOR LOCK ACTUATOR HARNESS

1. Disconnect BCM and front door lock actuator LH.
2. Check continuity between BCM connector M19 terminals 44, 50 and front door lock actuator LH connector D51 terminals 2, 3.

Connector	Terminals (Wire color)	Connector	Terminals (wire color)	Continuity
M19	44 (G)	D51	2 (G)	Yes
	50 (GR)		3 (GR)	Yes

3. Check continuity between BCM connector M19 terminals 44, 50 and body ground.

Connector	Terminals (Wire color)	Continuity
M19	44 (G)	No
	50 (GR)	No



OK or NG

- OK >> Replace front door lock assembly LH.
NG >> Repair or replace harness.

POWER DOOR LOCK SYSTEM


Door Lock Actuator Check (Front RH and Rear LH/RH)

E/S001G9

1. CHECK DOOR LOCK ACTUATOR SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between BCM connector M19 terminals 50, 51 and ground.

Con- nec- tor	Terminals Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M19	50 (GR)	Ground	Driver door lock/unlock switch is turned to UNLOCK	0 → Battery voltage
	51 (G/Y)		Driver door lock/unlock switch is turned to LOCK	0 → Battery voltage



OK or NG

- OK >> GO TO 2
NG >> Replace BCM.


2. CHECK DOOR LOCK ACTUATOR HARNESS

1. Disconnect BCM and each door lock actuator .
2. Check continuity between BCM connector M19 terminals 50, 51 and front door lock assembly RH, rear door lock actuator LH/RH connector D151, D205, D305 terminals 2, 3.

Terminal		Continuity
50 (GR)	3 (V)	YES
51 (G/Y)	2 (G/Y)	YES

3. Check continuity between BCM connector M19 terminals 50, 51 and body ground.

Terminals (Wire color)		Continuity
50 (GR)	Ground	NO
51 (G/Y)		NO



OK or NG

- OK >> Replace front door lock actuator RH or rear door lock actuator LH/RH.
NG >> Repair or replace harness.

POWER DOOR LOCK SYSTEM

Front Door Key Cylinder Switch LH Check

EIS001GA

1. CHECK DOOR KEY CYLINDER SWITCH LH

④ With CONSULT-II


Check front door key cylinder switch LH ("KEY CYL LK-SW") and ("KEY CYL UN-SW") in DATA MONITOR mode in CONSULT-II. Refer to [BL-26, "DATA MONITOR"](#).

- When key inserted in front key cylinder is turned to LOCK :

KEY CYL LK-SW : ON

- When key inserted in front key cylinder is turned to UNLOCK :


KEY CYL UN-SW : ON



⊗ Without CONSULT-II

Check voltage between main power window and door lock/unlock switch connector D7 terminals 4 and ground.

Connector	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
D7	4 (R)	Ground	Neutral/Unlock	5
			Lock	0
	6 (L)		Neutral/Lock	5
			Unlock	0



OK or NG

- OK >> Front door key cylinder switch LH signal is OK.
- NG >> GO TO 2


2. CHECK DOOR KEY CYLINDER SWITCH LH

- Turn ignition switch off.
- Disconnect front door key cylinder switch LH.
- Check continuity between door key cylinder switch LH connector terminals 1, 5 and 6.

Terminals	Condition	Continuity
1 - 5	Key is turned to UNLOCK.	Yes
6 - 5	Key is turned to LOCK.	Yes

OK or NG

- OK >> Check the following.
 - Front door key cylinder switch LH ground circuit.
 - Harness for open or short between main power window and door lock/unlock switch and front door key cylinder switch LH.
- NG >> Replace front door key cylinder switch LH.




REMOTE KEYLESS ENTRY SYSTEM

PFP:28596

Component Parts and Harness Connector Location

EIS001GD



LIIA0514E

System Description

INPUTS

Power is supplied at all times

- to BCM terminal 55
- through 50A fusible link (letter **f**, located in the fuse and fusible link box).
- to BCM terminal 42
- through 10A fuse [No. 21, located in the fuse block (J/B)].

When the key switch is ON, power is supplied

- to BCM terminal 37
- through key switch terminals 1 and 2
- through 10A fuse [No. 21, located in the fuse block (J/B)].

When the key switch is ACC or ON, power is supplied

- to BCM terminal 11
- through 10A fuse [No. 6, located in the fuse block (J/B)].

When the key switch is ON or START, power is supplied

- to BCM terminal 38
- through 10A fuse [No. 12, located in the fuse block (J/B)].

When the front door switch LH is ON (door is OPEN), ground is supplied

- to BCM terminal 62
- through front door switch LH terminal 2
- to front door switch LH case ground.

When the front door switch RH is ON (door is OPEN), ground is supplied

- to BCM terminal 12
- through front door switch RH terminal 2
- to front door switch RH case ground.

When the rear door switch LH is ON (door is OPEN), ground is supplied

- to BCM terminal 63
- through rear door switch LH terminal 1
- to rear door switch LH case ground.

When the rear door switch RH is ON (door is OPEN), ground is supplied

- to BCM terminal 13
- through rear door switch RH terminal 1
- to rear door switch RH case ground.

Key fob signal is inputted to BCM (the antenna of the system is combined with BCM).

The remote keyless entry system controls operation of the

- power door lock
- trunk lid opener
- interior lamp and step lamps
- panic alarm
- hazard and horn reminder
- keyless power window down (open)
- auto door lock operation

OPERATED PROCEDURE

Power Door Lock Operation

BCM receives a LOCK signal from key fob. BCM locks all doors with input of LOCK signal from key fob. When an UNLOCK signal is sent from key fob once, driver's door will be unlocked.

Then, if an UNLOCK signal is sent from key fob again within 5 seconds, all other door will be unlocked.

Hazard and Horn Reminder

BCM output to IPDM E/R for horn reminder signal as DATA LINE (CAN H line and CAN L line).

REMOTE KEYLESS ENTRY SYSTEM

The hazard and horn reminder has C mode (horn chirp mode) and S mode (non-horn chirp mode).

Operating function of hazard and horn reminder

	C mode		S mode	
Remote controller operation	Lock	Unlock	Lock	Unlock
Hazard warning lamp flash	Twice	Once	Twice	—
Horn sound	Once	—	—	—


How to change hazard and horn reminder mode

⑧ With CONSULT-II

Hazard and horn reminder can be changed using "WORK SUPPORT" mode in "MULTI ANSWER BACK SET".

⊗ Without CONSULT-II

When LOCK and UNLOCK signals are sent from the key fob for more than 2 seconds at the same time, the hazard and horn reminder mode is changed and hazard warning lamp flashes and horn sounds as follows:



SEL153WA

Interior Lamp Operation

When the following input signals are both supplied:

- door switch CLOSED (when all the doors are closed);
- interior lamp switch is in DOOR position.

Remote keyless entry system turns on interior lamp and ignition illumination (for 30 seconds) with input of UNLOCK signal from key fob.

For detailed description, refer to [LT-151, "ROOM LAMP TIMER OPERATION"](#).

Panic Alarm Operation

When key switch is OFF (when ignition key is not inserted in key cylinder), remote keyless entry system turns on and off horn and headlamp intermittently with input of PANIC ALARM signal from key fob.

The alarm automatically turns off after 25 seconds or when BCM receives any signal from key fob.

For detailed description, refer to [BL-79, "VEHICLE SECURITY \(THEFT WARNING\) SYSTEM"](#).

Trunk Lid Opener Operation

When a TRUNK OPEN signal is sent with key OFF (ignition key removed from key cylinder) from key fob, power is supplied

- through BCM terminal 57
- to trunk lamp switch and trunk release solenoid terminal 1.

When power and ground are supplied, trunk lamp switch and trunk release solenoid opens trunk lid.

Keyless Power Window Down (open) Operation

When key fob unlock switch is turned ON with ignition switch OFF, and the switch is detected to be on continuously for 3 seconds, the driver's door and passenger's door power windows are simultaneously opened.

Power window is operated to open and the operation continues as long as the key fob unlock switch is pressed.

Auto Door Lock Operation

Auto lock function signal is sent when any of the following signals are not sent after the unlock signal is sent from the key fob:

REMOTE KEYLESS ENTRY SYSTEM

- when door switch is turned ON for open.
- when the key switch is turned ON.
- when any signal is sent from the key fob.

Auto door lock mode can be changed using "WORK SUPPORT" mode in "AUTO LOCK SET". Refer to [BL-48, "Work Support"](#) .

CAN Communication System Description


EIS001GF

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped on a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

REMOTE KEYLESS ENTRY SYSTEM

Schematic

EIS001GG






A
B
C
D
E
F
G
H
BL
J
K
L
M

REMOTE KEYLESS ENTRY SYSTEM

Wiring Diagram — KEYLES—
FIG. 1

EIS001GH

BL-KEYLES-01





LIWA0104E

REMOTE KEYLESS ENTRY SYSTEM

FIG. 2



BL-KEYLES-02



REMOTE KEYLESS ENTRY SYSTEM

FIG. 3


BL-KEYLES-03



REMOTE KEYLESS ENTRY SYSTEM

Terminals and Reference Value for BCM

EIS001G1

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)
1	Y/G	Ignition key illumination	Key ring illumination ON	0
			Key ring illumination OFF	Battery voltage
11	V	Ignition switch (ACC)	Ignition switch in ACC	Battery voltage
12	BR/W	Front door switch RH	Door Close (OFF) → Open (ON)	Battery voltage → 0
13	L/R	Rear door switch RH	Door Close (OFF) → Open (ON)	Battery voltage → 0
22	Y	Anti-pinch serial link	—	
37	B/R	Key switch	Key inserted in IGN key cylinder → Key removed from IGN key cylinder	Battery voltage → 0
38	G/R	Ignition switch (ON)	Ignition switch ON	Battery voltage
39	L	CAN H	—	—
40	Y	CAN L	—	—
41	R/G	Battery saver (Interior lamp)	Battery saver does operated → Does not operated (ON → OFF)	Battery voltage → 0
42	Y/R	Power source (BAT)	—	Battery voltage
44	G	Driver door lock actuator	Door lock & unlock switch (Neutral → Unlock)	0 → Battery voltage
45	G/B	Turn signal LH	When doors are locked or unlocked using key fob (OFF → ON) *2	0 → Battery voltage
46	G/Y	Turn signal RH	When doors are locked or unlocked using key fob (OFF → ON) *2	0 → Battery voltage
47	R/W	Step lamp LH and RH	Step lamp ON	0
			Step lamp OFF	Battery voltage
48	R	Room lamp	Room lamp ON *1	Battery voltage
			Room Lamp OFF *1	0
49	B	Ground	—	0
50	G/R	Door lock actuators	Door lock & unlock switch (Neutral → Lock)	0 → Battery voltage
51	G/Y	Passenger and rear doors lock actuator	Door lock & unlock switch (Neutral → Unlock)	0 → Battery voltage
52	B	Ground	—	0
54	W/R	Power window power source	—	Battery voltage
55	W/B	Power source (BAT)	—	Battery voltage
57	V/W	Trunk switch	Trunk Close (OFF) → Open (ON)	Battery voltage → 0
62	SB	Front door switch LH	Door Close (OFF) → Open (ON)	Battery voltage → 0
63	R/B	Rear door switch LH	Door Close (OFF) → Open (ON)	Battery voltage → 0

● *1: when room lamp switch is in "DOOR" position.

● *2: when hazard reminder is ON.

REMOTE KEYLESS ENTRY SYSTEM

Terminals and Reference Value for IPDM E/R

E/S001PA

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)
38	B	Ground	—	0
48	L	CAN H	—	—
49	Y	CAN L	—	—
51	G/W	Horn relay	When doors locks are operated using key fob (OFF → ON) *	Battery voltage → 0
60	B	Ground	—	0

*: when horn reminder is ON.

CONSULT-II Function

E/S001GJ

- The following functions are executed by combining data received and command transmitted via the communication line from the BCM.

BCM diagnosis position	Inspection items and diagnosis mode		Description
BCM C/U*	Self-diagnosis results		Carries out the self-diagnosis.
	Data monitor	CAN diagnosis support monitor	Displays CAN communication system diagnosis, disabled transmission status, and communication status of each unit communicated with BCM.
		Selection from menu	Displays the input data to BCM on real-time basis.
MULTI REMOTE ENT	Data monitor		Displays the input remote keyless entry system data to BCM on real-time basis.
	Active test		Gives a drive to a load to check the operation.
	Work support		Changes the setting for each function.

*:Refer to [BCS-13, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#) .


CONSULT-II Inspection Procedure “MULTI REMOTE ENT”

E/S001GK

CAUTION:


If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

- Turn ignition switch OFF.
- Connect “CONSULT-II” to the data link connector.




REMOTE KEYLESS ENTRY SYSTEM


3. Turn ignition switch ON.
4. Touch "START".




5. Touch "BCM".
If "BCM" is not indicated, refer to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



6. Touch "MULTI REMOTE ENT".



7. Select diagnosis mode.
"DATA MONITOR", "ACTIVE TEST" and "WORK SUPPORT" are available.



CONSULT-II Application Items "MULTI REMOTE CONT SYS"

Data Monitor

Monitored Item	Description
DOOR SW-AS	Indicates [ON/OFF] condition of door switch RH.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.

REMOTE KEYLESS ENTRY SYSTEM

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch in ON position.
PANIC BTN	Indicates [ON/OFF] condition of panic signal from key fob.
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from key fob.
LK BUTTON/SIG	Indicates [ON/OFF] condition of lock signal from key fob.
KEY CYL LK-SW	Indicates [ON/OFF] condition of lock signal from door key cylinder switch.
KEY CYL UN-SW	Indicates [ON/OFF] condition of unlock signal from door key cylinder switch.
UNLK SW DR/AS	Indicates [ON/OFF] condition of unlock signal from lock/unlock switch.
LOCK SW DR/AS	Indicates [ON/OFF] condition of lock signal from lock/unlock switch.
DOOR SW-RL	Indicates [ON/OFF] condition of rear door switch LH.
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch RH.
LK/UN BTN ON	Indicates [ON/OFF] condition of lock/unlock signal at the same time from key fob.
TRUNK BTN/SIG	Indicates [ON/OFF] condition of trunk open signal from key fob.
UN BUTTON ON	Indicates [ON/OFF] condition of unlock signal from key fob.

Active Test

Test Item	Description
INT ILLUM	This test is able to check interior lamp illumination operation. The interior lamp illumination is turned on when "ON" on CONSULT-II screen is touched.
IGN ILLUM	This test is able to check ignition illumination operation. The ignition illumination is turned on when "ON" on CONSULT-II screen is touched.
FLASHER RIGHT(CAN)	This test is able to check right hazard reminder operation. The right hazard lamp turns on when "ON" on CONSULT-II screen is touched.
FLASHER LEFT(CAN)	This test is able to check left hazard reminder operation. The left hazard lamp turns on when "ON" on CONSULT-II screen is touched.
HORN	This test is able to check panic alarm and horn reminder operations. The alarm activate for 0.5 seconds after "ON" on CONSULT-II screen is touched.
HEAD LAMP (HI)	This test is able to check headlamps panic alarm operation. The headlamp illuminates for 0.5 seconds after "ON" on CONSULT-II screen is touched.
TRUNK/BACK DOOR	This test is able to check trunk lid opener actuator operation. The trunk is unlocked when "ON" on CONSULT-II screen is touched.

Work Support

Test Item	Description
REMO CONT ID CONFIR	It can be checked whether key fob ID code is registered or not in this mode.
REMO CONT ID REGIST	Key fob ID code can be registered.
REMO CONT ID ERASUR	Key fob ID code can be erased.
MULTI ANSWER BACK SET	Hazard and horn reminder mode can be changed in this mode. The reminder mode will be changed when "CHANG SETT" on CONSULT-II screen is touched.
AUTO LOCK SET	Auto locking function mode can be changed in this mode. The function mode will be changed when "CHANG SETT" on CONSULT-II screen is touched.
PANIC ALRM SET	Panic alarm operation mode can be changed in this mode. The operation mode will be changed when "CHANG SETT" on CONSULT-II screen is touched.
TRUNK OPEN SET	Trunk lid opener operation mode can be changed in this mode. The operation mode will be changed when "CHANG SETT" on CONSULT-II screen is touched.
PW DOWN SET	Keyless power window down (open) operation mode can be changed in this mode. The operation mode will be changed when "CHANG SETT" on CONSULT-II screen is touched.

REMOTE KEYLESS ENTRY SYSTEM

Hazard and horn reminder mode

	MODE 1 (C mode)		MODE 2 (S mode)		MODE 3		MODE 4		MODE 5		MODE 6	
Key fob operation	Lock	Unlock	Lock	Unlock	Lock	Unlock	Lock	Unlock	Lock	Unlock	Lock	Unlock
Hazard warning lamp flash	Twice	Once	Twice	—	—	—	Twice	Once	Twice	—	—	Once
Horn sound	Once	—	—	—	—	—	—	—	Once	—	Once	—

Auto locking function mode

	MODE 1	MODE 2	MODE 3
Auto locking function	5 minutes	Nothing	1 minute

Panic alarm operation mode

	MODE 1	MODE 2	MODE 3
Key fob operation	0.5 seconds	Nothing	1.5 seconds

Trunk lid open operation mode

	MODE 1	MODE 2	MODE 3
Key fob operation	0.5 seconds	Nothing	1.5 seconds

Keyless power window down operation mode

	MODE 1	MODE 2	MODE 3
Key fob operation	3 seconds	Nothing	5 seconds

Trouble Diagnosis Procedure

EIS001GM

1. Check the trouble symptom and customer's requests.
2. Understand outline of system. Refer to [BL-38, "System Description"](#).
3. Confirm that power door lock system operates normally. Refer to [BL-17, "POWER DOOR LOCK SYSTEM"](#).
4. Perform pre-diagnosis inspection. Refer to [BL-49, "Pre-Diagnosis Inspection"](#).
5. Refer to trouble diagnosis chart by symptom, repair or replace any malfunctioning parts. Refer to [BL-50, "Trouble Diagnoses"](#).
6. **Inspection End.**

Pre-Diagnosis Inspection

EIS001GN

BCM POWER SUPPLY AND GROUND CIRCUIT INSPECTION

1. FUSE INSPECTION

- Check the following fuses and fusible link in the fuse block (J/B) and fuse and fusible link box.

Unit	Terminal No.	Signal name	No.	Location
BCM	55	Battery power supply	f	Fuse and fusible link box
	11	ACC power supply	6	Fuse block (J/B)
	38	IGN power supply	12	Fuse block (J/B)

OK or NG

- OK >> GO TO 2
 NG >> Replace the fuse or fusible link.

REMOTE KEYLESS ENTRY SYSTEM

2. POWER SUPPLY CIRCUIT INSPECTION

Disconnect BCM connector, and connect vehicle-side connector terminals shown below to positive probe and body ground to negative probe. Measure voltage.

Unit	Terminal No.	Signal name	Ignition switch	Voltage
BCM	55	Battery power supply	OFF	Battery voltage
	11	ACC power supply	ACC	Battery voltage
	38	IGN power supply	ON	Battery voltage

OK or NG

OK >> GO TO 3

NG >> Repair or replace harness.

3. GROUND CIRCUIT INSPECTION

Check continuity between BCM vehicle-side connector and body ground.

Unit	Terminal No.	Signal name	Ignition switch	Continuity
BCM	49, 52	Ground	OFF	Yes

OK or NG

OK >> Power supply and ground circuits are normal.

NG >> Repair or replace harness.

Trouble Diagnoses

SYMPTOM CHART

E/S001GO

NOTE:

- Always check the "Trouble Diagnosis Procedure" before troubleshooting. Refer to [BL-49, "Trouble Diagnosis Procedure"](#).
- Always check key fob battery before replacing key fob. Refer to [BL-52, "Key Fob Battery and Function Check"](#).
- The panic alarm operation and trunk lid opener operation of remote keyless entry system do not activate with the ignition key inserted in the ignition key cylinder.
- Use Remote Keyless Entry Tester J-43241 (follow instructions on tester) to check operation of key fob before replacing key fob.

Symptom	Diagnoses/service procedure	Reference page
All function of remote keyless entry system do not operate.	1. Key fob battery and function check (use Remote Keyless Entry Tester J-43241)	BL-52
	2. Replace key fob (use Remote Keyless Entry Tester J-43241). Refer to ID Code Entry Procedure. NOTE: If the result of key fob function check with CONSULT-II is OK, Key fob is not malfunctioning.	BL-61
	3. Replace BCM.	BCS-19
The new ID of key fob cannot be entered.	1. Key fob battery and function check (use Remote Keyless Entry Tester J-43241)	BL-52
	2. Key switch (insert) check	BL-58
	3. Door switch check	BL-56
	4. ACC power check	BL-54
	5. Replace key fob (use Remote Keyless Entry Tester J-43241). Refer to ID Code Entry Procedure. NOTE: If the result of key fob function check with CONSULT-II is OK, Key fob is not malfunctioning.	BL-61
	6. Replace BCM.	BCS-19

REMOTE KEYLESS ENTRY SYSTEM

Symptom	Diagnoses/service procedure	Reference page	
Door lock or unlock does not function. (If the power door lock system does not operate manually, check power door lock system. Refer to BL-17, "POWER DOOR LOCK SYSTEM")	1. Key fob battery and function check (use Remote Keyless Entry Tester J-43241)	BL-52	A
	2. Replace key fob (use Remote Keyless Entry Tester J-43241). Refer to ID Code Entry Procedure . NOTE: If the result of key fob function check with CONSULT-II is OK, Key fob is not malfunctioning.	BL-61	B
	3. Replace BCM.	BCS-19	C
Hazard and horn reminder does not activate properly when pressing lock or unlock button of key fob.	1. Check hazard and horn reminder mode NOTE: Hazard and horn reminder mode can be changed. First check the hazard and horn reminder mode setting.	BL-48	D
	2. Door switch check	BL-56	E
	3. Trunk switch check	BL-58	F
	4. Replace BCM.	BCS-19	F
Hazard reminder does not activate properlywhen-pressing lock or unlock button of key fob. (Horn reminder OK)	1. Check hazard reminder mode NOTE: Hazard reminder mode can be changed. First check the hazard reminder mode setting.	BL-48	G
	2. Check hazard function with hazard switch	—	H
	3. Replace BCM.	BCS-19	H
Horn reminder does not activate properlywhen-pressing lock or unlock button of key fob. (Hazard reminder OK)	1. Check horn reminder mode NOTE: Horn reminder mode can be changed. First check the horn reminder mode setting.	BL-48	BL
	2. Check horn function with horn switch	—	J
	3. IPDM E/R operation check	BL-54	J
	4. Replace BCM.	BCS-19	K
Room lamp, ignition key illumination and step lamp operation do not activate properly.	1. Room lamp operation check	BL-60	K
	2. Ignition key illumination operation check	BL-60	L
	3. Step lamp operation check	LT-150	L
	4. Door switch check	BL-56	L
	5. Replace BCM.	BCS-19	M
Panic alarm (horn and headlamp) does not activate when panic alarm button is continuously pressed.	1. Key fob battery and function check (use Remote Keyless Entry Tester J-43241)	BL-52	M
	2. Vehicle security operation check. Refer to Vehicle security system.	BL-79	
	3. Key switch (insert) check	BL-58	
	4. Replace key fob (use Remote Keyless Entry Tester J-43241). Refer to ID Code Entry Procedure. NOTE: If the result of key fob function check with CONSULT-II is OK, Key fob is not malfunctioning.	BL-61	
	5. Replace BCM.	BCS-19	

REMOTE KEYLESS ENTRY SYSTEM

Symptom	Diagnoses/service procedure	Reference page
Trunk lid does not open when trunk opener button is continuously pressed.	1. Check trunk open operation mode NOTE: Trunk open operation mode can be changed. First check the trunk open operation mode setting.	BL-48, "Active Test"
	2. Key fob battery and function check (use Remote Keyless Entry Tester J-43241)	BL-52
	3. Trunk release solenoid check	BL-58
	4. Key switch (insert) check	BL-58
	5. Replace BCM.	BCS-19, "Removal and Installation of BCM"
Auto door lock operation does not activate properly. (All other remote keyless entry functions OK.)	1. Check auto door lock operation mode NOTE: Auto door lock operation mode can be changed. First check the auto door lock operation mode setting.	BL-48, "Work Support"
	2. Replace BCM.	BCS-19, "Removal and Installation of BCM"
Keyless power window down (open) operation does not activate properly. (All other remote keyless entry functions OK.)	1. Check power window down operation mode NOTE: Power window down operation mode can be changed. First check the power window down operation mode setting.	BL-48, "Work Support"
	2. Check power window function with switch	—
	3. Replace BCM.	BCS-19, "Removal and Installation of BCM"

Key Fob Battery and Function Check

EIS001GP

1. CHECK KEY FOB BATTERY

Remove battery and measure voltage across battery positive and negative terminals, (+) and (-).

Voltage : 2.5V - 3.0V


NOTE:

Key fob does not function if battery is not set correctly.

OK or NG

OK >> GO TO 2

NG >> Replace battery.



SEL237W

REMOTE KEYLESS ENTRY SYSTEM

2. CHECK KEY FOB FUNCTION



With CONSULT-II

Check key fob function in "DATA MONITOR" mode with CONSULT-II.
When pushing each button of key fob, the corresponding monitor item should be turned as follows.

Condition	Monitor item	
Pushing LOCK	KEYLESS LOCK	: ON
Pushing UNLOCK	KEYLESS UNLOCK	: ON
Keep pushing UNLOCK	RKE KEEP UNLK	: ON
	UN BUTTON ON turns to ON 3 seconds after UNLOCK button is pushed.	
Pushing TRUNK	KEYLESS TRUNK	: ON
Pushing PANIC	KEYLESS PANIC	: ON
Pushing LOCK and UNLOCK at the same time	RKE LCK-UNLCK	: ON

DATA MONITOR	
MONITOR	
KEYLESS LOCK	OFF
KEYLESS UNLOCK	OFF
RKE KEEP UNLK	OFF
RKE LCK-UNLOCK	OFF
KEYLESS PANIC	OFF

PIIA6468E

OK or NG

- OK >> Key fob is OK. Further inspection is necessary. Refer to [BL-50, "SYMPTOM CHART"](#) .
NG >> Replace key fob.

REMOTE KEYLESS ENTRY SYSTEM

ACC Power Check


EIS001PB

1. CHECK ACC POWER

With CONSULT-II

Check key switch "KEY ON SW" in DATA MONITOR mode with CONSULT-II. Refer to [BL-26, "DATA MONITOR"](#).


Monitor Item	Condition	
ACC ON SW	Ignition switch position is ACC	: ON
	Ignition switch position is OFF	: OFF



Without CONSULT-II

Check voltage between BCM connector M18 terminal 11 and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M18	11 (B/R)	Ground	ACC	Battery voltage
			OFF	0



OK or NG

OK >> ACC power circuit is OK.

NG >> Check the following.

- 10A fuse [No. 6, located in fuse block (J/B)]
- Harness for open or short.

IPDM E/R Operation Check

EIS001PC

1. CHECK IPDM E/R INPUT VOLTAGE


Check voltage between IPDM E/R connector E121 terminal 51 and ground.

Connector	Terminal (Wire color)		Voltage (V) (Approx.)
	(+)	(-)	
E121	51 (G/W)	Ground	Battery voltage

OK or NG

OK >> Replace IPDM E/R.

NG >> GO TO 2



REMOTE KEYLESS ENTRY SYSTEM


2. CHECK IPDM E/R INPUT VOLTAGE

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R and horn relay.
3. Check continuity between IPDM E/R connector E121 terminal 51 and horn relay connector H-1 terminal 1.

51 (G/W) - 1 (G/W) :Continuity should exist

OK or NG

- OK >> Further inspection is necessary. Refer to [BL-50, "SYMP-TOM CHART"](#).
- NG >> Repair or replace harness



REMOTE KEYLESS ENTRY SYSTEM

EIS001GQ

Door Switch Check

1. CHECK DOOR SWITCH INPUT SIGNAL

With CONSULT-II

Check door switches ("DOOR SW-RL", "DOOR SW-RR", "DOOR SW-DR" and "DOOR SW-AS") in "DATA MONITOR" mode with CONSULT-II.

Monitor item	Condition	
DOOR SW-RL	OPEN	: ON
	CLOSE	: OFF
DOOR SW-RR	OPEN	: ON
	CLOSE	: OFF
DOOR SW-DR	OPEN	: ON
	CLOSE	: OFF
DOOR SW-AS	OPEN	: ON
	CLOSE	: OFF


DATA MONITOR	
MONITOR	
KEYLESS LOCK	OFF
KEYLESS UNLOCK	OFF
RKE KEEP UNLK	OFF
RKE LCK-UNLOCK	OFF
KEYLESS PANIC	OFF

PIIA6468E

Without CONSULT-II

Check voltage between BCM harness connector terminals 12, 13, 62 and 63 and ground.

	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
Front door switch RH	12 (BR/W)	Ground	OPEN	0
			CLOSE	Battery voltage
Rear door switch RH	13 (L/R)	Ground	OPEN	0V
			CLOSE	Battery voltage
Front door switch LH	62 (SB)	Ground	OPEN	0V
			CLOSE	Battery voltage
Rear door switch LH	63 (R/B)	Ground	OPEN	0V
			CLOSE	Battery voltage



PIIA6376E

OK or NG

- OK >> Door switch circuit is OK.
- NG >> GO TO 2

REMOTE KEYLESS ENTRY SYSTEM


2. CHECK DOOR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door switch and BCM.
3. Check continuity between door switch connector B8 (front LH) or B108 (front RH) terminal 2, B18 (rear LH) or B116 (rear RH) terminal 1 and BCM connector M18, M20 terminals 12, 13, 62 and 63

2 (SB) - 62 (SB) :Continuity should exist
2 (BR/W) - 12 (BR/W) :Continuity should exist
1 (R/B) - 63 (R/B) :Continuity should exist
1 (L/R) - 13 (L/R) :Continuity should exist

4. Check continuity between door switch connector B8 (front LH) or B108 (front RH) terminal 2, B18 (rear LH) or B116 (rear RH) terminal 1 and ground.

2 (SB or BR/W) - Ground :Continuity should not exist
1 (R/B or L/R) - Ground :Continuity should not exist



OK or NG

OK >> GO TO 3
 NG >> Repair or replace harness.


3. CHECK DOOR SWITCHES

Check continuity between door switch connector terminals 1, 2 and ground part of door switch.

	Terminals	Condition	Continuity
Front door switch LH/RH	2 – Ground part of door switch	Released	Yes
		Pushed	No
Rear door switch LH/RH	1 – Ground part of door switch	Released	Yes
		Pushed	No

OK or NG

OK >> Check door switch case ground condition.
 NG >> Replace door switch.



REMOTE KEYLESS ENTRY SYSTEM

EIS001GR


Key Switch Check

1. CHECK KEY SWITCH INPUT SIGNAL

With CONSULT-II

Check key switch "KEY ON SW" in DATA MONITOR mode with CONSULT-II. Refer to [BL-26, "DATA MONITOR"](#).

- When key is inserted to ignition key cylinder :
KEY ON SW :ON
- When key is removed from ignition key cylinder :
KEY ON SW :OFF




Without CONSULT-II

Check voltage between BCM connector M18 terminal 37 and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M18	37 (B/R)	Ground	Key is inserted.	Battery voltage
			Key is removed.	0

OK or NG

- OK >> Key switch circuit is OK.
- NG >> GO TO 2




2. CHECK KEY SWITCH

Check continuity between key switch terminals.

Terminals	Condition	Continuity
1 - 2	Key is inserted.	Yes
	Key is removed.	No

OK or NG ?

- OK >> Repair or replace harness.
- NG >> Replace key switch.



Trunk Lamp Switch and Trunk Release Solenoid Check

EIS001GS

1. CHECK TRUNK LID OPENER

Check trunk release operation with trunk lid opener switch.

NOTE:

First check trunk lid opener cancel switch position. Refer to [BL-75, "TRUNK LID AND FUEL FILLER LID OPENER"](#).

Does trunk lid open?

- Yes >> Trunk lamp switch and trunk release solenoid circuit is OK.
- No >> GO TO 2

REMOTE KEYLESS ENTRY SYSTEM

2. CHECK TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID OPERATION

With CONSULT-II

1. Select "ACTIVE TEST" in "MULTI REMOTE ENT" with CONSULT-II.
2. Select "TRUNK/BACK DOOR" and touch "ON".


Trunk release solenoid should operate.

NOTE:

If CONSULT-II is not available, GO TO 3.

OK or NG

- OK >> Trunk lamp switch and trunk release solenoid circuit is OK.
- NG >> Repair or replace harness.



3. CHECK TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID CIRCUIT

Without CONSULT-II

1. Disconnect trunk lamp switch and trunk release solenoid.
2. Check voltage between trunk lamp switch and trunk release solenoid harness connector T103 terminal 3 and ground.


3 (R) - Ground : Battery voltage should exist.

3. Check continuity between trunk lamp switch and trunk release solenoid harness connector T103 terminal 4 and ground.

4 (B) - Ground : Continuity should exist.

OK or NG

- OK >> Replace trunk lamp switch and trunk release solenoid.
- NG >> Repair or replace harness.



REMOTE KEYLESS ENTRY SYSTEM

Check Hazard Function

EIS001GT

1. CHECK HAZARD WARNING LAMP

Does hazard indicator flash with hazard switch?

Yes or No

Yes >> Hazard warning lamp circuit is OK.

No >> Check "hazard indicator" Refer to [LT-90, "TURN SIGNAL AND HAZARD WARNING LAMPS"](#) .

Check Horn Function

EIS001GU

First, perform the "SELF-DIAG RESULTS" in "BCM" with CONSULT-II, then perform the trouble diagnosis of malfunction system indicated in "SELF-DIAG RESULTS" of "BCM".

1. CHECK HORN FUNCTION

Does horn sound with horn switch?

Yes or No

Yes >> Horn circuit is OK.

No >> Check horn circuit. Refer to [WW-35, "HORN"](#) .

Check Headlamp Function

EIS001GV

First, perform the "SELF-DIAG RESULTS" in "BCM" with CONSULT-II, then perform the trouble diagnosis of malfunction system indicated in "SELF-DIAG RESULTS" of "BCM".

1. CHECK HEADLAMP OPERATION

Does headlamp come on when turning lighting switch ON?

Yes or No

Yes >> Headlamp operation circuit is OK.

No >> Check headlamp circuit. Refer to [LT-6, "HEADLAMP \(FOR USA\)"](#) .

Check Map Lamp and Ignition Key Illumination Function

EIS001GW

1. CHECK MAP LAMP AND IGNITION KEY ILLUMINATION FUNCTION

When map lamp switch is in DOOR position, open the front door LH or RH.

Map lamp and ignition key illumination should illuminate.

OK or NG

OK >> System is OK.

NG >> Check ignition illumination circuit. Refer to [LT-174, "ILLUMINATION"](#) .

REMOTE KEYLESS ENTRY SYSTEM

ID Code Entry Procedure

EIS001GY

KEY FOB ID SET UP WITH CONSULT-II


NOTE:

- If a key fob is lost, the ID code of the lost key fob must be erased to prevent unauthorized use. A specific ID code can be erased with CONSULT-II. However, when the ID code of a lost key fob is not known, all controller ID codes should be erased. After all ID codes are erased, the ID codes of all remaining and/or new key fobs must be re-registered.
- When registering an additional key fob, the existing ID codes in memory may or may not be erased. If five ID codes are stored in memory when an additional code is registered, only the oldest code is erased. If less than five codes are stored in memory when an additional code is registered, the new ID code is added and no ID codes are erased.
- Entry of a maximum of five ID codes is allowed. When more than five codes are entered, the oldest ID code will be erased.
- Even if the same ID code that is already in memory is input, the same ID code can be entered. The code is counted as an additional code.


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. Turn ignition switch OFF.
2. Connect "CONSULT-II" to the data link connector.



3. Turn ignition switch ON.
4. Touch "START (NISSAN BASED VHCL)".



5. Touch "BCM".
If "BCM" is not indicated, refer to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



REMOTE KEYLESS ENTRY SYSTEM

6. Touch "MULTI REMOTE ENT".

SELECT TEST ITEM
MULTI REMOTE ENT
HEAD LAMP
COMB SW
WIPER
BCM C/U
FLASHER

LIIA0194E

7. Touch "WORK SUPPORT".

SELECT DIAG MODE
DATA MONITOR
ACTIVE TEST
WORK SUPPORT

SEL274W

8. The items are shown on the figure at left can be set up.

- "REMO CONT ID CONFIR"
Use this mode to confirm if a key fob ID code is registered or not.
- "REMO CONT ID REGIST"
Use this mode to register a key fob ID code.

NOTE:

Register the ID code when key fob or BCM is replaced, or when additional key fob is required.


- "REMO CONT ID ERASUR"
Use this mode to erase a key fob ID code.

SELECT WORK ITEM
REMO CONT ID CONFIR
REMO CONT ID ERASUR
MULTI ANSWER BACK SET
AUTO LOCK SET
PANIC ALARM SET
TRUNK OPEN SET

LIIA0207E

REMOTE KEYLESS ENTRY SYSTEM

KEY FOB ID SET UP WITHOUT CONSULT-II



REMOTE KEYLESS ENTRY SYSTEM

NOTE:


- If a key fob is lost, the ID code of the lost key fob must be erased to prevent unauthorized use. A specific ID code can be erased with CONSULT-II. However, when the ID code of a lost key fob is not known, all controller ID codes should be erased. After all ID codes are erased, the ID codes of all remaining and/or new key fobs must be re-registered.
To erase all ID codes in memory, register one ID code (key fob) five times. After all ID codes are erased, the ID codes of all remaining and/or new key fobs must be re-registered.
- When registering an additional key fob, the existing ID codes in memory may or may not be erased. If five ID codes are stored in memory, when an additional code is registered, only the oldest code is erased. If less than five ID codes are stored in memory, when an additional ID code is registered, the new ID code is added and no ID codes are erased.
- If you need to activate more than two additional new key fobs, repeat the procedure "Additional ID code entry" for each new key fob.
- Entry of maximum five ID codes is allowed. When more than five ID codes are entered, the oldest ID code will be erased.
- Even if same ID code that is already in the memory is input, the same ID code can be entered. The code is counted as an additional code.

Key Fob Battery Replacement

EIS001GZ

NOTE:


- Be careful not to touch the circuit board or battery terminal.
 - The key fob is water-resistant. However, if it does get wet, immediately wipe it dry.
1. Open the lid using a coin.
 2. Remove the battery.
 3. Install the new battery, positive side down.
 4. Close the lid securely. Push the key fob buttons two or three times to check operation.



LJIA0203E

DOOR

Fitting Adjustment



LIIA0422E

FRONT DOOR

Longitudinal clearance and surface height adjustment at front end

1. Remove the fender. Refer to.
2. Loosen the hinge mounting bolts. Raise the front door at rear end to adjust.


REAR DOOR

Longitudinal clearance and surface height adjustment at front end

1. Remove the center pillar upper garnish and center pillar lower garnish. Refer to [EI-32, "Removal and Installation"](#).
2. Accessing from inside the vehicle, loosen the mounting nuts. Open the rear door, and raise the rear door at rear end to adjust.

STRIKER ADJUSTMENT

1. Adjust the striker so that it becomes parallel with the lock insertion direction.



LIIA0113E


DOOR

E/S001H1


Removal and Installation

CAUTION:

- When removing and installing the door assembly, support the door with a jack and shop cloth to protect the door and body.
 - When removing and installing door assembly, be sure to carry out the fitting adjustment.
 - Check the hinge rotating part for poor lubrication. If necessary, apply "body grease".
1. Remove the door finisher. Refer to [EI-30, "DOOR FINISHER"](#) .
 2. Remove the inner seal.
 3. Remove the door window and module assembly. Refer to [GW-87, "Removal and Installation"](#) .
 4. Remove the door harness.
 5. Remove the check link cover.
 6. Remove the mounting bolts of the check link on the vehicle.




7. Remove the door-side hinge mounting nuts and bolts, and remove the door assembly.
- Install in the reverse order of removal.



DOOR

Door Weatherstrip

E/S001H2



A

B

C

D

E

F

G

H

BL

J

K

L

M


FRONT DOOR LOCK

FRONT DOOR LOCK

PFP:80502

Component Structure

EIS001NK




- | | | |
|--|---------------------------|---|
| 1. Front gasket | 2. Outside handle | 3. Door key cylinder assembly (Driver side)
Outside handle escutcheon (Passenger side) |
| 4. Rear gasket | 5. Outside handle bracket | 6. Grommet |
| 7. Key cylinder rod (Driver side only) | 8. Outside handle cable | 9. Door lock assembly |
| 10. Inside handle cable | 11. Lock knob cable | 12. Inside handle |

Removal and Installation

EIS001NL

REMOVAL

1. Remove the front door finisher. Refer to [EI-30, "Removal and Installation"](#)
2. Disconnect the inside handle cable and lock knob cable from the back side of the front door finisher.




3. Remove the front door window and front door module assembly. Refer to [GW-87, "Removal and Installation"](#).
4. Remove door side grommet, and remove door key cylinder assembly (driver side) and outside handle escutcheon (passenger side) bolts (TORX T30) from grommet hole.


FRONT DOOR LOCK

CAUTION:


Do not forcibly remove the TORX bolts (T30).




5. Reach to separate the key cylinder rod and outside handle rod connection (on the handle). If no door key cylinder is found, GO TO 6.
6. While pulling the outside handle, remove door key cylinder assembly.



7. While pulling outside handle, slide toward rear of vehicle to remove outside handle.




8. Remove the front gasket and rear gasket.




FRONT DOOR LOCK


9. Remove the TORX bolts (T30), remove the door lock assembly.




10. Remove the TORX bolt (T30) of the outside handle bracket.



11. While pulling outside handle bracket, slide toward rear of vehicle to remove outside handle bracket and door lock assembly.



12. Disconnect the door lock actuator connector.
13. Reach to separate the key cylinder rod and outside handle rod connection.



INSTALLATION

Install in the reverse order of removal.


CAUTION:

To install each rod, be sure to rotate the rod holder until a click is felt.

FRONT DOOR LOCK

Disassembly and Assembly DOOR KEY CYLINDER ASSEMBLY

EIS001NM



Remove the key cylinder escutcheon pawl and remove the door key cylinder.

A

B

C

D

E

F

G

H

BL

J

K

L

M


REAR DOOR LOCK

REAR DOOR LOCK

PFP:82502

Component Structure

EIS001NN




- | | | |
|-------------------------|---------------------------|------------------------------|
| 1. Front gasket | 2. Outside handle | 3. Outside handle escutcheon |
| 4. Rear gasket | 5. Outside handle bracket | 6. Grommet |
| 7. Outside handle cable | 8. Door lock assembly | 9. Inside handle cable |
| 10. Lock knob cable | 11. Inside handle | |

Removal and Installation

EIS001NO

REMOVAL

1. Remove the rear door finisher. Refer to [EI-30, "Removal and Installation"](#).
2. Disconnect the inside handle cable and lock knob cable from the back side of the front door finisher.




3. Remove the rear door window and rear door module assembly. Refer to [GW-90, "Removal and Installation"](#).
4. Remove door side grommet, and remove outside handle escutcheon bolt (TORX T30) from grommet hole.


REAR DOOR LOCK

CAUTION:


Do not forcibly remove the TORX bolts (T30).




5. While pulling the outside handle, remove outside handle escutcheon.



6. While pulling outside handle, slide toward rear of vehicle to remove outside handle.




7. Remove the front gasket and rear gasket.




REAR DOOR LOCK


8. Remove the TORX bolts (T30), remove the door lock assembly.



9. Remove the TORX bolt (T30), and remove the outside handle bracket.




10. While pulling outside handle, slide toward rear of vehicle to remove outside handle and door lock assembly.



11. Disconnect the door lock actuator connector.

12. Reach to separate outside handle rod connection.



INSTALLATION

Install in the reverse order of removal.

CAUTION:

To install each rod, be sure to rotate the rod holder until a click is felt.

TRUNK LID AND FUEL FILLER LID OPENER





TRUNK LID AND FUEL FILLER LID OPENER

PFP:84640

Wiring Diagram -TLID-

EIS00106

BL-TLID-01



LIWA0107E

TRUNK LID AND FUEL FILLER LID OPENER


Terminals and Reference Value for BCM

EIS00107

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)
55	W/B	BAT power supply	—	Battery voltage
68	R	Trunk lid opener release solenoid	When trunk lid opener release solenoid is operated using key fob (ON → OFF)	0 → Battery voltage
30	L	Trunk lid opener switch	OFF → ON	Battery voltage → 0

Fitting Adjustment

EIS00108



LIA0426E

LONGITUDINAL AND LATERAL CLEARANCE ADJUSTMENT

1. With the striker released, loosen the trunk lid hinge mounting bolts to close the trunk lid.
2. Make the lateral clearance and the clearance to the rear window glass equal, and open the trunk lid to tighten the mounting bolts to the specified torque.


SURFACE HEIGHT ADJUSTMENT

1. Loosen the striker mounting bolts. Raise the striker to the top position, and temporarily tighten the upper mounting bolt at the position.
2. Close the trunk lid lightly and adjust the surface height, then open the trunk lid to finally tighten the striker mounting bolts to the specified torque.

TRUNK LID AND FUEL FILLER LID OPENER

Removal and Installation of Trunk Lid Assembly

EIS00109



1. Remove the trunk lid finisher. Refer to [EI-42, "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#).
2. Disconnect the connectors in the trunk lid, and remove the harness clamps to pull the harness out of the trunk lid.
3. Remove the mounting bolts, and remove the trunk lid assembly.

CAUTION:

After installing, apply touch-up paint (the body color) onto the head of the hinge mounting bolts.


Install in the reverse order of removal.

Removal and Installation of Trunk Lid Lock

EIS0010A

LOCK REMOVAL


1. Remove the trunk lid finisher. Refer to [EI-42, "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#).
2. Disconnect the release cable.
3. After removing the harness connector, remove the mounting bolts, and remove the trunk lid lock.



TRUNK LID AND FUEL FILLER LID OPENER

STRIKER REMOVAL

1. Remove the trunk rear plate and trunk rear finisher. Refer to [EI-42, "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#).
2. After removing the cable connection, remove the mounting bolts, disconnect the release cable, and remove the striker from the trunk lock support.




LOCK AND STRIKER INSTALLATION

1. Install in the reverse order of removal.
2. After installing, close the trunk lid lightly. Perform the lock and surface height adjustment. Refer to [BL-76, "Fitting Adjustment"](#).
3. After installing, check the operation.

Removal and Installation of Trunk Lid Weatherstrip

EIS0010B



1. At rear side, align the weatherstrip seam to the center of the striker.
2. After installing, pull the weatherstrip lightly to check for looseness.

CAUTION:

The weatherstrip should fit tightly onto the corners and trunk lid rear plate.


VEHICLE SECURITY (THEFT WARNING) SYSTEM

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Component Parts and Harness Connector Location

PFP:28491

EIS001HH



LIIA0520E


VEHICLE SECURITY (THEFT WARNING) SYSTEM

EIS001HI

System Description

DESCRIPTION

Operation Flow



Setting the vehicle security system

Initial condition

- Ignition switch is in OFF position.

Disarmed phase

- When the vehicle is being driven or when doors or trunk lid is open, the vehicle security system is set in the disarmed phase on the assumption that the owner is inside or near the vehicle.

Pre-armed phase and armed phase

- The vehicle security system turns into the "pre-armed" phase when hood, trunk lid and all doors are closed and locked by electronic key. The security indicator lamp illuminates for 30 seconds. then, the system automatically shifts into the "armed" phase.

Canceling the set vehicle security system

When one of the following operations is performed, the armed phase is canceled.

1. Unlock the doors with the key or the key fob.
2. Open the trunk lid with the key or the key fob. When the trunk lid is closed after opening the trunk lid with the key fob, the system returns to the armed phase.

Activating the alarm operation of the vehicle security system

Make sure the system is in the armed phase.

When one of the following operations is performed, the system sounds the horns and flashes the head-lamps for about 50 seconds.

1. Engine hood or any door is opened before unlocking door with key or key fob.
2. Door is unlocked without using key or key fob.
3. Trunk lid is opened without using key or key fob.

POWER SUPPLY

Power is supplied at all times

- through 10A fuse [No.19, located in the fuse block (J/B)]
- to security indicator lamp terminal 1 and
- through 50A fusible link (letter f, located in the fuse and fusible link box)
- to BCM terminal 55
- through 15A fuse [No. 21, located in the fuse block (J/B)]

VEHICLE SECURITY (THEFT WARNING) SYSTEM

- to BCM terminal 42
- through 15A fuse (No. 25, located in the fuse and fusible link box)
- to horn relay terminal 2
- through 10A fuse (No. 34, located in the IPDM E/R)
- to IPDM E/R internal CPU.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in the fuse block (J/B)]
- to BCM terminal 11.

INITIAL CONDITION TO ACTIVATE THE SYSTEM

The operation of the vehicle security system is controlled by the doors, hood and trunk lid.

To activate the vehicle security system, BCM must receive signals indicating the doors and trunk lid are closed and the doors are locked.

When a door is open, BCM terminal 12, 13, 62 or 63 receives a ground signal from each door switch.

When front door LH is unlocked, BCM terminal 22 receives a signal from terminal 14 of main power window and door lock/unlock switch.

When front door RH or either rear door is unlocked, BCM terminal 22 receives a signal from terminal 16 of front power window switch RH or the rear power window switch LH or RH.

When the trunk lid is open, BCM terminal 57 receives a ground signal

- from terminal 2 of the trunk lamp and trunk release solenoid switch
- through body grounds B7 and B19.

VEHICLE SECURITY SYSTEM ALARM OPERATION

The vehicle security system is triggered by

- opening a door
- opening the trunk lid
- unlocking door without using the key or key fob.

The vehicle security system will be triggered once the system is in armed phase,

- when BCM receives a ground signal at terminals 12, 13, 62, 63 (door switch), or terminal 57 (trunk lamp and trunk release solenoid switch).

Power is supplied at all times

- to horn relay terminal 2
- through 15A fuse (No. 25, located in fuse and fusible link box).

When the vehicle security system is triggered, ground is supplied intermittently

- from IPDM E/R terminal 51
- to headlamp high relay and
- to horn relay terminal 1.

The headlamps flash and the horn sounds intermittently.

The alarm automatically turns off after 50 seconds, but will reactivate if the vehicle is tampered with again.

VEHICLE SECURITY SYSTEM DEACTIVATION

To deactivate the vehicle security system, a door or the trunk lid must be unlocked with the key or key fob.

When the key is used to unlock a door, BCM terminal 22 receives signal

- from terminal 14 of the main power window and door lock/unlock switch.

When the BCM receives either one of these signals or unlock signal from key fob or key cylinder switch, the vehicle security system is deactivated. (Disarmed phase)

PANIC ALARM OPERATION

Remote keyless entry system may or may not operate vehicle security system (horn and headlamps) as required.

When the remote keyless entry system is triggered, ground is supplied intermittently

- from IPDM E/R terminal 51
- to headlamp high relay and
- to horn relay terminal 1.

The headlamp flashes and the horn sounds intermittently.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

The alarm automatically turns off after 30 seconds or when BCM receives any signal from key fob.

CAN Communication System Description


EIS001HJ

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Schematic

EIS001HK



A

B

C

D

E

F

G

H

BL

J

K



L

M

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Wiring Diagram -VEHSEC-
FIG. 1



EIS001HL



LIWA0110E

A
B
C
D
E
F
G
H
BL
J
K
L
M




BL-VEHSEC-02



VEHICLE SECURITY (THEFT WARNING) SYSTEM

FIG. 4


BL-VEHSEC-04



VEHICLE SECURITY (THEFT WARNING) SYSTEM

FIG. 5

BL-VEHSEC-05



45	46	47	48	49	50	51	52	E121		E3	E108	2	H-1
53	54	55	56	57	58	59	60	W	+	B	B	1	3


VEHICLE SECURITY (THEFT WARNING) SYSTEM

CONSULT-II Function


EIS001HM

CONSULT-II INSPECTION PROCEDURE


1. With the ignition switch OFF, connect CONSULT-II to the data link connector, and turn the ignition switch ON.




2. Touch "START".



3. Touch "BCM" on the "SELECT SYSTEM" screen.



4. Touch "THEFT ALM" on the "SELECT TEST ITEM" screen.
 - WORK SUPPORT, DATA MONITOR and ACTIVE TEST are available for the vehicle security system.



CONSULT-II APPLICATION ITEM

Data Monitor

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.
KEY CYL LK SW	Indicates [ON/OFF] condition of lock signal from key cylinder switch.
KEY CYL UN SW	Indicates [ON/OFF] condition of unlock signal from key cylinder switch.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Monitored Item	Description
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switches.
TRNK OPN MTR	Indicates [ON/OFF] condition of trunk opener motor.
TRNK OPNR SW	Indicates [ON/OFF] condition of trunk opener switch.
TRUNK KEY SW	Indicates [ON/OFF] condition of trunk key cylinder switch.
HOOD SWITCH	Indicates [ON/OFF] condition of hood switch. (Displayed even if not equipped)
LOCK SW DR/AS	Indicates [ON/OFF] condition of lock signal from door lock/unlock switch LH and RH.
UNLK SW DR/AS	Indicates [ON/OFF] condition of unlock signal from door lock/unlock switch LH and RH.
LK BUTTON/SIG	Indicates [ON/OFF] condition of lock signal from key fob.
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from key fob.
TRUNK BTN/SIG	Indicates [ON/OFF] condition of trunk open signal from key fob.

Active Test

Test Item	Description
THEFT IND	This test is able to check security indicator lamp operation. The lamp will be turned on when "ON" on CONSULT-II screen is touched.
HEADLAMP	This test is able to check vehicle security lamp operation. The headlamps will be activated for 0.5 seconds after "ON" on CONSULT-II screen is touched.
HORN	This test is able to check vehicle security horn operation. The horns will be activated for 0.5 seconds after "ON" on CONSULT-II screen is touched.


Work Support

Test Item	Description
SECURITY ALARM SET	This mode can confirm and change security alarm ON-OFF setting.
THEFT ALM TRG	The switch which triggered vehicle security alarm is recorded. This mode is able to confirm and erase the record of vehicle security alarm. The trigger data can be erased by touching "CLEAR" on CONSULT-II screen.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnosis WORK FLOW

EIS001HN



LIIA0123E


- "POWER DOOR LOCK SYSTEM" Diagnosis refer to [BL-17, "POWER DOOR LOCK SYSTEM"](#) .
- "REMOTE CONTROL SYSTEM" Diagnosis refer to [BL-37, "REMOTE KEYLESS ENTRY SYSTEM"](#) .

VEHICLE SECURITY (THEFT WARNING) SYSTEM

EIS001HO

Preliminary Check

The system operation is canceled by turning ignition switch to ACC at any step between START and ARMED in the following flow chart.



LIA0568E

After performing preliminary check, go to symptom chart.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Symptom Chart

EIS001HP

PROCEDURE			Diagnostic procedure
SYMPTOM			
1	Vehicle security system cannot be set by	All items	Diagnostic Procedure 1 (Door, hood and trunk lamp and trunk release solenoid switch check) Refer to BL-94, "Diagnostic Procedure 1" .
			If the above systems are “OK”, replace BCM.
		Lock/unlock switch	Diagnostic Procedure 7 (Door lock/unlock switch check) Refer to BL-98, "Diagnostic Procedure 6" .
			If the above systems are “OK”, check main power window and door lock/unlock switch.
		Door outside key	Diagnostic Procedure 3 (Door key cylinder switch check) Refer to BL-98, "Diagnostic Procedure 3" .
	If the above systems are “OK”, check main power window and door lock/unlock switch.		
Security indicator does not turn “ON”.		Diagnostic Procedure 2 (Security indicator lamp check) Refer to BL-97, "Diagnostic Procedure 2" .	
		If the above systems are “OK”, replace BCM.	
2	*1 Vehicle security system does not alarm when	Any door is opened.	Diagnostic Procedure 1 (Door and trunk room lamp switch check) Refer to BL-94, "Diagnostic Procedure 1" .
			If the above systems are “OK”, replace BCM.
3	Vehicle security alarm does not activate.	Horn alarm	Diagnostic Procedure 5 (Vehicle security horn alarm check) Refer to BL-98, "Diagnostic Procedure 5" .
			If the above systems are “OK”, check horn system. Refer to WW-35, "HORN" .
		Head lamp alarm	Diagnostic Procedure 6 (Head lamp alarm check) Refer to BL-98, "Diagnostic Procedure 5" .
			If the above systems are “OK”, replace BCM.
4	Vehicle security system cannot be canceled by	Door outside key	Diagnostic Procedure 3 (Door key cylinder switch check) Refer to BL-98, "Diagnostic Procedure 3" .
			If the above systems are “OK”, check main power window and door lock/unlock switch.
		Trunk lid key	Diagnostic Procedure 4 (Trunk lid key cylinder switch check) Refer to BL-98, "Diagnostic Procedure 4" .
			If the above systems are “OK”, replace BCM.
		Key fob	Check remote keyless entry function
			If the above systems are “OK”, replace BCM.

*1 : Make sure the system is in the armed phase.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

EIS001HQ

Diagnostic Procedure 1

1 – 1 DOOR SWITCH CHECK

1. CHECK DOOR SWITCH INPUT SIGNAL

With CONSULT-II

Check door switches ("DOOR SW-RL", "DOOR SW-RR", "DOOR SW-DR" and "DOOR SW-AS") in "DATA MONITOR" mode with CONSULT-II.

Monitor item	Condition	
DOOR SW-RL	OPEN	: ON
	CLOSE	: OFF
DOOR SW-RR	OPEN	: ON
	CLOSE	: OFF
DOOR SW-DR	OPEN	: ON
	CLOSE	: OFF
DOOR SW-AS	OPEN	: ON
	CLOSE	: OFF


DATA MONITOR	
MONITOR	
DOOR SW-DR	OFF
DOOR SW-AS	OFF
DOOR SW-RL	OFF
DOOR SW-RR	OFF

PIIA6469E

Without CONSULT-II

Check voltage between BCM harness connector terminals 12, 13, 62 and 63 and ground.

	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
Front door switch RH	12 (BR/W)	Ground	OPEN	0
			CLOSE	Battery voltage
Rear door switch RH	13 (L/R)	Ground	OPEN	0V
			CLOSE	Battery voltage
Front door switch LH	62 (SB)	Ground	OPEN	0V
			CLOSE	Battery voltage
Rear door switch LH	63 (R/B)	Ground	OPEN	0V
			CLOSE	Battery voltage



OK or NG

- OK >> Door switch circuit is OK.
- NG >> GO TO 2

VEHICLE SECURITY (THEFT WARNING) SYSTEM


2. CHECK DOOR SWITCH CIRCUIT

- Turn ignition switch OFF.
- Disconnect door switch and BCM.
- Check continuity between door switch connector B8 (front LH) or B108 (front RH) terminal 2, B18 (rear LH) or B116 (rear RH) terminal 1 and BCM connector M18, M20 terminals 12, 13, 62 and 63

2 (SB) - 62 (SB) :Continuity should exist
2 (BR/W) - 12 (BR/W) :Continuity should exist
1 (R/B) - 63 (R/B) :Continuity should exist
1 (L/R) - 13 (L/R) :Continuity should exist

- Check continuity between door switch connector B8 (front LH) or B108 (front RH) terminal 2, B18 (rear LH) or B116 (rear RH) terminal 1 and ground.

2 (SB or BR/W) - Ground :Continuity should not exist
1 (R/B or L/R) - Ground :Continuity should not exist



OK or NG

OK >> GO TO 3
 NG >> Repair or replace harness.


3. CHECK DOOR SWITCHES

Check continuity between door switch connector terminals 1, 2 and ground part of door switch.

	Terminals	Condition	Continuity
Front door switch LH/RH	2 – Ground part of door switch	Released	Yes
		Pushed	No
Rear door switch LH/RH	1 – Ground part of door switch	Released	Yes
		Pushed	No

OK or NG

OK >> GO TO 4
 NG >> Replace door switch.




4. CHECK BCM OUTPUT SIGNAL

- Connect BCM.
- Check voltage between BCM harness connector M18, M20 terminals 12, 13, 62 and 63 and ground.

	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
Front door switch RH	12 (BR/W)	Ground	OPEN	0
			CLOSE	Battery voltage
Rear door switch RH	13 (L/R)	Ground	OPEN	0V
			CLOSE	Battery voltage
Front door switch LH	62 (SB)	Ground	OPEN	0V
			CLOSE	Battery voltage
Rear door switch LH	63 (R/B)	Ground	OPEN	0V
			CLOSE	Battery voltage

OK or NG

OK >> Check the condition harness and the connector.
 NG >> Replace BCM.



VEHICLE SECURITY (THEFT WARNING) SYSTEM


1 – 2 TRUNK LAMP AND TRUNK RELEASE SOLENOID SWITCH CHECK

1. CHECK TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID INPUT SIGNAL

 With CONSULT-II

Check "TRUNK SW" in "DATA MONITOR" mode with CONSULT-II.

When trunk lid is open : TRNK OPN MNTR ON
When trunk lid is closed : TRNK OPN MNTR OFF




 Without CONSULT-II

Check voltage between BCM harness connector M20 terminal 57 (V/W) and ground.

Refer to [BL-85, "FIG. 2"](#).

OK or NG

- OK >> Trunk room lamp and trunk release solenoid switch is OK.
 NG >> GO TO 2




2. CHECK TRUNK LAMP AND TRUNK RELEASE SOLENOID SWITCH

1. Turn ignition switch OFF.
2. Disconnect trunk lamp and trunk release solenoid switch.
3. Check continuity between trunk lamp and trunk release solenoid switch connector T103 terminals 1 and 2.

Connector	Terminals	Condition	Continuity
T103	1 – 2	Closed	No
		Open	Yes

OK or NG

- OK >> Check the following.
- Trunk lamp and trunk release solenoid switch ground circuit
 - Harness for open or short between trunk lamp and trunk release solenoid switch and BCM
- NG >> Replace trunk lamp and trunk release solenoid switch.



VEHICLE SECURITY (THEFT WARNING) SYSTEM

Diagnostic Procedure 2


EIS001HR

SECURITY INDICATOR LAMP CHECK

1. SECURITY INDICATOR LAMP ACTIVE TEST

With CONSULT-II

Check "THEFT IND" in "ACTIVE TEST" mode with CONSULT-II.




Without CONSULT-II

1. Disconnect BCM.
2. Check voltage between BCM harness connector M18 terminal 23 and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M18	23 G/O	Ground	ON	0
			OFF	Battery voltage

OK or NG

- OK >> Security indicator lamp is OK.
NG >> GO TO 2



2. SECURITY INDICATOR LAMP CHECK

Check indicator lamp condition.

Refer to [BL-84, "FIG. 1"](#).

OK or NG

- OK >> GO TO 3
NG >> Replace indicator lamp.


3. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and security indicator lamp connector.
3. Check continuity between BCM connector M18 terminal 23 and security indicator lamp harness connector M14 terminal 2 and ground.

23 (G/O) - 2 (G/O) : Continuity should exist.

OK or NG

- OK >> Check the following.
- 10A fuse [No. 19, located in fuse block (J/B)]
 - Harness for open or short between security indicator lamp and fuse
- NG >> Repair or replace harness.



VEHICLE SECURITY (THEFT WARNING) SYSTEM

Diagnostic Procedure 3

EIS001HS

1. FRONT DOOR KEY CYLINDER SWITCH LH CHECK

Check door key cylinder switch with key.

Do doors lock/unlock when using the key?

YES >> Front door key cylinder switch LH (lock) is OK.

NO >> Check door key cylinder switch circuit. Refer to [BL-36, "Front Door Key Cylinder Switch LH Check"](#) .

Diagnostic Procedure 4

EIS001HT

VEHICLE SECURITY HORN ALARM CHECK

1. CHECK HORN OPERATION

Check if horn sounds with horn switch.

Does horn operate?

YES >> Check harness for open or short between IPDM E/R and horn relay.

NO >> Check horn circuit. Refer to [WW-35, "HORN"](#) .

Diagnostic Procedure 5

EIS001HV

VEHICLE SECURITY HEADLAMP ALARM CHECK

1. CHECK VEHICLE SECURITY HEADLAMP ALARM OPERATION

Check if headlamps operate with lighting switch.

Do headlamps come on when turning switch ON?

YES >> Headlamp alarm is OK.

NO >> Check headlamp system. Refer to [LT-6, "HEADLAMP \(FOR USA\)"](#) .

Diagnostic Procedure 6

EIS001HW

DOOR LOCK/UNLOCK SWITCH CHECK

1. CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

Check if power door lock operates with door lock/unlock switch.

Do doors lock/unlock when using each door lock/unlock switch?

YES >> Door lock/unlock switch is OK.

NO >> Refer to [BL-32, "Door Lock/Unlock Switch Check"](#) .

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)


NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

PFP:28591



Component Parts and Harness Connector Location

EIS001HX


Fuse block (J/B)




Fuse and fusible link box





View with instrument panel removed



View with lower driver instrument panel removed



View with glove box removed



A
B
C
D
E
F
G
H
BL
J
K
L
M

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

EIS0010C

System Description

NVIS (Nissan Vehicle Immobilizer System-NATS) has the following immobilizer functions:

- Since only NVIS (NATS) ignition keys, whose IDs have been registered into the ECM and BCM, allow the engine to run, operation of a stolen vehicle without a NVIS (NATS) registered key is prevented by NVIS (NATS).
NVIS (NATS) will immobilize the engine if someone tries to start it without the registered key of NVIS (NATS).
- All of the originally supplied ignition key IDs have been NVIS (NATS) registered.
If requested by the vehicle owner, a maximum of five key IDs can be registered into the NVIS (NATS) components.
- The security indicator blinks when the ignition switch is in OFF or ACC position. NVIS (NATS) warns outsiders that the vehicle is equipped with the anti-theft system.
- When NVIS (NATS) detects trouble, the security indicator lamp lights up while ignition key is in the ON position.
- NVIS (NATS) trouble diagnoses, system initialization and additional registration of other NVIS (NATS) ignition key IDs must be carried out using CONSULT-II hardware and CONSULT-II NVIS (NATS) software. When NVIS (NATS) initialization has been completed, the ID of the inserted ignition key is automatically NVIS (NATS) registered. Then, if necessary, additional registration of other NVIS (NATS) ignition key IDs can be carried out.
Regarding the procedures of NVIS (NATS) initialization and NVIS (NATS) ignition key ID registration, refer to CONSULT-II Operation Manual NATS-IVIS/NVIS.
- **When servicing a malfunction of the NVIS (NATS) (indicated by lighting up of Security Indicator Lamp) or registering another NVIS (NATS) ignition key ID, it may be necessary to re-register original key identification. Therefore, be sure to receive ALL KEYS from vehicle owner.**

System Composition


EIS0010D

The immobilizer function of the NVIS (NATS) consists of the following:

- NATS ignition key
- NATS antenna amp. located in the ignition key cylinder
- Body control module (BCM)
- Engine control module (ECM)
- Security indicator

NOTE:

The communication between ECM and BCM uses the CAN communication system.



PIA1121E

ECM Re-communicating Function

EIS0010E

The following procedure can automatically perform re-communication of ECM and BCM, but only when the ECM has been replaced with a new one (*1).

*1: New one means a virgin ECM which has never been energized on-board.

(In this step, initialization procedure by CONSULT-II is not necessary)

NOTE:

- When registering new Key IDs or replacing the ECM other than brand new, refer to CONSULT-II Operation Manual NATS-IVIS/NVIS.
- If multiple keys are attached to the key holder, separate them before work.
- Distinguish keys with unregistered key ID from those with registered ID.

1. Install ECM.

2. Using a registered key (*2), turn ignition switch to ON.

*2: To perform this step, use the key (except for card plate key) that has been used before performing ECM replacement.

3. Maintain ignition switch in ON position for at least 5 seconds.

4. Turn ignition switch to OFF.

5. Start engine.

If engine can be started, procedure is completed.

If engine cannot be started, refer to CONSULT-II Operation Manual NATS-IVIS/NVIS and initialize control unit.

A

B

C

D

E

F

G

H

BL

J

K

L



M

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

Wiring Diagram — NATS —

EIS001OF

BL-NATS-01



LIWA0115E

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

Terminals and Reference Value for BCM

EIS0010G

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)
21	P	NATS antenna amp.	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move.
23	G/O	Security indicator lamp	Goes OFF → illuminates (Every 2.4 seconds)	Battery voltage → 0
25	G	NATS antenna amp.	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move.
38	G/R	Ignition switch (ON or START)	Ignition switch (ON or START position)	Battery voltage
39	L	CAN-H	—	—
40	Y	CAN-L	—	—
49, 52	B	Ground	—	0
55	W/B	Power source (Fusible link)	—	Battery voltage

CONSULT-II

EIS0010H

CONSULT-II INSPECTION PROCEDURE


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. Turn ignition switch OFF.
2. Insert NVIS (NATS) program card into CONSULT-II.

Program card : NATS (AEN02C)


3. Connect CONSULT-II and CONSULT-II CONVERTER to data link connector.



4. Turn ignition switch ON.
5. Touch "START".




6. Touch "OTHER"




NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

7. Select "NATS V.5.0".
If "NATS V5.0" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#) .



8. Perform each diagnostic test mode according to each service procedure.
For further information, see the CONSULT-II Operation Manual NATS-IVIS/NVIS.



CONSULT-II DIAGNOSTIC TEST MODE FUNCTION


CONSULT-II DIAGNOSTIC TEST MODE	Description
C/U INITIALIZATION	When replacing any of the following components, C/U initialization and re-registration of all NATS ignition keys are necessary. [(NATS ignition key/ BCM/ ECM]
SELF-DIAG RESULTS	Detected items (screen terms) are as shown in the chart. Refer to BL-105, "NVIS (NATS) SELF-DIAGNOSTIC RESULTS ITEM CHART" .

NOTE:

- When any initialization is performed, all IDs previously registered will be erased and all NATS ignition keys must be registered again.
- The engine cannot be started with an unregistered key. In this case, the system will show "DIFFERENCE OF KEY" or "LOCK MODE" as a self-diagnostic result on the CONSULT-II screen.
- In rare case, "CHAIN OF ECM-IMMU" might be stored as a self-diagnostic result during key registration procedure, even if the system is not malfunctioning.

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

HOW TO READ SELF-DIAGNOSTIC RESULTS




NVIS (NATS) SELF-DIAGNOSTIC RESULTS ITEM CHART

Detected items [NVIS (NATS) program card screen terms]	P No. Code (Self-diagnostic result of "ENGINE")	Malfunction is detected when....	Reference page
CHAIN OF ECM-IMMU [P1612]	NATS MAL-FUNCTION P1612	Communication impossible between ECM and BCM In rare case, "CHAIN OF ECM-IMMU" might be stored during key registration procedure, even if the system is not malfunctioning.	Refer to BL-109 .
DIFFERENCE OF KEY [P1615]	NATS MAL-FUNCTION P1615	BCM can receive the key ID signal but the result of ID verification between key ID and BCM is NG.	Refer to BL-110 .
CHAIN OF IMMU-KEY [P1614]	NATS MAL-FUNCTION P1614	BCM cannot receive the key ID signal.	Refer to BL-113 .
ID DISCORD, IMM-ECM [P1611]	NATS MAL-FUNCTION P1611	The result of ID verification between BCM and ECM is NG. System initialization is required.	Refer to BL-111 .
LOCK MODE [P1610]	NATS MAL-FUNCTION P1610	When the starting operation is carried out five or more times consecutively under the following conditions, NVIS (NATS) will shift the mode to one which prevents the engine from being started. ● Unregistered ignition key is used. ● BCM or ECM's malfunctioning.	Refer to BL-112 .
DON'T ERASE BEFORE CHECKING ENG DIAG	—	All engine trouble codes except NVIS (NATS) trouble code has been detected in ECM.	Refer to BL-106 .

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

Work Flow

EIS00101



SEL024X

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

Trouble Diagnoses SYMPTOM MATRIX CHART 1

E/S0010J

Self-diagnosis related item

Symptom	Displayed "SELF-DIAG RESULTS" on CONSULT-II screen.	Diagnostic Procedure (Reference page)	System (Malfunctioning part or mode)	Reference Part No. Of Illustration On System Diagram
- Security indicator lighting up* - Engine cannot be started	CHAIN OF ECM-IMMU [P1612]	PROCEDURE 1 (BL-109)	In rare case, "CHAIN OF ECM-IMMU" might be stored during key registration procedure, even if the system is not malfunctioning.	—
			Open circuit in battery voltage line of BCM circuit	C1
			Open circuit in ignition line of BCM circuit	C2
			Open circuit in ground line of BCM circuit	C3
			Open or short circuit between BCM and ECM communication line	C4
			ECM	B
			BCM	A
	DIFFERENCE OF KEY [P1615]	PROCEDURE 2 (BL-110)	Unregistered key	D
			BCM	A
	CHAIN OF IMMU-KEY [P1614]	PROCEDURE 5 (BL-113)	Malfunction of key ID chip	E5
			Communication line between ANT/ AMP and BCM:	E1
			Open circuit or short circuit of battery voltage line or ground line	E2
			Open circuit in power source line of ANT/ AMP circuit	E3
			Open circuit in ground line of ANT/ AMP circuit	E4
			NATS antenna amp.	E6
			BCM	A
	ID DISCORD, IMM-ECM [P1611]	PROCEDURE 3 (BL-111)	System initialization has not yet been completed.	F
			ECM	B
	LOCK MODE [P1610]	PROCEDURE 4 (BL-112)	LOCK MODE	D
Security indicator lighting up*	DON'T ERASE BEFORE CHECKING ENG DIAG	WORK FLOW (BL-106)	Engine trouble data and NVIS (NATS) trouble data have been detected in ECM	—

*: When NVIS (NATS) detects trouble, the security indicator lights up while ignition key is in the "ON" position.

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)


SYMPTOM MATRIX CHART 2

Non self-diagnosis related item

Symptom	Diagnostic Procedure (Reference page)	System (Malfunctioning part or mode)	Reference Part No. Of Illustration On System Diagram
Security indicator does not light up*.	PROCEDURE 6 (BL-116)	Combination meter (security indicator lamp)	—
		Open circuit between Fuse and BCM	—
		BCM	A

*: CONSULT-II self-diagnostic results display screen "no malfunction is detected".

DIAGNOSTIC SYSTEM DIAGRAM



Diagnostic Procedure 1

Self-diagnostic results:

"CHAIN OF ECM-IMMU" displayed on CONSULT-II screen

First perform the "SELF-DIAG RESULTS" in "BCM" with CONSULT-II, then perform the trouble diagnosis of malfunction system indicated "SELF-DIAG RESULTS" of "BCM". Refer to [BL-103, "CONSULT-II"](#)

1. CONFIRM SELF-DIAGNOSTIC RESULTS

Confirm SELF-DIAGNOSTIC RESULTS "CHAIN OF ECM-IMMU" displayed on CONSULT-II screen.

NOTE:

In rare case, "CHAIN OF ECM-IMMU" might be stored during key registration procedure, even if the system is not malfunctioning.

Is CONSULT-II screen displayed as above?

Yes >> GO TO 2

No >> GO TO [BL-107, "SYMPTOM MATRIX CHART 1"](#).

SELF DIAGNOSIS	
DTC RESULTS	TIME
CHAIN OF ECM-IMMU [P1612]	0

PIIA1260E

2. CHECK POWER SUPPLY CIRCUIT FOR BCM

1. Disconnect BCM.
2. Check voltage between BCM connector M19 terminal 55 and ground.

55 (W/B) – Ground

:Battery voltage


OK or NG

OK >> GO TO 3

NG >> Check the following.

- 50A fusible link (letter **f**, located in fuse and fusible link box)
- Harness for open or short between fuse and BCM connector

Ref. Part No. C1



LIAA0526E

3. CHECK IGN SW. ON SIGNAL

1. Turn ignition switch ON.
2. Check voltage between BCM connector M18 terminal 38 and ground.

38 (G/R) – Ground

:Battery voltage


OK or NG

OK >> GO TO 4

NG >> Check the following.

- 10A fuse [No. 12, located in the fuse block (J/B)]
- Harness for open or short between fuse and BCM connector

Ref. part No. C2



LIAA0527E

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

4. CHECK GROUND CIRCUIT FOR BCM

1. Turn ignition OFF.
2. Check continuity between BCM connector M18 terminals 49, 52 and ground.


49 (B) – Ground :Continuity should exist.

52 (B) – Ground :Continuity should exist.

OK or NG

OK >> GO TO 5

NG >> Repair or replace harness. **Ref. part No. C3**



5. REPLACE BCM

1. Replace BCM. **Ref. part No. A**
2. Perform initialization with CONSULT-II.
For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".

Does the engine start?

Yes >> BCM is malfunctioning.

No >> ● ECM is malfunctioning.

● Replace ECM. **Ref. part No. B**

● Perform initialization or re-communicating function.

● For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".

● For re-communicating function, refer to [BL-101, "ECM Re-communicating Function"](#).

Diagnostic Procedure 2

EIS0010M

Self-diagnostic results:

"DIFFERENCE OF KEY" displayed on CONSULT-II screen

1. CONFIRM SELF-DIAGNOSTIC RESULTS

Confirm SELF-DIAGNOSTIC RESULTS "DIFFERENCE OF KEY" displayed on CONSULT-II screen.

Is CONSULT-II screen displayed as above?

Yes >> GO TO 2

No >> GO TO [BL-107, "SYMPTOM MATRIX CHART 1"](#).

SELF DIAG RESULTS	
DTC RESULTS	TIME
DIFFERENCE OF KEY [P1615]	0

PIA1261E

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

2. PERFORM INITIALIZATION WITH CONSULT-II

Perform initialization with CONSULT-II. Re-register all NATS ignition key IDs.


For initialization and registration of NATS ignition key IDs, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".

NOTE:

If the initialization is not completed or malfunctions, CONSULT-II shows message on the screen.

Can the system be initialized and can the engine be started with re-registered NATS ignition key?

- Yes >> ● Ignition key ID was unregistered. **Ref. part No. D**
- No >> ● BCM is malfunctioning.
- Replace BCM. **Ref. part No. A**
 - Perform initialization with CONSULT-II.
 - For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".



Diagnostic Procedure 3

Self-diagnostic results:

"ID DISCORD, IMM-ECM" displayed on CONSULT-II screen

1. CONFIRM SELF-DIAGNOSTIC RESULTS

Confirm SELF-DIAGNOSTIC RESULTS "ID DISCORD, IMM-ECM" displayed on CONSULT-II screen.


NOTE:

"ID DISCORD IMM-ECM":

Registered ID of BCM is in discord with that of ECM.

Is CONSULT-II screen displayed as above?

- Yes >> GO TO 2
- No >> GO TO [BL-107, "SYMPTOM MATRIX CHART 1"](#) .



2. PERFORM INITIALIZATION WITH CONSULT-II

Perform initialization with CONSULT-II. Re-register all NATS ignition key IDs.


For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".

NOTE:

If the initialization is not completed or malfunctions, CONSULT-II shows message on the screen.

Can the system be initialized?

- Yes >> ● Start engine. (END)
- (System initialization had not been completed. **Ref. part No. F**)
- No >> ● ECM is malfunctioning.
- Replace ECM. **Ref. part No. B**
 - Perform initialization with CONSULT-II.
- For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".



NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

EIS00100

Diagnostic Procedure 4

Self-diagnostic results:

"LOCK MODE" displayed on CONSULT-II screen

1. CONFIRM SELF-DIAGNOSTIC RESULTS

Confirm SELF-DIAGNOSTIC RESULTS "LOCK MODE" is displayed on CONSULT-II screen.

Is CONSULT-II screen displayed as above?

Yes >> GO TO 2

No >> GO TO [BL-107, "SYMPTOM MATRIX CHART 1"](#).

SELF DIAG RESULTS	
DTC RESULTS	TIME
LOCK MODE [P1610]	0

PIA1264E

2. ESCAPE FROM LOCK MODE

1. Turn ignition switch OFF.
2. Turn ignition switch ON with registered key. (Do not start engine.) Wait 5 seconds.
3. Return the key to OFF position. Wait 5 seconds.
4. Repeat steps 2 and 3 twice (total of three cycles).
5. Start the engine.

Does engine start?

Yes >> System is OK (Now system is escaped from "LOCK MODE").

No >> GO TO 3

3. PERFORM INITIALIZATION WITH CONSULT-II

Perform initialization with CONSULT-II.

For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".

NOTE:

If the initialization is not completed or malfunctions, CONSULT-II shows the message on the screen.

Can the system be initialized?

Yes >> System is OK.

No >> GO TO 4

IMMU INITIALIZATION
INITIALIZATION FAIL
THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.

SEL297W

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

4. PERFORM INITIALIZATION WITH CONSULT-II AGAIN


1. Replace BCM.
2. Perform initialization with CONSULT-II.
For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".

NOTE:

If the initialization is not completed or malfunctions, CONSULT-II shows the message on the screen.

Can the system be initialized?

- Yes >> System is OK. (BCM is malfunctioning. **Ref. part No. A**)
- No >> ● ECM is malfunctioning.
- Replace ECM. **Ref. part No. B**
 - Perform initialization with CONSULT-II.
For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".



Diagnostic Procedure 5

EIS0010P

Self-diagnostic results:

"CHAIN OF IMMU-KEY" displayed on CONSULT-II screen

1. CONFIRM SELF-DIAGNOSTIC RESULTS

Confirm SELF-DIAGNOSTIC RESULTS "CHAIN OF IMMU-KEY" displayed on CONSULT-II screen.

Is CONSULT-II screen displayed as above?

- Yes >> GO TO 2
- No >> GO TO [BL-107, "SYMPTOM MATRIX CHART 1"](#) .

SELF DIAGNOSIS	
DTC RESULTS	TIME
CHAIN OF IMMU-KEY [P1614]	0

PIIA1263E

2. CHECK NATS ANTENNA AMP. INSTALLATION

Check NATS antenna amp. installation. Refer to [BL-117, "How to Replace NATS Antenna Amp."](#) .

OK or NG

- OK >> GO TO 3
- NG >> Reinstall NATS antenna amp. correctly.

3. CHECK NVIS (NATS) IGNITION KEY ID CHIP

Start engine with another registered NATS ignition key.

Does the engine start?

- Yes >> ● Ignition key ID chip is malfunctioning.
- Replace the ignition key.
Ref. part No, E5
 - Perform initialization with CONSULT-II.
For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".
- No >> GO TO 4

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)


4. CHECK POWER SUPPLY FOR NATS ANTENNA AMP.

1. Turn ignition switch ON.
2. Check voltage between NATS antenna amp. connector M21 terminal 1 and ground.

1 (W/L) – Ground :Battery voltage

OK or NG

- OK >> GO TO 5
NG >> Repair or replace harness.



5. CHECK NATS ANTENNA AMP. SIGNAL LINE- 1

Check voltage between NATS antenna amp. connector M21 terminal 2 and ground with analog tester.

Before turning ignition switch ON

Voltage: 0V

2 (P) – Ground

Just after turning ignition switch ON


: Pointer of tester should move.

OK or NG

- OK >> GO TO 6
NG >> ● Repair or replace harness.

NOTE:

If harness is OK, replace BCM, perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".



6. CHECK NATS ANTENNA AMP. SIGNAL LINE- 2

Check voltage between NATS antenna amp. connector M21 terminal 4 and ground with analog tester.

Before turning ignition switch ON

Voltage: 0V

4 (G) – Ground

Just after turning ignition switch ON


: Pointer of tester should move.

OK or NG

- OK >> GO TO 7
NG >> ● Repair or replace harness.

NOTE:

If harness is OK, replace BCM, perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".



NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

7. CHECK NATS ANTENNA AMP. GROUND LINE CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between NATS antenna amp. connector M21 terminal 3 and ground.

3 (B) – Ground :Continuity should exist.


OK or NG

OK >> ● NATS antenna amp. is malfunctioning.
Ref. part No. E6

NG >> ● Repair or replace harness.

NOTE:

If harness is OK, replace BCM, perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".



NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

EIS001PD

Diagnostic Procedure 6

“SECURITY INDICATOR LAMP DOES NOT LIGHT UP”

1. CHECK FUSE

Check 10A fuse [No.19, located in the fuse block (J/B)]

OK or NG

- OK >> GO TO 2
- NG >> Replace fuse.

2. CHECK SECURITY INDICATOR LAMP

1. Install 10A fuse.
2. Start engine and turn ignition switch OFF.
3. Check the security indicator lamp lights up.

Security indicator lamp should light up.

OK or NG

- OK >> Inspection END.
- NG >> GO TO 3


3. CHECK SECURITY INDICATOR LAMP POWER SUPPLY CIRCUIT

1. Disconnect security indicator lamp.
2. Check voltage between security indicator lamp connector M34 terminal 1 and ground.

1 (R/W) – Ground :Battery voltage

OK or NG

- OK >> GO TO 4
- NG >> Repair or replace harness.




4. CHECK BCM (NATS CONTROL UNIT) FUNCTION

1. Connect security indicator lamp.
2. Disconnect BCM.
3. Check voltage between BCM connector M18 terminal 23 and ground.

23 (G/O) – Ground :Battery voltage

OK or NG

- OK >> BCM is malfunctioning.
 - Replace BCM.
Ref. part No. A
 - Perform initialization with CONSULT-II.
 - For initialization, refer to “CONSULT-II Operation Manual NATS-IVIS/NVIS”.
- NG >> Check the following.
 - Harness for open or short between security indicator lamp and BCM (NATS control unit).
 - Indicator lamp condition




NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

How to Replace NATS Antenna Amp.

EIS0010Q

NOTE:

- If NATS antenna amp. is not installed correctly, NVIS (NATS) system will not operate properly and SELF-DIAG RESULTS on CONSULT-II screen will show "LOCK MODE" or "CHAIN OF IMMU-KEY".
- Initialization is not necessary only when NATS antenna amp. is replaced with a new one.



A
B
C
D
E
F
G
H
BL
J
K
L
M

INTEGRATED HOMELINK TRANSMITTER



INTEGRATED HOMELINK TRANSMITTER

PFP:96401

Wiring Diagram —TRNSCV—

EIS00114

BL-TRNSCV-01



INTEGRATED HOMELINK TRANSMITTER

E/S001/5

Trouble Diagnoses DIAGNOSTIC PROCEDURE

SYMPTOM: Transmitter does not activate receiver.


Before conducting the procedure given below, make sure that system receiver (garage door opener, etc.) operates with original, hand-held transmitter. If NG, receiver or hand-held transmitter is at fault, not vehicle related.

1. ILLUMINATE CHECK

- Turn ignition switch OFF.
- Does red light (LED) of transmitter illuminate when any button is pressed?

YES or NO

YES >> GO TO 2
NO >> GO TO 3



2. TRANSMITTER CHECK

Check transmitter with Tool*.

*:For details, refer to Technical Service Bulletin.

OK or NG

OK >> Receiver or handheld transmitter malfunction, not vehicle related.
NG >> Replace transmitter with sun visor assembly.

3. CHECK BCM OUTPUT POWER SUPPLY

Does roomlamp come on when driver side door is opened? Refer to [LT-149, "INTERIOR ROOM LAMP"](#).

Yes or No?

YES >> GO TO 4
NO >> Repair or replace the malfunctioning part.


4. POWER SUPPLY CHECK

1. Disconnect transmitter.
2. Check voltage between auto anti-dazzling inside mirror connector R7 terminal 5 and ground.

5 (B/R) – Ground :Battery voltage

OK or NG

OK >> GO TO 5
NG >> Repair or replace harness.



INTEGRATED HOMELINK TRANSMITTER

5. GROUND CIRCUIT CHECK

Check continuity between auto anti-dazzling inside mirror (integrated homelink transmitter) connector R7 terminal 8 (B) and body ground.


8 (B) – Ground

:Continuity should exist.

OK or NG

OK >> Replace inside mirror assembly.

NG >> Repair or replace harness.




BODY REPAIR

BODY REPAIR

PFP:60100

Body Exterior Paint Color

EIS00116



LIA0431E


Component			Color code	A15	A19	BW9	EY1	KH3	KY1	KY2	QX3
			Description	Red Opulence	Radiant Ember	Majestic Blue	Champagne Mist	Onyx	Liquid Silver	Spirited Bronze	Winter Frost
			Paint type	M	M	2p	M	2S	M	M	3P
			Clear coat	t	t	t	t	t	t	t	t
1	Roof side molding		Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
2	Rear door sash Cover		Black	KH3	KH3	KH3	KH3	KH3	KH3	KH3	KH3
3	Rear Spoiler		Body color	A15	A19	BW9	EY1	KH3	KY1	KY2	QX3
4	Rear pillar trim	Base	Black	KH3	KH3	KH3	KH3	KH3	KH3	KH3	KH3
		Body	Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
5	Outside handle		Body color	A15	A19	BW9	EY1	KH3	KY1	KY2	QX3
6	Outside mirror	Body	Body color	A15	A19	BW9	EY1	KH3	KY1	KY2	QX3
		Base	Black	AG01	AG01	AG01	AG01	AG01	AG01	AG01	AG01
7	Side guard molding	Body	Body color	A15	A19	BW9	EY1	KH3	KY1	KY2	QX3
8	Center mudguard		Body color	A15	A19	BW9	EY1	KH3	KY1	KY2	QX3
9	Bumper fascia	Body	Body color	A15	A19	BW9	EY1	KH3	KY1	KY2	QX3
10	Trunk lid finisher		Body color	A15	A19	BW9	EY1	KH3	KY1	KY2	QX3
11	Radiator grille	Center	Chromium-plate +Smoke Clear	Cr+HFM 09	Cr+HFM 09	Cr+HFM 09	Cr+HFM 09	Cr+H FM09	Cr+HFM 09	Cr+HFM 09	Cr+HF M09
12	Cowl top cover		Black	AG01	AG01	AG01	AG01	AG01	AG01	AG01	AG01
13	Door sash		Black tape	X	X	X	X	X	X	X	X

M: Metallic; 2S: 2-Coat Solid, 2P: 2-Coat Pearl; 3P: 3-Coat Pearl; t: New Cross Linking Clear Coat

BODY REPAIR

Body Component Parts
UNDERBODY COMPONENT PARTS

EIS00117




LIA0533E

BODY REPAIR

1. Hoodledge assembly (RH, LH)	A
2. Hoodledge reinforcement (RH, LH)	
3. Upper hoodledge (RH, LH)	
4. Lower front hoodledge (RH, LH)	B
5. Rear hoodledge reinforcement (RH, LH)	
6. Upper dash crossmember assembly	
7. Upper dash assembly	C
8. Side cowl top	
9. Lower dash	
10. Side dash (RH, LH)	D
11. Front floor center	
12. Front floor	
13. Inner sill (RH, LH)	E
14. Rear seat crossmember assembly	
15. Rear floor front	F
16. Rear seat crossmember	
17. Rear floor seat belt anchor reinforcement	
18. Rear seat back support assembly	G
19. Center rear crossmember	
20. Rear floor rear	
21. Muffler mounting bracket	H
22. Rear floor side (RH, LH)	
23. Spare tire clamp bracket	
24. Front side member closing plate assembly (RH, LH)	BL
25. Front side member front closing plate (RH, LH)	
26. Front side member assembly (RH, LH)	
27. Front side member (RH, LH)	J
28. Front side member outrigger assembly (RH, LH)	
29. Front side member patch (RH, LH)	K
30. Front side member rear extension (RH, LH)	
31. Rear side member (RH, LH)	
32. Rear side member extension (RH, LH)	L
33. Front center floor assembly	
34. Front floor RR LH reinforcement	M

BODY REPAIR

BODY COMPONENT PARTS



L1IA0432E

BODY REPAIR

1	Front Fender (RH,LH)	26	Center pillar inner (RH,LH)	51	Front door guard rear bracket (RH,LH)	A
2	Outer hood	27	Roof 2nd bow	52	Front door guard front bracket (RH,LH)	
3	Inner hood	28	Roof reinforcement	53	Lower front door hinge reinforcement (RH,LH)	B
4	Front body side outer (RH,LH)	29	Rear wheel outer (RH,LH)	54	Outer rear door panel (RH,LH)	
5	Front pillar upper hinge brace (RH,LH)	30	Rear wheel outer front extension (RH,LH)	55	Rear door inner (RH,LH)	C
6	Front pillar upper hinge bulkhead (RH,LH)	31	Fuel filler hinge A	56	Rear door inner reinforcement (RH,LH)	
7	Front pillar outer reinforcement (RH,LH)	32	Fuel filler hinge B	57	Rear door outer waist reinforcement (RH,LH)	D
8	Front pillar lower hinge brace (RH,LH)	33	Fuel filler plate	58	Rear door glass stopper bracket (RH,LH)	E
9	Front pillar lower gusset (RH,LH)	34	Parcel shelf reinforcement	59	Rear door rear inner sash bracket (RH,LH)	
10	Front pillar lower reinforcement (RH,LH)	35	Child seat anchor reinforcement	60	Rear door guard beam	F
11	Front sill outer reinforcement (RH,LH)	36	Rear upper panel	61	Rear door guard front bracket (RH,LH)	
12	Outer sill reinforcement (RH,LH)	37	Rear bumper fascia center bracket	62	Rear door sash bracket (RH,LH)	G
13	Outer sill brace A	38	Rear bumper bracket A (RH)	63	Hood lock striker outer support	
14	Outer sill brace B	39	Trunk lid outer	64	Hood lock striker base	H
15	Outer sill brace B	40	Trunk lid reinforcement	65	Hood hinge reinforcement (RH,LH)	
16	Center pillar reinforcement (RH,LH)	41	License plate base	66	Rear body side outer (RH,LH)	
17	Center pillar seat belt reinforcement (RH,LH)	42	Trunk lid lock reinforcement	67	Trunk lid assembly	BL
18	Outer roof slide rail reinforcement (RH,LH)	43	Trunk lid hinge reinforcement (RH,LH)	68	Rear door assembly (RH,LH)	
19	Rear fascia bracket B (RH,LH)	44	Outer front door panel (RH,LH)	69	Front door assembly (RH,LH)	J
20	Rear bumper bracket C (RH,LH)	45	Front door inner (RH,LH)	70	Hood assembly	
21	Front fender baffle (RH,LH)	46	Front door inner reinforcement (RH,LH)			K
22	Rear bumper side bracket A	47	Front door inner corner piece (RH,LH)			
23	Rear fender extension (RH,LH)	48	Front door inner waist reinforcement (RH,LH)			L
24	Front inner pillar lower (RH,LH)	49	Front door outer waist reinforcement (RH,LH)			
25	Front inner pillar upper (RH,LH)	50	Front door sash rear bracket (RH,LH)			M

Corrosion Protection


DESCRIPTION

To provide improved corrosion prevention, the following anti-corrosive measures have been implemented in NISSAN production plants. When repairing or replacing body panels, it is necessary to use the same anti-corrosive measures.

ANTI-CORROSIVE PRECOATED STEEL (GALVANNEALED STEEL)

To improve repairability and corrosion resistance, a new type of anti-corrosive precoated steel sheet has been adopted replacing conventional zinc-coated steel sheet.

Galvannealed steel is electroplated and heated to form Zinc-iron alloy, which provides excellent and long term corrosion resistance with cationic electrode position primer.




Nissan Genuine Service Parts are fabricated from galvannealed steel. Therefore, it is recommended that GENUINE NISSAN PARTS or equivalent be used for panel replacement to maintain the anti-corrosive performance built into the vehicle at the factory.

PHOSPHATE COATING TREATMENT AND CATIONIC ELECTRODEPOSITION PRIMER

A phosphate coating treatment and a cationic electrode position primer, which provide excellent corrosion protection, are employed on all body components.

CAUTION:

Confine paint removal during welding operations to an absolute minimum.




Nissan Genuine Service Parts are also treated in the same manner. Therefore, it is recommended that GENUINE NISSAN PARTS or equivalent be used for panel replacement to maintain anti-corrosive performance built into the vehicle at the factory.

BODY REPAIR

ANTI-CORROSIVE WAX

To improve corrosion resistance, anti-corrosive wax is applied inside the body sill and inside other closed sections. Accordingly, when replacing these parts, be sure to apply anti-corrosive wax to the appropriate areas of the new parts. Select an excellent anti-corrosive wax which will penetrate after application and has a long shelf life.



LIIA0266E

BODY REPAIR


UNDERCOATING

The underside of the floor and wheelhouse are undercoated to prevent rust, vibration, noise and stone chipping. Therefore, when such a panel is replaced or repaired, apply undercoating to that part. Use an undercoating which is rust preventive, soundproof, vibration-proof, shock-resistant, adhesive, and durable.

Precautions in undercoating

1. Do not apply undercoating to any place unless specified (such as the areas above the muffler and three way catalyst which are subjected to heat).
2. Do not undercoat the exhaust pipe or other parts which become hot.
3. Do not undercoat rotating parts.
4. Apply bitumen wax after applying undercoating.

 : Indicates undercoated portions.





LIA0129E

Body Sealing
DESCRIPTION


E/IS00119

The following figure shows the areas which are sealed at the factory. Sealant which has been applied to these areas should be smooth and free from cuts or gaps. Care should be taken not to apply an excess amount of sealant and not to allow other unaffected parts to come into contact with the sealant.




LIIA0506E

BODY REPAIR



L1IA0507E



A

B

C

D

E

F

G

H

BL

J

K


L

M

BODY REPAIR

Body Construction
BODY CONSTRUCTION

EIS001A





Section A - A	Section B - B	Section C - C	Section D - D
Section E - E	Section F - F	Section G - G	Section H - H
Section I - I	Section J - J	Section K - K	Section L - L

LIIA0509E

Body Alignment
BODY CENTER MARKS

E/S001/B

A mark has been placed on each part of the body to indicate the vehicle center. When repairing parts damaged by an accident which might affect the vehicle frame (members, pillars, etc.), more accurate and effective repair will be possible by using these marks together with body alignment specifications.





LIA0510E

BODY REPAIR

PANEL PARTS MATCHING MARKS

A mark has been placed on each body panel to indicate the parts matching positions. When repairing parts damaged by an accident which might affect the vehicle structure (members, pillars, etc.), more accurate and effective repair will be possible by using these marks together with body alignment specifications.




LIA0511E

BODY REPAIR

DESCRIPTION



- All dimensions indicated in the figures are actual.
- When using a tracking gauge, adjust both pointers to equal length. Then check the pointers and gauge itself to make sure there is no free play.
- When a measuring tape is used, check to be sure there is no elongation, twisting or bending.
- Measurements should be taken at the center of the mounting holes.
- An asterisk (*) following the value at the measuring point indicates that the measuring point on the other side is symmetrically the same value.
- The coordinates of the measurement points are the distances measured from the standard line of "X", "Y" and "Z".



PIIA0104E







BODY REPAIR

ENGINE COMPARTMENT MEASUREMENT



BODY REPAIR

MEASUREMENT POINTS



A

B

C

D

E

F

G

H

BL

J

K

L

M


BODY REPAIR

UNDERBODY
MEASUREMENT

Figures marked with a (*) indicate symmetrically identical dimensions on both right and left hand sides of the vehicle.


As viewed from underside.

All dimensions indicated in this figure are actual.



L1IA0552E

MEASUREMENT POINTS




Coordinates:

(A) (a)
 X : 494
 Y : -617
 Z : 141
 (B) (b)
 X : 495
 Y : -500
 Z : 357
 (C) (c)
 X : 438
 Y : 122
 Z : 339
 (D) (d)
 X : 309
 Y : 327
 Z : 387
 (E) (e)
 X : 410
 Y : 1140
 Z : 100
 (F) (f)
 X : 407
 Y : 1912
 Z : 91
 (G) (g)
 X : 661
 Y : 2105
 Z : 166
 (H) (h)
 X : 510
 Y : 2587
 Z : 152
 (M) (m)
 X : 497
 Y : 2961
 Z : 338
 (J) (j)
 X : 465
 Y : 3157
 Z : 226
 (K) (k)
 X : 479
 Y : 3636
 Z : 397

Strut tower centers


Coordinates:

(L) (l) Front
 X : 547
 Y : 28
 Z : 791
 (T) (t) Rear
 X : 530
 Y : 2857
 Z : 817



BODY REPAIR









PASSENGER COMPARTMENT MEASUREMENT



LIA0515E

BODY REPAIR


MEASUREMENT POINTS









LIIA0555E

BODY REPAIR

REAR BODY MEASUREMENT



MEASUREMENT POINTS



A
B
C
D
E
F
G
H
BL
J
K
L
M

BODY REPAIR

Handling Precautions for Plastics HANDLING PRECAUTIONS FOR PLASTICS


EIS001C

Abbreviation	Material name	Heatresisting temperature °C (°F)	Resistance to gasoline and solvents	Other cautions
PE	Polyethylene	60 (140)	Gasoline and most solvents are harmless if applied for a very short time (wipe up quickly).	Flammable
PVC	Polyvinyl Chloride	80 (176)	Same as above.	Poison gas is emitted when burned.
EPM/EPDM	Ethylene Propylene (Diene) rubber	80 (176)	Same as above.	Flammable
TPO/TPR	Thermoplastic Olefine/Thermoplastic Rubber	80 (176)	Same as above.	Flammable
PP	Polypropylene	90 (194)	Same as above.	Flammable, avoid battery acid.
UP	Polyester thermoset	90 (194)	Same as above.	Flammable
PS	Polystyrene	80 (176)	Avoid solvents.	Flammable
ABS	Acrylonitrile Butadiene Styrene resin	80 (176)	Avoid gasoline and solvents.	
AES	Acrylonitrile Ethylene Styrene	80 (176)	Same as above.	
PMMA	Polymethyl Methacrylate	85 (185)	Same as above.	
AAS	Acrylonitrile Acrylic Styrene	85 (185)	Same as above.	
AS	Acrylonitrile Styrene	85 (185)	Same as above.	
EVA	Polyvinyl Ethyl Acetate	90 (194)	Same as above.	
ASA	Acrylonitrile Styrene Acrylate	100 (222)	Same as above.	Flammable
PPO/PPE	Polyphenylene Oxide/Polyphenylene Ether	110 (230)	Same as above.	
PC	Polycarbonate	120 (248)	Same as above.	
PAR	Polyacrylate	180 (356)	Same as above.	
L-LDPE	Linear Low Density PE	45 (100)	Gasoline and most solvents are harmless.	Flammable
PUR	Polyurethane	90 (194)	Same as above.	
TPU	Thermoplastic Urethane	110 (230)	Same as above.	
PPC	Polypropylene Composite	115 (239)	Same as above.	Flammable
POM	Polyacetal	120 (248)	Same as above.	Avoid battery acid.
PBT+PC	Polybutylene Terephthalate+Polycarbonate	120 (248)	Same as above.	Flammable
PA	Polyamide (Nylon)	140 (284)	Same as above.	Avoid immersing in water.
PBT	Polybutylene Terephthalate	140 (284)	Same as above.	
FRP	Fiber Reinforced Plastics	170 (338)	Same as above.	Avoid battery acid.
PET	Polyethylene Terephthalate	180 (356)	Same as above.	
PEI	Polyetherimide	200 (392)	Same as above.	

1. When repairing and painting a portion of the body adjacent to plastic parts, consider their characteristics (influence of heat and solvent) and remove them if necessary or take suitable measures to protect them.
2. Plastic parts should be repaired and painted using methods suiting the materials' characteristics.


BODY REPAIR

LOCATION OF PLASTIC PARTS



LIA0517E

BODY REPAIR



BODY REPAIR

Precautions in Repairing High Strength Steel

EIS001D

High strength steel is used for body panels in order to reduce vehicle weight.

Accordingly, precautions in repairing automotive bodies made of high strength steel are described below:

HIGH STRENGTH STEEL (HSS) USED IN NISSAN VEHICLES

Tensile strength	Nissan/Infiniti designation	Major applicable parts
373 N/mm ² (38kg/mm ² ,54klb/sq in)	SP130	● Front side member assembly ● Upper hoodledge ● Upper pillar hinge brace assembly ● Rear side member extension ● Other reinforcements
785-981 N/mm ² (80-100kg/mm ² 114-142klb/sq in)	SP150	● Front bumper reinforcement ● Rear bumper reinforcement


SP130 is the most commonly used HSS.

SP150 HSS is used only on parts that require much more strength.


Read the following precautions when repairing HSS:

1. Additional points to consider


- The repair of reinforcements (such as side members) by heating is not recommended since it may weaken the component. When heating is unavoidable, do not heat HSS parts above 550°C (1,022°F). Verify heating temperature with a thermometer. (Crayon-type and other similar type thermometer are appropriate.)



- When straightening body panels, use caution in pulling any HSS panel. Because HSS is very strong, pulling may cause deformation in adjacent portions of the body. In this case, increase the number of measuring points, and carefully pull the HSS panel.




- When cutting HSS panels, avoid gas (torch) cutting if possible. Instead, use a saw to avoid weakening surrounding areas due to heat. If gas (torch) cutting is unavoidable, allow a minimum margin of 50 mm (1.97in).




BODY REPAIR

- When welding HSS panels, use spot welding whenever possible in order to minimize weakening surrounding areas due to heat. If spot welding is impossible, use M.I.G. welding. Do not use gas (torch) welding because it is inferior in welding strength.




- The spot weld on HSS panels is harder than that of an ordinary steel panel. Therefore, when cutting spot welds on a HSS panel, use a low speed high torque drill (1,000 to 1,200 rpm) to increase drill bit durability and facilitate the operation.
- SP150 HSS panels with a tensile strength of 785 to 981 N/mm² (80 to 100 kg/mm², 114 to 142 klb/sq in), used as reinforcement in the door guard beams, is too strong to repair. When these HSS parts are damaged, the outer panels also sustain substantial damage; therefore, the assembly parts must be replaced.




2. Precautions in spot welding HSS

This work should be performed under standard working conditions. Always note the following when spot welding HSS:

- The electrode tip diameter must be sized properly according to the metal thickness.



- The panel surfaces must fit flush to each other, leaving no gaps.




BODY REPAIR

- Follow the specifications for the proper welding pitch.

Unit:mm

Thickness (t)	Minimum pitch (ℓ)
0.6 (0.024)	10 (0.39) or over
0.8 (0.031)	12 (0.47) or over
1.0 (0.039)	18 (0.71) or over
1.2 (0.047)	20 (0.79) or over
1.6 (0.063)	27 (1.06) or over
1.8 (0.071)	31 (1.22) or over



A
B
C
D
E
F
G
H
BL

J
K
L
M

Replacement Operations

DESCRIPTION

EIS001E










This section is prepared for technicians who have attained a high level of skill and experience in repairing collision-damaged vehicles and also use modern service tools and equipment. Persons unfamiliar with body repair techniques should not attempt to repair collision-damaged vehicles by using this section.

Technicians are also encouraged to read Body Repair Manual (Fundamentals) in order to ensure that the original functions and quality of the vehicle can be maintained. The Body Repair Manual (Fundamentals) contains additional information, including cautions and warnings, that are not including in this manual. Technicians should refer to both manuals to ensure proper repairs.

Please note that this information is prepared for worldwide usage, and as such, certain procedures may not apply in some regions or countries.

BODY REPAIR

The symbols used in this section for cutting and welding / brazing operations are shown below.

 Saw cut or air chisel cut		 		
Spot weld	 2-spot welds		  	
	 3-spot welds			
 MIG plug weld		 		
 MIG seam weld/ Point weld				
 Brazing		 		
 Soldering		 		
 Sealing				

A

B

C

D

E

F

G

H

BL

J


K

L


M

BODY REPAIR


- Front pillar butt joint can be determined anywhere within shaded area as shown in the figure. The best location for the butt joint is at position A due to the construction of the vehicle. Refer to the front pillar section.



- Determine cutting position and record distance from the locating indent. Use this distance when cutting the service part. Cut outer front pillar over 60 mm above inner front pillar cut position.




- Prepare a cutting jig to make outer pillar easier to cut. Also, this will permit service part to be accurately cut at joint position.



- An example of cutting operation using a cutting jig is as follows.

- Mark cutting lines.
A: Cut position of outer pillar
B: Cut position of inner pillar
- Align cutting line with notch on jig. Clamp jig to pillar.
- Cut outer pillar along groove of jig. (At position A)
- Remove jig and cut remaining portions.
- Cut inner pillar at position B in same manner.




BODY REPAIR


HOODLEDGE

- Work after radiator core support has been removed.


Service Joint




2-spot welds



3-spot welds



MIG Plug weld



MIG seam weld/
Point weld




LIIA0540E

BODY REPAIR


HOODLEDGE (PARTIAL REPLACEMENT)

- Work after radiator core support has been removed.


Service Joint





2-spot welds



3-spot welds



MIG Plug weld



MIG seam weld/
Point weld




L1IA0538E

BODY REPAIR


FRONT SIDE MEMBER

- Work after hoodledge and radiator core support have been removed.


Service Joint





2-spot welds



3-spot welds



MIG Plug weld



MIG seam weld/
Point weld




LIIA0539E

BODY REPAIR

FRONT SIDE MEMBER (PARTIAL REPLACEMENT)


- Work after radiator core support has been removed.

Service Joint




Unit: mm


2-spot welds




3-spot welds



MIG Plug weld



For 3 panels plug weld method




MIG seam weld/
Point weld



BODY REPAIR

FRONT PILLAR


- Work after rear hoodedge reinforcement has been removed.




BODY REPAIR

Service Joint


Unit: mm




2-spot welds



3-spot welds



MIG Plug weld



For 3 panels plug weld method



MIG seam weld/
Point weld




LIA0542E

BODY REPAIR

Service Joint

Unit: mm



2-spot welds

3-spot welds

MIG Plug weld

For 3 panels plug weld method


MIG seam weld/
Point weld




LIIA0543E

BODY REPAIR


Service Joint




2-spot welds




3-spot welds



MIG Plug weld



For 3 panels plug weld method



MIG seam weld/
Point weld




L1IA0544E

BODY REPAIR

CENTER PILLAR

Service Joint

Unit: mm






2-spot welds

3-spot welds

MIG Plug weld

For 3 panels plug weld method


MIG seam weld/
Point weld




LIIA0545E

BODY REPAIR


Service Joint





2-spot welds



3-spot welds



MIG Plug weld




MIG seam weld/
Point weld



LIA0546E

BODY REPAIR

OUTER SILL




A
B
C
D
E
F
G
H
BL
J
K
L
M

LIIA0549E

BODY REPAIR

REAR FENDER




LIIA0547E

A
B
C
D
E
F
G
H
BL
J
K
L
M

BL

Service Joint

★ Indicates that there is an equivalent welding portion with the same dimensions on the opposite side




BODY REPAIR

REAR FLOOR REAR


- Work after rear panel has been removed.

Service Joint


★ Indicates that there is an equivalent welding portion with the same dimensions on the opposite side




2-spot welds



3-spot welds



MIG Plug weld



For 3 panels plug weld method




MIG seam weld/
Point weld



BODY REPAIR

REAR SIDE MEMBER EXTENSION

- Work after rear panel and rear end crossmember have been removed.



BODY REPAIR
