

BRC

SECTION

BRAKE CONTROL SYSTEM

CONTENTS

ABS		
PRECAUTIONS	4	
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	4	
Precautions for Brake System	4	
Precautions When Using CONSULT-II	4	
CHECK POINTS FOR USING CONSULT-II	4	
Precautions for Brake Control	5	
Precautions for CAN System	5	
Wiring Diagrams and Trouble Diagnosis	6	
PREPARATION	7	
Special Service Tool	7	
Commercial Service Tools	7	
SYSTEM DESCRIPTION	8	
System Diagram	8	
ABS Function	8	
EBD Function	8	
Wheel Sensors	9	
Fail-Safe Function	9	
ABS/EBD SYSTEM	9	
Hydraulic Circuit Diagram	10	
CAN COMMUNICATION	11	
System Description	11	
TROUBLE DIAGNOSIS	12	
How to Perform Trouble Diagnoses for Quick and Accurate Repair	12	
INTRODUCTION	12	
WORK FLOW	13	
CLARIFY CONCERN	14	
EXAMPLE OF DIAGNOSIS SHEET	14	
Component Parts and Harness Connector Location	15	
Schematic	16	
Wiring Diagram — ABS —	17	
Basic Inspection	21	
BRAKE FLUID LEVEL, FLUID LEAK, AND BRAKE PAD INSPECTION	21	
POWER SYSTEM TERMINAL LOOSENESS AND BATTERY INSPECTION	21	
ABS WARNING LAMP INSPECTION	21	
Warning Lamp and Indicator Timing	21	
Control Unit Input/Output Signal Standard	22	
REFERENCE VALUE FROM CONSULT-II	22	
CONSULT-II Function	24	
CONSULT-II FUNCTION APPLICATION	24	
CONSULT-II BASIC OPERATION PROCEDURE	24	
SELF-DIAGNOSIS	25	
DATA MONITOR	27	
ACTIVE TEST	29	
TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS	31	
Wheel Sensor System Inspection	31	
Engine System Inspection	32	
ABS Control Unit Inspection	33	
Actuator Motor, Motor Relay, and Circuit Inspection	33	
Stop Lamp Switch System Inspection	34	
ABS Control Unit Power and Ground Systems Inspection	35	
CAN Communication System Inspection	36	
TROUBLE DIAGNOSES FOR SYMPTOMS	37	
ABS Works Frequently	37	
Unexpected Pedal Action	38	
Long Stopping Distance	39	
ABS Does Not Work	39	
Pedal Vibration or ABS Operation Noise	39	
ABS Warning Lamp Does Not Come On When Ignition Switch Is Turned On	40	
ABS Warning Lamp Stays On When Ignition Switch Is Turned On	40	
WHEEL SENSORS	41	
Removal and Installation	41	
SENSOR ROTOR	42	
Removal and Installation	42	
REMOVAL	42	
INSTALLATION	42	
ACTUATOR AND ELECTRIC UNIT (ASSEMBLY)	43	
Removal and Installation	43	
REMOVAL	43	
INSTALLATION	43	

TCS/ABS

PRECAUTIONS	45
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	45
Precautions for Brake System	45
Precautions When Using CONSULT-II	45
CHECK POINTS FOR USING CONSULT-II	45
Precautions for Brake Control	46
Precautions for CAN System	46
Wiring Diagrams and Trouble Diagnosis	47
PREPARATION	48
Special Service Tool	48
Commercial Service Tools	48
SYSTEM DESCRIPTION	49
System Diagram	49
ABS Function	49
EBD Function	49
TCS Function	49
Wheel Sensors	50
Fail-Safe Function	50
ABS/EBD SYSTEM	50
TCS SYSTEM	50
Hydraulic Circuit Diagram	51
CAN COMMUNICATION	52
System Description	52
TROUBLE DIAGNOSIS	53
How to Perform Trouble Diagnoses for Quick and Accurate Repair	53
INTRODUCTION	53
WORK FLOW	54
CLARIFY CONCERN	55
EXAMPLE OF DIAGNOSIS SHEET	55
Component Parts and Harness Connector Location..	56
Schematic	57
Wiring Diagram — TCS —	58
Basic Inspection	62
BRAKE FLUID LEVEL, FLUID LEAK, AND BRAKE PAD INSPECTION	62
POWER SYSTEM TERMINAL LOOSENESS AND BATTERY INSPECTION	62
ABS WARNING LAMP AND SLIP INDICATOR LAMP INSPECTION	62
Warning Lamp and Indicator Timing	62
Control Unit Input/Output Signal Standard	63
REFERENCE VALUE FROM CONSULT-II	63
CONSULT-II Function	65
CONSULT-II FUNCTION APPLICATION	65
CONSULT-II BASIC OPERATION PROCEDURE	65
SELF-DIAGNOSIS	66
DATA MONITOR	68
ACTIVE TEST	70
TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS	73
Wheel Sensor System Inspection	73
Engine System Inspection	74
ABS/TCS Control Unit Inspection	75

Actuator Motor, Motor Relay, and Circuit Inspection..	75
Stop Lamp Switch System Inspection	76
ABS/TCS Control Unit Power and Ground Systems Inspection	77
CAN Communication System Inspection	78
TROUBLE DIAGNOSES FOR SYMPTOMS	79
ABS Works Frequently	79
Unexpected Pedal Action	80
Long Stopping Distance	81
ABS Does Not Work	81
Pedal Vibration or ABS Operation Noise	81
ABS Warning Lamp Does Not Come On When Ignition Switch Is Turned On	82
ABS Warning Lamp Stays On When Ignition Switch Is Turned On	82
Vehicle Jerks During TCS Activation	83
WHEEL SENSORS	84
Removal and Installation	84
SENSOR ROTOR	85
Removal and Installation	85
REMOVAL	85
INSTALLATION	85
ACTUATOR AND ELECTRIC UNIT (ASSEMBLY)...	86
Removal and Installation	86
REMOVAL	86
INSTALLATION	86

VDC/TCS/ABS

PRECAUTIONS	88
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	88
Precautions for Brake System	88
Precautions When Using CONSULT-II	88
CHECK POINTS FOR USING CONSULT-II	88
Precautions for Brake Control	89
Precautions for CAN System	89
Wiring Diagrams and Trouble Diagnosis	90
PREPARATION	91
Special Service Tool	91
Commercial Service Tools	91
SYSTEM DESCRIPTION	92
System Components	92
ABS Function	92
EBD Function	92
TCS Function	93
VDC Function	93
Wheel Sensors	94
Fail-Safe Function	94
ABS/EBD SYSTEM	94
VDC/TCS SYSTEM	94
Hydraulic Circuit Diagram	95
CAN COMMUNICATION	96
System Description	96
TROUBLE DIAGNOSIS	97
How to Perform Trouble Diagnoses for Quick and Accurate Repair	97
INTRODUCTION	

WORK FLOW	98	Brake Fluid Level Sensor System Inspection	130	
CLARIFY CONCERN	99	CAN Communication System Inspection	130	A
EXAMPLE OF DIAGNOSIS SHEET	99	Component Inspection	131	
Component Parts and Harness Connector Location	100	VDC OFF SWITCH	131	
Schematic	101	TROUBLE DIAGNOSES FOR SYMPTOMS	132	B
Wiring Diagram — VDC —	102	ABS Works Frequently	132	
Basic Inspection	108	Unexpected Pedal Action	133	
BRAKE FLUID LEVEL, FLUID LEAK, AND		Long Stopping Distance	134	C
BRAKE PAD INSPECTION	108	ABS Does Not Work	134	
POWER SYSTEM TERMINAL LOOSENESS		Pedal Vibration or ABS Operation Noise	134	
AND BATTERY INSPECTION	108	ABS Warning Lamp Does Not Come On When Igni-		D
ABS WARNING LAMP, SLIP INDICATOR LAMP		tion Switch Is Turned On	135	
AND VDC OFF INDICATOR LAMP INSPECTION	108	ABS Warning Lamp Stays On When Ignition Switch		
Warning Lamp and Indicator Timing	108	Is Turned On	135	
Control Unit Input/Output Signal Standard	109	Vehicle Jerks During TCS/VDC Activation	136	E
REFERENCE VALUE FROM CONSULT-II	109	ON-VEHICLE SERVICE	137	
CONSULT-II Function	112	Adjustment of Steering Angle Sensor Neutral Posi-		
CONSULT-II FUNCTION APPLICATION	112	tion	137	
CONSULT-II BASIC OPERATION PROCEDURE		Calibration of Yaw Rate/Side/Decel G Sensor	137	BRC
..	113	WHEEL SENSORS	139	
SELF-DIAGNOSIS	113	Removal and Installation	139	
DATA MONITOR	116	SENSOR ROTOR	140	G
ACTIVE TEST	119	Removal and Installation	140	
TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC		REMOVAL	140	
ITEMS	121	INSTALLATION	140	H
Wheel Sensor System Inspection	121	ACTUATOR AND ELECTRIC UNIT (ASSEMBLY).	141	
Engine System Inspection	122	Removal and Installation	141	
ABS/TCS/VDC Control Unit Inspection	123	REMOVAL	141	I
Steering Angle Sensor System Inspection	123	INSTALLATION	141	
Yaw Rate/Side/Decel G Sensor System Inspection	124	STEERING ANGLE SENSOR	143	
Solenoid and VDC Change-Over Valve System		Removal and Installation	143	J
Inspection	126	G SENSOR	144	
Actuator Motor, Motor Relay, and Circuit Inspection	127	Removal and Installation	144	
Stop Lamp Switch System Inspection	128	REMOVAL	144	
ABS/TCS/VDC Control Unit Power and Ground		INSTALLATION	144	K
Systems Inspection	129			

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EFS002PT

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:


- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for Brake System

EFS002PU

CAUTION:

- Recommended fluid is brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- To clean or wash all parts of master cylinder and disc brake caliper, use clean brake fluid.
- Never use mineral oils such as gasoline or kerosene. They will ruin rubber parts of the hydraulic system.
- Use flare nut wrench when removing and installing brake tube.
- If a brake fluid leak is found, the part must be disassembled without fail. Then it has to be replaced with a new one if a defect exists.
- Turn the ignition switch OFF and remove the connector of the ABS actuator control unit or the battery terminal before performing the work.
- Always torque brake lines when installing.
- Burnish the brake contact surfaces after refinishing or replacing rotors, after replacing pads, or if a soft pedal occurs at very low mileage.
Refer to [BR-28, "Brake Burnishing"](#) (front disc brake) or [BR-35, "Brake Burnishing"](#) (Rear disc brake).



SBR686C

WARNING:

- Clean brake pads and shoes with a waste cloth, then wipe with a dust collector.

Precautions When Using CONSULT-II

EFS0031O

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

CHECK POINTS FOR USING CONSULT-II

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
 - If YES, GO TO 2.
 - If NO, GO TO 5.

2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
 - If YES, GO TO 3.
 - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-8, "CAN COMMUNICATION"](#).

Precautions for Brake Control


EFS002UZ

- During ABS operation, the brake pedal may vibrate lightly and a mechanical noise may be heard. This is normal.
- Just after starting vehicle, the brake pedal may vibrate or a motor operating noise may be heard from engine compartment. This is a normal status of operation check.
- Stopping distance may be longer than that of vehicles without ABS when vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for simple causes before starting diagnosis. Besides electrical system inspection, check booster operation, brake fluid level, and fluid leaks.
- If incorrect tire sizes or types are installed on the vehicle or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- If there is a radio, antenna or related wiring near control module, ABS function may have a malfunction or error.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits or improper wiring.


Precautions for CAN System

EFS002V2

- Do not apply voltage of 7.0V or higher to terminal to be measured.
- Maximum open terminal voltage of tester in use must be less than 7.0V.
- Before checking harnesses, turn ignition switch OFF and disconnect battery negative cable.
- Area to be repaired must be soldered and wrapped with tape. Make sure that fraying of twisted wire is within 110 mm (4.33 in).



- Do not make a bypass connection to repaired area. (If the circuit is bypassed, characteristics of twisted wire will be lost.)



Wiring Diagrams and Trouble Diagnosis

When you read wiring diagrams, refer to the following:

- [GI-12, "How to Read Wiring Diagrams"](#)
- [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#)

When you perform trouble diagnosis, refer to the following:

- [GI-10, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#)
- [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#)

PREPARATION

[ABS]

PREPARATION


PFP:00002

Special Service Tool

EFS002VV

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.


Tool number (Kent-Moore No.) Tool name	Description
(J-45741) ABS active wheel sensor tester	Checking operation of ABS active wheel sensor



Commercial Service Tools

EFS002VW


Tool name	Description
1. Flare nut crowfoot a: 10mm (0.39 in)/12mm (0.47 in) 2. Torque wrench	Removing and installing brake piping



SYSTEM DESCRIPTION

System Diagram

EFS002VF



WFIA0118E

ABS Function

EFS002VG

- The Anti-Lock Brake System detects wheel revolution while braking and improves handling stability during sudden braking by electrically preventing wheel lockup. Maneuverability is also improved for avoiding obstacles.
- If the electrical system malfunctions, the Fail-Safe function is activated, the ABS becomes inoperative and the ABS warning lamp turns on.
- The electrical system can be diagnosed using CONSULT-II.
- During ABS operation, the brake pedal may vibrate lightly and a mechanical noise may be heard. This is normal.
- Just after starting the vehicle, the brake pedal may vibrate or a motor operating noise may be heard from engine compartment. This is a normal status of operation check.
- Stopping distance may be longer than that of vehicles without ABS when vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.


EBD Function

EFS002VH


- Electronic Brake Distribution is a function that detects subtle slippages between the front and rear wheels during braking, and it improves handling stability by electronically controlling the brake fluid pressure which results in reduced rear wheel slippage.
- If the electrical system malfunctions, the Fail-Safe function is activated, the EBD and ABS become inoperative, and the ABS warning lamp and BRAKE warning lamp are turned on.
- The electrical system can be diagnosed using CONSULT-II.
- During EBD operation, the brake pedal may vibrate lightly and a mechanical noise may be heard. This is normal.
- Just after starting the vehicle, the brake pedal may vibrate or a motor operating noise may be heard from engine compartment. This is a normal status of operation check.
- Stopping distance may be longer than that of vehicles without EBD when vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.

Wheel Sensors

The front sensor units consist of a gear-shaped sensor rotor and a sensor element. The element contains a magnet around which a coil is wound. The front wheel sensors are installed on the front of the wheel knuckles. As the wheel rotates, the sensor generates a square-wave signal. The frequency increases as the wheel speed increases.



The rear sensor units consist of wheel hubs with a series of internal magnets and a sensor element. The rear wheel sensors are installed on the inner side of the wheel knuckles. As the wheel rotates, the sensor generates a square-wave signal. The frequency increases as the wheel speed increases.



Fail-Safe Function

CAUTION:

If the Fail-Safe function is activated, perform the Self Diagnosis for ABS system.

ABS/EBD SYSTEM

In case of an electrical malfunction with the ABS, the ABS warning lamp will turn on. In case of an electrical malfunction with the EBD system, the BRAKE warning lamp and the ABS warning lamp will turn on. The system will revert to one of the following conditions of the Fail-Safe function.


1. For ABS malfunction, only the EBD is operative and the condition of the vehicle is the same condition of vehicles without ABS system.
2. For EBD malfunction, the EBD and ABS become inoperative, and the condition of the vehicle is the same as the condition of vehicles without ABS or EBD system.

SYSTEM DESCRIPTION

[ABS]

Hydraulic Circuit Diagram

EFS002VL



CAN COMMUNICATION

PFP:23710

System Description

EFS002W0

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Refer to [LAN-8, "CAN COMMUNICATION"](#) .

A

B

C

D

E

BRC

G

H

I

J

K

L

M

TROUBLE DIAGNOSIS**How to Perform Trouble Diagnoses for Quick and Accurate Repair**
INTRODUCTION



The ABS system has an electronic control unit to control major functions. The control unit accepts input signals from sensors and controls actuator operation. It is also important to check for conventional problems such as air leaks in the booster or lines, lack of brake fluid, or other problems with the brake system.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electrical connections or faulty wiring. In this case, careful checking of suspicious circuits may help prevent the replacement of good parts.


A visual check only may not find the cause of the problem, so a road test should be performed.

Before undertaking actual checks, take just a few minutes to talk with a customer who approaches with an ABS complaint. The customer is a very good source of information on such problems, especially intermittent ones. Through the talks with the customer, find out what symptoms are present and under what conditions they occur.

Start your diagnosis by looking for "conventional" problems first. This is one of the best ways to troubleshoot brake problems on an ABS equipped vehicle. Also check related Service Bulletins for information.



WORK FLOW



CLARIFY CONCERN

- A customer's description of a vehicle concern may vary depending on the individual. It is important to clarify the customer's concern.
- Ask the customer about what symptoms are present under what conditions. Use this information to reproduce the symptom while driving.
- It is also important to use the diagnosis sheet to understand what type of trouble the customer is having.

KEY POINTS

WHAT Vehicle model
WHEN Date, Frequencies
WHERE Road conditions
HOW Operating conditions,
 Weather conditions,
 Symptoms

SBR339B








EXAMPLE OF DIAGNOSIS SHEET

Customer name	Model & Year		VIN
Engine #	Trans.		Mileage
Incident Date	Manuf. Date		In Service Date
Symptoms	☐ Noise and vibration (from engine compartment)	☐ ABS warning lamp activates	☐ Pedal operation
	☐ Noise and vibration (from axle)	☐ SLIP warning lamp activates	☐ Large stroke pedal operation
	☐ TCS does not work (drive wheels slip when accelerating)	☐ ABS does not work (wheels slip when braking)	☐ Firm pedal
	☐ Lack of sense of acceleration		
Engine conditions	☐ When starting ☐ After starting		
Road conditions	☐ Low friction road (☐ Snow ☐ Gravel ☐ Other) ☐ Bumps/potholes		
Driving conditions	☐ Full-acceleration ☐ High speed cornering ☐ Vehicle speed: Greater than 10 km/h (6 MPH) ☐ Vehicle speed: 10 km/h (6 MPH) or less ☐ Vehicle is stopped		
Applying brake conditions	☐ Suddenly ☐ Gradually		
Other conditions	☐ Operation of electrical equipment ☐ Shift change ☐ Other descriptions		

WFIA0097E


Component Parts and Harness Connector Location

EFS002Z4



Schematic

EFS002Z5





WFWA0016E

Wiring Diagram — ABS —




EFS002Z6

BRC-ABS-01





REFER TO THE FOLLOWING.
(E30) - FUSE BLOCK -
JUNCTION BOX (J/B)




BRC-ABS-02



BRC-ABS-03

 : DATA LINE


BRC-ABS-04



Refer to the following.
(M4) - FUSE BLOCK -
 JUNCTION BOX (J/B)

Basic Inspection**BRAKE FLUID LEVEL, FLUID LEAK, AND BRAKE PAD INSPECTION**

1. Check fluid level in the brake fluid reservoir. If fluid level is low, add fluid.
2. Check the brake piping and around the ABS actuator and electric unit (control unit) for leaks. If there is leaking or seeping fluid, check the following items.
 - If ABS actuator and electric unit (control unit) connection is loose, tighten the piping to the specified torque and recheck for leaks.
 - If there is damage to the connection flare nut or ABS actuator and electric unit (control unit) screw, replace the damaged part and recheck for leaks.
 - When there is fluid leaking or seeping from a fluid connection, use a clean cloth to wipe off the fluid and recheck for leaks. If fluid is still seeping out, replace the damaged part. If the fluid is leaking at the ABS actuator and electric unit (control unit), replace the ABS actuator and electric unit (control unit) assembly.

CAUTION:

The ABS actuator and electric unit (control unit) cannot be disassembled and must be replaced as an assembly.

3. Check the brake pads for excessive wear.

POWER SYSTEM TERMINAL LOOSENESS AND BATTERY INSPECTION

Make sure the battery positive cable, negative cable and ground connection are not loose. In addition, make sure the battery is sufficiently charged.

ABS WARNING LAMP INSPECTION

1. Make sure ABS warning lamp turns on for approximately 1 second when the ignition switch is turned ON. Check CAN communications. If there are no errors with CAN communication system, check combination meter. Refer to [DI-5, "COMBINATION METERS"](#).
2. Make sure the lamp turns off approximately 1 second after the ignition switch is turned ON. If the lamp does not turn off, conduct self-diagnosis.
3. Make sure ABS warning lamp turns off approximately 2 seconds after the engine is started. If ABS warning lamp has not turned off 10 seconds after the engine has been started, conduct self-diagnosis of the ABS actuator and electric unit (control unit).
4. After conducting the self-diagnosis, be sure to erase the error memory. Refer to [BRC-24, "CONSULT-II Function"](#).

Warning Lamp and Indicator Timing

× : ON – : Lamp OFF

Condition	ABS warning lamp	Remarks
When the ignition switch is OFF	–	–
After the ignition switch is turned ON For approx. 0.5 seconds	×	–
Ignition switch ON Approx. 0.5 seconds later	–	Lamp goes off approx. 2 seconds after the engine start.
ABS malfunction	×	–
	×	When the ABS control unit is malfunctioning (power supply or ground malfunction).

TROUBLE DIAGNOSIS

[ABS]

EFS00229

Control Unit Input/Output Signal Standard REFERENCE VALUE FROM CONSULT-II

CAUTION:

The display shows the control unit calculation data, so a normal value might be displayed even in the event the output circuit (harness) is open or short circuited.

Monitor item	Display content	Data monitor		Note: Error inspection checklist
		Condition	Reference value in normal operation	
SLCT LVR POSI	PNP switch signal ON/OFF condition	A/T shift position = N or P position	ON	BRC-36, "CAN Communication System Inspection"
		A/T shift position = other than N and P positions	OFF	
GEAR	A/T gear position	1:1st gear 2:2nd gear 3:3rd gear 4:4th gear		BRC-36, "CAN Communication System Inspection"
FR RH SENSOR FR LH SENSOR RR RH SENSOR RR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]	BRC-31, "Wheel Sensor System Inspection"
		Vehicle running (Note 1)	Almost in accordance with speedometer display (within $\pm 10\%$)	
ACCEL POS SIG	Open/close condition of throttle valve (linked with accelerator pedal).	Accelerator pedal not depressed (ignition switch is ON)	0%	BRC-36, "CAN Communication System Inspection"
		Depress accelerator pedal (ignition switch is ON)	0 to 100%	
ENGINE SPEED	With engine running	With engine stopped	0 rpm	BRC-32, "Engine System Inspection"
		Engine running	Almost in accordance with tachometer display	
BATTERY VOLT	Battery voltage supplied to ABS actuator and electric unit (control unit)	Ignition switch ON	10 to 16V	BRC-35, "ABS Control Unit Power and Ground Systems Inspection"
STOP LAMP SW	Brake pedal operation	Brake pedal depressed	ON	BRC-34, "Stop Lamp Switch System Inspection"
		Brake pedal not depressed	OFF	
ABS WARN LAMP	ABS warning lamp ON condition (Note 2)	ABS warning lamp ON	ON	BRC-40, "ABS Warning Lamp Does Not Come On When Ignition Switch Is Turned On"
		ABS warning lamp OFF	OFF	
MOTOR RELAY	Operation status of motor and motor relay	Ignition switch ON or engine running (ABS not operated)	OFF	BRC-33, "Actuator Motor, Motor Relay, and Circuit Inspection"
		Ignition switch ON or engine running (ABS operated)	ON	
ACTUATOR RLY	Actuator relay operation status	Vehicle stopped (Ignition switch ON)	OFF	BRC-33, "Actuator Motor, Motor Relay, and Circuit Inspection"
		Vehicle stopped (Engine running)	ON	
FR LH IN SOL FR LH OUT SOL FR RH IN SOL FR RH OUT SOL RR RH IN SOL RR RH OUT SOL RR LH IN SOL RR LH OUT SOL	Solenoid valve operation	Actuator (solenoid) is active ("ACTIVE TEST" with CONSULT-II) or actuator relay is inactive (in fail-safe mode).	ON	—
		When actuator (solenoid) is not active and actuator relay is active (ignition switch ON).	OFF	

TROUBLE DIAGNOSIS

[ABS]

Monitor item	Display content	Data monitor		Note: Error inspection checklist
		Condition	Reference value in normal operation	
FLUID LEV SW	ON/OFF status of brake fluid level switch	When brake fluid level switch ON	ON	DI-45, "WARNING LAMPS"
		When brake fluid level switch OFF	OFF	
ABS FAIL SIG EBD FAIL SIG	Fail signal status	ABS fail EBD fail	OFF	ABS system EBD system

Note 1: Confirm tire pressure is normal.

Note 2: ON/OFF timing of ABS warning lamp

ON: For approximately 1.8 seconds after ignition switch is turned ON, or when a malfunction is detected.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

CONSULT-II Function

CAUTION:

- When the self-diagnosis, data monitor, or active test functions are being executed, EBD and ABS control is disabled.
- When using CONSULT-II to conduct ABS control unit self-diagnosis, active test, work support, etc., first stop engine, connect the CONSULT-II, and select "ABS".
- CONSULT-II self-diagnosis results are displayed without regard to occurrence timing. In some cases later ones (timing value is small) appear on the next screen.
- When an error is shown by the CONSULT-II SELF-DIAG RESULTS and CONSULT-II is used to conduct an active test, an engine system malfunction may be shown, but restarting the engine will return the status to normal.

CONSULT-II FUNCTION APPLICATION

Item	Self-diagnosis	Data monitor	Active test
Wheel sensors	×	×	—
Stop lamp switch	×	×	—
Solenoid valves	×	×	×
Actuator relay	×	×	×
Motor relay	×	×	×
ABS warning lamp	—	×	—
Battery voltage	×	×	—
ABS actuator and electric unit (control unit)	×	—	—
ABS actuator motor	×	×	×
CAN communication	×	—	—
Engine speed signal	×	×	—
Throttle angle	—	×	—
Gear	—	×	—
Selector lever position	—	×	—
EBD/ABS signals	×	×	—
Brake fluid level switch	×	×	—

×: Applicable

—: Not applicable


CONSULT-II BASIC OPERATION PROCEDURE

1. Turn ignition switch OFF.
2. Connect CONSULT-II and CONSULT-II CONVERTER to the data link connector.


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


3. Turn ignition switch ON.



- Touch "START (NISSAN BASED VHCL)".



- Touch "ABS" in the "Diagnosis System Selection" screen.
If "ABS" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



- Select the required diagnostic location from the "Diagnosis Mode Selection" screen.
For further information, see the CONSULT-II Operation Manual.

SELF-DIAGNOSIS

Description

If an error is detected in the system, the ABS warning lamp will turn on. In this case, perform self-diagnosis as follows:

Operation Procedure

- Turn ignition switch OFF.
- Connect CONSULT-II and CONSULT-II CONVERTER to the data link connector.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

- Turn ignition switch ON.
- Start engine and drive at approximately 30 km/h (19 MPH) for approximately 1 minute.
- After stopping the vehicle, with the engine running, touch "START (NISSAN BASED VHCL)", "ABS", "SELF-DIAG RESULTS" in order on the CONSULT-II screen.

CAUTION:

If "START (NISSAN BASED VHCL)" is touched immediately after starting the engine or turning on the ignition switch, "ABS" might not be displayed in the System Selection screen. In this case, repeat the operation from step 1.

- The self-diagnostic results are displayed. (If necessary, the self-diagnostic results can be printed out by touching "COPY".)

- When "NO FAILURE" is displayed, check the ABS warning lamp.

- Conduct the appropriate inspection from the display item list, and repair or replace the malfunctioning component.

- Start engine and drive at approximately 30 km/h (19 MPH) for approximately 1 minute.

CAUTION:

- When a wheel sensor "short-circuit" is detected, if the vehicle is not driven at 30 km/h (19 MPH) for at least 1 minute, the ABS warning lamp will not turn off even if the malfunction is repaired.

- Turn ignition switch OFF to prepare for erasing the memory.

10. Start the engine and touch "START (NISSAN BASED VHCL)", "ABS", "SELF-DIAG RESULTS", "ERASE MEMORY" in order on the CONSULT-II screen to erase the error memory.
If "ABS" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).

CAUTION:

If the error memory is not erased, re-conduct the operation from step 5.

11. For the final inspection, drive at approximately 30 km/h (19 MPH) for approximately 1 minute and confirm that the ABS warning lamp are off.

Display Item List

Self-diagnostic item	Malfunction detecting condition	Check system
FR LH SENSOR 1 [C1104]	Circuit of front LH wheel sensor is open	BRC-31, "Wheel Sensor System Inspection" (Note 1)
RR RH SENSOR 1 [C1101]	Circuit of rear RH wheel sensor is open	
FR RH SENSOR 1 [C1103]	Circuit of front RH wheel sensor is open	
RR LH SENSOR 1 [C1102]	Circuit of rear LH wheel sensor is open	
FR LH SENSOR 2 [C1108]	Circuit of front LH wheel sensor is shorted, or sensor power voltage is unusual. ABS actuator and electric unit (control unit) cannot identify sensor pulses, because of large gap between wheel sensor and sensor rotor.	
RR RH SENSOR 2 [C1105]	Circuit of rear RH wheel sensor is shorted, or sensor power voltage is unusual. ABS actuator and electric unit (control unit) cannot identify sensor pulses, because of large gap between wheel sensor and sensor rotor.	
FR RH SENSOR 2 [C1107]	Circuit of front RH wheel sensor is shorted, or sensor power voltage is unusual. ABS actuator and electric unit (control unit) cannot identify sensor pulses, because of large gap between wheel sensor and sensor rotor.	
RR LH SENSOR 2 [C1106]	Circuit of rear LH wheel sensor is shorted, or sensor power voltage is unusual. ABS actuator and electric unit (control unit) cannot identify sensor pulses, because of large gap between wheel sensor and sensor rotor.	BRC-34, "Stop Lamp Switch System Inspection"
STOP LAMP SW 1 [C1116]	Stop lamp switch or circuit malfunction.	
FR LH IN ABS SOL [C1120]	Circuit of front LH IN ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
FR LH OUT ABS SOL [C1121]	Circuit of front LH OUT ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
RR RH IN ABS SOL [C1126]	Circuit of rear RH IN ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
RR RH OUT ABS SOL [C1127]	Circuit of rear RH OUT ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
FR RH IN ABS SOL [C1122]	Circuit of front RH IN ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
FR RH OUT ABS SOL [C1123]	Circuit of front RH OUT ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
RR LH IN ABS SOL [C1124]	Circuit of rear LH IN ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
RR LH OUT ABS SOL [C1125]	Circuit of rear LH OUT ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	

TROUBLE DIAGNOSIS

[ABS]

Self-diagnostic item	Malfunction detecting condition	Check system
PUMP MOTOR (Note 3) [C1111]	During actuator motor operation with ON, when actuator motor turns OFF or when control line for actuator motor relay is open.	BRC-33, "Actuator Motor, Motor Relay, and Circuit Inspection"
	During actuator motor operation with OFF, when actuator motor turns ON or when control line for relay is shorted to ground.	
BATTERY VOLTAGE [ABNORMAL] [C1109]	ABS actuator and electric unit (control unit) power voltage is too low.	BRC-35, "ABS Control Unit Power and Ground Systems Inspection"
CONTROLLER FAILURE [C1110]	Internal malfunction of ABS actuator and electric unit (control unit)	BRC-33, "ABS Control Unit Inspection"
CAN COMM CIRCUIT [U1000]	- CAN communication line is open or shorted. - ABS actuator and electric unit (control unit) internal malfunction - Battery voltage for ECM is suddenly interrupted for approximately 0.5 seconds or more.	BRC-36, "CAN Communication System Inspection" (Note 2)
BR FLUID LEVEL LOW [C1155]	Brake fluid level drops or circuit between ABS actuator and electric unit (control unit) and brake fluid level switch is open or shorted.	DI-45, "WARNING LAMPS"
ENGINE SPEED SIG	Engine speed signal from ECM is abnormal.	BRC-32, "Engine System Inspection"
ENGINE SIGNAL 1 [C1130]	ECM judges the communication between ABS control unit and ECM is abnormal.	BRC-36, "CAN Communication System Inspection"
STOP LAMP SW 2 [C1176]	ASCD brake switch or circuit malfunction.	EC-656, "ASCD BRAKE SWITCH"

Note 1. If wheel sensor 2 for each wheel is indicated, check ABS actuator and electric unit (control unit) power supply voltage in addition to wheel sensor circuit check.

Note 2. If multiple malfunctions are detected including CAN communication line [U1000], perform diagnosis for CAN communication line first.

Note 3: "ACTUATOR RLY" on the CONSULT-II self-diagnosis results indicates the malfunction of the actuator motor relay or circuit.

DATA MONITOR

Operation Procedure

- After turning OFF the ignition switch, connect CONSULT-II and the CONVERTER to the data link connector.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

- Touch "START (NISSAN BASED VHCL)", "ABS", "DATA MONITOR" in order on the CONSULT-II screen. If "ABS" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).

CAUTION:

When "START (NISSAN BASED VHCL)" is touched immediately after starting the engine or turning on the ignition switch, "ABS" might not be displayed in the system selection screen. In this case, repeat the operation from step 2.

- Return to the Monitor Item Selection screen, and touch "C/U INPUT ITEM", "MAIN ITEM" or "ITEM MENU SELECTION". Refer to the following information.
- When "START" is touched, the data monitor screen is displayed.

TROUBLE DIAGNOSIS

[ABS]

Display Item List

Item (Unit)	Data monitor item selection				Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	CAN DIAG SUPPORT MNTR	
GEAR	×	×	×	—	Gear position judged by PNP switch signal is displayed.
FR RH SENSOR (km/h, MPH)	×	×	×	—	Wheel speed calculated by front RH wheel sensor signal is displayed.
FR LH SENSOR (km/h, MPH)	×	×	×	—	Wheel speed calculated by front LH wheel sensor signal is displayed.
RR RH SENSOR (km/h, MPH)	×	×	×	—	Wheel speed calculated by rear RH wheel sensor signal is displayed.
RR LH SENSOR (km/h, MPH)	×	×	×	—	Wheel speed calculated by rear LH wheel sensor signal is displayed.
BATTERY VOLT (V)	×	×	×	—	Voltage supplied to ABS actuator and electric unit (control unit) is displayed.
SLCT LVR POSI	×	×	×	—	Shift position judged by PNP switch signal.
ACCEL POS SIG (%)	×	—	×	—	Throttle valve open/close status judged by LAN communication signal is displayed.
ENGINE SPEED (rpm)	×	×	×	—	Engine speed judged by LAN communication signal is displayed.
STOP LAMP SW (ON/OFF)	×	×	×	—	Stop lamp switch (ON/OFF) status is displayed.
ABS WARN LAMP (ON/OFF)	—	×	×	—	ABS warning lamp (ON/OFF) status is displayed.
FR LH IN SOL (ON/OFF)	—	×	×	—	Front LH IN ABS solenoid (ON/OFF) status is displayed.
FR LH OUT SOL (ON/OFF)	—	×	×	—	Front LH OUT ABS solenoid (ON/OFF) status is displayed.
RR RH IN SOL (ON/OFF)	—	×	×	—	Rear RH IN ABS solenoid (ON/OFF) status is displayed.
RR RH OUT SOL (ON/OFF)	—	×	×	—	Rear RH OUT ABS solenoid (ON/OFF) status is displayed.
FR RH IN SOL (ON/OFF)	—	×	×	—	Front RH IN ABS solenoid (ON/OFF) status is displayed.
FR RH OUT SOL (ON/OFF)	—	×	×	—	Front RH OUT ABS solenoid (ON/OFF) status is displayed.
RR LH IN SOL (ON/OFF)	—	×	×	—	Rear LH IN ABS solenoid (ON/OFF) status is displayed.
RR LH OUT SOL (ON/OFF)	—	×	×	—	Rear LH OUT ABS solenoid (ON/OFF) status is displayed.
MOTOR RELAY (ON/OFF)	—	×	×	—	ABS motor relay signal (ON/OFF) status is displayed.
ACTUATOR RLY (ON/OFF)	—	×	×	—	ABS actuator relay signal (ON/OFF) status is displayed.

TROUBLE DIAGNOSIS

[ABS]

Item (Unit)	Data monitor item selection				Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	CAN DIAG SUPPORT MNTR	
ABS FAIL SIG (ON/OFF)	—	—	×	—	ABS fail signal (ON/OFF) status is displayed.
EBD FAIL SIG (ON/OFF)	—	—	×	—	EBD fail signal (ON/OFF) status is displayed.
FLUID LEV SW (ON/OFF)	×	—	×	—	Brake fluid level switch (ON/OFF) status is displayed.
EBD SIGNAL (ON/OFF)	—	—	×	—	EBD operation (ON/OFF) status is displayed.
ABS SIGNAL (ON/OFF)	—	—	×	—	ABS operation (ON/OFF) status is displayed.
CAN COMM (OK/NG)	—	—	—	×	CAN communication signal (OK/NG) status is displayed.
CAN CIRC 1 (OK/UNKWN)	—	—	—	×	CAN communication signal (OK/UNKWN) status is displayed.
CAN CIRC 2 (OK/UNKWN)	—	—	—	×	
CAN CIRC 3 (OK/UNKWN)	—	—	—	×	
CAN CIRC 4 (OK/UNKWN)	—	—	—	×	
CAN CIRC 5 (OK/UNKWN)	—	—	—	×	
CAN CIRC 6 (OK/UNKWN)	—	—	—	×	
CAN CIRC 7 (OK/UNKWN)	—	—	—	×	
CAN CIRC CLC (OK/UNKWN)	—	—	—	×	
TRQ MAP S/C	—	—	×	—	S/C is selected for engine torque map
TRQ MAP N/A	—	—	×	—	N/A is selected for engine

×: Applicable

—: Not applicable

ACTIVE TEST

CAUTION:

- Do not perform active test while driving.
- Make sure to completely bleed air from the brake system.
- The ABS and brake (EBD) warning lamps turn on during the active test.

Operation Procedure

1. Connect the CONSULT-II and CONVERTER to the data link connector and start the engine.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

2. Touch "START (NISSAN BASED VHCL)" on the display screen.
3. Touch "ABS".
If "ABS" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).
4. Touch "ACTIVE TEST".

TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS**Wheel Sensor System Inspection****INSPECTION PROCEDURE****1. CONNECTOR INSPECTION**

Disconnect the ABS actuator and electric unit connector E125 and wheel sensor of malfunctioning code. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

OK >> GO TO 2.

NG >> Repair or replace as necessary.

2. CHECK WHEEL SENSOR OUTPUT SIGNAL

1. Disconnect connectors from wheel sensor of malfunction code No.
2. Connect ABS active wheel sensor tester (J-45741) to wheel sensor using appropriate adapter.
3. Turn on the ABS active wheel sensor tester power switch.

NOTE:

The green POWER indicator should illuminate. If the POWER indicator does not illuminate, replace the battery in the ABS active wheel sensor tester before proceeding.

4. Spin the wheel of the vehicle by hand and observe the red SENSOR indicator on the ABS active wheel sensor tester. The red SENSOR indicator should flash on and off to indicate an output signal.

NOTE:

If the red SENSOR indicator illuminates but does not flash, reverse the polarity of the tester leads and retest.

Does the ABS active wheel sensor tester detect a signal?

Yes >> GO TO 3.

No >> GO TO 6.

3. CHECK TIRES

Check for inflation pressure, wear and size of each tire.

Are tire pressure and size correct and is tire wear within specifications?

Yes >> GO TO 4.

No >> Adjust tire pressure or replace tire(s).

4. CHECK WHEEL BEARINGS

Check wheel bearing axial end play. Refer to [FAX-5, "FRONT WHEEL BEARING"](#) or [RAX-5, "REAR WHEEL BEARING"](#).

OK or NG

OK >> GO TO 5.

NG >> Repair as necessary. Refer to [FAX-5, "FRONT WHEEL BEARING"](#) or [RAX-5, "REAR WHEEL BEARING"](#).

5. CHECK SENSOR ROTORS

Check sensor rotors for teeth damage.

OK or NG

OK >> GO TO 6.

NG >> Replace sensor rotor. Refer to [BRC-140, "Removal and Installation"](#).

6. CHECK WIRING HARNESS FOR SHORT CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector and wheel sensor connector of malfunction code No.
2. Check resistance between harness connector terminal and ground.

Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Repair the circuit.



7. CHECK WIRING HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and wheel sensor connector of malfunction code No.
2. Check continuity between both wiring harness ends.

Sensor	ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
	Connector - terminal	Wire color	Connector - terminal	Wire color	
Front LH	E125 - 22	G	E18 - 1	G	Yes
	E125 - 7	R	E18 - 2	R	
Front RH	E125 - 24	B	E117 - 1	B	
	E125 - 9	W	E117 - 2	W	
Rear LH	E125 - 11	P	B123 - 1	P	
	E125 - 26	L	B123 - 2	L	
Rear RH	E125 - 13	V	B122 - 1	V	
	E125 - 28	LG	B122 - 2	LG	

Continuity should exist.

OK or NG

OK >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-86, "Removal and Installation"](#).

NG >> Repair the circuit.

Engine System Inspection

EFS0030A

INSPECTION PROCEDURE

1. SELF-DIAGNOSIS RESULT CHECK

Check self-diagnosis results.

Self-diagnosis results
ENGINE SIGNAL 1
ENGINE SIGNAL 2
ENGINE SIGNAL 3
ENGINE SIGNAL 4
ENGINE SIGNAL 6

Is the above displayed in the self-diagnosis display items?

Yes >> GO TO 2.

No >> **INSPECTION END.**

2. ENGINE SYSTEM INSPECTION

1. Perform ECM self-diagnosis and repair as necessary.
2. Perform ABS actuator and electric unit (control unit) self-diagnosis again.

OK or NG

OK >> **INSPECTION END.**

NG >> Repair as necessary.

ABS Control Unit Inspection

EFS0030B

INSPECTION PROCEDURE**1. SELF-DIAGNOSIS RESULT CHECK**

Check self-diagnosis results.

Self-diagnosis results

CONTROLLER FAILURE

Is the above displayed in the self-diagnosis display items?

Yes >> Replace ABS actuator and electric unit. Refer to [BRC-86, "Removal and Installation"](#).No >> **INSPECTION END.****Actuator Motor, Motor Relay, and Circuit Inspection**

EFS0030C

INSPECTION PROCEDURE**1. CHECKING SELF-DIAGNOSIS RESULTS**

Check self-diagnosis results.

Self-diagnosis results

CONSULT-II display items

PUMP MOTOR

Does "PUMP MOTOR" appear in self-diagnosis results display?

Yes >> GO TO 2.

No >> **INSPECTION END.****2. CONNECTOR INSPECTION**

Disconnect the ABS actuator and electric unit connector E125.

Check the terminals for deformation, disconnection, looseness or damage.

OK or NG


OK >> GO TO 3.

NG >> Repair or replace as necessary.

3. CHECKING ABS MOTOR AND MOTOR RELAY POWER SYSTEM


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check voltage between ABS actuator and electric unit (control unit) connector E125 and body ground.

ABS actuator and electric unit (control unit) connector E125	Body ground	Measured value (Approx.)
1 (R/B)	—	12V



3. Check resistance between ABS actuator and electric unit (control unit) connector E125 and ground.

ABS actuator and electric unit (control unit) connector E125	Body ground	Measured value (Approx.)
30 (B)	—	0Ω



OK or NG

OK >> Perform self-diagnosis again. If the same result appears, replace ABS actuator and electric unit (control unit). Refer to [BRC-86, "Removal and Installation"](#).

NG >> Repair the circuit.

Stop Lamp Switch System Inspection

EFS0030E

INSPECTION PROCEDURE

1. SELF-DIAGNOSIS RESULT CHECK

Check self-diagnosis results.

Self-diagnosis results
STOP LAMP SW

Is the above displayed in the self-diagnosis display items?

Yes >> GO TO 2.

No >> **INSPECTION END.**

2. CONNECTOR INSPECTION

1. Turn off the ignition switch and disconnect the ABS actuator and electric unit connector E125 and stop lamp switch connector E38.
2. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace as necessary.

3. STOP LAMP SWITCH INSPECTION

Turn the ignition switch on and check the voltage between the ABS actuator and electric unit connector E125 terminal 17 (R/G) and ground.

17 (R/G) - Ground


Brake pedal depressed : Battery voltage (approx. 12V)

Brake pedal not depressed : Approx. 0V

OK or NG

OK >> Connect the connectors and conduct ABS actuator and electric unit self-diagnosis.

NG >> Repair the circuit.



ABS Control Unit Power and Ground Systems Inspection

EFS0030F

INSPECTION PROCEDURE

1. SELF-DIAGNOSIS RESULT CHECK

Check self-diagnosis results.

Self-diagnosis results
BATTERY VOLTAGE

Is the above displayed in the self-diagnosis item?

Yes >> GO TO 2.

No >> **INSPECTION END.**

2. CONNECTOR INSPECTION

1. Turn the ignition switch off and disconnect the ABS actuator and electric unit connector E125.
2. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace as necessary.

3. ABS CONTROL UNIT POWER AND GROUND CIRCUIT INSPECTION

1. Disconnect ABS actuator and electric unit connector E125.
2. Turn the ignition switch on.
3. Measure the voltage and continuity between the ABS actuator and electric unit connector E125 and the ground.

Signal name	ABS actuator and electric unit (control unit) connector E125	Ground	Measured value
Power supply	29 (GR)	—	Battery voltage (Approx. 12V)
Ground	16 (B)		Continuity should exist.
	30 (B)		

OK or NG

OK >> Check the battery for loose terminals, low voltage, etc. Repair as necessary.

NG >> Repair the circuit.

CAN Communication System Inspection

INSPECTION PROCEDURE

1. PERFORM SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis.

Is "CAN COMM CIRCUIT" displayed in the self-diagnosis display items?

Yes >> Print out the self-diagnosis results and go to 2.

No >> **INSPECTION END.**

2. CONNECTOR INSPECTION

1. Disconnect ABS actuator and electric unit connector E125.

2. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace as necessary.

3. CAN COMMUNICATION SYSTEM CHECK

Check the data monitor item "CAN Diagnosis Support Monitor".

Normal	Error (example)
CAN COMM: OK	CAN COMM: OK
CAN CIRC 1: OK	CAN CIRC 1: UNKWN
CAN CIRC 2: OK	CAN CIRC 2: UNKWN
CAN CIRC 3: OK	CAN CIRC 3: UNKWN
CAN CIRC 4: UNKWN	CAN CIRC 4: UNKWN
CAN CIRC 5: OK	CAN CIRC 5: UNKWN
CAN CIRC 6: UNKWN	CAN CIRC 6: UNKWN

>> After printing out the monitor items, go to CAN system. Refer to [LAN-8, "CAN COMMUNICATION"](#).

TROUBLE DIAGNOSES FOR SYMPTOMS

ABS Works Frequently

1. CHECK WARNING LAMP ACTIVATION

Make sure warning lamp remains off while driving.

OK or NG

OK >> GO TO 2.

NG >> Carry out self-diagnosis. Refer to [BRC-25, "SELF-DIAGNOSIS"](#).

2. CHECK WHEEL SENSORS

Check the following.

- Wheel sensor mounting for looseness
- Wheel sensors for physical damage
- Wheel sensor connectors for terminal damage or loose connections

OK or NG

OK >> GO TO 3.

NG >> Repair as necessary.

3. CHECK FRONT AXLE

Check front and rear axles for excessive looseness. Refer to [FAX-5, "FRONT WHEEL BEARING"](#) or [RAX-5, "REAR WHEEL BEARING"](#).

OK or NG

OK >> GO TO 4.

NG >> Repair as necessary.

4. CHECK BRAKE FLUID PRESSURE

Check brake fluid pressure distribution.

Refer to [BR-36, "Inspection"](#).

Is brake fluid pressure distribution normal?

Yes >> **INSPECTION END.**

No >> Perform Basic Inspection. Refer to [BRC-21, "Basic Inspection"](#).

A

B

C

D

E

BRC

G

H

I

J

K

L

M

Unexpected Pedal Action

1. CHECK WARNING LAMP ACTIVATION

Make sure warning lamp remains off while driving.

OK or NG

OK >> GO TO 2.

NG >> Carry out self-diagnosis. Refer to [BRC-25, "SELF-DIAGNOSIS"](#).


2. CHECK BRAKE PEDAL STROKE

Check brake pedal stroke.

Is pedal stroke excessive?

Yes >> Perform Basic Inspection. Refer to [BRC-21, "Basic Inspection"](#).

No >> GO TO 3.



3. CHECK CONNECTOR AND BRAKING PERFORMANCE

1. Disconnect ABS actuator and electric unit (control unit) connector.

2. Check brake effectiveness.

OK or NG

OK >> GO TO 4.

NG >> Perform Basic Inspection. Refer to [BRC-21, "Basic Inspection"](#).

4. CHECK WHEEL SENSORS

Check the following.

- Wheel sensor mounting for looseness
- Wheel sensors for physical damage
- Wheel sensor connectors for terminal damage or loose connections

OK or NG

OK >> Check ABS actuator and electric unit (control unit) pin terminals for damage and the connection of harness connector. Reconnect ABS actuator and electric unit (control unit) harness connector. Then retest.

NG >> Repair as necessary.

Long Stopping Distance

EFS002ZQ

1. CHECK BASE BRAKING SYSTEM PERFORMANCE

1. Disable ABS by disconnecting ABS actuator and electric unit (control unit) connector.
2. Drive vehicle and check to see if stopping distance is still long.

OK or NG

- OK >> Go to [BRC-37, "ABS Works Frequently"](#) .
- NG >> Perform Basic Inspection. Refer to [BRC-21, "Basic Inspection"](#) .

NOTE:

Stopping distance may be longer than vehicles without ABS when road condition is slippery.

ABS Does Not Work

EFS002ZR

CAUTION:

The ABS does not operate when the vehicle speed is 10 km/h (6 MPH) or less.

1. CHECK WARNING LAMP ACTIVATION

Turn ignition switch ON and check for warning lamp activation.

- Warning lamp should activate for approximately 1 second after turning the ignition switch ON.

OK or NG

- OK >> Carry out self-diagnosis. Refer to [BRC-25, "SELF-DIAGNOSIS"](#) .
- NG >> Go to [BRC-40, "ABS Warning Lamp Does Not Come On When Ignition Switch Is Turned On"](#) .

Pedal Vibration or ABS Operation Noise

EFS002ZS

NOTE:

During ABS activation, pedal vibration may be felt and a noise may be heard. This is normal and does not indicate a malfunction.

1. CHECK SYMPTOM

1. Apply brake.
2. Start engine.

Does the symptom occur only when engine is started?

- Yes >> Carry out self-diagnosis. Refer to [BRC-25, "SELF-DIAGNOSIS"](#) .
- No >> GO TO 2.

2. RECHECK SYMPTOM

Does the symptom occur only when electrical equipment switches (such as headlamp) are turned on?

- Yes >> Check for radio, antenna or related wiring that is routed too close to the ABS actuator and electric unit (control unit) and reroute as necessary.
- No >> Go to [BRC-37, "ABS Works Frequently"](#) .

ABS Warning Lamp Does Not Come On When Ignition Switch Is Turned On EFS002ZT**1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) FUSES**

Check 30A fusible link **g** and 30A fusible link **h** for ABS actuator and electric unit (control unit). For fusible link layout, refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).

OK or NG

OK >> GO TO 2.

NG >> If fusible link is blown, be sure to eliminate cause of problem before replacing.


2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUITS

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check voltage between ABS actuator connector terminal 1 and ground and terminal 15 and ground.

Does battery voltage exist?

Yes >> GO TO 3.

No >> Repair harness or connectors between fusible link and ABS actuator and electric unit (control unit).


**3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT**

Check continuity between ABS actuator connector terminal 16 and ground and terminal 30 and ground.

Does continuity exist?

Yes >> Replace ABS actuator and electric unit (control unit).

No >> Repair harness or connectors between ABS actuator and electric unit (control unit) and ground.

**ABS Warning Lamp Stays On When Ignition Switch Is Turned On** EFS002ZU**1. CARRY OUT SELF-DIAGNOSIS**

Carry out self-diagnosis. Refer to [BRC-25, "SELF-DIAGNOSIS"](#).


Are malfunctions detected in self-diagnosis?

Yes >> Refer to [BRC-26, "Display Item List"](#).

No >> Refer to [DI-45, "WARNING LAMPS"](#).

WHEEL SENSORS

Removal and Installation



CAUTION:

Be careful not to damage sensor edge and sensor rotor teeth.

When removing the front or rear wheel hub assembly, first remove the ABS wheel sensor from the assembly. Failure to do so may result in damage to the sensor wires making the sensor inoperative.

CAUTION:

Pull out the sensor being careful to turn it as little as possible. Do not pull on the sensor harness. Installation should be performed while paying attention to the following, and then tighten fasteners to the specified torque.

- Before installing wheel sensor, make sure no foreign materials (such as iron fragments) are adhered to the pick-up part of the sensor, to the inside of the sensor mounting hole or on the rotor mounting surface.

SENSOR ROTOR


Removal and Installation

NOTE:

The rear wheel sensor rotor is built into the rear wheel hub. For removal and installation procedure, refer to [RAX-6, "Removal and Installation"](#).


REMOVAL

1. Remove the front wheel hub. Refer to [FAX-6, "Removal and Installation"](#).
2. Remove the sensor rotor using suitable puller.

**INSTALLATION**


Install the sensor rotor using a hammer and a wooden block.

- Always replace sensor rotor with new one.



ACTUATOR AND ELECTRIC UNIT (ASSEMBLY)

Removal and Installation



REMOVAL

1. Disconnect battery cable.
2. Remove windshield wiper and linkage assembly. Refer to [WW-28, "REMOVAL"](#).
3. Drain brake fluid. Refer to [BR-8, "Changing Brake Fluid"](#).
4. Discharge the A/C refrigerant. Refer to [ATC-116, "HFC-134a \(R-134a\) Service Procedure"](#).
5. Disconnect and remove high-pressure and low-pressure A/C pipes to allow access to ABS actuator and electric unit (control unit). Refer to [ATC-118, "Components"](#).
6. Disconnect harness connectors from ABS actuator and electric unit (control unit).
7. Disconnect brake pipes.
8. Remove fasteners for ABS actuator and electric unit (control unit) and remove from vehicle.

INSTALLATION

CAUTION:

After installation of ABS actuator and electric unit (control unit), refill brake fluid. Then bleed air from system. Refer to [BR-8, "Bleeding Brake System"](#).

1. Position ABS actuator and electric unit (control unit) in vehicle.
2. Connect brake pipes and fasteners temporarily.
3. Tighten fasteners and brake pipes.
4. Connect ABS actuator and electric unit (control unit) harness connectors.
5. Install and connect high-pressure and low-pressure A/C pipes. Refer to [ATC-118, "Components"](#).
6. Install windshield wiper and linkage assembly. Refer to [WW-28, "INSTALLATION"](#).

7. Reconnect battery cable.
8. Evacuate and recharge the A/C system. Refer to [ATC-116, "HFC-134a \(R-134a\) Service Procedure"](#).

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EFS002V9

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:


- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for Brake System

EFS002VA

CAUTION:

- Recommended fluid is brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- To clean or wash all parts of master cylinder and disc brake caliper, use clean brake fluid.
- Never use mineral oils such as gasoline or kerosene. They will ruin rubber parts of the hydraulic system.
- Use flare nut wrench when removing and installing brake tube.
- If a brake fluid leak is found, the part must be disassembled without fail. Then it has to be replaced with a new one if a defect exists.
- Turn the ignition switch OFF and remove the connector of the ABS actuator control unit or the battery terminal before performing the work.
- Always torque brake lines when installing.
- Burnish the brake contact surfaces after refinishing or replacing rotors, after replacing pads, or if a soft pedal occurs at very low mileage.
Refer to [BR-28, "Brake Burnishing"](#) (front disc brakes) or [BR-35, "Brake Burnishing"](#) (rear disc brakes).



WARNING:

- Clean brake pads and shoes with a waste cloth, then wipe with a dust collector.

Precautions When Using CONSULT-II

EFS0031P

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

CHECK POINTS FOR USING CONSULT-II

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
 - If YES, GO TO 2.
 - If NO, GO TO 5.

2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
 - If YES, GO TO 3.
 - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-8, "CAN COMMUNICATION"](#).

Precautions for Brake Control


EFS002VB

- During ABS operation, the brake pedal may vibrate lightly and a mechanical noise may be heard. This is normal.
- Just after starting vehicle, the brake pedal may vibrate or a motor operating noise may be heard from engine compartment. This is a normal status of operation check.
- Stopping distance may be longer than that of vehicles without ABS when vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for simple causes before starting diagnosis. Besides electrical system inspection, check booster operation, brake fluid level, and fluid leaks.
- If incorrect tire sizes or types are installed on the vehicle or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- If there is a radio, antenna or related wiring near control module, ABS function may have a malfunction or error.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits or improper wiring.


Precautions for CAN System

EFS002VC

- Do not apply voltage of 7.0V or higher to terminal to be measured.
- Maximum open terminal voltage of tester in use must be less than 7.0V.
- Before checking harnesses, turn ignition switch OFF and disconnect battery negative cable.
- Area to be repaired must be soldered and wrapped with tape. Make sure that fraying of twisted wire is within 110 mm (4.33 in).



- Do not make a bypass connection to repaired area. (If the circuit is bypassed, characteristics of twisted wire will be lost.)



Wiring Diagrams and Trouble Diagnosis

When you read wiring diagrams, refer to the following:

- [GI-12, "How to Read Wiring Diagrams"](#)
- [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#)

When you perform trouble diagnosis, refer to the following:

- [GI-10, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#)
- [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#)

A

B

C

D

E

BRC

G

H

I

J

K

L

M

PREPARATION

[TCS/ABS]

PREPARATION


PFP:00002

Special Service Tool

EFS002VM

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.


Tool number (Kent-Moore No.) Tool name	Description
(J-45741) ABS active wheel sensor tester	Checking operation of ABS active wheel sensor



Commercial Service Tools


EFS002VN

Tool name	Description
1. Flare nut crowfoot a: 10mm (0.39 in)/12mm (0.47 in) 2. Torque wrench	Removing and installing brake piping



SYSTEM DESCRIPTION

System Diagram



ABS Function

- The Anti-Lock Brake System detects wheel revolution while braking and improves handling stability during sudden braking by electrically preventing wheel lockup. Maneuverability is also improved for avoiding obstacles.
- If the electrical system malfunctions, the Fail-Safe function is activated, the ABS becomes inoperative and the ABS warning lamp turns on.
- The electrical system can be diagnosed using CONSULT-II.
- During ABS operation, the brake pedal may vibrate lightly and a mechanical noise may be heard. This is normal.
- Just after starting the vehicle, the brake pedal may vibrate or a motor operating noise may be heard from engine compartment. This is a normal status of operation check.
- Stopping distance may be longer than that of vehicles without ABS when vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.

EBD Function

- Electronic Brake Distribution is a function that detects subtle slippages between the front and rear wheels during braking, and it improves handling stability by electronically controlling the brake fluid pressure which results in reduced rear wheel slippage.
- If the electrical system malfunctions, the Fail-Safe function is activated, the EBD and ABS become inoperative, and the ABS warning lamp and BRAKE warning lamp are turned on.
- The electrical system can be diagnosed using CONSULT-II.
- During EBD operation, the brake pedal may vibrate lightly and a mechanical noise may be heard. This is normal.
- Just after starting the vehicle, the brake pedal may vibrate or a motor operating noise may be heard from engine compartment. This is a normal status of operation check.
- Stopping distance may be longer than that of vehicles without EBD when vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.

TCS Function


- Spinning of the drive wheels is detected by the ABS/TCS control unit using inputs from the wheel speed sensors. If wheel spin occurs, the drive wheel right and left brake fluid pressure control and engine fuel cut are conducted while the throttle value is restricted to reduce the engine torque and decrease the amount of wheel spin. In addition, the throttle opening is controlled to achieve the optimum engine torque.

- Depending on road condition, the vehicle may have a sluggish feel. This is normal, because optimum traction has the highest priority during TCS operation.
- TCS may be activated during sudden vehicle acceleration, wide open throttle acceleration, sudden transmission shifts or when the vehicle is driven on a road with a varying surface friction coefficient.
- The SLIP indicator lamp flashes to inform the driver of TCS operation.


Wheel Sensors

EFS002VY

The front sensor units consist of a gear-shaped sensor rotor and a sensor element. The element contains a magnet around which a coil is wound. The front wheel sensors are installed on the front of the wheel knuckles. As the wheel rotates, the sensor generates a square-wave signal. The frequency increases as the wheel speed increases.



The rear sensor units consist of wheel hubs with a series of internal magnets and a sensor element. The rear wheel sensors are installed on the inner side of the wheel knuckles. As the wheel rotates, the sensor generates a square-wave signal. The frequency increases as the wheel speed increases.



EFS002VT

Fail-Safe Function

CAUTION:

If the Fail-Safe function is activated, perform the Self Diagnosis for ABS/TCS system.

ABS/EBD SYSTEM

In case of an electrical malfunction with the ABS, the ABS warning lamp and SLIP indicator lamp will turn on. In case of an electrical malfunction with the EBD system, the BRAKE warning lamp, ABS warning lamp and SLIP indicator lamp will turn on.

The system will revert to one of the following conditions of the Fail-Safe function.


1. For ABS malfunction, only the EBD is operative and the condition of the vehicle is the same condition of vehicles without ABS/TCS system.
2. For EBD malfunction, the EBD and ABS become inoperative, and the condition of the vehicle is the same as the condition of vehicles without ABS/TCS or EBD system.

TCS SYSTEM

In case of TCS system malfunction, the SLIP indicator lamp is turned on and the condition of the vehicle is the same as the condition of vehicles without TCS system. In case of an electrical malfunction with the TCS system, the ABS control continues to operate normally without TCS control.

Hydraulic Circuit Diagram

EFS002VU



A
B
C
D
E
BRC
G
H
I
J
K
L
M

CAN COMMUNICATION

PFP:23710

System Description

EFS00314

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Refer to [LAN-8, "CAN COMMUNICATION"](#) .

TROUBLE DIAGNOSIS

How to Perform Trouble Diagnoses for Quick and Accurate Repair



INTRODUCTION

The ABS/TCS system has an electronic control unit to control major functions. The control unit accepts input signals from sensors and controls actuator operation. It is also important to check for conventional problems such as air leaks in the booster or lines, lack of brake fluid, or other problems with the brake system.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electrical connections or faulty wiring. In this case, careful checking of suspicious circuits may help prevent the replacement of good parts.


A visual check only may not find the cause of the problem, so a road test should be performed.

Before undertaking actual checks, take just a few minutes to talk with a customer who approaches with an ABS/TCS complaint. The customer is a very good source of information on such problems, especially intermittent ones. Through the talks with the customer, find out what symptoms are present and under what conditions they occur. Start your diagnosis by looking for "conventional" problems first. This is one of the best ways to troubleshoot brake problems on an ABS/TCS equipped vehicle. Also check related Service Bulletins for information.



A
B
C
D
E
BRC
G
H
I
J
K
L
M

WORK FLOW



TROUBLE DIAGNOSIS

[TCS/ABS]

CLARIFY CONCERN

- A customer's description of a vehicle concern may vary depending on the individual. It is important to clarify the customer's concern.
- Ask the customer about what symptoms are present under what conditions. Use this information to reproduce the symptom while driving.
- It is also important to use the diagnosis sheet to understand what type of trouble the customer is having.

KEY POINTS

WHAT Vehicle model
WHEN Date, Frequencies
WHERE Road conditions
HOW Operating conditions,
Weather conditions,
Symptoms

SBR339B








EXAMPLE OF DIAGNOSIS SHEET

Customer name	Model & Year	VIN	
Engine #	Trans.	Mileage	
Incident Date	Manuf. Date	In Service Date	
Symptoms	☐ Noise and vibration (from engine compartment)	☐ ABS warning lamp activates	☐ Pedal operation
	☐ Noise and vibration (from axle)	☐ SLIP warning lamp activates	☐ Large stroke pedal operation
	☐ TCS does not work (drive wheels slip when accelerating)	☐ ABS does not work (wheels slip when braking)	☐ Firm pedal
	☐ Lack of sense of acceleration		
Engine conditions	☐ When starting ☐ After starting		
Road conditions	☐ Low friction road (☐ Snow ☐ Gravel ☐ Other) ☐ Bumps/potholes		
Driving conditions	☐ Full-acceleration ☐ High speed cornering ☐ Vehicle speed: Greater than 10 km/h (6 MPH) ☐ Vehicle speed: 10 km/h (6 MPH) or less ☐ Vehicle is stopped		
Applying brake conditions	☐ Suddenly ☐ Gradually		
Other conditions	☐ Operation of electrical equipment ☐ Shift change ☐ Other descriptions		

WFIA0097E


Component Parts and Harness Connector Location

EFS002YB



Schematic

EFS002YC





A
B
C
D
E
BRC
G
H
I
J
K
L
M

WFWA0022E

Wiring Diagram — TCS —



BRC-TCS-01



REFER TO THE FOLLOWING.


(E30) - FUSE BLOCK -
JUNCTION BOX (J/B)

BRC-TCS-02






[TCS/ABS]

 : DATA LINE



BRC-60



Refer to the following.

(M4) - FUSE BLOCK - JUNCTION BOX (J/B)

Basic Inspection**BRAKE FLUID LEVEL, FLUID LEAK, AND BRAKE PAD INSPECTION**

1. Check fluid level in the brake fluid reservoir. If fluid level is low, add fluid.
2. Check the brake piping and around the ABS actuator and electric unit (control unit) for leaks. If there is leaking or seeping fluid, check the following items.
 - If ABS actuator and electric unit (control unit) connection is loose, tighten the piping to the specified torque and recheck for leaks.
 - If there is damage to the connection flare nut or ABS actuator and electric unit (control unit) screw, replace the damaged part and recheck for leaks.
 - When there is fluid leaking or seeping from a fluid connection, use a clean cloth to wipe off the fluid and recheck for leaks. If fluid is still seeping out, replace the damaged part. If the fluid is leaking at the ABS actuator and electric unit (control unit), replace the ABS actuator and electric unit (control unit) assembly.

CAUTION:

The ABS actuator and electric unit (control unit) cannot be disassembled and must be replaced as an assembly.

3. Check the brake pads for excessive wear.

POWER SYSTEM TERMINAL LOOSENESS AND BATTERY INSPECTION

Make sure the battery positive cable, negative cable and ground connection are not loose. In addition, make sure the battery is sufficiently charged.

ABS WARNING LAMP AND SLIP INDICATOR LAMP INSPECTION

1. Make sure ABS warning lamp and SLIP indicator lamp turn on for approximately 1 second when the ignition switch is turned ON. Check CAN communications. If there are no errors with the CAN communication system, check combination meter. Refer to [DI-5, "COMBINATION METERS"](#).
2. Make sure the lamps turn off approximately 1 second after the ignition switch is turned ON. If the lamp does not turn off, conduct self-diagnosis.
3. Make sure ABS warning lamp and SLIP indicator lamp turn off approximately 2 seconds after the engine is started. If ABS warning lamp and SLIP indicator lamp have not turned off 10 seconds after the engine has been started, conduct self-diagnosis of the ABS actuator and electric unit (control unit).
4. After conducting the self-diagnosis, be sure to erase the error memory. Refer to [BRC-65, "CONSULT-II Function"](#).

Warning Lamp and Indicator Timing

× : ON – : Lamp OFF

Condition	ABS warning lamp	TCS OFF indicator lamp	SLIP indicator lamp	Remarks
When the ignition switch is OFF	–	–	–	–
After the ignition switch is turned ON For approx. 0.5 seconds	×	×	×	–
Ignition switch ON Approx. 0.5 seconds later	–	–	–	Lamp goes off approx. 2 seconds after the engine start.
When the TCS OFF switch turns ON (TCS function OFF).	–	×	–	–
TCS/ABS malfunction	×	×	×	–
	×	×	–	When the TCS/ABS control unit is malfunctioning (power supply or ground malfunction).
When the TCS is malfunctioning.	–	×	×	–

TROUBLE DIAGNOSIS

[TCS/ABS]

EFS002YG

Control Unit Input/Output Signal Standard REFERENCE VALUE FROM CONSULT-II

CAUTION:

The display shows the control unit calculation data, so a normal value might be displayed even in the event the output circuit (harness) is open or short circuited.

Monitor item	Display content	Data monitor		Note: Error inspection checklist
		Condition	Reference value in normal operation	
SLCT LVR POSI	PNP switch signal ON/OFF condition	A/T shift position = N or P position	ON	BRC-78. "CAN Communication System Inspection"
		A/T shift position = other than N and P positions	OFF	
GEAR	A/T gear position	1:1st gear 2:2nd gear 3:3rd gear 4:4th gear		BRC-78. "CAN Communication System Inspection"
FR RH SENSOR FR LH SENSOR RR RH SENSOR RR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]	BRC-73. "Wheel Sensor System Inspection"
		Vehicle running (Note 1)	Almost in accordance with speedometer display (within ±10%)	
ACCEL POS SIG	Open/close condition of throttle valve (linked with accelerator pedal).	Accelerator pedal not depressed (ignition switch is ON)	0%	BRC-78. "CAN Communication System Inspection"
		Depress accelerator pedal (ignition switch is ON)	0 to 100%	
ENGINE SPEED	With engine running	With engine stopped	0 rpm	BRC-74. "Engine System Inspection"
		Engine running	Almost in accordance with tachometer display	
PRESS SENSOR	Brake fluid pressure detected by pressure sensor	With ignition switch turned ON and brake pedal released	Approx. 0 bar	—
		With ignition switch turned ON and brake pedal depressed	–0 to 350 bar	
BATTERY VOLT	Battery voltage supplied to ABS actuator and electric unit (control unit)	Ignition switch ON	10 to 16V	BRC-77. "ABS/TCS Control Unit Power and Ground Systems Inspection"
STOP LAMP SW	Brake pedal operation	Brake pedal depressed	ON	BRC-76. "Stop Lamp Switch System Inspection"
		Brake pedal not depressed	OFF	
ABS WARN LAMP	ABS warning lamp ON condition (Note 2)	ABS warning lamp ON	ON	BRC-82. "ABS Warning Lamp Does Not Come On When Ignition Switch Is Turned On"
		ABS warning lamp OFF	OFF	
MOTOR RELAY	Operation status of motor and motor relay	Ignition switch ON or engine running (ABS not operated)	OFF	BRC-75. "Actuator Motor, Motor Relay, and Circuit Inspection"
		Ignition switch ON or engine running (ABS operated)	ON	
ACTUATOR RLY	Actuator relay operation status	Vehicle stopped (Ignition switch ON)	OFF	BRC-75. "Actuator Motor, Motor Relay, and Circuit Inspection"
		Vehicle stopped (Engine running)	ON	

TROUBLE DIAGNOSIS

[TCS/ABS]

Monitor item	Display content	Data monitor		Note: Error inspection checklist
		Condition	Reference value in normal operation	
SLIP LAMP	SLIP indicator lamp status (Note 4)	When SLIP indicator lamp is ON	ON	DI-9, "Combination Meter"
		When SLIP indicator lamp is OFF	OFF	
FR LH IN SOL FR LH OUT SOL FR RH IN SOL FR RH OUT SOL RR RH IN SOL RR RH OUT SOL RR LH IN SOL RR LH OUT SOL	Solenoid valve operation	Actuator (solenoid) is active ("ACTIVE TEST" with CONSULT-II) or actuator relay is inactive (in fail-safe mode).	ON	—
		When actuator (solenoid) is not active and actuator relay is active (ignition switch ON).	OFF	
FLUID LEV SW	ON/OFF status of brake fluid level switch	When brake fluid level switch ON	ON	DI-45, "WARNING LAMPS"
		When brake fluid level switch OFF	OFF	
TCS FAIL SIG ABS FAIL SIG EBD FAIL SIG	Fail signal status	TCS fail ABS fail EBD fail	OFF	TCS system ABS system EBD system

Note 1: Confirm tire pressure is normal.

Note 2: ON/OFF timing of ABS warning lamp

ON: For approximately 1.8 seconds after ignition switch is turned ON, or when a malfunction is detected.

OFF: Approximately 1.8 seconds after ignition switch is turned ON (when system is in normal operation) and TCS function is not activated.

Note 4: SLIP indicator lamp ON/OFF timing

ON: For approximately 1.8 seconds after ignition switch is turned ON, or when a malfunction is detected and TCS function is activated while driving.

OFF: Approximately 1.8 seconds after ignition switch is turned ON (when system is in normal operation) and TCS function is not activated.

Flashing: TCS function is active during driving

CONSULT-II Function

CAUTION:

- When the self-diagnosis, data monitor, or active test functions are being executed, EBD, ABS and TCS control is disabled.
- When using CONSULT-II to conduct ABS/TCS control unit self-diagnosis, active test, work support, etc., first stop engine, connect the CONSULT-II, and select "ABS".
- CONSULT-II self-diagnosis results are displayed without regard to occurrence timing. In some cases later ones (timing value is small) appear on the next screen.
- When an error is shown by the CONSULT-II SELF-DIAG RESULTS and CONSULT-II is used to conduct an active test, an engine system malfunction may be shown, but restarting the engine will return the status to normal.

CONSULT-II FUNCTION APPLICATION

Item	Self-diagnosis	Data monitor	Active test
Wheel sensors	×	×	—
Stop lamp switch	×	×	—
Solenoid valves	×	×	×
Pressure sensor	×	×	—
Actuator relay	×	×	×
Motor relay	×	×	×
ABS warning lamp	—	×	—
Battery voltage	×	×	—
ABS actuator and electric unit (control unit)	×	—	—
ABS/TCS actuator motor	×	×	×
CAN communication	×	—	—
Engine speed signal	×	×	—
SLIP indicator lamp	—	×	—
Throttle angle	—	×	—
Gear	—	×	—
Selector lever position	—	×	—
EBD/ABS/TCS signals	×	×	—
Brake fluid level switch	×	×	—

×: Applicable

—: Not applicable


CONSULT-II BASIC OPERATION PROCEDURE

1. Turn ignition switch OFF.
2. Connect CONSULT-II and CONSULT-II CONVERTER to the data link connector.

CAUTION:


If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

3. Turn ignition switch ON.




BBIA0002E

4. Touch "START (NISSAN BASED VHCL)".



5. Touch "ABS" in the "Diagnosis System Selection" screen.
If "ABS" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



6. Select the required diagnostic location from the "Diagnosis Mode Selection" screen.
For further information, see the CONSULT-II Operation Manual.

SELF-DIAGNOSIS

Description

If an error is detected in the system, the ABS warning lamp will turn on. In this case, perform self-diagnosis as follows:

Operation Procedure

1. Turn ignition switch OFF.
2. Connect CONSULT-II and CONSULT-II CONVERTER to the data link connector.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

3. Turn ignition switch ON.
4. Start engine and drive at approximately 30 km/h (19 MPH) for approximately 1 minute.
5. After stopping the vehicle, with the engine running, touch "START (NISSAN BASED VHCL)", "ABS", "SELF-DIAG RESULTS" in order on the CONSULT-II screen.

CAUTION:

If "START (NISSAN BASED VHCL)" is touched immediately after starting the engine or turning on the ignition switch, "ABS" might not be displayed in the System Selection screen. In this case, repeat the operation from step 1.

6. The self-diagnostic results are displayed. (If necessary, the self-diagnostic results can be printed out by touching "COPY".)
 - When "NO FAILURE" is displayed, check the ABS warning lamp and SLIP indicator lamp.
7. Conduct the appropriate inspection from the display item list, and repair or replace the malfunctioning component.
8. Start engine and drive at approximately 30 km/h (19 MPH) for approximately 1 minute.

CAUTION:

When a wheel sensor "short-circuit" is detected, if the vehicle is not driven at 30 km/h (19 MPH) for at least 1 minute, the ABS warning lamp will not turn off even if the malfunction is repaired.

9. Turn ignition switch OFF to prepare for erasing the memory.

TROUBLE DIAGNOSIS

[TCS/ABS]

10. Start the engine and touch "START (NISSAN BASED VHCL)", "ABS", "SELF-DIAG RESULTS", "ERASE MEMORY" in order on the CONSULT-II screen to erase the error memory.
If "ABS" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).

CAUTION:

If the error memory is not erased, re-conduct the operation from step 5.

11. For the final inspection, drive at approximately 30 km/h (19 MPH) for approximately 1 minute and confirm that the ABS warning lamp and SLIP indicator lamp are off.

Display Item List

Self-diagnostic item	Malfunction detecting condition	Check system
FR LH SENSOR 1 [C1104]	Circuit of front LH wheel sensor is open	BRC-73. "Wheel Sensor System Inspection" (Note 1)
RR RH SENSOR 1 [C1101]	Circuit of rear RH wheel sensor is open	
FR RH SENSOR 1 [C1103]	Circuit of front RH wheel sensor is open	
RR LH SENSOR 1 [C1102]	Circuit of rear LH wheel sensor is open	
FR LH SENSOR 2 [C1108]	Circuit of front LH wheel sensor is shorted, or sensor power voltage is unusual. ABS actuator and electric unit (control unit) cannot identify sensor pulses, because of large gap between wheel sensor and sensor rotor.	
RR RH SENSOR 2 [C1105]	Circuit of rear RH wheel sensor is shorted, or sensor power voltage is unusual. ABS actuator and electric unit (control unit) cannot identify sensor pulses, because of large gap between wheel sensor and sensor rotor.	
FR RH SENSOR 2 [C1107]	Circuit of front RH wheel sensor is shorted, or sensor power voltage is unusual. ABS actuator and electric unit (control unit) cannot identify sensor pulses, because of large gap between wheel sensor and sensor rotor.	
RR LH SENSOR 2 [C1106]	Circuit of rear LH wheel sensor is shorted, or sensor power voltage is unusual. ABS actuator and electric unit (control unit) cannot identify sensor pulses, because of large gap between wheel sensor and sensor rotor.	
STOP LAMP SW 1 [C1116]	Stop lamp switch or circuit malfunction.	BRC-76. "Stop Lamp Switch System Inspection"
FR LH IN ABS SOL [C1120]	Circuit of front LH IN ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	—
FR LH OUT ABS SOL [C1121]	Circuit of front LH OUT ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
RR RH IN ABS SOL [C1126]	Circuit of rear RH IN ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
RR RH OUT ABS SOL [C1127]	Circuit of rear RH OUT ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
FR RH IN ABS SOL [C1122]	Circuit of front RH IN ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
FR RH OUT ABS SOL [C1123]	Circuit of front RH OUT ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
RR LH IN ABS SOL [C1124]	Circuit of rear LH IN ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
RR LH OUT ABS SOL [C1125]	Circuit of rear LH OUT ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	

TROUBLE DIAGNOSIS

[TCS/ABS]

Self-diagnostic item	Malfunction detecting condition	Check system
PUMP MOTOR (Note 3) [C1111]	During actuator motor operation with ON, when actuator motor turns OFF or when control line for actuator motor relay is open. During actuator motor operation with OFF, when actuator motor turns ON or when control line for relay is shorted to ground.	BRC-75, "Actuator Motor, Motor Relay, and Circuit Inspection"
BATTERY VOLTAGE [ABNORMAL] [C1109]	ABS actuator and electric unit (control unit) power voltage is too low.	BRC-77, "ABS/TCS Control Unit Power and Ground Systems Inspection"
CONTROLLER FAILURE [C1110]	Internal malfunction of ABS actuator and electric unit (control unit)	BRC-75, "ABS/TCS Control Unit Inspection"
CAN COMM CIRCUIT [U1000]	● CAN communication line is open or shorted. ● ABS actuator and electric unit (control unit) internal malfunction ● Battery voltage for ECM is suddenly interrupted for approximately 0.5 seconds or more.	BRC-78, "CAN Communication System Inspection" (Note 2)
BR FLUID LEVEL LOW [C1155]	Brake fluid level drops or circuit between ABS actuator and electric unit (control unit) and brake fluid level switch is open or shorted.	DI-45, "WARNING LAMPS"
ENGINE SPEED SIG	Engine speed signal from ECM is abnormal.	BRC-74, "Engine System Inspection"
ENGINE SIGNAL 1 [C1130]	ECM judges the communication between ABS/TCS control unit and ECM is abnormal.	BRC-78, "CAN Communication System Inspection"
STOP LAMP SW 2 [C1176]	ASCD brake switch or circuit malfunction.	EC-558, "DTC P1572 ASCD BRAKE SWITCH"

Note 1. If wheel sensor 2 for each wheel is indicated, check ABS actuator and electric unit (control unit) power supply voltage in addition to wheel sensor circuit check.

Note 2. If multiple malfunctions are detected including CAN communication line [U1000], perform diagnosis for CAN communication line first.

Note 3: "ACTUATOR RLY" on the CONSULT-II self-diagnosis results indicates the malfunction of the actuator motor relay or circuit.

DATA MONITOR

Operation Procedure

1. After turning OFF the ignition switch, connect CONSULT-II and the CONVERTER to the data link connector.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

2. Touch "START (NISSAN BASED VHCL)", "ABS", "DATA MONITOR" in order on the CONSULT-II screen. If "ABS" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).

CAUTION:

When "START (NISSAN BASED VHCL)" is touched immediately after starting the engine or turning on the ignition switch, "ABS" might not be displayed in the system selection screen. In this case, repeat the operation from step 2.

3. Return to the Monitor Item Selection screen, and touch "C/U INPUT ITEM", "MAIN ITEM" or "ITEM MENU SELECTION". Refer to the following information.
4. When "START" is touched, the data monitor screen is displayed.

TROUBLE DIAGNOSIS

[TCS/ABS]

Display Item List

Item (Unit)	Data monitor item selection				Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	CAN DIAG SUPPORT MNTR	
GEAR	×	×	×	—	Gear position judged by PNP switch signal is displayed.
FR RH SENSOR (km/h, MPH)	×	×	×	—	Wheel speed calculated by front RH wheel sensor signal is displayed.
FR LH SENSOR (km/h, MPH)	×	×	×	—	Wheel speed calculated by front LH wheel sensor signal is displayed.
RR RH SENSOR (km/h, MPH)	×	×	×	—	Wheel speed calculated by rear RH wheel sensor signal is displayed.
RR LH SENSOR (km/h, MPH)	×	×	×	—	Wheel speed calculated by rear LH wheel sensor signal is displayed.
BATTERY VOLT (V)	×	×	×	—	Voltage supplied to ABS actuator and electric unit (control unit) is displayed.
SLCT LVR POSI	×	×	×	—	Shift position judged by PNP switch signal.
ACCEL POS SIG (%)	×	—	×	—	Throttle valve open/close status judged by LAN communication signal is displayed.
ENGINE SPEED (rpm)	×	×	×	—	Engine speed judged by LAN communication signal is displayed.
PRESS SENSOR (bar)	×	—	×	—	Brake fluid pressure detected by pressure sensor is displayed.
STOP LAMP SW (ON/OFF)	×	×	×	—	Stop lamp switch (ON/OFF) status is displayed.
ABS WARN LAMP (ON/OFF)	—	×	×	—	ABS warning lamp (ON/OFF) status is displayed.
SLIP LAMP (ON/OFF)	—	×	×	—	SLIP indicator lamp (ON/OFF) status is displayed.
FR LH IN SOL (ON/OFF)	—	×	×	—	Front LH IN ABS solenoid (ON/OFF) status is displayed.
FR LH OUT SOL (ON/OFF)	—	×	×	—	Front LH OUT ABS solenoid (ON/OFF) status is displayed.
RR RH IN SOL (ON/OFF)	—	×	×	—	Rear RH IN ABS solenoid (ON/OFF) status is displayed.
RR RH OUT SOL (ON/OFF)	—	×	×	—	Rear RH OUT ABS solenoid (ON/OFF) status is displayed.
FR RH IN SOL (ON/OFF)	—	×	×	—	Front RH IN ABS solenoid (ON/OFF) status is displayed.
FR RH OUT SOL (ON/OFF)	—	×	×	—	Front RH OUT ABS solenoid (ON/OFF) status is displayed.
RR LH IN SOL (ON/OFF)	—	×	×	—	Rear LH IN ABS solenoid (ON/OFF) status is displayed.
RR LH OUT SOL (ON/OFF)	—	×	×	—	Rear LH OUT ABS solenoid (ON/OFF) status is displayed.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

TROUBLE DIAGNOSIS

[TCS/ABS]

Item (Unit)	Data monitor item selection				Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	CAN DIAG SUPPORT MNTR	
OFF LAMP (ON/OFF)	—	×	×	—	OFF Lamp (ON/OFF) status is displayed.
MOTOR RELAY (ON/OFF)	—	×	×	—	ABS motor relay signal (ON/OFF) status is displayed.
ACTUATOR RLY (ON/OFF)	—	×	×	—	ABS actuator relay signal (ON/OFF) status is displayed.
TCS FAIL SIG (ON/OFF)	—	—	×	—	TCS fail signal (ON/OFF) status is displayed.
ABS FAIL SIG (ON/OFF)	—	—	×	—	ABS fail signal (ON/OFF) status is displayed.
EBD FAIL SIG (ON/OFF)	—	—	×	—	EBD fail signal (ON/OFF) status is displayed.
FLUID LEV SW (ON/OFF)	×	—	×	—	Brake fluid level switch (ON/OFF) status is displayed.
EBD SIGNAL (ON/OFF)	—	—	×	—	EBD operation (ON/OFF) status is displayed.
ABS SIGNAL (ON/OFF)	—	—	×	—	ABS operation (ON/OFF) status is displayed.
TCS SIGNAL (ON/OFF)	—	—	×	—	TCS operation (ON/OFF) status is displayed.
CAN COMM (OK/NG)	—	—	—	×	CAN communication signal (OK/NG) status is displayed.
CAN CIRC 1 (OK/UNKWN)	—	—	—	×	CAN communication signal (OK/UNKWN) status is displayed.
CAN CIRC 2 (OK/UNKWN)	—	—	—	×	
CAN CIRC 3 (OK/UNKWN)	—	—	—	×	
CAN CIRC 4 (OK/UNKWN)	—	—	—	×	
CAN CIRC 5 (OK/UNKWN)	—	—	—	×	
CAN CIRC 6 (OK/UNKWN)	—	—	—	×	
CAN CIRC 7 (OK/UNKWN)	—	—	—	×	
CAN CIRC CLC (OK/UNKWN)	—	—	—	×	S/C is selected for engine torque map
TRQ MAP S/C	—	—	×	—	
TRQ MAP N/A	—	—	×	—	

×: Applicable

—: Not applicable

ACTIVE TEST

CAUTION:

- Do not perform active test while driving.
- Make sure to completely bleed air from the brake system.
- The ABS and brake (EBD) warning lamps turn on during the active test.


Operation Procedure

1. Connect the CONSULT-II and CONVERTER to the data link connector and start the engine.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

2. Touch "START (NISSAN BASED VHCL) " on the display screen.
3. Touch "ABS".
If "ABS" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#) .
4. Touch "ACTIVE TEST".
5. The test item selection screen is displayed.
6. Touch necessary test item.



7. With the "MAIN ITEM" display shown in reverse, touch "START".
8. The Active Test screen will be displayed, so conduct the following test.

Solenoid Valve Operation Chart

Operation		ABS solenoid valve			ABS solenoid valve (ACT)		
		UP	KEEP	DOWN	UP	ACTUA-TOR UP	ACTUA-TOR KEEP
FR RH SOL FR RH ABS SOLE- NOID (ACT)	FR RH IN SOL	OFF	ON	ON	OFF	OFF	OFF
	FR RH OUT SOL	OFF	OFF	ON*	OFF	OFF	OFF
FR LH SOL FR LH ABS SOLE- NOID (ACT)	FR LH IN SOL	OFF	ON	ON	OFF	OFF	OFF
	FR LH OUT SOL	OFF	OFF	ON*	OFF	OFF	OFF
RR RH SOL RR RH ABS SOLE- NOID (ACT)	RR RH IN SOL	OFF	ON	ON	OFF	OFF	OFF
	RR RH OUT SOL	OFF	OFF	ON*	OFF	OFF	OFF
RR LH SOL RR LH ABS SOLE- NOID (ACT)	RR LH IN SOL	OFF	ON	ON	OFF	OFF	OFF
	RR LH OUT SOL	OFF	OFF	ON*	OFF	OFF	OFF
REAR SOL	RR RH IN SOL	OFF	ON	ON	OFF	OFF	OFF
	RR RH OUT SOL	OFF	OFF	ON*	OFF	OFF	OFF
	RR LH IN SOL	OFF	ON	ON	OFF	OFF	OFF
	RR LH OUT SOL	OFF	OFF	ON*	OFF	OFF	OFF

*: ON for 1 to 2 seconds after the touch, and then OFF

NOTE:

- If active test is performed with brake pedal depressed, pedal stroke may change. This is normal.
- "TEST IS STOPPED" is displayed approximately 10 seconds after operation starts.
- After "TEST IS STOPPED" is displayed, to perform test again, repeat Step 6.

ABS Motor

Touch "ON" and "OFF" on the screen. Check that ABS motor relay operates as shown in table below.

Operation	ON	OFF
ABS actuator relay	ON	ON
ABS motor relay	ON	OFF

NOTE:

- If active test is performed with brake pedal depressed, pedal stroke may change. This is normal.
- "TEST IS STOPPED" is displayed approximately 10 seconds after operation starts.

ACTIVE TEST			
ABS MOTOR		OFF	
MONITOR			
MOTOR RELAY		OFF	
ACTUATOR RLY		ON	
ON			
MODE	BACK	LIGHT	COPY

SFIA0593E

TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS**Wheel Sensor System Inspection****INSPECTION PROCEDURE****1. CONNECTOR INSPECTION**

Disconnect the ABS actuator and electric unit connector E125 and wheel sensor of malfunctioning code. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

OK >> GO TO 2.

NG >> Repair or replace as necessary.

2. CHECK WHEEL SENSOR OUTPUT SIGNAL

1. Disconnect connectors from wheel sensor of malfunction code No.
2. Connect ABS active wheel sensor tester (J-45741) to wheel sensor using appropriate adapter.
3. Turn on the ABS active wheel sensor tester power switch.

NOTE:

The green POWER indicator should illuminate. If the POWER indicator does not illuminate, replace the battery in the ABS active wheel sensor tester before proceeding.

4. Spin the wheel of the vehicle by hand and observe the red SENSOR indicator on the ABS active wheel sensor tester. The red SENSOR indicator should flash on and off to indicate an output signal.

NOTE:

If the red SENSOR indicator illuminates but does not flash, reverse the polarity of the tester leads and retest.

Does the ABS active wheel sensor tester detect a signal?

Yes >> GO TO 3.

No >> GO TO 6.

3. CHECK TIRES

Check for inflation pressure, wear and size of each tire.

Are tire pressure and size correct and is tire wear within specifications?

Yes >> GO TO 4.

No >> Adjust tire pressure or replace tire(s).

4. CHECK WHEEL BEARINGS

Check wheel bearing axial end play. Refer to [FAX-5, "FRONT WHEEL BEARING"](#) or [RAX-5, "REAR WHEEL BEARING"](#).

OK or NG

OK >> GO TO 5.

NG >> Repair as necessary. Refer to [FAX-5, "FRONT WHEEL BEARING"](#) or [RAX-5, "REAR WHEEL BEARING"](#).

5. CHECK SENSOR ROTORS

Check sensor rotors for teeth damage.

OK or NG

OK >> GO TO 6.

NG >> Replace sensor rotor. Refer to [BRC-140, "Removal and Installation"](#).

6. CHECK WIRING HARNESS FOR SHORT CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector and wheel sensor connector of malfunction code No.
2. Check resistance between harness connector terminal and ground.

Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Repair the circuit.

**7. CHECK WIRING HARNESS FOR OPEN CIRCUIT**

1. Disconnect ABS actuator and electric unit (control unit) connector and wheel sensor connector of malfunction code No.
2. Check continuity between both wiring harness ends.

Sensor	ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
	Connector - terminal	Wire color	Connector - terminal	Wire color	
Front LH	E125 - 22	G	E18 - 1	G	Yes
	E125 - 7	R	E18 - 2	R	
Front RH	E125 - 24	B	E117 - 1	B	
	E125 - 9	W	E117 - 2	W	
Rear LH	E125 - 11	P	B123 - 1	P	
	E125 - 26	L	B123 - 2	L	
Rear RH	E125 - 13	V	B122 - 1	V	
	E125 - 28	LG	B122 - 2	LG	

Continuity should exist.

OK or NG

OK >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-86, "Removal and Installation"](#).

NG >> Repair the circuit.

Engine System Inspection

EFS002ZX

INSPECTION PROCEDURE**1. SELF-DIAGNOSIS RESULT CHECK**

Check self-diagnosis results.

Self-diagnosis results
ENGINE SIGNAL 1
ENGINE SIGNAL 2
ENGINE SIGNAL 3
ENGINE SIGNAL 4
ENGINE SIGNAL 6

Is the above displayed in the self-diagnosis display items?

Yes >> GO TO 2.

No >> **INSPECTION END.**

2. ENGINE SYSTEM INSPECTION

1. Perform ECM self-diagnosis and repair as necessary.
2. Perform ABS actuator and electric unit (control unit) self-diagnosis again.

OK or NG

OK >> **INSPECTION END.**

NG >> Repair as necessary.

ABS/TCS Control Unit Inspection

EFS002ZY

INSPECTION PROCEDURE**1. SELF-DIAGNOSIS RESULT CHECK**

Check self-diagnosis results.

Self-diagnosis results

CONTROLLER FAILURE

Is the above displayed in the self-diagnosis display items?

Yes >> Replace ABS actuator and electric unit. Refer to [BRC-86, "Removal and Installation"](#).No >> **INSPECTION END.****Actuator Motor, Motor Relay, and Circuit Inspection**

EFS00302

INSPECTION PROCEDURE**1. CHECKING SELF-DIAGNOSIS RESULTS**

Check self-diagnosis results.

Self-diagnosis results

CONSULT-II display items

PUMP MOTOR

Does "PUMP MOTOR" appear in self-diagnosis results display?

Yes >> GO TO 2.

No >> **INSPECTION END.****2. CONNECTOR INSPECTION**

Disconnect the ABS actuator and electric unit connector E125.

Check the terminals for deformation, disconnection, looseness or damage.

OK or NG


OK >> GO TO 3.

NG >> Repair or replace as necessary.

3. CHECKING ABS MOTOR AND MOTOR RELAY POWER SYSTEM


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check voltage between ABS actuator and electric unit (control unit) connector E125 and body ground.

ABS actuator and electric unit (control unit) connector E125	Body ground	Measured value (Approx.)
1 (R/B)	—	12V



3. Check resistance between ABS actuator and electric unit (control unit) connector E125 and ground.

ABS actuator and electric unit (control unit) connector E125	Body ground	Measured value (Approx.)
30 (B)	—	0Ω



OK or NG

OK >> Perform self-diagnosis again. If the same result appears, replace ABS actuator and electric unit (control unit). Refer to [BRC-86, "Removal and Installation"](#).

NG >> Repair the circuit.

Stop Lamp Switch System Inspection

EFS00304

INSPECTION PROCEDURE

1. SELF-DIAGNOSIS RESULT CHECK

Check self-diagnosis results.

Self-diagnosis results
STOP LAMP SW

Is the above displayed in the self-diagnosis display items?

Yes >> GO TO 2.

No >> **INSPECTION END.**

2. CONNECTOR INSPECTION

1. Disconnect the ABS actuator and electric unit connector E125 and stop lamp switch connector E38.
2. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace as necessary.

3. STOP LAMP SWITCH INSPECTION

Turn the ignition switch on and check the voltage between the ABS actuator and electric unit connector E125 terminal 17 (R/G) and ground.

17 (R/G) - Ground


Brake pedal depressed : Battery voltage (approx. 12V)

Brake pedal not depressed : Approx. 0V

OK or NG

OK >> Connect the connectors and conduct ABS actuator and electric unit self-diagnosis.

NG >> Repair the circuit.



ABS/TCS Control Unit Power and Ground Systems Inspection

EFS00305

INSPECTION PROCEDURE

1. SELF-DIAGNOSIS RESULT CHECK

Check self-diagnosis results.

Self-diagnosis results
BATTERY VOLTAGE

Is the above displayed in the self-diagnosis item?

Yes >> GO TO 2.

No >> **INSPECTION END.**

2. CONNECTOR INSPECTION

1. Turn the ignition switch off and disconnect the ABS actuator and electric unit connector E125.
2. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace as necessary.

3. ABS/TCS CONTROL UNIT POWER AND GROUND CIRCUIT INSPECTION

Measure the voltage and continuity between the ABS actuator and electric unit connector E125 and the ground.

Signal name	ABS actuator and electric unit (control unit) connector E125	Ground	Measured value
Power supply	29 (GR)	—	Battery voltage (Approx. 12V)
Ground	16 (B)		Continuity should exist.
	30 (B)		

OK or NG

OK >> Check the battery for loose terminals, low voltage, etc. Repair as necessary.

NG >> Repair the circuit.

CAN Communication System Inspection

INSPECTION PROCEDURE

1. PERFORM SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis.

Is "CAN COMM CIRCUIT" displayed in the self-diagnosis display items?

Yes >> Print out the self-diagnosis results and go to 2.

No >> **INSPECTION END.**

2. CONNECTOR INSPECTION

1. Turn the ignition switch off and disconnect the ABS actuator and electric unit connector E125.

2. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace as necessary.

3. CAN COMMUNICATION SYSTEM CHECK

Check the data monitor item "CAN Diagnosis Support Monitor".

Normal	Error (example)
CAN COMM: OK	CAN COMM: OK
CAN CIRC 1: OK	CAN CIRC 1: UNKWN
CAN CIRC 2: OK	CAN CIRC 2: UNKWN
CAN CIRC 3: OK	CAN CIRC 3: UNKWN
CAN CIRC 4: UNKWN	CAN CIRC 4: UNKWN
CAN CIRC 5: OK	CAN CIRC 5: UNKWN
CAN CIRC 6: UNKWN	CAN CIRC 6: UNKWN

>> After printing out the monitor items, go to CAN system. Refer to [LAN-8, "CAN COMMUNICATION"](#).

TROUBLE DIAGNOSES FOR SYMPTOMS**ABS Works Frequently****1. CHECK WARNING LAMP ACTIVATION**

Make sure warning lamp remains off while driving.

OK or NG

OK >> GO TO 2.

NG >> Carry out self-diagnosis. Refer to [BRC-66, "SELF-DIAGNOSIS"](#).

2. CHECK WHEEL SENSORS

Check the following.

- Wheel sensor mounting for looseness
- Wheel sensors for physical damage
- Wheel sensor connectors for terminal damage or loose connections

OK or NG

OK >> GO TO 3.

NG >> Repair as necessary.

3. CHECK FRONT AXLE

Check front and rear axles for excessive looseness. Refer to [FAX-5, "FRONT WHEEL BEARING"](#) or [RAX-5, "REAR WHEEL BEARING"](#).

OK or NG

OK >> GO TO 4.

NG >> Repair as necessary.

4. CHECK BRAKE FLUID PRESSURE

Check brake fluid pressure distribution.

Refer to [BR-36, "Inspection"](#).

Is brake fluid pressure distribution normal?

Yes >> **INSPECTION END.**

No >> Perform Basic Inspection. Refer to [BRC-62, "Basic Inspection"](#).

A

B

C

D

E

BRC

G

H

I

J

K

L

M

Unexpected Pedal Action

1. CHECK WARNING LAMP ACTIVATION

Make sure warning lamp remains off while driving.

OK or NG

OK >> GO TO 2.

NG >> Carry out self-diagnosis. Refer to [BRC-66, "SELF-DIAGNOSIS"](#) .


2. CHECK BRAKE PEDAL STROKE

Check brake pedal stroke.

Is pedal stroke excessive?

Yes >> Perform Basic Inspection. Refer to [BRC-62, "Basic Inspection"](#) .

No >> GO TO 3.



3. CHECK CONNECTOR AND BRAKING PERFORMANCE

1. Disconnect ABS actuator and electric unit (control unit) connector.

2. Check brake effectiveness.

OK or NG

OK >> GO TO 4.

NG >> Perform Basic Inspection. Refer to [BRC-62, "Basic Inspection"](#) .

4. CHECK WHEEL SENSORS

Check the following.

- Wheel sensor mounting for looseness
- Wheel sensors for physical damage
- Wheel sensor connectors for terminal damage or loose connections

OK or NG

OK >> Check ABS actuator and electric unit (control unit) pin terminals for damage and the connection of harness connector. Reconnect ABS actuator and electric unit (control unit) harness connector. Then retest.

NG >> Repair as necessary.

Long Stopping Distance

EFS002YX

A

1. CHECK BASE BRAKING SYSTEM PERFORMANCE

1. Disable ABS by disconnecting ABS actuator and electric unit (control unit) connector.
2. Drive vehicle and check to see if stopping distance is still long.

B

OK or NG

C

- OK >> Go to [BRC-79, "ABS Works Frequently"](#) .
- NG >> Perform Basic Inspection. Refer to [BRC-62, "Basic Inspection"](#) .

NOTE:

Stopping distance may be longer than vehicles without ABS when road condition is slippery.

D

ABS Does Not Work

EFS002YY

E

CAUTION:

The ABS does not operate when the vehicle speed is 10 km/h (6 MPH) or less.

1. CHECK WARNING LAMP ACTIVATION

BRC

Turn ignition switch ON and check for warning lamp activation.

- Warning lamp should activate for approximately 1 second after turning the ignition switch ON.

G

OK or NG

- OK >> Carry out self-diagnosis. Refer to [BRC-66, "SELF-DIAGNOSIS"](#) .
- NG >> Go to [BRC-82, "ABS Warning Lamp Does Not Come On When Ignition Switch Is Turned On"](#) .

H

Pedal Vibration or ABS Operation Noise

EFS002YZ

I

NOTE:

During ABS activation, pedal vibration may be felt and a noise may be heard. This is normal and does not indicate a malfunction.

J

1. CHECK SYMPTOM

1. Apply brake.
2. Start engine.

K

Does the symptom occur only when engine is started?

- Yes >> Carry out self-diagnosis. Refer to [BRC-66, "SELF-DIAGNOSIS"](#) .
- No >> GO TO 2.

L

2. RECHECK SYMPTOM

M

Does the symptom occur only when electrical equipment switches (such as headlamp) are turned on?

- Yes >> Check for radio, antenna or related wiring that is routed too close to the ABS actuator and electric unit (control unit) and reroute as necessary.
- No >> Go to [BRC-79, "ABS Works Frequently"](#) .

ABS Warning Lamp Does Not Come On When Ignition Switch Is Turned On EFS002Z0**1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) FUSES**

Check 30A fusible link **g** and 30A fusible link **h** for ABS actuator and electric unit (control unit). For fusible link layout, refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).

OK or NG

OK >> GO TO 2.

NG >> If fusible link is blown, be sure to eliminate cause of problem before replacing.


2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUITS

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check voltage between ABS actuator connector terminal 1 and ground and terminal 15 and ground.

Does battery voltage exist?

Yes >> GO TO 3.

No >> Repair harness or connectors between fusible link and ABS actuator and electric unit (control unit).


**3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT**

Check continuity between ABS actuator connector terminal 16 and ground and terminal 30 and ground.

Does continuity exist?

Yes >> Replace ABS actuator and electric unit (control unit).

No >> Repair harness or connectors between ABS actuator and electric unit (control unit) and ground.

**ABS Warning Lamp Stays On When Ignition Switch Is Turned On** EFS002Z1**1. CARRY OUT SELF-DIAGNOSIS**

Carry out self-diagnosis. Refer to [BRC-66, "SELF-DIAGNOSIS"](#).

Are malfunctions detected in self-diagnosis?

Yes >> Refer to [BRC-69, "Display Item List"](#).

No >> Refer to [DI-45, "WARNING LAMPS"](#).

Vehicle Jerks During TCS Activation**1. ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS**

Perform ABS actuator and electric unit (control unit) self-diagnosis.

Are self-diagnosis result items displayed?

Yes >> After checking and repairing the applicable item, perform the ABS actuator and electric unit (control unit) self-diagnosis again.

No >> GO TO 2.

2. ENGINE SPEED SIGNAL INSPECTION

Perform data monitor with CONSULT-II for the ABS actuator and electric unit (control unit).

Is the engine speed at idle 400 rpm or higher?

Yes >> GO TO 4.

No >> GO TO 3.

3. ECM SELF-DIAGNOSIS

Perform ECM self-diagnosis.

Are self-diagnosis result items displayed?

Yes >> After checking and repairing the applicable item, perform the ECM self-diagnosis again.

No >> GO TO 4.

4. TCM SELF-DIAGNOSIS

Perform TCM self-diagnosis.

Are self-diagnosis result items displayed?

Yes >> After checking and repairing the applicable item, perform the ECM self-diagnosis again.

No >> GO TO 5.

5. CONNECTOR INSPECTION

Disconnect the ABS actuator and electric unit (control unit) connector and the ECM connectors and check the terminals for deformation, disconnection, looseness or damage.

OK or NG

OK >> GO TO 6.

NG >> Repair or replace the connector terminal.

6. CAN COMMUNICATION INSPECTION

Check the CAN communication system. Refer to [BRC-78, "CAN Communication System Inspection"](#).

OK or NG

OK >> **INSPECTION END.**

NG >> Reconnect the connectors, and perform ABS actuator and electric unit (control unit) self-diagnosis.

A

B

C

D

E

BRC

G

H

I

J


K

L

M

WHEEL SENSORS

Removal and Installation



CAUTION:

Be careful not to damage sensor edge and sensor rotor teeth.

When removing the front or rear wheel hub assembly, first remove the ABS wheel sensor from the assembly. Failure to do so may result in damage to the sensor wires making the sensor inoperative.

CAUTION:

Pull out the sensor being careful to turn it as little as possible. Do not pull on the sensor harness. Installation should be performed while paying attention to the following, and then tighten fasteners to the specified torque.

- Before installing wheel sensor, make sure no foreign materials (such as iron fragments) are adhered to the pick-up part of the sensor, to the inside of the sensor mounting hole or on the rotor mounting surface.

SENSOR ROTOR


Removal and Installation

NOTE:

The rear wheel sensor rotor is built into the rear wheel hub. For removal and installation procedure, refer to [RAX-6, "Removal and Installation"](#) .

REMOVAL


1. Remove the front wheel hub. Refer to [FAX-6, "Removal and Installation"](#) .
2. Remove the sensor rotor using suitable puller.



INSTALLATION

Install the sensor rotor using a hammer and a wooden block.

- Always replace sensor rotor with new one.




ACTUATOR AND ELECTRIC UNIT (ASSEMBLY)

PFP:47660

Removal and Installation

EFS002W9



WFIA0104E

REMOVAL

1. Disconnect battery cable.
2. Remove windshield wiper and linkage assembly. Refer to [WW-28, "REMOVAL"](#).
3. Drain brake fluid. Refer to [BR-8, "Changing Brake Fluid"](#).
4. Discharge the A/C refrigerant. Refer to [ATC-116, "HFC-134a \(R-134a\) Service Procedure"](#).
5. Disconnect and remove high-pressure and low-pressure A/C pipes to allow access to ABS actuator and electric unit (control unit). Refer to [ATC-118, "Components"](#).
6. Disconnect harness connectors from ABS actuator and electric unit (control unit).
7. Disconnect brake pipes.
8. Remove fasteners for ABS actuator and electric unit (control unit) and remove from vehicle.

INSTALLATION

CAUTION:

After installation of ABS actuator and electric unit (control unit), refill brake fluid. Then bleed air from system. Refer to [BR-8, "Bleeding Brake System"](#).

1. Position ABS actuator and electric unit (control unit) in vehicle.
2. Connect brake pipes and fasteners temporarily.
3. Tighten fasteners and brake pipes.
4. Connect ABS actuator and electric unit (control unit) harness connectors.
5. Install and connect high-pressure and low-pressure A/C pipes. Refer to [ATC-118, "Components"](#).
6. Install windshield wiper and linkage assembly. Refer to [WW-28, "INSTALLATION"](#).

- 7. Reconnect battery cable.
- 8. Evacuate and recharge the A/C system. Refer to [ATC-116, "HFC-134a \(R-134a\) Service Procedure"](#) .

A

B

C

D

E

BRC

G

H

I

J

K

L

M

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EFS002V3

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:


- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for Brake System

EFS002V4

CAUTION:

- Recommended fluid is brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- To clean or wash all parts of master cylinder and disc brake caliper, use clean brake fluid.
- Never use mineral oils such as gasoline or kerosene. They will ruin rubber parts of the hydraulic system.
- Use flare nut wrench when removing and installing brake tube.
- If a brake fluid leak is found, the part must be disassembled without fail. Then it has to be replaced with a new one if a defect exists.
- Turn the ignition switch OFF and remove the connector of the ABS actuator control unit or the battery terminal before performing the work.
- Always torque brake lines when installing.
- Burnish the brake contact surfaces after refinishing or replacing rotors, after replacing pads, or if a soft pedal occurs at very low mileage.
Refer to [BR-28, "Brake Burnishing"](#) (front disc brake) or [BR-35, "Brake Burnishing"](#) (rear disc brake).



WARNING:

- Clean brake pads and shoes with a waste cloth, then wipe with a dust collector.

Precautions When Using CONSULT-II

EFS0031Q

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

CHECK POINTS FOR USING CONSULT-II

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
 - If YES, GO TO 2.
 - If NO, GO TO 5.

2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
 - If YES, GO TO 3.
 - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-8, "CAN COMMUNICATION"](#).

Precautions for Brake Control

EFS002V5

- During ABS operation, the brake pedal may vibrate lightly and a mechanical noise may be heard. This is normal.
- Just after starting vehicle, the brake pedal may vibrate or a motor operating noise may be heard from engine compartment. This is a normal status of operation check.
- Stopping distance may be longer than that of vehicles without ABS when vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for simple causes before starting diagnosis. Besides electrical system inspection, check booster operation, brake fluid level, and fluid leaks.
- If incorrect tire sizes or types are installed on the vehicle or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- If there is a radio, antenna or related wiring near control module, ABS function may have a malfunction or error.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits or improper wiring.
- If the following components are replaced with non-genuine components or modified, the VDC OFF indicator lamp and SLIP indicator lamp may turn on or the VDC system may not operate properly. Components related to suspension (shock absorbers, struts, springs, bushings, etc.), tires, wheels (exclude specified size), components related to brake system (pads, rotors, calipers, etc.), components related to engine (muffler, ECM, etc.), components related to body reinforcement (roll bar, tower bar, etc.).
- Driving with broken or excessively worn suspension components, tires or brake system components may cause the VDC OFF indicator lamp and the SLIP indicator lamp to turn on, and the VDC system may not operate properly.
- When the TCS or VDC is activated by sudden acceleration or sudden turn, some noise may occur. The noise is a result of the normal operation of the TCS and VDC.
- When driving on roads which have extreme slopes (such as mountainous roads) or high banks (such as sharp curves on a freeway), the VDC may not operate normally, or the VDC warning lamp and the SLIP indicator lamp may turn on. This is not a problem if normal operation can be resumed after restarting the engine.
- Sudden turns (such as spin turns, acceleration turns), drifting, etc. with VDC turned off may cause the yaw rate/side G sensor to indicate a problem. This is not a problem if normal operation can be resumed after restarting the engine.

Precautions for CAN System


EFS002V6

- Do not apply voltage of 7.0V or higher to terminal to be measured.
- Maximum open terminal voltage of tester in use must be less than 7.0V.
- Before checking harnesses, turn ignition switch OFF and disconnect battery negative cable.


PRECAUTIONS

[VDC/TCS/ABS]

- Area to be repaired must be soldered and wrapped with tape. Make sure that fraying of twisted wire is within 110 mm (4.33 in).



- Do not make a bypass connection to repaired area. (If the circuit is bypassed, characteristics of twisted wire will be lost.)



EFS002V7

Wiring Diagrams and Trouble Diagnosis

When you read wiring diagrams, refer to the following:

- [GI-12, "How to Read Wiring Diagrams"](#)
- [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#)

When you perform trouble diagnosis, refer to the following:

- [GI-10, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#)
- [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#)

PREPARATION

[VDC/TCS/ABS]

PREPARATION


PFP:00002

Special Service Tool

EFS002V8

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.


Tool number (Kent-Moore No.) Tool name	Description
(J-45741) ABS active wheel sensor tester	Checking operation of ABS active wheel sensor



Commercial Service Tools


EFS002TE

Tool name	Description
1. Flare nut crowfoot a: 10mm (0.39 in)/12mm (0.47 in) 2. Torque wrench	Removing and installing brake piping



SYSTEM DESCRIPTION

System Components



ABS Function

- The Anti-Lock Brake System detects wheel revolution while braking and improves handling stability during sudden braking by electrically preventing wheel lockup. Maneuverability is also improved for avoiding obstacles.
- If the electrical system malfunctions, the Fail-Safe function is activated, the ABS becomes inoperative and the ABS warning lamp turns on.
- The electrical system can be diagnosed using CONSULT-II.
- During ABS operation, the brake pedal may vibrate lightly and a mechanical noise may be heard. This is normal.
- Just after starting the vehicle, the brake pedal may vibrate or a motor operating noise may be heard from engine compartment. This is a normal status of operation check.
- Stopping distance may be longer than that of vehicles without ABS when vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.

EBD Function

- Electronic Brake Distribution is a function that detects subtle slippages between the front and rear wheels during braking, and it improves handling stability by electronically controlling the brake fluid pressure which results in reduced rear wheel slippage.
- If the electrical system malfunctions, the Fail-Safe function is activated, the EBD and ABS become inoperative, and the ABS warning lamp and BRAKE warning lamp are turned on.
- The electrical system can be diagnosed using CONSULT-II.
- During EBD operation, the brake pedal may vibrate lightly and a mechanical noise may be heard. This is normal.
- Just after starting the vehicle, the brake pedal may vibrate or a motor operating noise may be heard from engine compartment. This is a normal status of operation check.

- Stopping distance may be longer than that of vehicles without EBD when vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.

A

TCS Function

EFS002TK

- Spinning of the drive wheels is detected by the ABS/TCS/VDC control unit using inputs from the wheel speed sensors. If wheel spin occurs, the drive wheel right and left brake fluid pressure control and engine fuel cut are conducted while the throttle value is restricted to reduce the engine torque and decrease the amount of wheel spin. In addition, the throttle opening is controlled to achieve the optimum engine torque.
- Depending on road condition, the vehicle may have a sluggish feel. This is normal, because optimum traction has the highest priority during TCS operation.
- TCS may be activated during sudden vehicle acceleration, wide open throttle acceleration, sudden transmission shifts or when the vehicle is driven on a road with a varying surface friction coefficient.
- The SLIP indicator lamp flashes to inform the driver of TCS operation.

B

C

D

VDC Function

EFS002TJ

- In addition to the ABS/TCS function, the driver steering amount and brake operation amount are detected from the steering angle sensor and pressure sensor, and the vehicle's driving status (amount of under steering/over steering) is determined using inputs from the yaw rate sensor/side G sensor, wheel speed sensors, etc. and this information is used to improve vehicle stability by controlling the braking and engine torque application to the wheels.
- The SLIP indicator lamp flashes to inform the driver of VDC operation.
- During VDC operation, the vehicle body and brake pedal may vibrate lightly and a mechanical noise may be heard. This is normal.
- The ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp may turn on when the vehicle is subject to strong shaking or large vibration, such as when the vehicle is on a turn table or a ship while the engine is running or steep slope. In this case, restart the engine on a normal road and if the ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp turn off, there is no problem.

E

BRC

G

H

I

J


K

L


M

Wheel Sensors

The front sensor units consist of a gear-shaped sensor rotor and a sensor element. The element contains a magnet around which a coil is wound. The front wheel sensors are installed on the front of the wheel knuckles. As the wheel rotates, the sensor generates a square-wave signal. The frequency increases as the wheel speed increases.



The rear sensor units consist of wheel hubs with a series of internal magnets and a sensor element. The rear wheel sensors are installed on the inner side of the wheel knuckles. As the wheel rotates, the sensor generates a square-wave signal. The frequency increases as the wheel speed increases.



Fail-Safe Function ABS/EBD SYSTEM

In case of an electrical malfunction with the ABS, the ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp will turn on. In case of an electrical malfunction with the EBD system, the BRAKE warning lamp, ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp will turn on. The system will revert to one of the following conditions of the Fail-Safe function.

1. For ABS malfunction, only the EBD is operative and the condition of the vehicle is the same condition of vehicles without ABS/TCS/VDC system.
2. For EBD malfunction, the EBD and ABS become inoperative, and the condition of the vehicle is the same as the condition of vehicles without ABS/TCS/VDC or EBD system.

VDC/TCS SYSTEM


In case of TCS/VDC system malfunction, the VDC OFF indicator lamp and SLIP indicator lamp are turned on and the condition of the vehicle is the same as the condition of vehicles without TCS/VDC system. In case of an electrical malfunction with the TCS/VDC system, the ABS control continues to operate normally without TCS/VDC control.

CAUTION:

If the Fail-Safe function is activated, perform the Self Diagnosis for ABS/TCS/VDC system.

Hydraulic Circuit Diagram

EFS002TO



PFIA0452E

CAN COMMUNICATION

PFP:23710

System Description

EFS00315

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Refer to [LAN-8, "CAN COMMUNICATION"](#) .

TROUBLE DIAGNOSIS

How to Perform Trouble Diagnoses for Quick and Accurate Repair

INTRODUCTION



The ABS/TCS/VDC system has an electronic control unit to control major functions. The control unit accepts input signals from sensors and controls actuator operation. It is also important to check for conventional problems such as air leaks in the booster or lines, lack of brake fluid, or other problems with the brake system.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electrical connections or faulty wiring. In this case, careful checking of suspicious circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problem, so a road test should be performed.


Before undertaking actual checks, take just a few minutes to talk with a customer who approaches with an ABS/TCS/VDC complaint. The customer is a very good source of information on such problems, especially intermittent ones. Through the talks with the customer, find out what symptoms are present and under what conditions they occur.

Start your diagnosis by looking for "conventional" problems first. This is one of the best ways to troubleshoot brake problems on an ABS/TCS/VDC equipped vehicle. Also check related Service Bulletins for information.



A
B
C
D
E
BRC
G
H
I
J
K
L
M

WORK FLOW



TROUBLE DIAGNOSIS

[VDC/TCS/ABS]

CLARIFY CONCERN

- A customer's description of a vehicle concern may vary depending on the individual. It is important to clarify the customer's concern.
- Ask the customer about what symptoms are present under what conditions. Use this information to reproduce the symptom while driving.
- It is also important to use the diagnosis sheet to understand what type of trouble the customer is having.

KEY POINTS

WHAT Vehicle model
WHEN Date, Frequencies
WHERE Road conditions
HOW Operating conditions,
Weather conditions,
Symptoms

SBR339B








EXAMPLE OF DIAGNOSIS SHEET

Customer name	Model & Year		VIN
Engine #	Trans.		Mileage
Incident Date	Manuf. Date		In Service Date
Symptoms	☐ Noise and vibration (from engine compartment)	☐ ABS warning lamp activates	☐ Pedal operation
	☐ Noise and vibration (from axle)	☐ SLIP warning lamp activates	☐ Large stroke pedal operation
	☐ TCS does not work (drive wheels slip when accelerating)	☐ ABS does not work (wheels slip when braking)	☐ Firm pedal
	☐ Lack of sense of acceleration		
Engine conditions	☐ When starting ☐ After starting		
Road conditions	☐ Low friction road (☐ Snow ☐ Gravel ☐ Other) ☐ Bumps/potholes		
Driving conditions	☐ Full-acceleration ☐ High speed cornering ☐ Vehicle speed: Greater than 10 km/h (6 MPH) ☐ Vehicle speed: 10 km/h (6 MPH) or less ☐ Vehicle is stopped		
Applying brake conditions	☐ Suddenly ☐ Gradually		
Other conditions	☐ Operation of electrical equipment ☐ Shift change ☐ Other descriptions		


WFIA0097E

Component Parts and Harness Connector Location

EFS002XY



Schematic



[VDC/TCS/ABS]

EFS002Y0

Wiring Diagram for ABS/TCS/VDC Control Unit

Power Supply:

- BATTERY** (10A 20) → **FUSE BLOCK (J/B) (E30)** → **R/Y** → **STOP LAMP SWITCH (E38)** → **P/L** → **DIAG-K** → **ABS/TCS/VDC CONTROL UNIT (E125)**
- BATTERY** (10A 12) → **FUSE BLOCK (J/B) (E30)** → **P** → **IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) (E124)** → **GR** → **IGN** → **ABS/TCS/VDC CONTROL UNIT (E125)**

Switches and Relays:


- IGNITION SWITCH ON OR START** (10A 49) → **GR** → **IGN** → **ABS/TCS/VDC CONTROL UNIT (E125)**
- IGNITION SWITCH ON OR START** (10A 12) → **P** → **IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) (E124)** → **GR** → **IGN** → **ABS/TCS/VDC CONTROL UNIT (E125)**
- ASC D BRAKE SWITCH (E37)** → **1** → **RELEASED** → **2** → **G/B** → **2** → **G/R** → **G/R** → **TO EC-ASCBOF EC-ASC/BS** → **5** → **G/B** → **37** → **ASC D BR** → **ABS/TCS/VDC CONTROL UNIT (E125)**
- STOP LAMP SWITCH (E38)** → **1** → **DEPRESSED** → **2** → **R/G** → **15** → **P/L** → **6** → **R/G** → **23** → **BRL** → **ABS/TCS/VDC CONTROL UNIT (E125)**

Connectors and Wires:



- GR** (Green/Red)
- P** (Purple)
- R/Y** (Red/Yellow)
- G/B** (Green/Blue)
- G/R** (Green/Red)
- R/G** (Red/Green)
- P/L** (Purple/Light Blue)
- LG** (Light Green)
- P/L** (Purple/Light Blue)

Other Components:





- DATA LINK CONNECTOR (M22)** → **7** → **LG** → **16** → **P/L** → **8** → **DIAG-K** → **ABS/TCS/VDC CONTROL UNIT (E125)**
- ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) (E125)**





(E30) - FUSE BLOCK -
JUNCTION BOX (J/B)



BRC-VDC-03





[VDC/TCS/ABS]

 : DATA LINE






Diagram showing the wiring connections for the relays:

- M47 W**: 3, 2, 1, 8, 7, 6, 5, 4
- M49 GR**: 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20
- M50 GR**: 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36
- M81 GR**: 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20
- E125 B**: 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46

Legend: W (Wiring), GR (Ground), H.S. (High Speed)

WFWA0032F



REFER TO THE FOLLOWING.

M4 - FUSE BLOCK - JUNCTION BOX (J/B)

Basic Inspection**BRAKE FLUID LEVEL, FLUID LEAK, AND BRAKE PAD INSPECTION**

1. Check fluid level in the brake fluid reservoir. If fluid level is low, add fluid.
2. Check the brake piping and around the ABS actuator and electric unit (control unit) for leaks. If there is leaking or seeping fluid, check the following items.
 - If ABS actuator and electric unit (control unit) connection is loose, tighten the piping to the specified torque and recheck for leaks.
 - If there is damage to the connection flare nut or ABS actuator and electric unit (control unit) screw, replace the damaged part and recheck for leaks.
 - When there is fluid leaking or seeping from a fluid connection, use a clean cloth to wipe off the fluid and recheck for leaks. If fluid is still seeping out, replace the damaged part. If the fluid is leaking at the ABS actuator and electric unit (control unit), replace the ABS actuator and electric unit (control unit) assembly.

CAUTION:

The ABS actuator and electric unit (control unit) cannot be disassembled and must be replaced as an assembly.

3. Check the brake pads for excessive wear.

POWER SYSTEM TERMINAL LOOSENESS AND BATTERY INSPECTION

Make sure the battery positive cable, negative cable and ground connection are not loose. In addition, make sure the battery is sufficiently charged.

ABS WARNING LAMP, SLIP INDICATOR LAMP AND VDC OFF INDICATOR LAMP INSPECTION

1. Make sure ABS warning lamp, SLIP indicator lamp and VDC OFF indicator lamp (when VDC OFF switch is off), turn on for approximately 1 second when the ignition switch is turned ON. If they do not, check the VDC OFF indicator lamp and then VDC OFF switch. Refer to [BRC-131, "VDC OFF SWITCH"](#). Check CAN communications. If there are no errors with VDC OFF switch and CAN communication system, check combination meter. Refer to [DI-5, "COMBINATION METERS"](#).
2. Make sure the lamps turn off approximately 1 second after the ignition switch is turned ON. If the lamp does not turn off, conduct self-diagnosis.
3. With the engine running, make sure VDC OFF indicator lamp turns on and off when VDC OFF switch is turned on and off. If the indicator lamp status does not correspond to switch operation, check the VDC OFF switch system. Refer to [BRC-131, "VDC OFF SWITCH"](#).
4. Make sure ABS warning lamp, SLIP indicator lamp and VDC OFF indicator lamp turn off approximately 2 seconds after the engine is started. If ABS warning lamp, SLIP indicator lamp or VDC OFF indicator lamp have not turned off 10 seconds after the engine has been started, conduct self-diagnosis of the ABS actuator and electric unit (control unit).
5. After conducting the self-diagnosis, be sure to erase the error memory. Refer to [BRC-112, "CONSULT-II Function"](#).

Warning Lamp and Indicator Timing

× : ON – : Lamp OFF

Condition	ABS warning lamp	VDC OFF indicator lamp	SLIP indicator lamp	Remarks
When the ignition switch is OFF	–	–	–	–
After the ignition switch is turned ON For approx. 0.5 seconds	×	×	×	–
Ignition switch ON Approx. 0.5 seconds later	–	–	–	Lamp goes off approx. 2 seconds after the engine start.
When the VDC OFF switch turns ON (VDC function OFF).	–	×	–	–

TROUBLE DIAGNOSIS

[VDC/TCS/ABS]

Condition	ABS warning lamp	VDC OFF indicator lamp	SLIP indicator lamp	Remarks
ABS/TCS/VDC malfunction	×	×	×	—
	×	×	—	When the ABS/TCS/VDC control unit is malfunctioning (power supply or ground malfunction).
When the VDC is malfunctioning.	—	×	×	—

Control Unit Input/Output Signal Standard REFERENCE VALUE FROM CONSULT-II

EFS002Y2

CAUTION:

The display shows the control unit calculation data, so a normal value might be displayed even in the event the output circuit (harness) is open or short circuited.

Monitor item	Display content	Data monitor		Note: Error inspection checklist
		Condition	Reference value in normal operation	
SLCT LVR POSI	PNP switch signal ON/OFF condition	A/T shift position = N or P position	ON	BRC-130, "CAN Communication System Inspection"
		A/T shift position = other than N and P positions	OFF	
GEAR	A/T gear position	1:1st gear 2:2nd gear 3:3rd gear 4:4th gear	—	
FR RH SENSOR FR LH SENSOR RR RH SENSOR RR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]	BRC-121, "Wheel Sensor System Inspection"
		Vehicle running (Note 1)	Almost in accordance with speedometer display (within ±10%)	
ACCEL POS SIG	Open/close condition of throttle valve (linked with accelerator pedal).	Accelerator pedal not depressed (ignition switch is ON)	0%	BRC-130, "CAN Communication System Inspection"
		Depress accelerator pedal (ignition switch is ON)	0 to 100%	
ENGINE SPEED	With engine running	With engine stopped	0 rpm	BRC-122, "Engine System Inspection"
		Engine running	Almost in accordance with tachometer display	
STR ANGLE SIG	Steering angle detected by steering angle sensor	Straight-ahead	Approx. 0 deg	BRC-123, "Steering Angle Sensor System Inspection"
		Steering wheel turned	−756 to 756 deg	
YAW RATE SEN	Yaw rate detected by yaw rate sensor	Vehicle stopped	Approx. 0 d/s	BRC-124, "Yaw Rate/Side/Decel G Sensor System Inspection"
		Vehicle running	−100 to 100 d/s	
SIDE G SENSOR	Transverse G detected by side G-sensor	Vehicle stopped	Approx. 0 m/s ²	BRC-124, "Yaw Rate/Side/Decel G Sensor System Inspection"
		Vehicle running	−16.7 to 16.7 m/s ²	
PRESS SENSOR	Brake fluid pressure detected by pressure sensor	With ignition switch turned ON and brake pedal released	Approx. 0 bar	—
		With ignition switch turned ON and brake pedal depressed	−0 to 350 bar	
BATTERY VOLT	Battery voltage supplied to ABS actuator and electric unit (control unit)	Ignition switch ON	10 to 16V	BRC-129, "ABS/TCS/VDC Control Unit Power and Ground Systems Inspection"

TROUBLE DIAGNOSIS

[VDC/TCS/ABS]

Monitor item	Display content	Data monitor		Note: Error inspection checklist
		Condition	Reference value in normal operation	
STOP LAMP SW	Brake pedal operation	Brake pedal depressed	ON	BRC-128, "Stop Lamp Switch System Inspection"
		Brake pedal not depressed	OFF	
OFF SW	VDC OFF switch ON/OFF status	VDC OFF switch ON (When VDC OFF indicator lamp is ON)	ON	BRC-131, "VDC OFF SWITCH"
		VDC OFF switch OFF (When VDC OFF indicator lamp is OFF)	OFF	
ABS WARN LAMP	ABS warning lamp ON condition (Note 2)	ABS warning lamp ON	ON	BRC-135, "ABS Warning Lamp Does Not Come On When Ignition Switch Is Turned On"
		ABS warning lamp OFF	OFF	
MOTOR RELAY	Operation status of motor and motor relay	Ignition switch ON or engine running (ABS not operated)	OFF	BRC-127, "Actuator Motor, Motor Relay, and Circuit Inspection"
		Ignition switch ON or engine running (ABS operated)	ON	
ACTUATOR RLY	Actuator relay operation status	Vehicle stopped (Ignition switch ON)	OFF	BRC-127, "Actuator Motor, Motor Relay, and Circuit Inspection"
		Vehicle stopped (Engine running)	ON	
OFF LAMP	VDC OFF indicator lamp status (Note 3)	When VDC OFF indicator lamp is ON	ON	BRC-130, "CAN Communication System Inspection"
		When VDC OFF indicator lamp is OFF	OFF	
SLIP LAMP	SLIP indicator lamp status (Note 4)	When SLIP indicator lamp is ON	ON	BRC-130, "CAN Communication System Inspection"
		When SLIP indicator lamp is OFF	OFF	
FR LH IN SOL FR LH OUT SOL FR RH IN SOL FR RH OUT SOL RR RH IN SOL RR RH OUT SOL RR LH IN SOL RR LH OUT SOL	Solenoid valve operation	Actuator (solenoid) is active ("ACTIVE TEST" with CONSULT-II) or actuator relay is inactive (in fail-safe mode).	ON	BRC-126, "Solenoid and VDC Change-Over Valve System Inspection"
		When actuator (solenoid) is not active and actuator relay is active (ignition switch ON).	OFF	
CV1 CV2 SV1 SV2	VDC switch-over valve status	When actuator (switch-over valve) is active ("ACTIVE TEST" with CONSULT-II) or actuator relay is inactive (when in fail-safe mode).	ON	BRC-126, "Solenoid and VDC Change-Over Valve System Inspection"
		When actuator (switch-over valve) is not active and actuator relay is active (ignition switch ON).	OFF	
DECEL G-SEN	Longitudinal acceleration detected by Decel G-Sensor	Vehicle stopped	ON	BRC-124, "Yaw Rate/Side/Decel G Sensor System Inspection"
		Vehicle running	OFF	

TROUBLE DIAGNOSIS

[VDC/TCS/ABS]

Monitor item	Display content	Data monitor		Note: Error inspection checklist
		Condition	Reference value in normal operation	
FLUID LEV SW	ON/OFF status of brake fluid level switch	When brake fluid level switch ON	ON	DI-45. "WARNING LAMPS"
		When brake fluid level switch OFF	OFF	
VDC FAIL SIG TCS FAIL SIG ABS FAIL SIG EBD FAIL SIG	Fail signal status	VDC fail TCS fail ABS fail EBD fail	OFF	VDC system TCS system ABS system EBD system

Note 1: Confirm tire pressure is normal.

Note 2: ON/OFF timing of ABS warning lamp

ON: For approximately 1.8 seconds after ignition switch is turned ON, or when a malfunction is detected.

OFF: Approximately 1.8 seconds after ignition switch is turned ON (when system is in normal operation) and TCS/VDC function is not activated.

Note 3: ON/OFF timing of VDC OFF indicator lamp

ON: For approximately 1.8 seconds after ignition switch is turned ON, or when a malfunction is detected and VDC OFF switch is ON.

OFF: Approximately 1.8 seconds after ignition switch is turned ON (when system is in normal operation.) And when VDC OFF switch is OFF.

Note 4: SLIP indicator lamp ON/OFF timing

ON: For approximately 1.8 seconds after ignition switch is turned ON, or when a malfunction is detected and TCS/VDC function is activated while driving.

OFF: Approximately 1.8 seconds after ignition switch is turned ON (when system is in normal operation) and TCS/VDC function is not activated.

Flashing: TCS/VDC function is active during driving

A

B

C

D

E

BRC

G

H

I

J

K

L

M

CONSULT-II Function**CAUTION:**

- When the self-diagnosis, data monitor, or active test functions are being executed, EBD, ABS, TCS, and VDC control is disabled.
- When using CONSULT-II to conduct ABS/TCS/VDC control unit self-diagnosis, active test, work support, etc., first stop engine, connect the CONSULT-II, and select "ABS".
- CONSULT-II self-diagnosis results are displayed without regard to occurrence timing. In some cases later ones (timing value is small) appear on the next screen.
- When an error is shown by the CONSULT-II SELF-DIAG RESULTS and CONSULT-II is used to conduct an active test, an engine system malfunction may be shown, but restarting the engine will return the status to normal.

CONSULT-II FUNCTION APPLICATION

Item	Self-diagnosis	Data monitor	Active test
Wheel sensors	×	×	—
Stop lamp switch	×	×	—
Solenoid valves	×	×	×
Switch-over solenoid valves	×	×	—
Yaw rate/side G sensor	×	×	—
Pressure sensor	×	×	—
Steering angle sensor	×	×	—
Actuator relay	×	×	×
Motor relay	×	×	×
ABS warning lamp	—	×	—
Battery voltage	×	×	—
ABS actuator and electric unit (control unit)	×	—	—
ABS/TCS/VDC actuator motor	×	×	×
CAN communication	×	—	—
Engine speed signal	×	×	—
VDC OFF switch	—	×	—
VDC OFF indicator lamp	—	×	—
SLIP indicator lamp	—	×	—
Throttle angle	—	×	—
Gear	—	×	—
Selector lever position	—	×	—
EBD/ABS/TCS/VDC signals	×	×	—
Brake fluid level switch	×	×	—

×: Applicable

—: Not applicable


CONSULT-II BASIC OPERATION PROCEDURE

1. Turn ignition switch OFF.
2. Connect CONSULT-II and CONSULT-II CONVERTER to the data link connector.


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


3. Turn ignition switch ON.



4. Touch "START (NISSAN BASED VHCL)".



5. Touch "ABS" in the "Diagnosis System Selection" screen. If "ABS" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



6. Select the required diagnostic location from the "Diagnosis Mode Selection" screen. For further information, see the CONSULT-II Operation Manual.

SELF-DIAGNOSIS**Description**

If an error is detected in the system, the ABS warning lamp will turn on. In this case, perform self-diagnosis as follows:

Operation Procedure

1. Turn ignition switch OFF.
2. Connect CONSULT-II and CONSULT-II CONVERTER to the data link connector.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

3. Turn ignition switch ON.
4. Start engine and drive at approximately 30 km/h (19 MPH) for approximately 1 minute.
5. After stopping the vehicle, with the engine running, touch "START (NISSAN BASED VHCL)", "ABS", "SELF-DIAG RESULTS" in order on the CONSULT-II screen.

CAUTION:

If "START (NISSAN BASED VHCL)" is touched immediately after starting the engine or turning on the ignition switch, "ABS" might not be displayed in the System Selection screen. In this case, repeat the operation from step 1.

6. The self-diagnostic results are displayed. (If necessary, the self-diagnostic results can be printed out by touching "COPY".)
 - When "NO FAILURE" is displayed, check the ABS warning lamp, SLIP indicator lamp and VDC OFF indicator lamp.
7. Conduct the appropriate inspection from the display item list, and repair or replace the malfunctioning component.
8. Start engine and drive at approximately 30 km/h (19 MPH) for approximately 1 minute.

CAUTION:

● When a wheel sensor "short-circuit" is detected, if the vehicle is not driven at 30 km/h (19 MPH) for at least 1 minute, the ABS warning lamp will not turn off even if the malfunction is repaired.

9. Turn ignition switch OFF to prepare for erasing the memory.
10. Start the engine and touch "START (NISSAN BASED VHCL)", "ABS", "SELF-DIAG RESULTS", "ERASE MEMORY" in order on the CONSULT-II screen to erase the error memory.
If "ABS" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).

CAUTION:

If the error memory is not erased, re-conduct the operation from step 5.

11. For the final inspection, drive at approximately 30 km/h (19 MPH) for approximately 1 minute and confirm that the ABS warning lamp, SLIP indicator lamp, and VDC OFF indicator lamp are off.

Display Item List

Self-diagnostic item	Malfunction detecting condition	Check system
FR LH SENSOR 1 [C1104]	Circuit of front LH wheel sensor is open	BRC-121, "Wheel Sensor System Inspection" (Note 1)
RR RH SENSOR 1 [C1101]	Circuit of rear RH wheel sensor is open	
FR RH SENSOR 1 [C1103]	Circuit of front RH wheel sensor is open	
RR LH SENSOR 1 [C1102]	Circuit of rear LH wheel sensor is open	
FR LH SENSOR 2 [C1108]	Circuit of front LH wheel sensor is shorted, or sensor power voltage is unusual. ABS actuator and electric unit (control unit) cannot identify sensor pulses, because of large gap between wheel sensor and sensor rotor.	
RR RH SENSOR 2 [C1105]	Circuit of rear RH wheel sensor is shorted, or sensor power voltage is unusual. ABS actuator and electric unit (control unit) cannot identify sensor pulses, because of large gap between wheel sensor and sensor rotor.	
FR RH SENSOR 2 [C1107]	Circuit of front RH wheel sensor is shorted, or sensor power voltage is unusual. ABS actuator and electric unit (control unit) cannot identify sensor pulses, because of large gap between wheel sensor and sensor rotor.	
RR LH SENSOR 2 [C1106]	Circuit of rear LH wheel sensor is shorted, or sensor power voltage is unusual. ABS actuator and electric unit (control unit) cannot identify sensor pulses, because of large gap between wheel sensor and sensor rotor.	
STOP LAMP SW 1 [C1116]	Stop lamp switch or circuit malfunction.	BRC-128, "Stop Lamp Switch System Inspection"
ST ANGLE SEN CIRCUIT [C1143, C1163]	Neutral position of steering angle sensor is dislocated, or steering angle sensor is malfunctioning.	BRC-123, "Steering Angle Sensor System Inspection"

TROUBLE DIAGNOSIS

[VDC/TCS/ABS]

Self-diagnostic item	Malfunction detecting condition	Check system
YAW RATE SENSOR [C1145]	Yaw rate sensor has generated an error, or yaw rate sensor signal line is open or shorted.	BRC-124, "Yaw Rate/Side/Decel G Sensor System Inspection"
FR LH IN ABS SOL [C1120]	Circuit of front LH IN ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	BRC-126, "Solenoid and VDC Change-Over Valve System Inspection"
FR LH OUT ABS SOL [C1121]	Circuit of front LH OUT ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
RR RH IN ABS SOL [C1126]	Circuit of rear RH IN ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
RR RH OUT ABS SOL [C1127]	Circuit of rear RH OUT ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
FR RH IN ABS SOL [C1122]	Circuit of front RH IN ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
FR RH OUT ABS SOL [C1123]	Circuit of front RH OUT ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
RR LH IN ABS SOL [C1124]	Circuit of rear LH IN ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
RR LH OUT ABS SOL [C1125]	Circuit of rear LH OUT ABS solenoid is open or shorted, or control line is open or shorted to power supply or ground.	
CV1 [C1164]	Front side VDC switch-over solenoid valve (cut valve) is open or shorted, or control line is open or shorted to power supply or ground.	
CV2 [C1165]	Rear side VDC switch-over solenoid valve (cut valve) is open or shorted, or control line is open or shorted to power supply or ground.	
SV1 [C1166]	Front side VDC switch-over solenoid valve (suction valve) is open or shorted, or control line is open or shorted to power supply or ground.	BRC-127, "Actuator Motor, Motor Relay, and Circuit Inspection"
SV2 [C1167]	Rear side VDC switch-over solenoid valve (suction valve) is open or shorted, or control line is open or shorted to power supply or ground.	
PUMP MOTOR (Note 3) [C1111]	During actuator motor operation with ON, when actuator motor turns OFF or when control line for actuator motor relay is open. During actuator motor operation with OFF, when actuator motor turns ON or when control line for relay is shorted to ground.	BRC-129, "ABS/TCS/VDC Control Unit Power and Ground Systems Inspection"
BATTERY VOLTAGE [ABNORMAL] [C1109]	ABS actuator and electric unit (control unit) power voltage is too low.	BRC-123, "Steering Angle Sensor System Inspection"
ST ANGLE SEN SIGNAL [C1144]	Neutral position correction of steering angle sensor is not finished.	
ST ANG SEN COM CIR [C1156]	CAN communication line or steering angle sensor has generated an error.	
LONGITUDINAL G-SENSOR [C1113]	Longitudinal G-sensor is malfunctioning, or signal line of longitudinal G-sensor is open or shorted.	BRC-124, "Yaw Rate/Side/Decel G Sensor System Inspection"
CONTROLLER FAILURE [C1110]	Internal malfunction of ABS actuator and electric unit (control unit)	BRC-123, "ABS/TCS/VDC Control Unit Inspection"
CAN COMM CIRCUIT [U1000]	- CAN communication line is open or shorted. - ABS actuator and electric unit (control unit) internal malfunction - Battery voltage for ECM is suddenly interrupted for approximately 0.5 seconds or more.	BRC-130, "CAN Communication System Inspection" (Note 2)

A

B

C

D

E

BRC

G

H

I

J

K

L

M

TROUBLE DIAGNOSIS

[VDC/TCS/ABS]

Self-diagnostic item	Malfunction detecting condition	Check system
LATERAL G-SENSOR [C1146]	Lateral G-sensor is malfunctioning, or signal line of lateral G-sensor is open or shorted.	BRC-124, "Yaw Rate/Side/Decel G Sensor System Inspection"
BR FLUID LEVEL LOW [C1155]	Brake fluid level drops or circuit between ABS actuator and electric unit (control unit) and brake fluid level switch is open or shorted.	DI-45, "WARNING LAMPS"
ENGINE SPEED SIG	Engine speed signal from ECM is abnormal.	BRC-122, "Engine System Inspection"
ENGINE SIGNAL 1 [C1130]	ECM judges the communication between ABS/TCS/VDC control unit and ECM is abnormal.	BRC-130, "CAN Communication System Inspection"
STOP LAMP SW 2 [C1176]	ASCD brake switch or circuit malfunction.	EC-686, "AUTOMATIC SPEED CONTROL DEVICE (ASCD)"

Note 1. If wheel sensor 2 for each wheel is indicated, check ABS actuator and electric unit (control unit) power supply voltage in addition to wheel sensor circuit check.

Note 2. If multiple malfunctions are detected including CAN communication line [U1000], perform diagnosis for CAN communication line first.

Note 3: "ACTUATOR RLY" on the CONSULT-II self-diagnosis results indicates the malfunction of the actuator motor relay or circuit.

DATA MONITOR

Operation Procedure

- After turning OFF the ignition switch, connect CONSULT-II and the CONVERTER to the data link connector.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

- Touch "START (NISSAN BASED VHCL)", "ABS", "DATA MONITOR" in order on the CONSULT-II screen. If "ABS" is not indicated, go to [GI-36, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).

CAUTION:

When "START (NISSAN BASED VHCL)" is touched immediately after starting the engine or turning on the ignition switch, "ABS" might not be displayed in the system selection screen. In this case, repeat the operation from step 2.

- Return to the Monitor Item Selection screen, and touch "C/U INPUT ITEM", "MAIN ITEM" or "ITEM MENU SELECTION". Refer to the following information.
- When "START" is touched, the data monitor screen is displayed.

Display Item List

Item (Unit)	Data monitor item selection				Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	CAN DIAG SUPPORT MNTR	
GEAR	×	×	×	—	Gear position judged by PNP switch signal is displayed.
FR RH SENSOR (km/h, MPH)	×	×	×	—	Wheel speed calculated by front RH wheel sensor signal is displayed.
FR LH SENSOR (km/h, MPH)	×	×	×	—	Wheel speed calculated by front LH wheel sensor signal is displayed.
RR RH SENSOR (km/h, MPH)	×	×	×	—	Wheel speed calculated by rear RH wheel sensor signal is displayed.

TROUBLE DIAGNOSIS

[VDC/TCS/ABS]

Item (Unit)	Data monitor item selection				Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	CAN DIAG SUPPORT MNTR	
RR LH SENSOR (km/h, MPH)	×	×	×	—	Wheel speed calculated by rear LH wheel sensor signal is displayed.
BATTERY VOLT (V)	×	×	×	—	Voltage supplied to ABS actuator and electric unit (control unit) is displayed.
SLCT LVR POSI	×	×	×	—	Shift position judged by PNP switch signal.
ACCEL POS SIG (%)	×	—	×	—	Throttle valve open/close status judged by LAN communication signal is displayed.
ENGINE SPEED (rpm)	×	×	×	—	Engine speed judged by LAN communication signal is displayed.
STR ANGLE SIG (deg)	×	—	×	—	Steering angle detected by steering angle sensor is displayed.
YAW RATE SEN (d/s)	×	×	×	—	Yaw rate detected by yaw rate sensor is displayed.
DECEL G SEN (d/s)	×	×	×	—	Longitudinal acceleration detected by Decel G-sensor is displayed.
SIDE G-SENSOR (m/s ²)	×	—	×	—	Transverse acceleration detected by side G-sensor is displayed.
PRESS SENSOR (bar)	×	—	×	—	Brake fluid pressure detected by pressure sensor is displayed.
STOP LAMP SW (ON/OFF)	×	×	×	—	Stop lamp switch (ON/OFF) status is displayed.
OFF SW (ON/OFF)	×	×	×	—	VDC OFF switch (ON/OFF) status is displayed.
ABS WARN LAMP (ON/OFF)	—	×	×	—	ABS warning lamp (ON/OFF) status is displayed.
SLIP LAMP (ON/OFF)	—	×	×	—	SLIP indicator lamp (ON/OFF) status is displayed.
FR LH IN SOL (ON/OFF)	—	×	×	—	Front LH IN ABS solenoid (ON/OFF) status is displayed.
FR LH OUT SOL (ON/OFF)	—	×	×	—	Front LH OUT ABS solenoid (ON/OFF) status is displayed.
RR RH IN SOL (ON/OFF)	—	×	×	—	Rear RH IN ABS solenoid (ON/OFF) status is displayed.
RR RH OUT SOL (ON/OFF)	—	×	×	—	Rear RH OUT ABS solenoid (ON/OFF) status is displayed.
FR RH IN SOL (ON/OFF)	—	×	×	—	Front RH IN ABS solenoid (ON/OFF) status is displayed.
FR RH OUT SOL (ON/OFF)	—	×	×	—	Front RH OUT ABS solenoid (ON/OFF) status is displayed.
RR LH IN SOL (ON/OFF)	—	×	×	—	Rear LH IN ABS solenoid (ON/OFF) status is displayed.
RR LH OUT SOL (ON/OFF)	—	×	×	—	Rear LH OUT ABS solenoid (ON/OFF) status is displayed.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

TROUBLE DIAGNOSIS

[VDC/TCS/ABS]

Item (Unit)	Data monitor item selection				Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	CAN DIAG SUPPORT MNTR	
OFF LAMP (ON/OFF)	—	×	×	—	OFF Lamp (ON/OFF) status is displayed.
MOTOR RELAY (ON/OFF)	—	×	×	—	ABS motor relay signal (ON/OFF) status is displayed.
ACTUATOR RLY (ON/OFF)	—	×	×	—	ABS actuator relay signal (ON/OFF) status is displayed.
CV1 (ON/OFF)	—	—	×	—	Front side switch-over solenoid valve (cut valve) (ON/OFF) status is displayed.
CV2 (ON/OFF)	—	—	×	—	Rear side switch-over solenoid valve (cut-valve) (ON/OFF) status is displayed.
SV1 (ON/OFF)	—	—	×	—	Front side switch-over solenoid valve (suction valve) (ON/OFF) status is displayed.
SV2 (ON/OFF)	—	—	×	—	Rear side switch-over solenoid valve (suction valve) (ON/OFF) status is displayed.
VDC FAIL SIG (ON/OFF)	—	—	×	—	VDC fail signal (ON/OFF) status is displayed.
TCS FAIL SIG (ON/OFF)	—	—	×	—	TCS fail signal (ON/OFF) status is displayed.
ABS FAIL SIG (ON/OFF)	—	—	×	—	ABS fail signal (ON/OFF) status is displayed.
EBD FAIL SIG (ON/OFF)	—	—	×	—	EBD fail signal (ON/OFF) status is displayed.
FLUID LEV SW (ON/OFF)	×	—	×	—	Brake fluid level switch (ON/OFF) status is displayed.
EBD SIGNAL (ON/OFF)	—	—	×	—	EBD operation (ON/OFF) status is displayed.
ABS SIGNAL (ON/OFF)	—	—	×	—	ABS operation (ON/OFF) status is displayed.
TCS SIGNAL (ON/OFF)	—	—	×	—	TCS operation (ON/OFF) status is displayed.
VDC SIGNAL (ON/OFF)	—	—	×	—	VDC operation (ON/OFF) status is displayed.
CAN COMM (OK/NG)	—	—	—	×	CAN communication signal (OK/NG) status is displayed.

TROUBLE DIAGNOSIS

[VDC/TCS/ABS]

Item (Unit)	Data monitor item selection				Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	CAN DIAG SUPPORT MNTR	
CAN CIRC 1 (OK/UNKWN)	—	—	—	×	CAN communication signal (OK/UNKWN) status is displayed.
CAN CIRC 2 (OK/UNKWN)	—	—	—	×	
CAN CIRC 3 (OK/UNKWN)	—	—	—	×	
CAN CIRC 4 (OK/UNKWN)	—	—	—	×	
CAN CIRC 5 (OK/UNKWN)	—	—	—	×	
CAN CIRC 6 (OK/UNKWN)	—	—	—	×	
CAN CIRC 7 (OK/UNKWN)	—	—	—	×	
CAN CIRC CLC (OK/UNKWN)	—	—	—	×	S/C is selected for engine torque map
TRQ MAP S/C	—	—	×	—	
TRQ MAP N/A	—	—	×	—	

×: Applicable

—: Not applicable

ACTIVE TEST

CAUTION:

- Do not perform active test while driving.
- Make sure to completely bleed air from the brake system.
- The ABS and brake (EBD) warning lamps turn on during the active test.

Operation Procedure

1. Connect the CONSULT-II and CONVERTER to the data link connector and start the engine.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

2. Touch "START (NISSAN BASED VHCL)" on the display screen.
3. Touch "ABS".
If "ABS" is not indicated, go to [GI-36. "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).
4. Touch "ACTIVE TEST".
5. The test item selection screen is displayed.
6. Touch necessary test item.

SELECT TEST ITEM
FR RH SOL
FR LH SOL
REAR SOL
ABS MOTOR

LBR379

7. With the "MAIN ITEM" display shown in reverse, touch "START".
8. The Active Test screen will be displayed, so conduct the following test.

Solenoid Valve Operation Chart

Operation		ABS solenoid valve			ABS solenoid valve (ACT)		
		UP	KEEP	DOWN	UP	ACTUA-TOR UP	ACTUA-TOR KEEP
FR RH SOL FR RH ABS SOLE- NOID (ACT)	FR RH IN SOL	OFF	ON	ON	OFF	OFF	OFF
	FR RH OUT SOL	OFF	OFF	ON*	OFF	OFF	OFF
FR LH SOL FR LH ABS SOLE- NOID (ACT)	FR LH IN SOL	OFF	ON	ON	OFF	OFF	OFF
	FR LH OUT SOL	OFF	OFF	ON*	OFF	OFF	OFF
RR RH SOL RR RH ABS SOLE- NOID (ACT)	RR RH IN SOL	OFF	ON	ON	OFF	OFF	OFF
	RR RH OUT SOL	OFF	OFF	ON*	OFF	OFF	OFF
RR LH SOL RR LH ABS SOLE- NOID (ACT)	RR LH IN SOL	OFF	ON	ON	OFF	OFF	OFF
	RR LH OUT SOL	OFF	OFF	ON*	OFF	OFF	OFF
REAR SOL	RR RH IN SOL	OFF	ON	ON	OFF	OFF	OFF
	RR RH OUT SOL	OFF	OFF	ON*	OFF	OFF	OFF
	RR LH IN SOL	OFF	ON	ON	OFF	OFF	OFF
	RR LH OUT SOL	OFF	OFF	ON*	OFF	OFF	OFF

*: ON for 1 to 2 seconds after the touch, and then OFF

NOTE:

- If active test is performed with brake pedal depressed, pedal stroke may change. This is normal.
- "TEST IS STOPPED" is displayed approximately 10 seconds after operation starts.
- After "TEST IS STOPPED" is displayed, to perform test again, repeat Step 6.

ABS Motor

Touch "ON" and "OFF" on the screen. Check that ABS motor relay operates as shown in table below.

Operation	ON	OFF
ABS actuator relay	ON	ON
ABS motor relay	ON	OFF

NOTE:

- If active test is performed with brake pedal depressed, pedal stroke may change. This is normal.
- "TEST IS STOPPED" is displayed approximately 10 seconds after operation starts.

ACTIVE TEST

ABS MOTOR	OFF
MONITOR	
MOTOR RELAY	OFF
ACTUATOR RLY	ON
ON	
MODE	BACK
LIGHT	COPY

SFIA0593E

TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS**Wheel Sensor System Inspection****INSPECTION PROCEDURE****1. CONNECTOR INSPECTION**

Disconnect the ABS actuator and electric unit connector E125 and wheel sensor of malfunctioning code. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

OK >> GO TO 2.

NG >> Repair or replace as necessary.

2. CHECK WHEEL SENSOR OUTPUT SIGNAL

1. Disconnect connectors from wheel sensor of malfunction code No.
2. Connect ABS active wheel sensor tester (J-45741) to wheel sensor using appropriate adapter.
3. Turn on the ABS active wheel sensor tester power switch.

NOTE:

The green POWER indicator should illuminate. If the POWER indicator does not illuminate, replace the battery in the ABS active wheel sensor tester before proceeding.

4. Spin the wheel of the vehicle by hand and observe the red SENSOR indicator on the ABS active wheel sensor tester. The red SENSOR indicator should flash on and off to indicate an output signal.

NOTE:

If the red SENSOR indicator illuminates but does not flash, reverse the polarity of the tester leads and retest.

Does the ABS active wheel sensor tester detect a signal?

Yes >> GO TO 3.

No >> GO TO 6.

3. CHECK TIRES

Check for inflation pressure, wear and size of each tire.

Are tire pressure and size correct and is tire wear within specifications?

Yes >> GO TO 4.

No >> Adjust tire pressure or replace tire(s).

4. CHECK WHEEL BEARINGS

Check wheel bearing axial end play. Refer to [FAX-5, "FRONT WHEEL BEARING"](#) or [RAX-5, "REAR WHEEL BEARING"](#).

OK or NG

OK >> GO TO 5.

NG >> Repair as necessary. Refer to [FAX-5, "FRONT WHEEL BEARING"](#) or [RAX-5, "REAR WHEEL BEARING"](#).

5. CHECK SENSOR ROTORS

Check sensor rotors for teeth damage.

OK or NG

OK >> GO TO 6.

NG >> Replace sensor rotor. Refer to [BRC-140, "Removal and Installation"](#).

6. CHECK WIRING HARNESS FOR SHORT CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector and wheel sensor connector of malfunction code No.
2. Check resistance between harness connector terminal and ground.

Continuity should not exist.

OK or NG

OK >> GO TO 7.

NG >> Repair the circuit.



7. CHECK WIRING HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and wheel sensor connector of malfunction code No.
2. Check continuity between both wiring harness ends.

Sensor	ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
	Connector - terminal	Wire color	Connector - terminal	Wire color	
Front LH	E125 - 14	G	E18 - 1	G	Yes
	E125 - 13	R	E18 - 2	R	
Front RH	E125 - 26	B	E117 - 1	B	
	E125 - 27	W	E117 - 2	W	
Rear LH	E125 - 29	P	B123 - 1	P	
	E125 - 28	L	B123 - 2	L	
Rear RH	E125 - 11	V	B122 - 1	V	
	E125 - 12	LG	B122 - 2	LG	

Continuity should exist.

OK or NG

OK >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-86, "Removal and Installation"](#).

NG >> Repair the circuit.

Engine System Inspection

EFS002XC

INSPECTION PROCEDURE

1. SELF-DIAGNOSIS RESULT CHECK

Check self-diagnosis results.

Self-diagnosis results
ENGINE SIGNAL 1
ENGINE SIGNAL 2
ENGINE SIGNAL 3
ENGINE SIGNAL 4
ENGINE SIGNAL 6

Is the above displayed in the self-diagnosis display items?

Yes >> GO TO 2.

No >> **INSPECTION END.**

2. ENGINE SYSTEM INSPECTION

1. Perform ECM self-diagnosis and repair as necessary.
2. Perform ABS actuator and electric unit (control unit) self-diagnosis again.

OK or NG

OK >> **INSPECTION END.**

NG >> Repair as necessary.

ABS/TCS/VDC Control Unit Inspection

EFS002XD

INSPECTION PROCEDURE

1. SELF-DIAGNOSIS RESULT CHECK

Check self-diagnosis results.

Self-diagnosis results

CONTROLLER FAILURE

Is the above displayed in the self-diagnosis display items?

Yes >> Replace ABS actuator and electric unit. Refer to [BRC-86, "Removal and Installation"](#).No >> **INSPECTION END.**

Steering Angle Sensor System Inspection

EFS002XF

INSPECTION PROCEDURE

1. SELF-DIAGNOSIS RESULT CHECK

Check self-diagnosis results.

Self-diagnosis results

ST ANGLE SEN CIRCUIT

ST ANGLE SEN SIGNAL

Is the above displayed in the self-diagnosis item?

Yes >> GO TO 3.

No >> GO TO 2.

2. DATA MONITOR CHECK

Conduct "Data Monitor" of the "STEERING ANGLE SIGNAL" to check if the status is normal.

Steering condition	Data monitor
Straight-ahead	-5deg - +5deg
Turn wheel 90° to the right.	Approx. +90°
Turn wheel 90° to the left.	Approx. -90°

OK or NG

OK >> **INSPECTION END.**

NG >> GO TO 3.

3. CONNECTOR INSPECTION

1. Disconnect the ABS actuator and electric unit connector E125 and steering angle sensor M47.
2. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG


OK >> GO TO 4.

NG >> Repair or replace as necessary.

4. CHECKING STEERING ANGLE SENSOR POWER AND GROUND


1. Turn the ignition switch on.
2. Check voltage between steering angle sensor connector M47 and ground.

Steering angle sensor connector E125	Body ground	Measured value (Approx.)
1 (Y/R)	—	12V
3 (G)		



3. Check resistance between steering angle sensor connector M47 and ground.

Steering angle sensor connector E125	Body ground	Measured value (Approx.)
2 (B)	—	0 Ω



OK or NG

OK >> Check the CAN communication system. Refer to [BRC-130, "CAN Communication System Inspection"](#). If the CAN communication system is OK, replace spiral cable (steering angle sensor) and adjust neutral position of steering angle sensor. Refer to [BRC-137, "Adjustment of Steering Angle Sensor Neutral Position"](#).

NG >> Repair the circuit.

Yaw Rate/Side/Decel G Sensor System Inspection

EFS002XG

CAUTION:

Sudden turns (such as spin turns, acceleration turns), drifting, etc. When VDC function is OFF (VDC SW ON) may cause the yaw rate/side/decel G sensor system to indicate a problem. However this is not a problem if normal operation can be resumed after restarting the engine.

INSPECTION PROCEDURE

1. SELF-DIAGNOSIS RESULT CHECK

Check self-diagnosis results.

Self-diagnosis results
YAW RATE SENSOR
SIDE G-SEN CIRCUIT

CAUTION:

When on a turntable, such as at a parking structure entrance, or when on a moving object with the engine running, the VDC OFF indicator lamp might turn on and the self-diagnosis using the CONSULT-II the yaw rate sensor system might be displayed, but in this case there is no problem with the yaw rate sensor system. As soon as the vehicle leaves the turntable or moving object, restart the engine to return the system to normal.

Is the above displayed in the self-diagnosis display items?

Yes >> GO TO 2.

No >> INSPECTION END.

2. CONNECTOR INSPECTION

Disconnect the ABS actuator and electric unit connector E125 and yaw rate/side/decel G sensor connector M46.

Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace as necessary.

3. YAW RATE SENSOR/SIDE/DECEL G SENSOR HARNESS INSPECTION

1. Turn off the ignition switch and disconnect yaw rate sensor/side/decel G sensor connector M46 and ABS actuator and electric unit connector E125.
2. Check the continuity between the ABS actuator and electric unit vehicle side connector and the yaw rate/side/decel G sensor connector M46.

ABS actuator and electric unit (control unit) connector E125	Yaw rate/side/decel G sensor connector M46	Continuity
19 (O)	1 (O)	Continuity should exist.
36 (Y)	2 (Y)	
35 (G)	3 (G)	
34 (B)	4 (B)	
4 (R)	5 (R)	
6 (W)	6 (W)	

OK or NG

OK >> GO TO 4.

NG >> Repair or replace as necessary.

4. YAW RATE SENSOR/SIDE/DECEL G SENSOR INSPECTION

1. Connect the yaw rate sensor/side/decel G sensor M46 and ABS actuator and electric unit connector E125.
2. Use "Data Monitor" to check if the yaw rate sensor/side/decel G sensor are normal.

Vehicle status	Yaw rate sensor (Data monitor standard)	Side G sensor (Data monitor standard)
When stopped	-4 to +4 deg/s	-1.1 to +1.1 m/s ²
Right hand turn	Negative value	Negative value
Left turn	Positive value	Positive value

OK or NG

OK >> **INSPECTION END.**

NG >> Replace the yaw rate sensor/side/decel G sensor. Refer to [BRC-144, "Removal and Installation"](#).

Solenoid and VDC Change-Over Valve System Inspection

EFS002XH

INSPECTION PROCEDURE

1. SELF-DIAGNOSIS RESULT CHECK

Check self-diagnosis results.

Self-diagnosis results
FR LH IN ABS SOL
FR LH OUT ABS SOL
RR RH IN ABS SOL
RR RH OUT ABS SOL
FR RH IN ABS SOL
FR RH OUT ABS SOL
RR LH IN ABS SOL
RR LH OUT ABS SOL
CV 1
CV 2
SV 1
SV 2

Is the above displayed in the self-diagnosis display items?

Yes >> GO TO 2.

No >> **INSPECTION END.****2. CONNECTOR INSPECTION**

1. Disconnect ABS actuator and electric unit (control unit) connector E125.
2. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace as necessary.


TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS

[VDC/TCS/ABS]

3. CHECKING SOLENOID POWER AND GROUND


1. Disconnect ABS actuator and electric unit (control unit) connector E125.
2. Check voltage between ABS actuator and electric unit (control unit) connector E125 and ground.

ABS actuator and electric unit (control unit) connector E125	Body ground	Measured value (Approx.)
16 (G/R)	—	12V



3. Check resistance between ABS actuator and electric unit (control unit) connector E125 and body ground.

ABS actuator and electric unit (control unit) connector E125	Body ground	Measured value Ω (Approx.)
31 (B)	—	0 Ω
46 (B)		



OK or NG

- OK >> Perform self-diagnosis again. If the same results appear, replace ABS actuator and electric unit (control unit). Refer to [BRC-123, "ABS/TCS/VDC Control Unit Inspection"](#).
- NG >> Repair the circuit.

Actuator Motor, Motor Relay, and Circuit Inspection

EFS002XI

INSPECTION PROCEDURE

1. CHECKING SELF-DIAGNOSIS RESULTS

Check self-diagnosis results.

Self-diagnosis results
CONSULT-II display items
PUMP MOTOR

Does "PUMP MOTOR" appear in self-diagnosis results display?

- Yes >> GO TO 2.
- No >> **INSPECTION END.**

2. CONNECTOR INSPECTION

Disconnect the ABS actuator and electric unit connector E125.

Check the terminals for deformation, disconnection, looseness or damage.


OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace as necessary.

3. CHECKING ABS MOTOR AND MOTOR RELAY POWER SYSTEM


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check voltage between ABS actuator and electric unit (control unit) connector E125 and body ground.

ABS actuator and electric unit (control unit) connector E125	Body ground	Measured value (Approx.)
1 (R/B)	—	12V



3. Check resistance between ABS actuator and electric unit (control unit) connector E125 and ground.

ABS actuator and electric unit (control unit) connector E125	Body ground	Measured value (Approx.)
46 (B)	—	0Ω



OK or NG

OK >> Perform self-diagnosis again. If the same result appears, replace ABS actuator and electric unit (control unit). Refer to [BRC-86, "Removal and Installation"](#).

NG >> Repair the circuit.

Stop Lamp Switch System Inspection

EFS002XK

INSPECTION PROCEDURE

1. SELF-DIAGNOSIS RESULT CHECK

Check self-diagnosis results.

Self-diagnosis results
STOP LAMP SW

Is the above displayed in the self-diagnosis display items?

Yes >> GO TO 2.

No >> **INSPECTION END.**

2. CONNECTOR INSPECTION

1. Turn the ignition switch off and disconnect the ABS actuator and electric unit connector E125 and stop lamp switch connector E38.
2. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace as necessary.

3. STOP LAMP SWITCH INSPECTION

Check the voltage between the ABS actuator and electric unit connector E125 terminal 23 (R/G) and ground.

23 (R/G) - Ground


Brake pedal depressed : Battery voltage (approx. 12V)

Brake pedal not depressed : Approx. 0V

OK or NG

OK >> Connect the connectors and conduct ABS actuator and electric unit self-diagnosis.

NG >> Repair the circuit.



ABS/TCS/VDC Control Unit Power and Ground Systems Inspection

EFS002XL

INSPECTION PROCEDURE

1. SELF-DIAGNOSIS RESULT CHECK

Check self-diagnosis results.

Self-diagnosis results

BATTERY VOLTAGE

Is the above displayed in the self-diagnosis item?

Yes >> GO TO 2.

No >> **INSPECTION END.**

2. CONNECTOR INSPECTION

1. Turn the ignition switch off and disconnect the ABS actuator and electric unit connector E125.
2. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace as necessary.

3. ABS/TCS/VDC CONTROL UNIT POWER AND GROUND CIRCUIT INSPECTION

Measure the voltage and continuity between the ABS actuator and electric unit connector E125 and the ground.

Signal name	ABS actuator and electric unit (control unit) connector E125	Ground	Measured value
Power supply	45 (GR)	—	Battery voltage (Approx. 12V)
Ground	31 (B)		Continuity should exist.
	46 (B)		

OK or NG

OK >> Check the battery for loose terminals, low voltage, etc. Repair as necessary.

NG >> Repair the circuit.

Brake Fluid Level Sensor System Inspection

INSPECTION PROCEDURE

1. SELF-DIAGNOSIS RESULT CHECK

1. Check the brake reservoir tank fluid level. If the level is low, add brake fluid.
2. Erase the self-diagnosis results and check the self-diagnosis results.

Self-diagnosis results

BR FLUID LEVEL LOW

Is the above displayed in the self-diagnosis display items?

- Yes >> GO TO 2.
 No >> **INSPECTION END.**

2. CONNECTOR INSPECTION

1. Turn the ignition switch off and disconnect the ABS actuator and electric unit connector E125 and brake fluid level sensor connector E21.
2. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 3.
 NG >> Repair or replace as necessary.

3. CHECK THE HARNESS BETWEEN THE BRAKE FLUID LEVEL SENSOR AND THE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Check the continuity between the brake fluid level sensor connector E21 and the ABS actuator and electric unit (control unit) connector E125.

ABS actuator and electric unit connector E125	Brake fluid level sensor connector E21	Continuity
38 (SB)	+ (SB)	Continuity should exist.
38 (SB)	Ground	Continuity should not exist.
Ground	- (B)	Continuity should exist.

OK or NG

- OK >> Connect the connectors and conduct a ABS actuator and electric unit self-diagnosis.
 NG >> Repair the circuit.

CAN Communication System Inspection

INSPECTION PROCEDURE

1. PERFORM SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis.

Is "CAN COMM CIRCUIT" displayed in the self-diagnosis display items?

- Yes >> Print out the self-diagnosis results and go to 2.
 No >> **INSPECTION END.**

TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS

[VDC/TCS/ABS]

2. CONNECTOR INSPECTION

Disconnect the ABS actuator and electric unit connector E125.
Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace as necessary.

3. CAN COMMUNICATION SYSTEM CHECK

Check the data monitor item "CAN Diagnosis Support Monitor".


Normal	Error (example)
CAN COMM: OK	CAN COMM: OK
CAN CIRC 1: OK	CAN CIRC 1: UNKWN
CAN CIRC 2: OK	CAN CIRC 2: UNKWN
CAN CIRC 3: OK	CAN CIRC 3: UNKWN
CAN CIRC 4: UNKWN	CAN CIRC 4: UNKWN
CAN CIRC 5: OK	CAN CIRC 5: UNKWN
CAN CIRC 6: UNKWN	CAN CIRC 6: UNKWN

>> After printing out the monitor items, go to CAN system. Refer to [LAN-8, "CAN COMMUNICATION"](#).

Component Inspection

VDC OFF SWITCH

- Check the continuity between terminals 1 and 2.
 - 1 -2 : Continuity should exist when pushing the switch.**
 - Continuity should not exist when releasing the switch.**



TROUBLE DIAGNOSES FOR SYMPTOMS**ABS Works Frequently**

1. CHECK WARNING LAMP ACTIVATION

Make sure warning lamp remains off while driving.

OK or NG

OK >> GO TO 2.

NG >> Carry out self-diagnosis. Refer to [BRC-113, "SELF-DIAGNOSIS"](#) .

2. CHECK WHEEL SENSORS

Check the following.

- Wheel sensor mounting for looseness
- Wheel sensors for physical damage
- Wheel sensor connectors for terminal damage or loose connections

OK or NG

OK >> GO TO 3.

NG >> Repair as necessary.

3. CHECK FRONT AXLE

Check front and rear axles for excessive looseness. Refer to [FAX-5, "FRONT WHEEL BEARING"](#) or [RAX-5, "REAR WHEEL BEARING"](#) .

OK or NG

OK >> GO TO 4.

NG >> Repair as necessary.

4. CHECK BRAKE FLUID PRESSURE

Check brake fluid pressure distribution.

Refer to [BR-36, "Inspection"](#) .

Is brake fluid pressure distribution normal?

Yes >> **INSPECTION END.**

No >> Perform Basic Inspection. Refer to [BRC-108, "Basic Inspection"](#) .

Unexpected Pedal Action**1. CHECK WARNING LAMP ACTIVATION**

Make sure warning lamp remains off while driving.

OK or NG

OK >> GO TO 2.

NG >> Carry out self-diagnosis. Refer to [BRC-113, "SELF-DIAGNOSIS"](#).


2. CHECK BRAKE PEDAL STROKE

Check brake pedal stroke.

Is pedal stroke excessive?

Yes >> Perform Basic Inspection. Refer to [BRC-108, "Basic Inspection"](#).

No >> GO TO 3.

**3. CHECK CONNECTOR AND BRAKING PERFORMANCE**

1. Disconnect ABS actuator and electric unit (control unit) connector.

2. Check brake effectiveness.

OK or NG

OK >> GO TO 4.

NG >> Perform Basic Inspection. Refer to [BRC-108, "Basic Inspection"](#).

4. CHECK WHEEL SENSORS

Check the following.

- Wheel sensor mounting for looseness
- Wheel sensors for physical damage
- Wheel sensor connectors for terminal damage or loose connections

OK or NG

OK >> Check ABS actuator and electric unit (control unit) pin terminals for damage and the connection of harness connector. Reconnect ABS actuator and electric unit (control unit) harness connector. Then retest.

NG >> Repair as necessary.

Long Stopping Distance

EFS002XR

1. CHECK BASE BRAKING SYSTEM PERFORMANCE

1. Disable ABS by disconnecting ABS actuator and electric unit (control unit) connector.
2. Drive vehicle and check to see if stopping distance is still long.

OK or NG

- OK >> Go to [BRC-132, "ABS Works Frequently"](#) .
- NG >> Perform Basic Inspection. Refer to [BRC-108, "Basic Inspection"](#) .

NOTE:

Stopping distance may be longer than vehicles without ABS when road condition is slippery.

ABS Does Not Work

EFS002XS

CAUTION:

The ABS does not operate when the vehicle speed is 10 km/h (6 MPH) or less.

1. CHECK WARNING LAMP ACTIVATION

Turn ignition switch ON and check for warning lamp activation.

- Warning lamp should activate for approximately 1 second after turning the ignition switch ON.

OK or NG

- OK >> Carry out self-diagnosis. Refer to [BRC-113, "SELF-DIAGNOSIS"](#) .
- NG >> Go to [BRC-135, "ABS Warning Lamp Does Not Come On When Ignition Switch Is Turned On"](#) .

Pedal Vibration or ABS Operation Noise

EFS002XT

NOTE:

During ABS activation, pedal vibration may be felt and a noise may be heard. This is normal and does not indicate a malfunction.

1. CHECK SYMPTOM

1. Apply brake.
2. Start engine.

Does the symptom occur only when engine is started?

- Yes >> Carry out self-diagnosis. Refer to [BRC-113, "SELF-DIAGNOSIS"](#) .
- No >> GO TO 2.

2. RECHECK SYMPTOM

Does the symptom occur only when electrical equipment switches (such as headlamp) are turned on?

- Yes >> Check for radio, antenna or related wiring that is routed too close to the ABS actuator and electric unit (control unit) and reroute as necessary.
- No >> Go to [BRC-132, "ABS Works Frequently"](#) .

ABS Warning Lamp Does Not Come On When Ignition Switch Is Turned On EFS002XU**1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) FUSES**

Check 40A fusible link **i** and 50A fusible link **j** for ABS actuator and electric unit (control unit). For fusible link layout, refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#).

OK or NG

OK >> GO TO 2.

NG >> If fusible link is blown, be sure to eliminate cause of problem before replacing.


2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUITS

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check voltage between ABS actuator connector terminal 1 and ground and terminal 16 and ground.

Does battery voltage exist?

Yes >> GO TO 3.

No >> Repair harness or connectors between fusible link and ABS actuator and electric unit (control unit).


**3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT**

Check continuity between ABS actuator connector terminal 31 and ground and terminal 46 and ground.

Does continuity exist?

Yes >> Replace ABS actuator and electric unit (control unit).

No >> Repair harness or connectors between ABS actuator and electric unit (control unit) and ground.

**ABS Warning Lamp Stays On When Ignition Switch Is Turned On** EFS002XV**1. CARRY OUT SELF-DIAGNOSIS**

Carry out self-diagnosis. Refer to [BRC-113, "SELF-DIAGNOSIS"](#).

Are malfunctions detected in self-diagnosis?

Yes >> Refer to [BRC-116, "Display Item List"](#).

No >> Refer to [DI-45, "WARNING LAMPS"](#).

Vehicle Jerks During TCS/VDC Activation

1. ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

Perform ABS actuator and electric unit (control unit) self-diagnosis.

Are self-diagnosis result items displayed?

- Yes >> After checking and repairing the applicable item, perform the ABS actuator and electric unit (control unit) self-diagnosis again.
- No >> GO TO 2.

2. ENGINE SPEED SIGNAL INSPECTION

Perform data monitor with CONSULT-II for the ABS actuator and electric unit (control unit).

Is the engine speed at idle 400 rpm or higher?

- Yes >> GO TO 4.
- No >> GO TO 3.

3. ECM SELF-DIAGNOSIS

Perform ECM self-diagnosis.

Are self-diagnosis result items displayed?

- Yes >> After checking and repairing the applicable item, perform the ECM self-diagnosis again.
- No >> GO TO 4.

4. TCM SELF-DIAGNOSIS

Perform TCM self-diagnosis.

Are self-diagnosis result items displayed?

- Yes >> After checking and repairing the applicable item, perform the ECM self-diagnosis again.
- No >> GO TO 5.

5. CONNECTOR INSPECTION

Disconnect the ABS actuator and electric unit (control unit) connector and the ECM connectors and check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 6.
- NG >> Repair or replace the connector terminal.

6. CAN COMMUNICATION INSPECTION

Check the CAN communication system. Refer to [BRC-130, "CAN Communication System Inspection"](#).

OK or NG

- OK >> **INSPECTION END.**
- NG >> Reconnect the connectors, and perform ABS actuator and electric unit (control unit) self-diagnosis.

ON-VEHICLE SERVICE

PFP:00000

Adjustment of Steering Angle Sensor Neutral Position


EFS002TF

After removing/installing or replacing ABS actuator and electric unit (control unit), steering angle sensor, steering components, suspension components, tires, or after adjusting wheel alignment, be sure to adjust neutral position of steering angle sensor before running vehicle.

NOTE:

Adjustment of steering angle sensor neutral position requires CONSULT-II.

1. Stop vehicle with front wheels in straight-ahead position.
2. Connect CONSULT-II to data link connector on vehicle, and turn ignition switch ON (do not start engine).
3. Touch "ABS", "WORK SUPPORT" and "ST ANGLE SENSOR ADJUSTMENT" on CONSULT-II screen in this order.




4. Touch "START".

CAUTION:

Do not touch steering wheel while adjusting steering angle sensor.

5. After approximately 10 seconds, touch "END". (After approximately 60 seconds, it ends automatically.)
6. Turn ignition switch OFF, then turn it ON again.
7. Run vehicle with front wheels in straight-ahead position, then stop.
8. Select "DATA MONITOR", "SELECTION FROM MENU", and "STR ANGLE SIG" on CONSULT-II screen. Then check that "STR ANGLE SIG" is within 0 ± 2.5 deg. If value is more than specification, repeat steps 1 to 5.
9. Erase memory of ABS actuator and electric unit (control unit) and ECM.
10. Turn ignition switch to OFF.



Calibration of Yaw Rate/Side/Decel G Sensor


EFS002TG

After removing/installing or replacing yaw rate/side/decel G sensor, ABS actuator and electric unit (control unit), steering components, suspension components, tires or after adjusting wheel alignment, be sure to adjust neutral position of steering angle sensor before running vehicle.


NOTE:

Calibration of yaw rate/side/decel G sensor requires CONSULT-II.

1. Stop vehicle with front wheels in straight-ahead position.
2. Connect CONSULT-II to data link connector on vehicle, and turn ignition switch ON (do not start engine).
3. Touch "ABS", "WORK SUPPORT" and "DECEL G SEN CALI-BRATION" on CONSULT-II screen in this order.




4. Touch "START".
5. After approximately 10 seconds, touch "END". (After approximately 60 seconds, it ends automatically.)
6. Turn ignition switch OFF, then turn it ON again.
7. Run vehicle with front wheels in straight-ahead position, then stop.
8. Select "DATA MONITOR", "SELECTION FROM MENU", and "DECEL G SEN" on CONSULT-II screen. Then check that "DECEL G SEN" is within $\pm 0.08G$. If value is more than specification, repeat steps 1 to 5.
9. Erase memory of ABS actuator and electric unit (control unit) and ECM.
10. Turn ignition switch to OFF.



WHEEL SENSORS

Removal and Installation

**CAUTION:**

Be careful not to damage sensor edge and sensor rotor teeth.

When removing the front or rear wheel hub assembly, first remove the ABS wheel sensor from the assembly. Failure to do so may result in damage to the sensor wires making the sensor inoperative.

CAUTION:

Pull out the sensor being careful to turn it as little as possible. Do not pull on the sensor harness. Installation should be performed while paying attention to the following, and then tighten fasteners to the specified torque.

- Before installing wheel sensor, make sure no foreign materials (such as iron fragments) are adhered to the pick-up part of the sensor, to the inside of the sensor mounting hole or on the rotor mounting surface.

SENSOR ROTOR


Removal and Installation

NOTE:

The rear wheel sensor rotor is built into the rear wheel hub. For removal and installation procedure, refer to [RAX-6, "Removal and Installation"](#).

REMOVAL


1. Remove the front wheel hub. Refer to [FAX-6, "Removal and Installation"](#).
2. Remove the sensor rotor using suitable puller.



INSTALLATION

Install the sensor rotor using a hammer and a wooden block.

- Always replace sensor rotor with new one.




ACTUATOR AND ELECTRIC UNIT (ASSEMBLY)

PFP:47660

Removal and Installation

EFS002WA



WFIA0104E

REMOVAL

1. Disconnect battery cable.
2. Remove windshield wiper and linkage assembly. Refer to [WW-28, "REMOVAL"](#).
3. Drain brake fluid. Refer to [BR-8, "Changing Brake Fluid"](#).
4. Discharge the A/C refrigerant. Refer to [ATC-116, "HFC-134a \(R-134a\) Service Procedure"](#).
5. Disconnect and remove high-pressure and low-pressure A/C pipes to allow access to ABS actuator and electric unit (control unit). Refer to [ATC-118, "Components"](#).
6. Disconnect harness connectors from ABS actuator and electric unit (control unit).
7. Disconnect brake pipes.
8. Remove fasteners for ABS actuator and electric unit (control unit) and remove from vehicle.

INSTALLATION

CAUTION:

After installation of ABS actuator and electric unit (control unit), refill brake fluid. Then bleed air from system. Refer to [BR-8, "Bleeding Brake System"](#).

1. Position ABS actuator and electric unit (control unit) in vehicle.
2. Connect brake pipes and fasteners temporarily.
3. Tighten fasteners and brake pipes.
4. Connect ABS actuator and electric unit (control unit) harness connectors.
5. Install and connect high-pressure and low-pressure A/C pipes. Refer to [ATC-118, "Components"](#).
6. Install windshield wiper and linkage assembly. Refer to [WW-28, "INSTALLATION"](#).

ACTUATOR AND ELECTRIC UNIT (ASSEMBLY)

[VDC/TCS/ABS]

7. Reconnect battery cable.
8. Evacuate and recharge the A/C system. Refer to [ATC-116, "HFC-134a \(R-134a\) Service Procedure"](#).
9. Adjust the steering angle sensor. Refer to [BRC-137, "Adjustment of Steering Angle Sensor Neutral Position"](#).

STEERING ANGLE SENSOR

PFP:25554

Removal and Installation

EFS0031B

Refer to [SRS-42, "Removal and Installation"](#) .

A

B

C

D

E

BRC

G

H

I

J

K

L

M

G SENSOR


Removal and Installation

REMOVAL

1. Remove center console. Refer to [IP-17, "Center Console"](#) .
2. Disconnect harness connector.
3. Remove attaching nuts and remove yaw rate/side/decel G sensor.

CAUTION:

- Do not drop or strike the yaw rate/side/decel G sensor.
- Do not use power tools to remove or install yaw rate/side/decel G sensor.



INSTALLATION

To install, reverse the removal procedure.

CAUTION:

- Do not drop or strike the yaw rate/side/decel G sensor.