

CONTENTS

PRECAUTION	2	FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY	11
PRECAUTIONS	2	Removal and Installation	11
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	EVAP CANISTER	16
FUEL SYSTEM	3	Exploded View	16
General Precaution	3	Removal and Installation	16
PREPARATION	4	Component Inspection	17
PREPARATION	4	UNIT DISASSEMBLY AND ASSEMBLY ...	18
Special Service Tool	4	FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY	18
Commercial Service Tool	4	Exploded View	18
BASIC INSPECTION	5	Disassembly and Assembly	18
FUEL SYSTEM	5	SERVICE DATA AND SPECIFICATIONS (SDS)	19
Checking Fuel Line	5	SERVICE DATA AND SPECIFICATIONS (SDS)	19
UNIT REMOVAL AND INSTALLATION	6	Standard and Limit	19
FUEL TANK	6		
Removal and Installation	6		

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000011563896

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

FUEL SYSTEM

< PRECAUTION >

FUEL SYSTEM

General Precaution

INFOID:0000000011563897

WARNING:

When replacing fuel line parts, be sure to observe the following.

- Put a "CAUTION: FLAMMABLE" sign in the workshop.
- Be sure to work in a well ventilated area and furnish workshop with a CO2 fire extinguisher.
- Do not smoke while servicing fuel system. Keep open flames and sparks away from the work area.


CAUTION:

• Before removing fuel line parts, carry out the following procedures:

- Put drained fuel in an explosion-proof container and put the lid on securely. Keep the container in safe area.
- Release fuel pressure from the fuel lines. Refer to [EC-496, "Fuel Pressure Check"](#).
- Disconnect the battery negative terminal.
- Always replace O-rings and clamps with new ones.
- Do not kink or twist hoses when they are being installed.
- After connecting the fuel tube quick connectors, make sure the quick connectors are secure.

Ensure that the connector and resin tube do not contact any adjacent parts.

- After installing tubes, make sure there is no fuel leakage at connections in the following steps.
- Apply fuel pressure to fuel lines with turning ignition switch ON (with engine stopped). Then check for fuel leaks at connections.
- Start the engine and rev it up and check for fuel leaks at connections.
- Use only a Genuine NISSAN fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- For servicing "Evaporative Emission System" parts, refer to [FL-16, "Removal and Installation"](#).
- For servicing "On Board Refueling Vapor Recovery (ORVR)" parts, refer to [EC-498, "How to Detect Fuel Vapor Leakage"](#).



PREPARATION

< PREPARATION >



PREPARATION


PREPARATION

Special Service Tool


INFOID:0000000011563898

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
KV101207S0 (—) Unified fuel lock ring wrench	Removing and installing fuel tank lock ring
 JPBIA6384ZZ	
— (J-45747) Fuel tank lock ring wrench	
 JSBIA1952ZZ	



JPBIA6384ZZ



JSBIA1952ZZ

Commercial Service Tool

INFOID:0000000011563899

Tool name	Description
Power tool	Loosening nuts, screws and bolts



PIIB1407E

FUEL SYSTEM

< BASIC INSPECTION >

BASIC INSPECTION

FUEL SYSTEM


Checking Fuel Line

INFOID:0000000011563900

Inspect fuel lines, fuel filler cap and fuel tank for improper attachment, leaks, cracks, damage, loose connections, chafing or deterioration.

- (A) : Engine
- (B) : Fuel line
- (C) : Fuel tank

If necessary, repair or replace damaged parts.



A

FL

C

D

E

F

G

H

I

J

K

L

M

N

O

P

FUEL TANK


< UNIT REMOVAL AND INSTALLATION >

UNIT REMOVAL AND INSTALLATION

FUEL TANK

Removal and Installation

INFOID:0000000011563901



- | | | |
|-----------------------------|----------------------|---|
| 1. Fuel line pump protector | 2. Lock ring | 3. Fuel level sensor, fuel filter, and fuel pump assembly |
| 4. Fuel tank | 5. Fuel tank straps | 6. O-ring |
| 7. Fuel filler hose | 8. Fuel filler pipe | 9. Fuel filler pipe grommet |
| 10. Fuel filler cap | 11. Fuel tank shield | |

REMOVAL

WARNING:

Follow the “General Precautions” before working on the fuel system. Refer to [FL-3, "General Precaution"](#).

NOTE:

FUEL TANK


< UNIT REMOVAL AND INSTALLATION >

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

1. Remove the fuel filler cap to release the pressure from inside the fuel tank.

2. Check the fuel level on level gauge. If the fuel gauge indicates more than the level as shown (half tank), drain the fuel from the fuel tank until the fuel gauge indicates the level as shown, or less.


- As a guide, the fuel level reaches the fuel gauge position as shown, or less, when approximately 52.9 ℓ (14 US gal, 11-5/8 Imp gal) of fuel is drained from a full tank.
- If the fuel pump does not operate, use the following procedure to drain the fuel to the specified level.



a. Insert a suitable hose of less than 15 mm (0.59 in) diameter into the fuel filler pipe through the fuel filler opening to drain the fuel from fuel filler pipe.


b. Remove the rear wheel and tire (LH) using power tool. Refer to [WT-51, "Balancing Wheels"](#).

c. Remove the fuel filler pipe shield.



d. Disconnect the fuel filler hose from the fuel filler pipe and disconnect the vent hose quick connector.

e. Insert a suitable hose into the fuel tank through the fuel filler hose to drain the fuel from the fuel tank.




3. Release the fuel pressure from the fuel lines. Refer to [EC-496, "Fuel Pressure Check"](#).

4. Disconnect the battery negative terminal. Refer to [PG-85, "Removal and Installation"](#).

5. Remove the three nuts and remove fuel line pump protector.


6. Disconnect the EVAP hose at the EVAP canister.



FUEL TANK


< UNIT REMOVAL AND INSTALLATION >

7. Disconnect the fuel level sensor, fuel filter, and fuel pump assembly harness connector, and the fuel feed hose.




Disconnect the quick connector as follows:

- Hold the sides of the connector, push in tabs and pull out the tube.
- If the connector and the tube are stuck together, push and pull several times until they start to move. Then disconnect them by pulling.



CAUTION:


- The quick connector can be disconnected when the tabs are completely depressed. Do not twist the quick connector more than necessary.
- Do not use any tools to disconnect the quick connector.
- Keep the resin tube away from heat. Be especially careful when welding near the tube.
- Prevent any acid liquids such as battery electrolyte, from getting on the resin tube.
- Do not bend or twist the resin tube during connection.
- Do not remove the remaining retainer on the hard tube (or the equivalent) except when the resin tube or the retainer is replaced.
- When the resin tube or hard tube, or the equivalent, is replaced, also replace the retainer with a new one (white colored retainer).




FUEL TANK

< UNIT REMOVAL AND INSTALLATION >

- To keep the quick connector clean and to avoid damage and contamination from foreign materials, cover the quick connector with plastic bags or suitable material as shown.



- Remove the four bolts and remove the fuel tank shield using power tool.
- Disconnect fuel filler hose at the fuel tank side.
- Remove the fuel tank strap bolts while supporting the fuel tank with a suitable lift jack.
- Lower the fuel tank using a suitable lift jack and remove it from the vehicle.




- If necessary, remove the lock ring using Tool as shown.

Tool number : — (J-45747) (shown)
: KV101207S0 (—)

- If necessary, remove the fuel level sensor, fuel filter and fuel pump assembly. Discard the O-ring.

CAUTION:

- Do not bend the float arm during removal.
- Avoid impacts such as dropping when handling the components.
- Do not reuse O-ring.




INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Do not reuse O-ring.

- Connect the quick connector as follows:
 - Check the connection for any damage or foreign materials.
 - Align the connector with the pipe, then insert the connector straight into the pipe until a click is heard.
 - After connecting the quick connector, make sure that the connection is secure by checking as follows:
 - Pull the tube and the connector to make sure they are securely connected.
 - Visually inspect the connector to make sure the two retainer tabs are securely connected.



INSPECTION AFTER INSTALLATION

FUEL TANK

< UNIT REMOVAL AND INSTALLATION >

1. Turn the ignition switch ON but do not start engine, then check the fuel pipe and hose connections for leaks while applying fuel pressure to the system.
2. Start the engine and rev it above idle speed, then check that there are no fuel leaks at any of the fuel pipe and hose connections.


FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY

Removal and Installation

INFOID:0000000011563902



- | | | |
|-----------------------------|----------------------|---|
| 1. Fuel line pump protector | 2. Lock ring | 3. Fuel level sensor, fuel filter, and fuel pump assembly |
| 4. Fuel tank | 5. Fuel tank straps | 6. O-ring |
| 7. Fuel filler hose | 8. Fuel filler pipe | 9. Fuel filler pipe grommet |
| 10. Fuel filler cap | 11. Fuel tank shield | |

REMOVAL

WARNING:

Follow the “General Precautions” before working on the fuel system. Refer to [FL-3, "General Precaution"](#).

NOTE:



When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

1. Remove the fuel filler cap to release the pressure from inside the fuel tank.


FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >


2. Check the fuel level on level gauge. If the fuel gauge indicates more than the level as shown (half tank), drain the fuel from the fuel tank until the fuel gauge indicates the level as shown, or less.
 - As a guide, the fuel level reaches the fuel gauge position shown, or less, when approximately 52.9 ℓ (14 US gal, 11-5/8 Imp gal) of fuel is drained from a full tank.
 - If the fuel pump does not operate, use the following procedure to drain the fuel to the specified level.
- a. Insert a suitable hose of less than 15 mm (0.59 in) diameter into the fuel filler pipe through the fuel filler opening to drain the fuel from fuel filler pipe.
- b. Remove the rear wheel and tire (LH) using power tool. Refer to [WT-51, "Balancing Wheels"](#).
- c. Remove the fuel filler pipe shield.



- d. Disconnect the fuel filler hose from the fuel filler pipe and disconnect the vent hose quick connector.
- e. Insert a suitable hose into the fuel tank through the fuel filler hose to drain the fuel from the fuel tank.




3. Release the fuel pressure from the fuel lines. Refer to [EC-496, "Fuel Pressure Check"](#).
4. Disconnect the battery negative terminal. Refer to [PG-85, "Removal and Installation"](#).
5. Remove the three nuts and remove fuel line pump protector.
6. Disconnect the EVAP hose at the EVAP canister.



FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY


< UNIT REMOVAL AND INSTALLATION >

7. Disconnect the fuel level sensor, fuel filter, and fuel pump assembly harness connector and the fuel feed hose.




Disconnect the quick connector as follows:

- Hold the sides of the connector, push in tabs and pull out the tube.
- If the connector and the tube are stuck together, push and pull several times until they start to move. Then disconnect them by pulling.



CAUTION:


- The quick connector can be disconnected when the tabs are completely depressed. Do not twist the quick connector more than necessary.
- Do not use any tools to disconnect the quick connector.
- Keep the resin tube away from heat. Be especially careful when welding near the tube.
- Prevent any acid liquids such as battery electrolyte, from getting on the resin tube.
- Do not bend or twist the resin tube during connection.
- Do not remove the remaining retainer on the hard tube (or the equivalent) except when the resin tube or the retainer is replaced.
- When the resin tube or hard tube, or the equivalent, is replaced, also replace the retainer with a new one (white colored retainer).




FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

- To keep the quick connector clean and to avoid damage and contamination from foreign materials, cover the quick connector with plastic bags or suitable material as shown.



8. Remove the four bolts and remove the fuel tank shield using power tool.
9. Remove the fuel tank strap bolts while supporting the fuel tank with a suitable lift jack.
10. Lower the fuel tank using a suitable lift jack and remove it from the vehicle to access the fuel level sensor, fuel filter, and fuel pump assembly.




11. Remove the lock ring using Tool as shown.

Tool number : — (J-45747) (shown)
: KV101207S0 (—)

12. Remove the fuel level sensor, fuel filter and fuel pump assembly. Remove and discard the O-ring.

CAUTION:

- Do not bend the float arm during removal.
- Avoid impacts such as dropping when handling the components.
- Do not reuse O-ring.




INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Do not reuse O-ring.

- Connect the quick connector as follows:
 - Check the connection for any damage or foreign materials.
 - Align the connector with the pipe, then insert the connector straight into the pipe until a click is heard.
 - After connecting the quick connector, make sure that the connection is secure by checking as follows:
 - Pull the tube and the connector to make sure they are securely connected.
 - Visually inspect the connector to make sure the two retainer tabs are securely connected.



INSPECTION AFTER INSTALLATION

1. Turn the ignition switch ON but do not start engine, then check the fuel pipes and hose connections for leaks while applying fuel pressure to the system.

FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

2. Start the engine and rev it above idle speed, then check that there are no fuel leaks at any of the fuel pipe and hose connections.

A

FL

C

D

E

F

G

H

I

J

K

L

M

N

O

P


EVAP CANISTER

< UNIT REMOVAL AND INSTALLATION >

EVAP CANISTER

Exploded View

INFOID:0000000011563903



- | | | |
|------------------|--|-------------------------------------|
| 1. EVAP canister | 2. O-ring | 3. EVAP canister vent control valve |
| 4. O-ring | 5. EVAP control system pressure sensor | |

Removal and Installation

INFOID:0000000011563904

EVAP CANISTER

Removal

1. Disconnect the EVAP canister control pressure sensor hose.
2. Disconnect the harness connector from EVAP canister control pressure sensor.
3. Remove the EVAP canister control pressure sensor and O-ring, if necessary.

CAUTION:

Do not reuse O-ring.

4. Disconnect the fuel tank EVAP breather hose.
5. Disconnect the harness connector from EVAP canister vent control valve.
6. Disconnect the EVAP canister vent control valve hose.
7. Remove the EVAP canister retaining bolt.
8. Remove the EVAP canister.
9. Remove the EVAP canister vent control valve and O-ring, if necessary.

CAUTION:

Do not reuse O-ring.

Installation

Installation is in the reverse order of removal.

CAUTION:

Do not reuse O-ring.

EVAP CANISTER VENT CONTROL VALVE

Removal

1. Disconnect the harness connector from EVAP canister vent control valve.
2. Disconnect the EVAP canister vent control valve hose.


EVAP CANISTER

< UNIT REMOVAL AND INSTALLATION >

3. Turn EVAP canister vent control valve counterclockwise.
4. Remove the EVAP canister vent control valve and O-ring.

CAUTION:

Do not reuse O-ring.



Installation

Installation is in the reverse order of removal.

CAUTION:

Do not reuse O-ring.

EVAP CANISTER CONTROL PRESSURE SENSOR

Removal

1. Disconnect the harness connector from EVAP canister control pressure sensor.
2. Remove the EVAP canister control pressure sensor and O-ring.

CAUTION:

Do not reuse O-ring.

Installation

Installation is in the reverse order of removal.

CAUTION:

Do not reuse O-ring.


Component Inspection

INFOID:0000000011563905

EVAP CANISTER

Check EVAP canister as follows:

1. Block port (B).
2. Blow air into port (A) and check that it flows freely out of port (C).
3. Release blocked port (B).
4. Apply vacuum pressure to port (B) and check that vacuum pressure exists at the ports (A) and (C).
5. Block port (A) and (B).
6. Apply pressure to port (C) and check that there is no leakage.



FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

UNIT DISASSEMBLY AND ASSEMBLY

FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY

Exploded View

INFOID:0000000011563906



- | | | |
|-----------------------|------------------------|----------------------|
| 1. Harness connector | 2. Sending unit module | 3. Fuel level sensor |
| 4. Float arm assembly | | |

Disassembly and Assembly

INFOID:0000000011563907

Disassembly

1. Remove fuel level sensor unit, fuel filter and fuel pump assembly. Refer to [FL-11, "Removal and Installation"](#).
2. Disconnect the harness connector.
3. Remove the fuel level sensor from the fuel pump assembly.
4. Remove the sending unit module and float arm assembly.

Assembly

Assembly is in the reverse order of disassembly.

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Standard and Limit

INFOID:0000000011563908

FL

Fuel tank capacity	105.8 ℓ (28 US gal, 23-1/4 Imp gal)
--------------------	-------------------------------------

A
C
D
E
F
G
H
I
J
K
L
M
N
O
P