

SECTION SE SEAT

CONTENTS

DTC/CIRCUIT DIAGNOSIS	2	PREPARATION	22
HEATED SEAT	2	Special Service Tool	22
Description	2	Commercial Service Tool	22
WIRING DIAGRAM	3	CLIP LIST	23
POWER SEAT FOR DRIVER SIDE	3	Descriptions for Clips	23
Wiring Diagram - Without Automatic Drive Posi- tioner	3	REMOVAL AND INSTALLATION	27
POWER SEAT FOR PASSENGER SIDE	7	FRONT SEAT	27
Wiring Diagram	7	Exploded View	27
HEATED SEAT	11	Removal and Installation - Front Seat Assembly	34
Wiring Diagram	11	Removal and Installation - Power Seat Switch	34
SYMPTOM DIAGNOSIS	15	SIDE AIR BAG MODULE	38
SQUEAK AND RATTLE TROUBLE DIAG- NOSES	15	DRIVER SIDE	38
Work Flow	15	DRIVER SIDE : Side Air Bag Module	38
Generic Squeak and Rattle Troubleshooting	16	PASSENGER SIDE	39
Diagnostic Worksheet	19	PASSENGER SIDE : Side Air Bag Module	39
PRECAUTION	21	REAR SEAT	41
PRECAUTIONS	21	Exploded View	41
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	21	Removal and Installation	43
Precaution for Work	21	UNIT DISASSEMBLY AND ASSEMBLY ...	44
PREPARATION	22	FRONT SEAT	44
		Exploded View	44
		Disassembly and Assembly	51
		REAR SEAT	55
		Exploded View	55

HEATED SEAT

< DTC/CIRCUIT DIAGNOSIS >


DTC/CIRCUIT DIAGNOSIS

HEATED SEAT

Description

INFOID:0000000011560494

- When handling seat, be extremely careful not to scratch heating unit.
- Front passenger seat cushion and seatbacks equipped with air bags cannot be disassembled. They are replaced as assemblies only.
- Do not use any organic solvent, such as thinner, benzene, alcohol, etc. to clean trim.



POWER SEAT FOR DRIVER SIDE

< WIRING DIAGRAM >


WIRING DIAGRAM

POWER SEAT FOR DRIVER SIDE

Wiring Diagram - Without Automatic Drive Positioner

INFOID:0000000011560495

POWER SEAT FOR DRIVER SIDE - WITHOUT AUTOMATIC DRIVE POSITIONER



ABJWA0461GB

POWER SEAT FOR DRIVER SIDE

< WIRING DIAGRAM >


POWER SEAT FOR DRIVER SIDE CONNECTORS - WITHOUT AUTOMATIC DRIVE POSITIONER

Connector No.	M82
Connector Name	CIRCUIT BREAKER-2
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L/B	-
2	W/B	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
91J	L/B	-


Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
96G	W/B	-

POWER SEAT FOR DRIVER SIDE

< WIRING DIAGRAM >



POWER SEAT FOR DRIVER SIDE

< WIRING DIAGRAM >

Connector No.	B215
Connector Name	LIFTING MOTOR (REAR) (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	V	-
2	W/G	-

Connector No.	B214
Connector Name	LIFTING MOTOR (FRONT) (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	B/Y	-
2	R/Y	-

Connector No.	B232
Connector Name	RECLINING MOTOR LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	G	-

Terminal No.	Color of Wire	Signal Name
5	G	-
6	L	-
7	V	-
8	W/G	-
9	B/Y	-
10	R/Y	-

Connector No.	B216
Connector Name	POWER SEAT SWITCH LH (WITHOUT AUTOMATIC DRIVE POSITIONER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-
3	R	-
4	Y	-

ABJIA0683GB

POWER SEAT FOR PASSENGER SIDE


< WIRING DIAGRAM >

POWER SEAT FOR PASSENGER SIDE

Wiring Diagram

INFOID:0000000011560496

POWER SEAT FOR PASSENGER SIDE



ABJWA0298GB

POWER SEAT FOR PASSENGER SIDE


< WIRING DIAGRAM >

POWER SEAT FOR PASSENGER SIDE CONNECTORS

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
96G	W/B	-

Terminal No.	Color of Wire	Signal Name
91A	W/L	-

Connector No.	M82
Connector Name	CIRCUIT BREAKER-2
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/B	-
2	W/B	-

POWER SEAT FOR PASSENGER SIDE


< WIRING DIAGRAM >

Connector No.	B154
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W/L	-
2	B	-

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
91A	W/L	-

Terminal No.	Color of Wire	Signal Name
96G	W/B	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	Y	-
3	G	-
4	W	-
5	B	-
6	R	-

Connector No.	B308
Connector Name	POWER SEAT SWITCH RH
Connector Color	WHITE



Connector No.	B303
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

ABJIA0686GB

A B C D E F G H I SE K L M N O P

POWER SEAT FOR PASSENGER SIDE

< WIRING DIAGRAM >

Connector No.	B372
Connector Name	RECLINING MOTOR RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
2	L	-

Connector No.	B309
Connector Name	SLIDING MOTOR RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	R	-

ABJIA0687GB

HEATED SEAT


< WIRING DIAGRAM >

HEATED SEAT

Wiring Diagram

INFOID:0000000011560497

HEATED SEAT



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P


AAJWA0308GB

HEATED SEAT

< WIRING DIAGRAM >


HEATED SEAT CONNECTORS

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1A	GR/B	—
2A	GR/L	—

Connector No.	M39
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5Q	G	—

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
95J	GR	—
100J	L/B	—


Connector No.	M159
Connector Name	FRONT HEATED SEAT SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	—
2	GR	—
3	L/B	—
4	B	—

HEATED SEAT

< WIRING DIAGRAM >



Connector No.	B118
Connector Name	FRONT SEAT HEATER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR/L	-
2	B	-
3	GR/B	-

SE

SQUEAK AND RATTLE TROUBLE DIAGNOSES


< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:0000000011560498



SBT842

CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [SE-19, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping.
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on CVT and A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear: J-39565 and mechanic's stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fasteners can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.Refer to [SE-16. "Generic Squeak and Rattle Troubleshooting"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A NISSAN Squeak and Rattle Kit (J-50397) is available through your authorized NISSAN Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

- Always check with the Parts Department for the latest parts information.
- The materials contained in the NISSAN Squeak and Rattle Kit (J-50397) are listed on the inside cover of the kit; and can each be ordered separately as needed.
- The following materials not found in the kit can also be used to repair squeaks and rattles:
 - SILICONE GREASE: Use instead of UHMW tape that will be visible or does not fit. The silicone grease will only last a few months.
 - SILICONE SPRAY: Use when grease cannot be applied.
 - DUCT TAPE: Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Generic Squeak and Rattle Troubleshooting

INFOID:0000000011560499

Refer to Table of Contents for specific component removal and installation information.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. Cluster lid A and the instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar finisher
4. Instrument panel to windshield
5. Instrument panel pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicone spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shift selector assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the NISSAN Squeak and Rattle Kit (J-50397) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sun visor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

OVERHEAD CONSOLE (FRONT AND REAR)

Overhead console noises are often caused by the console panel clips not being engaged correctly. Most of these incidents are repaired by pushing up on the console at the clip locations until the clips engage.

In addition look for:

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

1. Loose harness or harness connectors.
2. Front console map/reading lamp lens loose.
3. Loose screws at console attachment points.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component installed to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator installation pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine rpm or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Diagnostic Worksheet

INFOID:0000000011560500





Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| ☐ Anytime | ☐ After sitting out in the rain |
| ☐ 1st time in the morning | ☐ When it is raining or wet |
| ☐ Only when it is cold outside | ☐ Dry or dusty conditions |
| ☐ Only when it is hot outside | ☐ Other: |

III. WHEN DRIVING:

- ☐ Through driveways
- ☐ Over rough roads
- ☐ Over speed bumps
- ☐ Only about ____ mph
- ☐ On acceleration
- ☐ Coming to a stop
- ☐ On turns: left, right or either (circle)
- ☐ With passengers or cargo
- ☐ Other: _____
- ☐ After driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- ☐ Squeak (like tennis shoes on a clean floor)
- ☐ Creak (like walking on an old wooden floor)
- ☐ Rattle (like shaking a baby rattle)
- ☐ Knock (like a knock at the door)
- ☐ Tick (like a clock second hand)
- ☐ Thump (heavy muffled knock noise)
- ☐ Buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	☐	☐	_____
- Noise verified on test drive	☐	☐	_____
- Noise source located and repaired	☐	☐	_____
- Follow up test drive performed to confirm repair	☐	☐	_____

VIN: _____ Customer Name _____

W.O.# _____ Date: _____

This form must be attached to Work Order

LATA0071E

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000011560501

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:0000000011560502

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >



PREPARATION

PREPARATION

Special Service Tool


INFOID:000000011560503

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-39570) Chassis Ear  SIIA0993E	Locating the noise
— (J-50397) NISSAN Squeak and Rattle Kit  ALJIA1232ZZ	Repairing the cause of noise
— (J-46534) Trim Tool Set  AWJIA0483ZZ	Removing trim components

Commercial Service Tool

INFOID:000000011560504

(TechMate No.) Tool name	Description
(J-39565) Engine Ear  SIIA0995E	Locating the noise

CLIP LIST











< PREPARATION >

CLIP LIST

Descriptions for Clips

INFOID:0000000011560505

Replace any clips which are damaged during removal or installation.









Symbol No.	Shapes	Removal & Installation
C101 		Removal: Remove by bending up with flat-bladed screwdrivers or clip remover. 
C103 		 Removal: Remove with a clip remover.
C203 		Removal: Push center pin to catching position. (Do not remove center pin by hitting it.) Push  Installation: Push 
C205 		Removal: Flat-bladed screwdriver  Clip Finisher
C206 		Removal: 

SIIA0315E

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

CLIP LIST






< PREPARATION >

Symbol No.	Shapes	Removal & Installation
CE103 		Removal: 
CF110 		Removal: 
CF118 		Removal: 
CR103 		Removal: Holder portion of clip must be spread out to remove rod. 
CS101 		Removal: 1. Screw out with a Phillips screwdriver. 2. Remove female portion with flat-bladed screwdriver. 

SIIA0316E

CLIP LIST







< PREPARATION >

Symbol No.	Shapes	Removal & Installation	
CG101 		Removal:  Rotate 45° to remove	Installation: 
		Removal: 	
CS102 			
CS113 		Removal: Disconnect upper connection of clip with a flat-bladed screwdriver, then remove clip while inserting a flat-bladed screwdriver between body panel and clip. 	
C111 			

SIIA0317E

CLIP LIST

< PREPARATION >

Symbol No.	Shapes	Removal & Installation
CG104 		Removal: Remove by bending up with flat-bladed screwdrivers. 
CE114 		
CF118 		Removal: Flat-bladed screwdrivers 

ALJIA0564GB

FRONT SEAT

< REMOVAL AND INSTALLATION >


REMOVAL AND INSTALLATION

FRONT SEAT

Exploded View

INFOID:0000000011560506

Power Driver Seat



FRONT SEAT


< REMOVAL AND INSTALLATION >

- | | | |
|--------------------------------------|-------------------------------------|--|
| 1. Headrest | 2. Armrest washer (if equipped) | 3. Armrest assembly (if equipped) |
| 4. Armrest insert (if equipped) | 5. Armrest pivot bolt (if equipped) | 6. Armrest pivot bolt finisher (if equipped) |
| 7. Seat cushion assembly | 8. Seat cushion pad | 9. Seat cushion trim |
| 10. Power seat switch | 11. Power seat switch finisher | 12. Seat recline knob |
| 13. Seat slide knob | 14. Seat cushion frame | 15. Seat cushion heater (if equipped) |
| 16. Seat cushion outer finisher (RH) | 17. Seat cushion front finisher | 18. Seat frame assembly |
| 19. Seat slide motor | 20. Bolt cover | 21. Slide finisher (LH) |
| 22. Seat cushion outer finisher (LH) | 23. Rear slide finisher (RH) | 24. Seat harness |
| 25. Recline motor | 26. Recline mechanism cover (LH) | 27. Recline mechanism cover (RH) |
| 28. Recline rod | 29. Seatback assembly | 30. Seatback board |
| 31. Headrest holder (locked) | 32. Headrest holder (free) | 33. Side air bag module (LH) |
| A. Seatback board clip | | |

FRONT SEAT

< REMOVAL AND INSTALLATION >

Manual Driver Seat



- | | | |
|---------------------------------|-------------------------------------|--|
| 1. Headrest | 2. Headrest holder (locked) | 3. Headrest holder (free) |
| 4. Seatback assembly | 5. Armrest assembly (if equipped) | 6. Armrest washer (if equipped) |
| 7. Armrest insert (if equipped) | 8. Armrest pivot bolt (if equipped) | 9. Armrest pivot bolt finisher (if equipped) |
| 10. Seat cushion trim | 11. Seat cushion pad | 12. Lumbar lever (if equipped) |
| 13. Seat cushion assembly | 14. Seat cushion frame | 15. Rear slide finisher (RH) |


FRONT SEAT

< REMOVAL AND INSTALLATION >

- | | | |
|--------------------------------------|--------------------------------------|-------------------------|
| 16. Recline mechanism cover (RH) | 17. Recline mechanism cover (LH) | 18. Recline rod |
| 19. Seat frame cover | 20. Seat cushion outer finisher (RH) | 21. Slide release wire |
| 22. Front seat frame support | 23. Recline lever | 24. Seat frame assembly |
| 25. Bolt cover | 26. Slide finisher (LH) | 27. Bolt cover |
| 28. Seat cushion outer finisher (LH) | 29. Side air bag module (LH) | |

Center Seat

SEC. 870



AWJIA17192Z

FRONT SEAT

< REMOVAL AND INSTALLATION >

1. Cup holder	2. Armrest finisher	3. Armrest frame	A
4. Armrest trim	5. Armrest pad	6. Armrest assembly	
7. Armrest pivot arm (RH)	8. Armrest release bracket	9. Armrest pivot release lever	
10. Upper armrest pivot finisher (RH)	11. Lower armrest pivot finisher (RH)	12. Seat cushion assembly	B
13. Inner armrest pivot cover (RH)	14. Seat cushion trim	15. Seat cushion pad	
16. Seat cushion frame	17. Pedestal support (RH)	18. Pedestal support (LH)	
19. Seat belt	20. Lower armrest pivot finisher (LH)	21. Armrest pivot arm (LH)	C
22. Inner armrest pivot cover (LH)	23. Rear hinge finisher	24. Support pad	

D

E

F

G

H

I

SE

K

L


M

N

O

P

Power Passenger Seat




FRONT SEAT

< REMOVAL AND INSTALLATION >

- | | | |
|------------------------------------|--------------------------------------|---|
| 19. Armrest assembly (if equipped) | 20. Armrest insert (if equipped) | 21. Armrest pivot bolt finisher (if equipped) |
| 22. Armrest washer (if equipped) | 23. Armrest pivot bolt (if equipped) | 24. Seatback assembly |
| 25. Headrest holder (free) | 26. Seat fold lever | 27. Headrest holder (locked) |
| 28. Seatback board | 29. Headrest | 30. Side air bag module (RH) |
| A. Seatback board clip | | |

Manual Passenger Seat



FRONT SEAT

< REMOVAL AND INSTALLATION >

- | | | |
|--------------------------------------|-------------------------------------|---|
| 1. Seat cushion assembly | 2. Bolt cover | 3. Recline lever |
| 4. Seat cushion outer finisher (RH) | 5. Slide finisher (RH) | 6. Slide release wire |
| 7. Front seat frame support | 8. Seat cushion outer finisher (LH) | 9. Rear slide finisher (LH) |
| 10. Seat frame cover | 11. Recline rod | 12. Recline mechanism cover (LH) |
| 13. Seat cushion assembly | 14. Recline mechanism cover (RH) | 15. Armrest washer (if equipped) |
| 16. Armrest assembly (if equipped) | 17. Armrest insert (if equipped) | 18. Armrest pivot bolt finisher (if equipped) |
| 19. Armrest pivot bolt (if equipped) | 20. Seatback assembly | 21. Headrest holder (free) |
| 22. Seat fold lever | 23. Headrest holder (locked) | 24. Seatback board |
| 25. Headrest | 26. Side air bag module (RH) | A. Seatback board clip |

Removal and Installation - Front Seat Assembly

INFOID:0000000011560507

REMOVAL

CAUTION:

- When removing or installing the seat trim, handle it carefully to keep dirt out and avoid damage.
- Before removing the front seat, turn the ignition switch off, disconnect both battery cables and wait at least three minutes.
- When checking the power seat circuit for continuity using a circuit tester, do not confuse its connector with the side air bag module connector. Such an error may cause the air bag to deploy.
- Do not drop, tilt, or bump the side air bag module while installing the seat. Always handle it with care.
- After front side air bag module inflates, front seatback assembly must be replaced.
- Front passenger seat is equipped with Occupant Classification System sensor and control module. Do not disassemble front passenger seat cushion assembly or remove trim as this will affect the Occupant Classification System calibration.
- Always replace passenger seat cushion as an assembly.

1. Slide the seat until the four seat to body bolts are visible and a tool can be inserted.

NOTE:

- If disassembling the seat after removal, set the front/rear cushion lifters to the top position.

2. Disconnect the negative and positive battery terminals and wait at least three minutes. Refer to [PG-85, "Removal and Installation"](#).
3. Disconnect the side air bag module harness connector.
4. Remove the bolt and leg covers.
5. Remove the four seat to body bolts.
6. Disconnect the power seat harness connectors and remove the seat from the vehicle.

NOTE:

When removing and installing the seat, use shop cloths to protect the vehicle from damage.

INSTALLATION

Installation is in the reverse order of removal.

- Tighten the seat bolts to specification. Refer to [SE-27, "Exploded View"](#).

CAUTION:

Make sure that the seat harness or the floor trim is not damaged during installation.

Removal and Installation - Power Seat Switch

INFOID:0000000011560508


REMOVAL

1. Remove the passenger seat. Refer to [SE-34, "Removal and Installation - Front Seat Assembly"](#).
2. Place the seat, back side down, on a work bench


FRONT SEAT

< REMOVAL AND INSTALLATION >


3. Release the trim at bottom of seat as shown.



4. Remove the seat recline knob and seat slide knob (1), then the power seat switch finisher (2).




5. Remove the four seat cushion assembly bolts (A) from the seat frame assembly.




FRONT SEAT

< REMOVAL AND INSTALLATION >

6. Disconnect the harness connectors for the occupant classification system (1) and the power seat switch (2).



7. Release the two power seat switch harness clips (1) from the seat cushion frame.




8. Release the seat cushion trim J-clip retainers on same side as power seat switch.
9. Remove the seat cushion outer finisher.

FRONT SEAT

< REMOVAL AND INSTALLATION >

10. Remove the two screws (A) and the power seat switch (1).



INSTALLATION

Installation is in the reverse order of removal.

- Tighten the seat cushion assembly bolts to specification. Refer to [SE-27. "Exploded View"](#).

SIDE AIR BAG MODULE

< REMOVAL AND INSTALLATION >

SIDE AIR BAG MODULE

DRIVER SIDE

DRIVER SIDE : Side Air Bag Module


INFOID:0000000011875171

WARNING:

- If the vehicle has been involved in a collision and the side air bag module has deployed, the seat-back pad and seatback trim must be replaced.
- Do not leave any objects (screwdrivers, tools, etc.) on the seat during repair. It can lead to personal injury if the side air bag module should accidentally deploy.
- Always work from the side or back of the seatback, do not work in front of seat.
- Do not attempt to disassemble the side air bag module.
- Handle the side air bag module carefully. During removal, always hold the side air bag module, do not let it hang by the wire harness.
- Do not use air tools or electric tools for servicing the seat assembly.
- Do not insert any objects into the side air bag module.
- Do not expose the side air bag module to temperatures exceeding 93°C (200°F).
- Do not expose the side air bag module to any oil, grease, detergent or water.
- Do not damage the chute, connectors, retainers, clips, module harness or the side air bag module.
- Before servicing, turn ignition switch OFF, disconnect both battery terminals then wait at least three minutes.

REMOVAL

1. Remove the driver side seatback. Refer to [SE-51, "Disassembly and Assembly"](#).
2. Open the seatback trim, pull the side air bag module (1) out of the chute (A) and remove.



CAUTION:

- Replace the side air bag module if it has been dropped or sustained an impact.
- Do not strike the side air bag module.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Inspect seatback pad, seatback trim and seatback trim chutes. Replace if damaged.
- When installing the side air bag module, make sure there are no wrinkles and the chute is not folded, twisted or pinched.
- Always route side air bag module harness in original location. Replace any deformed or damaged clips with same type and color. Always install clips in the original location in the harness.

SIDE AIR BAG MODULE

< REMOVAL AND INSTALLATION >

- After the work is completed, perform self-diagnosis to check that no malfunction is detected. Refer to [SRC-15, "Trouble Diagnosis Introduction"](#).

PASSENGER SIDE

PASSENGER SIDE : Side Air Bag Module


INFOID:000000011875172

WARNING:

- If the vehicle has been involved in a collision and the side air bag module has deployed, the seat-back pad and seatback trim must be replaced.
- Do not leave any objects (screwdrivers, tools, etc.) on the seat during repair. It can lead to personal injury if the side air bag module should accidentally deploy.
- Always work from the side or back of the seatback, do not work in front of seat.
- Do not attempt to disassemble the side air bag module.
- Handle the side air bag module carefully. During removal, always hold the side air bag module, do not let it hang by the wire harness.
- Do not use air tools or electric tools for servicing the seat assembly.
- Do not insert any objects into the side air bag module.
- Do not expose the side air bag module to temperatures exceeding 93°C (200°F).
- Do not expose the side air bag module to any oil, grease, detergent or water.
- Do not damage the chute, connectors, retainers, clips, module harness or the side air bag module.
- Before servicing, turn ignition switch OFF, disconnect both battery terminals then wait at least three minutes.

REMOVAL

1. Remove the passenger side seatback. Refer to [SE-51, "Disassembly and Assembly"](#).
2. Open the seatback trim, pull the side air bag module (1) out of the chute (A) and remove.



CAUTION:

- Replace the side air bag module if it has been dropped or sustained an impact.
- Do not strike the side air bag module.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Inspect seatback pad, seatback trim and seatback trim chutes. Replace if damaged.
- When installing the side air bag module, make sure there are no wrinkles and the chute is not folded, twisted or pinched.
- Always route side air bag module harness in original location. Replace any deformed or damaged clips with same type and color. Always install clips in the original location in the harness.

SIDE AIR BAG MODULE

< REMOVAL AND INSTALLATION >

- After the work is completed, perform self-diagnosis to check that no malfunction is detected. Refer to [SRC-15, "Trouble Diagnosis Introduction"](#).

REAR SEAT

< REMOVAL AND INSTALLATION >


REAR SEAT

Exploded View

INFOID:0000000011560509

LH

SEC. 880



1. Seatback pad

2. Headrest

3. Seatback latch

4. Seatback latch release strap

5. Seatback latch striker


6. Seatback frame

REAR SEAT

< REMOVAL AND INSTALLATION >

- | | | |
|-----------------------------------|----------------------------|-------------------------------|
| 7. Outboard pivot cover | 8. Release lever handle | 9. Seat cushion frame |
| 10. Seat cushion release assembly | 11. Outboard seat support | 12. Grocery bag hooks |
| 13. Inboard seat support | 14. Rear seat bracket | 15. Seat cushion pad |
| 16. Seat cushion trim | 17. Seatback trim | 18. Inboard outer pivot cover |
| 19. Inboard inner pivot cover | 20. Headrest holder (free) | 21. Headrest holder (locked) |

RH



REAR SEAT

< REMOVAL AND INSTALLATION >


- | | | |
|---------------------------------|------------------------------------|-----------------------------------|
| 1. Seatback trim with armrest | 2. Seatback pad with armrest | 3. Seatback trim without armrest |
| 4. Seatback pad without armrest | 5. Seatback frame without armrest | 6. Seat cushion trim |
| 7. Seat cushion pad | 8. Seatback striker assembly | 9. Outboard pivot cover |
| 10. Seat cushion release handle | 11. Outboard seatback pivot anchor | 12. Seat cushion release lever |
| 13. Seat cushion frame | 14. Grocery bag hooks | 15. Inboard seatback pivot anchor |
| 16. Rear seat bracket | 17. Outer inboard hinge cover | 18. Inner inboard hinge cover |
| 19. Seatback frame with armrest | 20. Arm rest pad and frame | 21. Arm rest trim |
| 22. Seatback latch assembly | 23. Headrest holder (locked) | 24. Headrest |
| 25. Seatback release strap | 26. Headrest holder (free) | |

Removal and Installation


INFOID:0000000011560510

Removal

1. Lift the seat cushion into the stowed position.
2. Remove the seat belt and seat anchor bolts.



3. Remove the outboard pivot cover.
4. Remove the seatback hinge covers.
5. Remove the seat cushion release handle.
6. Release the seatback and remove the seat.



Installation

Installation is in the reverse order of removal.

- Tighten the seat bolts to specification. Refer to [SE-41, "Exploded View"](#).

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

UNIT DISASSEMBLY AND ASSEMBLY


FRONT SEAT

Exploded View

INFOID:0000000011560511

Power Driver Seat

SEC. 870



FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

1. Headrest	2. Armrest washer (if equipped)	3. Armrest assembly (if equipped)	A
4. Armrest insert (if equipped)	5. Armrest pivot bolt (if equipped)	6. Armrest pivot bolt finisher (if equipped)	
7. Seat cushion assembly	8. Seat cushion pad	9. Seat cushion trim	B
10. Power seat switch	11. Power seat switch finisher	12. Seat recline knob	
13. Seat slide knob	14. Seat cushion frame	15. Seat cushion heater (if equipped)	
16. Seat cushion outer finisher (RH)	17. Seat cushion front finisher	18. Seat frame assembly	C
19. Seat slide motor	20. Bolt cover	21. Slide finisher (LH)	
22. Seat cushion outer finisher (LH)	23. Rear slide finisher (RH)	24. Seat harness	
25. Recline motor	26. Recline mechanism cover (LH)	27. Recline mechanism cover (RH)	D
28. Recline rod	29. Seatback assembly	30. Seatback board	
31. Headrest holder (locked)	32. Headrest holder (free)	33. Side air bag module (LH)	
A. Seatback board clip			E

F

G

H

I

SE

K

L

M

N

O


P

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

Manual Driver Seat

SEC. 870



- | | | |
|---------------------------------|-------------------------------------|--|
| 1. Headrest | 2. Headrest holder (locked) | 3. Headrest holder (free) |
| 4. Seatback assembly | 5. Armrest assembly (if equipped) | 6. Armrest washer (if equipped) |
| 7. Armrest insert (if equipped) | 8. Armrest pivot bolt (if equipped) | 9. Armrest pivot bolt finisher (if equipped) |
| 10. Seat cushion trim | 11. Seat cushion pad | 12. Lumbar lever (if equipped) |
| 13. Seat cushion assembly | 14. Seat cushion frame | 15. Rear slide finisher (RH) |


FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

- | | | |
|--------------------------------------|--------------------------------------|-------------------------|
| 16. Recline mechanism cover (RH) | 17. Recline mechanism cover (LH) | 18. Recline rod |
| 19. Seat frame cover | 20. Seat cushion outer finisher (RH) | 21. Slide release wire |
| 22. Front seat frame support | 23. Recline lever | 24. Seat frame assembly |
| 25. Bolt cover | 26. Slide finisher (LH) | 27. Bolt cover |
| 28. Seat cushion outer finisher (LH) | 29. Side air bag module (LH) | |

Center Seat

SEC. 870



AWJIA17192Z

FRONT SEAT


< UNIT DISASSEMBLY AND ASSEMBLY >

- | | | |
|---------------------------------------|---------------------------------------|--------------------------------|
| 1. Cup holder | 2. Armrest finisher | 3. Armrest frame |
| 4. Armrest trim | 5. Armrest pad | 6. Armrest assembly |
| 7. Armrest pivot arm (RH) | 8. Armrest release bracket | 9. Armrest pivot release lever |
| 10. Upper armrest pivot finisher (RH) | 11. Lower armrest pivot finisher (RH) | 12. Seat cushion assembly |
| 13. Inner armrest pivot cover (RH) | 14. Seat cushion trim | 15. Seat cushion pad |
| 16. Seat cushion frame | 17. Pedestal support (RH) | 18. Pedestal support (LH) |
| 19. Seat belt | 20. Lower armrest pivot finisher (LH) | 21. Armrest pivot arm (LH) |
| 22. Inner armrest pivot cover (LH) | 23. Rear hinge finisher | 24. Support pad |

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

Power Passenger Seat



- | | | |
|--------------------------------------|-------------------------------------|----------------------------------|
| 1. Seat slide knob | 2. Seat recline knob | 3. Power seat switch finisher |
| 4. Power seat switch | 5. Seat cushion assembly | 6. Recline motor |
| 7. Bolt cover | 8. Seat cushion outer finisher (RH) | 9. Slide finisher (RH) |
| 10. Seat slide motor | 11. Seat cushion front finisher | 12. Seat frame assembly |
| 13. Seat cushion outer finisher (LH) | 14. Seat harness | 15. Rear slide finisher (LH) |
| 16. Recline mechanism cover (LH) | 17. Recline rod | 18. Recline mechanism cover (RH) |


FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

- | | | |
|------------------------------------|--------------------------------------|---|
| 19. Armrest assembly (if equipped) | 20. Armrest insert (if equipped) | 21. Armrest pivot bolt finisher (if equipped) |
| 22. Armrest washer (if equipped) | 23. Armrest pivot bolt (if equipped) | 24. Seatback assembly |
| 25. Headrest holder (free) | 26. Seat fold lever | 27. Headrest holder (locked) |
| 28. Seatback board | 29. Headrest | 30. Side air bag module (RH) |
| A. Seatback board clip | | |

Manual Passenger Seat

SEC. 870



AWJIA1721ZZ

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

- | | | | |
|--------------------------------------|-------------------------------------|---|---|
| 1. Seat cushion assembly | 2. Bolt cover | 3. Recline lever | A |
| 4. Seat cushion outer finisher (RH) | 5. Slide finisher (RH) | 6. Slide release wire | |
| 7. Front seat frame support | 8. Seat cushion outer finisher (LH) | 9. Rear slide finisher (LH) | B |
| 10. Seat frame cover | 11. Recline rod | 12. Recline mechanism cover (LH) | |
| 13. Seat cushion assembly | 14. Recline mechanism cover (RH) | 15. Armrest washer (if equipped) | C |
| 16. Armrest assembly (if equipped) | 17. Armrest insert (if equipped) | 18. Armrest pivot bolt finisher (if equipped) | |
| 19. Armrest pivot bolt (if equipped) | 20. Seatback assembly | 21. Headrest holder (free) | D |
| 22. Seat fold lever | 23. Headrest holder (locked) | 24. Seatback board | |
| 25. Headrest | 26. Side air bag module (RH) | A. Seatback board clip | E |

Disassembly and Assembly


INFOID:0000000011560512

SEATBACK TRIM AND PAD

NOTE:

Only complete outboard seatback assemblies can be replaced on vehicles equipped with side air bags. Be sure to set the front/rear cushion lifter to the top position.


1. Remove the seatback board.
2. Remove the retainer.




3. Remove the headrest.
4. From inside of the seatback, squeeze the headrest holder tabs at the base of the stay pipe and pull the up to remove.

NOTE:

Before installing the headrest holder, check its orientation (front/rear and right/left).



5. Remove the snap ring and the lumbar support lever knob.



FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

6. **CAUTION:**


On the passenger seat during installation, the wire harness clips must be installed in the holes they were originally in.

Do not add additional clips.

Disconnect the seatback heater harness. Remove the seatback trim and pad assembly. Remove the hog ring to separate the seatback trim from the pad and the heater unit.

Removal of seatback assembly

1. Remove the seatback board.
2. Remove the retainer.
3. Remove the side air bag harness connector from the seat cushion.
4. Remove the seatback bolts (two for each side) and seatback assembly.




Installation of seatback assembly

- Installation is in the reverse order of removal.


SEATBACK BOARD - SOFT SEATBACK

Removal

1. The seatback board is attached to the seat frame with the following:
 - 2 top tabs (A)
 - 4 side tabs (B)
 - 2 bottom clips (C) (must be replaced)
2. Move seat to forward position.




3. Hold the seatback board as shown and pull the top of the seatback board away from the seat back frame.



FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

4. Pull the middle part of the seatback board to disengage the side tabs (B) from the seatback frame.
5. Pull the lower part of the seatback board to disengage the bottom clips from the seatback frame.




Installation

Installation is in the reverse order of removal.


SEATBACK BOARD - HARD SEATBACK

Removal


1. The seatback board is attached to the seat frame with the following:
 - 2 top tabs (A)
 - 2 side tabs (B)
 - 2 bottom clips (C) (must be replaced)
2. Move seat to forward position.



3. Hold the seatback board as shown and pull the bottom of the seatback board away from the seat back frame.



4. Pull the middle part of the seatback board to disengage the side tabs (B) from the seatback frame.
5. Lift the upper part of the seatback board to disengage the top tabs from the seatback frame.



Installation

Installation is in the reverse order of removal.

FRONT SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

SEAT CUSHION TRIM AND PAD


CAUTION:

- Front passenger seat is equipped with Occupant Classification System sensor and control module. Do not disassemble front passenger seat cushion assembly or remove trim as this will affect the Occupant Classification System calibration.
- Always replace passenger seat cushion as an assembly.
- When removed, the passenger seat cushion must always be placed pan side UP to prevent damage.
- During installation, the wire harness clips must be installed in the holes they were originally in. Do not add additional clips.
- The Occupant Classification System control module can only be replaced as part of the seat cushion assembly.


NOTE:

If the vehicle has been involved in a collision the seat must be inspected for damage. Refer to [SR-4, "For Frontal Collision"](#).


1. Remove the power seat switch knobs and power seat switch escutcheon (or recline knobs on manual seat).



2. Remove the front seat cushion finisher (inner).



3. Remove the power seat switch screws (or lift knobs on manual seats).
4. Remove four bolts and the seat cushion assembly.




5. Remove the retainer on the seat cushion frame, then remove the harness connector for the seat heater.
6. On the drivers seat only, after removing the seat cushion trim and pad, remove the hog rings to separate the trim cover from the pad and seat cushion heater unit.

REAR SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

- | | | |
|-----------------------------------|----------------------------|-------------------------------|
| 7. Outboard pivot cover | 8. Release lever handle | 9. Seat cushion frame |
| 10. Seat cushion release assembly | 11. Outboard seat support | 12. Grocery bag hooks |
| 13. Inboard seat support | 14. Rear seat bracket | 15. Seat cushion pad |
| 16. Seat cushion trim | 17. Seatback trim | 18. Inboard outer pivot cover |
| 19. Inner inboard pivot cover | 20. Headrest holder (free) | 21. Headrest holder (locked) |

RH



REAR SEAT

< UNIT DISASSEMBLY AND ASSEMBLY >

- | | | |
|---------------------------------|------------------------------------|-----------------------------------|
| 1. Seatback trim with armrest | 2. Seatback pad with armrest | 3. Seatback trim without armrest |
| 4. Seatback pad without armrest | 5. Seatback frame without armrest | 6. Seat cushion trim |
| 7. Seat cushion pad | 8. Seatback striker assembly | 9. Outboard pivot cover |
| 10. Seat cushion release handle | 11. Outboard seatback pivot anchor | 12. Seat cushion release lever |
| 13. Seat cushion frame | 14. Grocery bag hooks | 15. Inboard seatback pivot anchor |
| 16. Rear seat bracket | 17. Outer inboard hinge cover | 18. Inner inboard hinge cover |
| 19. Seatback frame with armrest | 20. Arm rest pad and frame | 21. Arm rest trim |
| 22. Seatback latch assembly | 23. Headrest holder (locked) | 24. Headrest |
| 25. Seatback release strap | 26. Headrest holder (free) | |

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P