

# WW

## SECTION

### WIPER, WASHER & HORN

A  
B  
C

D

E

## CONTENTS

|  |  |
|--|--|
| <p><b>PRECAUTION</b> ..... 2</p> <p>    Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER” ..... 2</p> <p><b>FRONT WIPER AND WASHER SYSTEM</b> ..... 3</p> <p>    Components Parts and Harness Connector Location ..... 3</p> <p>    System Description ..... 3</p> <p>        LOW SPEED WIPER OPERATION ..... 4</p> <p>        HI SPEED WIPER OPERATION ..... 4</p> <p>        INTERMITTENT OPERATION ..... 4</p> <p>        AUTO STOP OPERATION ..... 5</p> <p>        FRONT WASHER OPERATION ..... 5</p> <p>        MIST OPERATION ..... 5</p> <p>        FAIL-SAFE FUNCTION ..... 5</p> <p>        COMBINATION SWITCH READING FUNCTION... 5</p> <p>    CAN Communication System Description ..... 5</p> <p>    Schematic ..... 6</p> <p>    Wiring Diagram — WIPER — ..... 7</p> <p>    Terminals and Reference Values for BCM ..... 10</p> <p>    Terminals and Reference Values for IPDM E/R .... 10</p> <p>    Work Flow ..... 10</p> <p>    Preliminary Inspection ..... 10</p> <p>        INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT ..... 10</p> <p>    CONSULT-II Function (BCM) ..... 12</p> <p>        CONSULT-II START PROCEDURE ..... 12</p> <p>        WORK SUPPORT ..... 12</p> <p>        DATA MONITOR ..... 12</p> <p>        ACTIVE TEST ..... 12</p> <p>    CONSULT-II Function (IPDM E/R) ..... 13</p> <p>        CONSULT-II START PROCEDURE ..... 13</p> <p>        DATA MONITOR ..... 13</p> <p>        ACTIVE TEST ..... 13</p> <p>    Front Wiper Does Not Operate ..... 14</p> <p>        FRONT WIPER STOP POSITION IS INCORRECT ..... 17</p> <p>        ONLY FRONT WIPER LOW DOES NOT OPER-</p> | <p>        ATE ..... 18</p> <p>        ONLY FRONT WIPER HI DOES NOT OPERATE.. 20</p> <p>        ONLY FRONT WIPER INTERMITTENT DOES NOT OPERATE ..... 21</p> <p>        FRONT WIPER INTERMITTENT OPERATION SWITCH POSITION CANNOT BE ADJUSTED.. 22</p> <p>        WIPERS DO NOT WIPER WHEN FRONT WASHER OPERATES ..... 22</p> <p>        FRONT WIPERS OPERATE FOR 10 SECONDS, STOP FOR 20 SECONDS, AND AFTER REPEATING THIS OPERATION FIVE TIMES, THEY BECOME INOPERATIVE ..... 22</p> <p>    Front Wiper Arms ..... 24</p> <p>        REMOVAL AND INSTALLATION ..... 24</p> <p>        FRONT WIPER ARM ADJUSTMENT ..... 24</p> <p>    Wiper Motor and Linkage ..... 25</p> <p>        REMOVAL AND INSTALLATION ..... 25</p> <p>    Washer Nozzle Adjustment ..... 25</p> <p>    Washer Tube Layout ..... 26</p> <p>    Wiper and Washer Switch ..... 26</p> <p>        REMOVAL AND INSTALLATION ..... 26</p> <p>    Washer Fluid Reservoir ..... 26</p> <p>        REMOVAL AND INSTALLATION ..... 26</p> <p>    Washer Motor ..... 27</p> <p>        REMOVAL AND INSTALLATION ..... 27</p> <p>    <b>POWER SOCKET</b> ..... <b>28</b></p> <p>        Wiring Diagram — P/SCKT — ..... 28</p> <p>        Front Power Socket LH, Rear Cargo Power Socket.. 29</p> <p>        REMOVAL AND INSTALLATION ..... 29</p> <p>        Front Power Socket RH (For Cigarette Lighter), Front Power Socket (Center Armrest), Console Power Socket ..... 29</p> <p>        REMOVAL AND INSTALLATION ..... 29</p> <p>    <b>HORN</b> ..... <b>30</b></p> <p>        Wiring Diagram — HORN — ..... 30</p> <p>        Removal and Installation ..... 31</p> <p>        REMOVAL ..... 31</p> <p>        INSTALLATION ..... 31</p> |
|--|--|

F

G

H

I

J

WW

L

M

# PRECAUTION

---

## PRECAUTION

PF0:00011

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EKS00AE9

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

#### **WARNING:**

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.**


# FRONT WIPER AND WASHER SYSTEM

## FRONT WIPER AND WASHER SYSTEM

PF2:28810

### Components Parts and Harness Connector Location

EKS00GFR



1. IPDM E/R  
E118, E119, E120, E121, E122,  
E123, E124

4. Washer fluid reservoir

7. BCM M18, M20

2. Air cleaner case

5. Front wiper motor  
E23

3. Front washer motor connector  
E105

6. Combination switch (wiper switch)  
M28

WKIA5719E

## System Description

EKS00AEC

- Both front wiper relays are located in the IPDM E/R (intelligent power distribution module engine room).
- The wiper switch (combination switch) is composed of a combination of 5 output terminals and 5 input terminals. Terminal combination status is read by the BCM (body control module) when the wiper switch is turned ON.
- BCM controls front wiper LO, HI, and INT (intermittent) operation.
- IPDM E/R operates the wiper motor according to CAN communication signals from the BCM.

Power is supplied at all times

- through 50A fusible link (letter f , located in the fuse and fusible link box)
- to BCM terminal 70, and
- through 30A fuse (No. 39, located in the IPDM E/R)
- to front wiper relay (located in the IPDM E/R).

With the ignition switch in ON or START position, power is supplied

- through 10A fuse (No. 59, located in the fuse and relay box)
- to BCM terminal 38.

Ground is supplied

- to BCM terminal 67 and
- to combination switch terminal 12

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
WW

# FRONT WIPER AND WASHER SYSTEM

---

- through grounds M57, M61 and M79, and
- to IPDM E/R terminals 38 and 59 and
- to front wiper motor terminal 1
- through grounds E9, E15 and E24.

## LOW SPEED WIPER OPERATION

When the ignition switch is in the ON or START position, and the front wiper switch is turned to the low position, the BCM detects a low speed wiper ON request through the combination switch (wiper switch) reading function.

The BCM then sends a front wiper (low) request signal over CAN communication lines

- from BCM terminals 39 and 40
- to IPDM E/R terminals 39 and 40.

When IPDM E/R receives front wiper (low) request signal, it supplies ground to energize the front wiper relay. With the front wiper relay energized, power is supplied

- through front wiper relay
- through front wiper high relay
- through IPDM E/R terminal 32
- to front wiper motor terminal 3.

With power and ground supplied, the front wiper motor operates at low speed.

## HI SPEED WIPER OPERATION

When the ignition switch is in the ON or START position, and the front wiper switch is turned to the high position, the BCM detects a high speed wiper ON request through the combination switch (wiper switch) reading function.

The BCM then sends a front wiper (high) request signal over CAN communication lines

- from BCM terminals 39 and 40
- to IPDM E/R terminals 39 and 40.

When the IPDM E/R receives a front wiper (high) request signal, it supplies ground to energize the front wiper and the front wiper high relays.

With the front wiper and the front wiper high relays energized, power is supplied

- through front wiper relay
- through front wiper high relay
- through IPDM E/R terminal 35
- to front wiper motor terminal 2.

With power and ground supplied, the front wiper motor operates at high speed.

## INTERMITTENT OPERATION

Wiper intermittent operation delay interval is determined from the combination of the intermittent wiper dial position inputs and vehicle speed. During each intermittent operation delay interval, the BCM sends a front wiper request signal to the IPDM E/R to operate the wipers.

When the ignition switch is in the ON or START position, and the front wiper switch is turned to an intermittent position, the BCM detects a front wiper (intermittent) ON request through the combination switch (wiper switch) reading function.

The BCM then sends a front wiper (intermittent) request signal over CAN communication lines

- from BCM terminals 39 and 40
- to IPDM E/R terminals 39 and 40.

When the BCM determines that combination switch status is front wiper intermittent ON, it performs the following operations.

- BCM detects ON/OFF status of intermittent wiper dial position
- BCM calculates operation interval from wiper dial position and vehicle speed signal received through CAN communications.
- BCM sends front wiper request signal (INT) to IPDM E/R at calculated operation interval.

When the IPDM E/R receives a front wiper request signal (INT), it supplies ground to energize the front wiper relay. It then sends an auto-stop signal to the BCM, and conducts intermittent front wiper motor operation.

# FRONT WIPER AND WASHER SYSTEM

## AUTO STOP OPERATION

When the wiper arms are not located at the base of the windshield, and the wiper switch is turned OFF, the wiper motor will continue to operate until the wiper arms reach the windshield base. When the wiper arms reach the base of windshield, front wiper motor terminals 6 and 1 are connected.

Ground is supplied

- to IPDM E/R terminal 43
- through front wiper motor terminal 6
- through front wiper motor terminal 1
- through grounds E9, E15 and E24.

The IPDM E/R sends an auto stop operation signal to the BCM through CAN communication lines.

When the BCM receives an auto stop operation signal, the BCM sends wiper stop signal to the IPDM E/R over CAN communication lines. The IPDM E/R then de-energizes the front wiper relay.

The wiper motor will then stop the wiper arms at the STOP position.

## FRONT WASHER OPERATION

When the ignition switch is in the ON or START position, and the front washer switch is OFF, the front washer motor is supplied power

- through 10A fuse (No. 9, located in the fuse block J/B)
- to front washer motor terminal 1.

When the front wiper switch is in the front washer position, the BCM detects a front washer signal request through the combination switch (wiper switch) reading function.

Combination switch ground is supplied

- to front washer motor terminal 2
- through combination switch (wiper switch) terminal 11
- through combination switch (wiper switch) terminal 12
- through grounds M57, M61 and M79.

With ground supplied, the front washer motor operates.

When the BCM detects that front washer motor has operated for 0.4 seconds or longer, the BCM uses CAN communication and sends a wiper request signal to the IPDM E/R for low speed operation of wipers.

When the BCM detects that the washer switch is OFF, low speed operation cycles approximately 3 times and then stops.

## MIST OPERATION

When the wiper switch is temporarily placed in the mist position, wiper low speed operation cycles once and then stops.

For additional information about wiper operation under this condition, refer to [WW-4, "LOW SPEED WIPER OPERATION"](#).

If the switch is held in the mist position, low speed operation continues.

## FAIL-SAFE FUNCTION

The BCM includes fail-safe function to prevent malfunction of electrical components controlled by CAN communications if a malfunction in CAN communications occurs.

The BCM uses CAN communications to stop output of electrical components it controls.

Until the ignition switch is turned off, the front wiper system remains in same status as just before fail-safe control was initiated. (If wiper was in low speed operation just before fail-safe, it continues low speed operation until ignition switch is turned OFF.)

When fail-safe status is initiated, the BCM remains in standby until normal signals are received.

When normal signals are received, fail-safe status is canceled.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#).

## CAN Communication System Description


Refer to [LAN-2, "SYSTEM DESCRIPTION"](#).

EKS00AED

# FRONT WIPER AND WASHER SYSTEM

## Schematic

EKS00AEE



\*: THIS RELAY IS BUILT INTO THE IPDM E/R  
(INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


# FRONT WIPER AND WASHER SYSTEM

## Wiring Diagram — WIPER —

EKS00AEF



### WW-WIPER-01

— : DATA LINE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

WW





REFER TO THE FOLLOWING.  
**(M31)** - SUPER MULTIPLE JUNCTION (SMJ)

WKWA3698E

# FRONT WIPER AND WASHER SYSTEM

## WW-WIPER-02

▬ : DATA LINE





REFER TO THE FOLLOWING.  
 M31 - SUPER MULTIPLE JUNCTION (SMJ)

WKWA3699E



# FRONT WIPER AND WASHER SYSTEM

WW-WIPER-03



# FRONT WIPER AND WASHER SYSTEM

## Terminals and Reference Values for BCM

EKS00AEG

Refer to [BCS-12, "Terminals and Reference Values for BCM"](#) .

## Terminals and Reference Values for IPDM E/R

EKS00AEH

Refer to [PG-24, "Terminals and Reference Values for IPDM E/R"](#) .

## Work Flow

EKS00AEI

1. Confirm the symptom or customer complaint.
2. Understand the system description, refer to [WW-3, "System Description"](#) .
3. Perform preliminary inspection, refer to [WW-10, "Preliminary Inspection"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does wiper function operate normally? If it operates normally, GO TO 6. If not, GO TO 4.
6. Inspection End.

## Preliminary Inspection

EKS00AEJ

### INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT

Inspection procedure

#### 1. CHECK FUSE

Check if wiper or washer fuse is blown.

| Unit               | Power source         | Fuse No. |
|--------------------|----------------------|----------|
| Front washer motor | Ignition ON or START | 9        |
| Front wiper relay  | Battery              | 39       |
| BCM                | Ignition ON or START | 59       |
|                    | Battery              | f        |

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of blown fuse before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .

#### 2. CHECK POWER SUPPLY CIRCUIT


1. Disconnect BCM connectors.
2. Check voltage between BCM harness connector terminals and ground.

| Terminals |          | Ignition switch position |                 |                 |
|-----------|----------|--------------------------|-----------------|-----------------|
| (+)       | (-)      | OFF                      | ON              |                 |
| Connector | Terminal | Ground                   | 0V              | Battery voltage |
| M18       | 38       |                          | Battery voltage |                 |
| M20       | 70       |                          |                 |                 |

OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between BCM and fuse.



# FRONT WIPER AND WASHER SYSTEM

## 3. GROUND CIRCUIT INSPECTION (BCM)


Check for continuity between BCM terminal and ground.

| Terminals |          |        | Ignition switch condition | Continuity |
|-----------|----------|--------|---------------------------|------------|
| Connector | Terminal |        |                           |            |
| M20       | 67       | Ground | OFF                       | Yes        |

OK or NG

OK >> Inspection End.

NG >> Repair/replace BCM ground circuit.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

WW

# FRONT WIPER AND WASHER SYSTEM

## CONSULT-II Function (BCM)

EKS00AEK

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

| BCM diagnostic test item | Diagnostic mode       | Description  |
|--------------------------|-----------------------|--|
| Inspection by part       | WORK SUPPORT          | Supports inspections and adjustments. Commands are transmitted to the BCM for setting the status suitable for required operation, input/output signals are received from the BCM and received data is displayed. |
|                          | DATA MONITOR          | Displays BCM input/output data in real time.   |
|                          | ACTIVE TEST           | Operation of electrical loads can be checked by sending drive signal to them.  |
|                          | SELF-DIAG RESULTS     | Displays BCM self-diagnosis results.   |
|                          | CAN DIAG SUPPORT MNTR | The result of transmit/receive diagnosis of CAN communication can be read.   |
|                          | ECU PART NUMBER       | BCM part number can be read.   |
|                          | CONFIGURATION         | Performs BCM configuration read/write functions.   |

## CONSULT-II START PROCEDURE

Refer to [GI-38, "CONSULT-II Start Procedure"](#).

## WORK SUPPORT

### Work Support Setting Item

| Item                | Description   | CONSULT-II |
|---------------------|---|------------|
| WIPER SPEED SETTING | When wiper switch is at INTERMITTENT, front wiper intermittent time can be selected according to vehicle speed.<br>● ON (Operated)/OFF (Not operated) | ON/OFF     |

## DATA MONITOR

|                     |  |
|---------------------|--|
| ALL SIGNALS         | Monitors all the items.                            |
| SELECTION FROM MENU | Selects and monitors the individual item selected. |

## Display Item List

| Monitor item name<br>"OPERATION OR UNIT" | Contents   |
|--|--|
| IGN ON SW "ON/OFF"                       | Displays "IGN Position (ON)/OFF, ACC Position (OFF)" status as judged from ignition switch signal. |
| IGN SW CAN "ON/OFF"                      | Displays "IGN switch ON (ON)/Other OFF or ACC (OFF)" status as judged from CAN communications.     |
| FR WIPER HI "ON/OFF"                     | Displays "Front Wiper HI (ON)/Other (OFF)" status as judged from wiper switch signal.              |
| FR WIPER LOW "ON/OFF"                    | Displays "Front Wiper LOW (ON)/Other (OFF)" status as judged from wiper switch signal.             |
| FR WIPER INT "ON/OFF"                    | Displays "Front Wiper INT (ON)/Other (OFF)" status as judged from wiper switch signal.             |
| FR WASHER SW "ON/OFF"                    | Displays "Front Washer Switch (ON)/Other (OFF)" status as judged from wiper switch signal.         |
| INT VOLUME (1 - 7)                       | Displays intermittent operation dial position setting (1 - 7) as judged from wiper switch signal.  |
| FR WIPER STOP "ON/OFF"                   | Displays "Stopped (ON)/Operating (OFF)" status as judged from the auto-stop signal.                |
| VEHICLE SPEED "0.0 km/h"                 | Displays vehicle speed as received from CAN communication.   |

## ACTIVE TEST

### Display Item List

| Test item              | Display on CONSULT-II screen | Description  |
|------------------------|------------------------------|--|
| Front wiper HI output  | FR WIPER (HI)                | Front wiper HI can be operated by any ON-OFF operation.  |
| Front wiper LO output  | FR WIPER (LO)                | Front wiper LO can be operated by any ON-OFF operation.  |
| Front wiper INT output | FR WIPER (INT)               | Front wiper INT can be operated by any ON-OFF operation. |

# FRONT WIPER AND WASHER SYSTEM

## CONSULT-II Function (IPDM E/R)

EKS00AEL

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

| IPDM E/R diagnostic Mode | Description   |
|--------------------------|---|
| SELF-DIAG RESULTS        | Displays IPDM E/R self-diagnosis results.                                     |
| DATA MONITOR             | Displays IPDM E/R input/output data in real time.                             |
| CAN DIAG SUPPORT MNTR    | The result of transmit/receive diagnosis of CAN communication can be read.    |
| ACTIVE TEST              | Operation of electrical loads can be checked by sending drive signal to them. |

## CONSULT-II START PROCEDURE

Refer to [GI-38, "CONSULT-II Start Procedure"](#).

## DATA MONITOR

|                     |  |
|---------------------|--|
| ALL SIGNALS         | Monitors all the items.                            |
| MAIN SIGNALS        | Monitors predetermined items.                      |
| SELECTION FROM MENU | Selects and monitors the individual item selected. |

## All Signals, Main Signals, Selection From Menu

| Item name           | CONSULT-II screen display | Display or unit  | Monitor item selection |              |                     | Description                   |
|---------------------|---------------------------|------------------|------------------------|--------------|---------------------|-------------------------------|
|                     |                           |                  | ALL SIGNALS            | MAIN SIGNALS | SELECTION FROM MENU |                               |
| Front wiper request | FR WIP REQ                | STOP/1LOW/LOW/HI | x                      | x            | x                   | Signal status input from BCM. |
| Wiper auto stop     | WIP AUTO STOP             | ACT P/STOP P     | x                      | x            | x                   | Output status of IPDM E/R.    |
| Wiper protection    | WIP PROT                  | OFF/LS/HS/BLOCK  | x                      | x            | x                   | Control status of IPDM E/R.   |

### NOTE:

Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.

## ACTIVE TEST

### Display Item List

| Test item                   | CONSULT-II screen display | Description  |
|-----------------------------|---------------------------|--|
| Front wiper (HI, LO) output | FRONT WIPER               | With a certain operation (OFF, HI, LO) front wiper relays can be operated. |

# FRONT WIPER AND WASHER SYSTEM

EKS00AEM

## Front Wiper Does Not Operate

### CAUTION:

During IPDM E/R fail-safe control, front wipers may not operate. Refer to [PG-18, "CAN COMMUNICATION LINE CONTROL"](#) to make sure that it is not in fail-safe status.

### Inspection Procedure

#### 1. CHECK IPDM E/R TO FRONT WIPERS

##### ☐ With CONSULT-II

1. Select "IPDM E/R" with CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "FRONT WIPER" on "SELECT TEST ITEM" screen.
3. Confirm front wiper operation.

##### ☒ Without CONSULT-II

1. Turn on front wipers using auto active test. Refer to [PG-22, "Auto Active Test"](#).
2. Confirm front wiper operation.

##### OK or NG

- OK >> GO TO 4.  
NG >> GO TO 2.

| ACTIVE TEST |      |       |      |
|-------------|------|-------|------|
| FRONT WIPER |      | OFF   |      |
|             |      |       |      |
| HI          |      | LO    |      |
|             |      |       |      |
|             |      |       |      |
| MODE        | BACK | LIGHT | COPY |


SKIA3486E

# FRONT WIPER AND WASHER SYSTEM

## 2. IPDM E/R TO FRONT WIPERS CIRCUIT INSPECTION


1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connectors and front wiper motor connector.
3. Check continuity between IPDM E/R harness connector terminals and front wiper motor harness connector terminals.

| Terminals |          |           |          | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal |            |
| E121      | 32       | E23       | 3        | Yes        |
|           | 35       |           | 2        |            |
| E122      | 43       |           | 6        |            |




4. Check continuity between IPDM E/R harness connector terminals and ground.

| Terminals |          |        |  | Continuity |
|-----------|----------|--------|--|------------|
| Connector | Terminal |        |  |            |
| E121      | 32       | Ground |  | No         |
|           | 35       |        |  |            |
| E122      | 43       |        |  |            |




5. Check continuity between IPDM E/R harness connector terminal and ground.

| Terminals |          |        |  | Continuity |
|-----------|----------|--------|--|------------|
| Connector | Terminal |        |  |            |
| E122      | 38       | Ground |  | Yes        |
| E124      | 59       |        |  |            |



6. Check continuity between front wiper motor harness connector terminal 1 and ground.

| Terminals |          |        |  | Continuity |
|-----------|----------|--------|--|------------|
| Connector | Terminal |        |  |            |
| E23       | 1        | Ground |  | Yes        |



### OK or NG

- OK >> Connect connectors. GO TO 3.  
 NG >> Check for open circuit in harness between front wiper motor and ground.

# FRONT WIPER AND WASHER SYSTEM

## 3. IPDM E/R INSPECTION


☑ With CONSULT-II

1. Select "HI" on "ACTIVE TEST" screen.
2. When front wiper relay, and front wiper HI relay are operating, check voltage between IPDM E/R terminals and ground.

☒ Without CONSULT-II

1. Turn on front wipers using the auto active test. Refer to [PG-22, "Auto Active Test"](#).
2. When front wiper relay, and front wiper HI relay are operating, check voltage between IPDM E/R terminals and ground.

| Terminals |          | (-)    | Condition    | Voltage (Approx.) |
|-----------|----------|--------|--------------|-------------------|
| (+)       | Terminal |        |              |                   |
| E121      | 32       | Ground | Stopped      | 0                 |
|           |          |        | LO operation | Battery voltage   |
|           | 35       |        | Stopped      | 0                 |
|           |          |        | HI operation | Battery voltage   |



OK or NG

- OK >> Replace the front wiper motor. Refer to [WW-25, "REMOVAL AND INSTALLATION"](#).
- NG >> Replace IPDM E/R. Refer to [PG-30, "Removal and Installation of IPDM E/R"](#).

## 4. COMBINATION SWITCH TO BCM INSPECTION

Select "BCM" on CONSULT-II. With "WIPER" data monitor, check that "FR WIPER INT", "FR WIPER LOW" and "FR WIPER HI" turn ON-OFF according to operation of wiper switch.

OK or NG

- OK >> GO TO 5.
- NG >> Check wiper switch. Refer to [WW-5, "COMBINATION SWITCH READING FUNCTION"](#).

| DATA MONITOR  |          |
|---------------|----------|
| MONITOR       |          |
| IGN ON SW     | OFF      |
| IGN SW CAN    | ON       |
| FR WIPER HI   | OFF      |
| FR WIPER LOW  | OFF      |
| FR WIPER INT  | OFF      |
| FR WASHER SW  | OFF      |
| INT VOLUME    | 7        |
| FR WIPER STOP | ON       |
| VEHICLE SPEED | 0.0 km/h |
| PAGE DOWN     |          |
| RECORD        |          |
| MODE          | BACK     |
| LIGHT         | COPY     |

WKIA1018E

## 5. BCM INSPECTION

Select "BCM" on CONSULT-II. Carry out self-diagnosis of BCM.

Displayed self-diagnosis results

NO DTC>> Replace the BCM. Refer to [BCS-26, "REMOVAL AND INSTALLATION"](#).

CAN COMM CIRCUIT>> Check CAN communication line of BCM. GO TO [BCS-19, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#).

| SELF-DIAG RESULTS        |      |       |      |
|--------------------------|------|-------|------|
| DTC RESULTS              |      | TIME  |      |
| CAN COMM CIRCUIT [U1000] |      | PAST  |      |
|                          |      |       |      |
|                          |      |       |      |
| ERASE                    |      | PRINT |      |
| MODE                     | BACK | LIGHT | COPY |

SKIA1039E



# FRONT WIPER AND WASHER SYSTEM

## FRONT WIPER STOP POSITION IS INCORRECT

### 1. CHECK IPDM E/R TO FRONT WIPER MOTOR

Ⓜ With CONSULT-II

Select "IPDM E/R" with CONSULT-II. With data monitor, confirm that "WIP AUTO STOP" changes from "ACT P" to "STOP P" according to wiper operation.

ⓧ Without CONSULT-II

GO TO 2.

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-30, "Removal and Installation of IPDM E/R"](#).

NG >> GO TO 2.


| DATA MONITOR  |        |
|---------------|--------|
| MONITOR       |        |
| MOTOR FAN REQ | 1      |
| AC COMP REQ   | OFF    |
| TAIL&CLR REQ  | OFF    |
| HL LO REQ     | OFF    |
| HL HI REQ     | OFF    |
| FR FOG REQ    | OFF    |
| FR WIP REQ    | STOP   |
| WIP AUTO STOP | STOP P |
| WIP PROT      | OFF    |
| Page DOWN     |        |
| RECORD        |        |
| MODE          | BACK   |
| LIGHT         | COPY   |

SKIA5301E

### 2. IPDM E/R TO FRONT WIPER MOTOR CIRCUIT INSPECTION


1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front wiper motor connector.
3. Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

| Terminals |          |           |          | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal |            |
| E122      | 43       | E23       | 6        | Yes        |




4. Check continuity between IPDM E/R harness connector terminal and ground.

| Terminals |          |        | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | Ground |            |
| E122      | 43       | Ground | No         |



5. Check continuity between front wiper motor harness connector terminal 1 and ground.

| Terminals |          |        | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | Ground |            |
| E23       | 1        | Ground | Yes        |



OK or NG

OK >> GO TO 3.

NG >> ● Check for short circuit or open circuit in harness between IPDM E/R and front wiper motor.

- Check for open circuit in harness between front wiper motor and ground.

# FRONT WIPER AND WASHER SYSTEM


## 3. IPDM E/R INSPECTION

☑ With CONSULT-II


1. Connect IPDM E/R connector and front wiper motor connector.
2. Select "IPDM E/R" with CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Select "FRONT WIPER" on "SELECT TEST ITEM" screen.
4. Select "LO" on "ACTIVE TEST" screen.
5. When front wipers are operating and when stopped, measure voltage between IPDM E/R terminal 43 and ground.

☒ Without CONSULT-II

1. Connect IPDM E/R connector and front wiper motor connector.
2. Turn on front wipers using the auto active test. Refer to [PG-22, "Auto Active Test"](#).
3. When front wipers are operating and when stopped, measure voltage between IPDM E/R terminal 43 and ground.



| Terminals |          | (-)    | Condition       | Voltage (Approx.) |
|-----------|----------|--------|-----------------|-------------------|
| (+)       | Terminal |        |                 |                   |
| Connector |          | Ground | Wiper operating | Battery voltage   |
| E122      | 43       |        | Wiper stopped   | 0V                |



OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-30, "Removal and Installation of IPDM E/R"](#).  
 NG >> Replace front wiper motor. Refer to [WW-25, "REMOVAL AND INSTALLATION"](#).

### ONLY FRONT WIPER LOW DOES NOT OPERATE

#### 1. CHECK IPDM E/R TO FRONT WIPERS

☑ With CONSULT-II


1. Select "IPDM E/R" with CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "FRONT WIPER" on "SELECT TEST ITEM" screen.
3. Select "LO" on "ACTIVE TEST" screen.
4. Confirm front wiper low operation.

☒ Without CONSULT-II

1. Turn on front wipers using auto active test. Refer to [PG-22, "Auto Active Test"](#).
2. Confirm front wiper low operation.

OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 2.



# FRONT WIPER AND WASHER SYSTEM


## 2. IPDM E/R INSPECTION

④ With CONSULT-II

1. Select "LO" on "ACTIVE TEST" screen.

⊗ Without CONSULT-II

1. Turn on front wipers using the auto active test. Refer to [PG-22, "Auto Active Test"](#).




When front wiper relay is operating, check voltage between IPDM E/R terminal and ground.

| Terminals |          |        |                 | Voltage (Approx.) |
|-----------|----------|--------|-----------------|-------------------|
| (+)       |          | (-)    | Condition       |                   |
| Connector | Terminal |        |                 |                   |
| E121      | 32       | Ground | Wiper operating | Battery voltage   |

OK or NG

OK >> GO TO 3.

NG >> Replace IPDM E/R. Refer to [PG-30, "Removal and Installation of IPDM E/R"](#).



## 3. IPDM E/R TO FRONT WIPERS CIRCUIT INSPECTION


1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front wiper motor connector.
3. Check continuity between IPDM E/R harness connector terminal and front wiper motor harness connector terminal.

| Terminals |          |           |          | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal |            |
| E121      | 32       | E23       | 3        | Yes        |

OK or NG

OK >> Replace the wiper motor. Refer to [WW-25, "REMOVAL AND INSTALLATION"](#).

NG >> Repair harness or connector.



## 4. COMBINATION SWITCH TO BCM INSPECTION

Select "BCM" on CONSULT-II. With "WIPER" data monitor, check that "FR WIPER LOW" turns ON-OFF according to operation of wiper switch.

OK or NG

OK >> Replace BCM. Refer to [BCS-26, "REMOVAL AND INSTALLATION"](#).

NG >> Replace wiper switch. Refer to [WW-26, "REMOVAL AND INSTALLATION"](#).

| DATA MONITOR  |          |
|---------------|----------|
| MONITOR       |          |
| IGN ON SW     | OFF      |
| IGN SW CAN    | ON       |
| FR WIPER HI   | OFF      |
| FR WIPER LOW  | OFF      |
| FR WIPER INT  | OFF      |
| FR WASHER SW  | OFF      |
| INT VOLUME    | 7        |
| FR WIPER STOP | ON       |
| VEHICLE SPEED | 0.0 km/h |
| PAGE DOWN     |          |
| RECORD        |          |
| MODE          | BACK     |
| LIGHT         | COPY     |


# FRONT WIPER AND WASHER SYSTEM

## ONLY FRONT WIPER HI DOES NOT OPERATE

### 1. CHECK IPDM E/R TO FRONT WIPERS

Ⓟ With CONSULT-II

1. Select "IPDM E/R" with CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "FRONT WIPER" on "SELECT TEST ITEM" screen.
3. Select "HI" on "ACTIVE TEST" screen.
4. Confirm front wiper high operation.



ⓧ Without CONSULT-II

1. Turn on front wipers using auto active test. Refer to [PG-22, "Auto Active Test"](#).
2. Confirm front wiper operation.

OK or NG

- OK >> GO TO 4.  
 NG >> GO TO 2.


### 2. IPDM E/R INSPECTION

Ⓟ With CONSULT-II

1. Select "HI" on "ACTIVE TEST" screen.

ⓧ Without CONSULT-II

1. Turn on front wipers using the auto active test. Refer to [PG-22, "Auto Active Test"](#).




When front wiper relay high is operating, check voltage between IPDM E/R terminal and ground.

| Terminals |          |        |                 | Voltage (Approx.) |
|-----------|----------|--------|-----------------|-------------------|
| (+)       |          | (-)    | Condition       |                   |
| Connector | Terminal |        |                 |                   |
| E121      | 35       | Ground | Wiper operating | Battery voltage   |

OK or NG

- OK >> GO TO 3.  
 NG >> Replace IPDM E/R. Refer to [PG-30, "Removal and Installation of IPDM E/R"](#).



# FRONT WIPER AND WASHER SYSTEM


## 3. IPDM E/R TO FRONT WIPERS CIRCUIT INSPECTION

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front wiper motor connector.
3. Check continuity between IPDM E/R harness connector terminal and front wiper motor harness connector terminal.

| Terminals |          |           |          | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal |            |
| E121      | 35       | E23       | 2        | Yes        |

### OK or NG

- OK >> Replace the wiper motor. Refer to [WW-25, "REMOVAL AND INSTALLATION"](#) .
- NG >> Repair harness or connector.



## 4. COMBINATION SWITCH TO BCM INSPECTION

Select "BCM" on CONSULT-II. With "WIPER" data monitor, check that "FR WIPER HI" turns ON-OFF according to operation of wiper switch.

### OK or NG

- OK >> Replace BCM. Refer to [BCS-26, "REMOVAL AND INSTALLATION"](#) .
- NG >> Replace wiper switch. Refer to [WW-26, "REMOVAL AND INSTALLATION"](#) .

| DATA MONITOR  |          |
|---------------|----------|
| MONITOR       |          |
| IGN ON SW     | OFF      |
| IGN SW CAN    | ON       |
| FR WIPER HI   | OFF      |
| FR WIPER LOW  | OFF      |
| FR WIPER INT  | OFF      |
| FR WASHER SW  | OFF      |
| INT VOLUME    | 7        |
| FR WIPER STOP | ON       |
| VEHICLE SPEED | 0.0 km/h |
| PAGE DOWN     |          |
| RECORD        |          |
| MODE          | BACK     |
| LIGHT         | COPY     |

WKIA1018E

## ONLY FRONT WIPER INTERMITTENT DOES NOT OPERATE

### 1. COMBINATION SWITCH TO BCM INSPECTION

Select "BCM" on CONSULT-II. With "WIPER" data monitor, check that "FR WIPER INT" turns ON-OFF according to operation of wiper switch.

### OK or NG

- OK >> Replace BCM. Refer to [BCS-26, "REMOVAL AND INSTALLATION"](#) .
- NG >> Replace wiper switch. Refer to [WW-26, "REMOVAL AND INSTALLATION"](#) .

| DATA MONITOR  |          |
|---------------|----------|
| MONITOR       |          |
| IGN ON SW     | OFF      |
| IGN SW CAN    | ON       |
| FR WIPER HI   | OFF      |
| FR WIPER LOW  | OFF      |
| FR WIPER INT  | OFF      |
| FR WASHER SW  | OFF      |
| INT VOLUME    | 7        |
| FR WIPER STOP | ON       |
| VEHICLE SPEED | 0.0 km/h |
| PAGE DOWN     |          |
| RECORD        |          |
| MODE          | BACK     |
| LIGHT         | COPY     |

WKIA1018E

# FRONT WIPER AND WASHER SYSTEM

## FRONT WIPER INTERMITTENT OPERATION SWITCH POSITION CANNOT BE ADJUSTED

### 1. COMBINATION SWITCH TO BCM INSPECTION

Select "BCM" on CONSULT-II. With "WIPER" data monitor, check that "INT VOLUME" changes in order from 1 to 7 according to operation of the intermittent switch dial position.

OK or NG

- OK >> Replace BCM. Refer to [BCS-26, "REMOVAL AND INSTALLATION"](#).
- NG >> Replace wiper switch. Refer to [WW-26, "REMOVAL AND INSTALLATION"](#).

| DATA MONITOR  |      |           |      |
|---------------|------|-----------|------|
| MONITOR       |      |           |      |
| IGN ON SW     |      | OFF       |      |
| IGN SW CAN    |      | ON        |      |
| FR WIPER HI   |      | OFF       |      |
| FR WIPER LOW  |      | OFF       |      |
| FR WIPER INT  |      | OFF       |      |
| FR WASHER SW  |      | OFF       |      |
| INT VOLUME    |      | 7         |      |
| FR WIPER STOP |      | ON        |      |
| VEHICLE SPEED |      | 0.0 km/h  |      |
|               |      | PAGE DOWN |      |
|               |      | RECORD    |      |
| MODE          | BACK | LIGHT     | COPY |

WKIA1018E

## WIPERS DO NOT WIPER WHEN FRONT WASHER OPERATES

### 1. COMBINATION SWITCH TO BCM INSPECTION

Select "BCM" on CONSULT-II. With "WIPER" data monitor, check that "FR WASHER SW" turns ON-OFF according to operation of front washer switch.

OK or NG

- OK >> Replace BCM. Refer to [BCS-26, "REMOVAL AND INSTALLATION"](#).
- NG >> Replace wiper switch. Refer to [WW-26, "REMOVAL AND INSTALLATION"](#).

| DATA MONITOR  |      |           |      |
|---------------|------|-----------|------|
| MONITOR       |      |           |      |
| IGN ON SW     |      | OFF       |      |
| IGN SW CAN    |      | ON        |      |
| FR WIPER HI   |      | OFF       |      |
| FR WIPER LOW  |      | OFF       |      |
| FR WIPER INT  |      | OFF       |      |
| FR WASHER SW  |      | OFF       |      |
| INT VOLUME    |      | 7         |      |
| FR WIPER STOP |      | ON        |      |
| VEHICLE SPEED |      | 0.0 km/h  |      |
|               |      | PAGE DOWN |      |
|               |      | RECORD    |      |
| MODE          | BACK | LIGHT     | COPY |

WKIA1018E

## FRONT WIPERS OPERATE FOR 10 SECONDS, STOP FOR 20 SECONDS, AND AFTER REPEATING THIS OPERATION FIVE TIMES, THEY BECOME INOPERATIVE

### CAUTION:

- When auto stop signal has not varied for 10 seconds or longer while IPDM E/R is operating front wipers, IPDM E/R considers front wipers locked and stops wiper output, which causes this symptom.
- This status can be checked by using IPDM E/R "DATA MONITOR". Under this condition, "WIP PROT" reads "BLOCK".

### 1. CHECK IPDM E/R TO FRONT WIPER MOTOR

Ⓜ With CONSULT-II

Select "IPDM E/R" with CONSULT-II. With data monitor, confirm that "WIP AUTO STOP" changes from "ACT P" to "STOP P" according to wiper operation.

ⓧ Without CONSULT-II

GO TO 2.

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-30, "Removal and Installation of IPDM E/R"](#).
- NG >> GO TO 2.

| DATA MONITOR  |      |           |      |
|---------------|------|-----------|------|
| MONITOR       |      |           |      |
| MOTOR FAN REQ |      | 1         |      |
| AC COMP REQ   |      | OFF       |      |
| TAIL&CLR REQ  |      | OFF       |      |
| HL LO REQ     |      | OFF       |      |
| HL HI REQ     |      | OFF       |      |
| FR FOG REQ    |      | OFF       |      |
| FR WIP REQ    |      | STOP      |      |
| WIP AUTO STOP |      | STOP P    |      |
| WIP PROT      |      | OFF       |      |
|               |      | Page DOWN |      |
|               |      | RECORD    |      |
| MODE          | BACK | LIGHT     | COPY |


SKIA5301E

# FRONT WIPER AND WASHER SYSTEM

## 2. IPDM E/R TO FRONT WIPER MOTOR CIRCUIT INSPECTION


1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front wiper motor connector.
3. Check continuity between IPDM E/R harness connector terminal and front wiper motor harness connector terminal.

| Terminals |          |           |          | Continuity |
|-----------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal |            |
| E122      | 43       | E23       | 6        | Yes        |



4. Check continuity between IPDM E/R harness connector terminal and ground.

| Terminals |          |        | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| E122      | 43       | Ground | No         |




### OK or NG

- OK >> Connect connectors. GO TO 3.
- NG >> Repair harness or connector.

## 3. IPDM E/R TO FRONT WIPER MOTOR AUTO STOP CIRCUIT INSPECTION

While front wiper motor is stopped and while operating, measure voltage between IPDM E/R terminal 43 and ground.

| Terminals |          |        |                 | Voltage (Approx.) |
|-----------|----------|--------|-----------------|-------------------|
| (+)       |          | (-)    | Condition       |                   |
| Connector | Terminal |        |                 |                   |
| E122      | 43       | Ground | Wiper operating | Battery voltage   |
|           |          |        | Wiper stopped   | 0V                |



### OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-30, "Removal and Installation of IPDM E/R"](#).
- NG >> Replace front wiper motor. Refer to [WW-25, "REMOVAL AND INSTALLATION"](#).

# FRONT WIPER AND WASHER SYSTEM

EKS00GDS


## Front Wiper Arms REMOVAL AND INSTALLATION

### Removal

1. Remove wiper arm covers and wiper arm nuts.
2. Remove front RH wiper arm and front LH wiper arm.
3. Remove front RH blade assembly and front LH blade assembly.

### Installation

1. Operate wiper motor one full cycle, then turn "OFF" (Auto Stop).
2. Clean up the pivot area as shown. This will reduce possibility of wiper arm looseness.




3. Install front RH blade assembly and front LH blade assembly.
4. Install front RH wiper arm and front LH wiper arm.
5. Tighten wiper arm nuts to specified torque, and install wiper arm covers. Refer to [WW-25, "Wiper Motor and Linkage"](#).
6. Ensure that wiper blades stop within proper clearance. Refer to [WW-24, "FRONT WIPER ARM ADJUSTMENT"](#).

## FRONT WIPER ARM ADJUSTMENT

1. Operate windshield washer and wiper motor one full cycle, then turn "OFF" (Auto Stop).
2. Lift the wiper blade up and then rest it onto glass surface, check the blade clearance "L1" and "L2".

**Clearance "L1" : 41.5 - 56.5 mm (1.634 - 2.224 in)**

**Clearance "L2" : 52.5 - 67.5 mm (2.067 - 2.657 in)**




3. Remove wiper arm covers and wiper arm nuts.
4. Adjust front wiper arms on wiper motor pivot shafts to obtain above specified blade clearances.
5. Tighten wiper arm nuts to specified torque, and install wiper arm covers. Refer to [WW-25, "Wiper Motor and Linkage"](#).



# FRONT WIPER AND WASHER SYSTEM

## Wiper Motor and Linkage REMOVAL AND INSTALLATION

EKS00GDT



- |                       |                         |  |
|-----------------------|-------------------------|--|
| 1. Wiper arm covers   | 2. Wiper arm nuts       | 3. Front RH wiper arm and blade assembly |
| 4. Wiper frame bolts  | 5. Wiper frame assembly | 6. Wiper motor to frame bolts            |
| 7. Wiper motor spacer | 8. Wiper motor          | 9. Front LH wiper arm and blade assembly |

### Removal

1. Remove the cowl top. Refer to [EI-21, "COWL TOP"](#).
2. Remove wiper frame bolts, and remove wiper frame assembly.
3. Remove wiper motor from wiper frame assembly.

### Installation


#### CAUTION:

- Do not drop the wiper motor or cause it to contact other parts.
  - Check the grease condition of the motor arm and wiper link joint(s). Apply grease if necessary.
1. Connect wiper motor to connector. Turn the wiper switch ON to operate wiper motor, then turn the wiper switch OFF (auto stop).
  2. Disconnect wiper motor connector.
  3. Install wiper motor to wiper frame assembly, and install wiper frame assembly.
  4. Install cowl top. Refer to [EI-21, "COWL TOP"](#).
  5. Ensure that wiper blades stop within proper clearance. Refer to front wiper arm adjustment [WW-24, "FRONT WIPER ARM ADJUSTMENT"](#).

### Washer Nozzle Adjustment

EKS00GDU

- This vehicle is equipped with non-adjustable washer nozzles.
- If not satisfied with washer fluid spray coverage, confirm that the washer nozzle is installed correctly.
- If the washer nozzle is installed correctly, and the washer fluid spray coverage is not satisfactory, replace washer nozzle.




# FRONT WIPER AND WASHER SYSTEM

## Washer Tube Layout

EKS00GDV

SEC. 289



WKIA4597E

1. Washer nozzles


2. Washer fluid reservoir

## Wiper and Washer Switch REMOVAL AND INSTALLATION

EKS00GDW

### Removal

1. Remove steering column covers.
2. Remove wiper washer switch connector.
3. Pinch tabs at wiper and washer switch base and slide switch away from steering column to remove.



WKIA0071E

### Installation


Installation is in the reverse order of removal.

## Washer Fluid Reservoir REMOVAL AND INSTALLATION

EKS00GDY

### Removal

1. Remove side washer fluid reservoir screw.




LKIA0411E


2. Remove front and rear washer motor connector.

# FRONT WIPER AND WASHER SYSTEM

3. Remove washer fluid level sensor connector.
4. Disconnect front and rear washer hoses.



5. Remove front washer fluid reservoir screw (2).
6. Remove washer fluid reservoir from the vehicle (1).



## Installation

Installation is in the reverse order of removal.

### CAUTION:


After installation, add water up to the upper level of the washer fluid reservoir inlet and check for water leaks.

## Washer Motor REMOVAL AND INSTALLATION

EKS00GDY

### Removal

1. Remove washer fluid reservoir. Refer to [WW-26, "Washer Fluid Reservoir"](#).
2. Remove washer motor (1) in the direction of the arrow as shown, from washer fluid reservoir (2).



### Installation

Installation is in the reverse order of removal.

### CAUTION:

When installing front and rear washer motor, there should be no packing twists, etc.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

WW

L  
M

# POWER SOCKET

FFP:253A2


## POWER SOCKET

### Wiring Diagram — P/SCKT —


EKS00AEU

## WW-P/SCKT-01

**(FB)**: WITH FRONT BENCH SEAT



REFER TO "PG-POWER".



REFER TO THE FOLLOWING.

**(C1)** - SUPER MULTIPLE JUNCTION (SMJ)

WKWA3701E


# POWER SOCKET

## Front Power Socket LH, Rear Cargo Power Socket REMOVAL AND INSTALLATION

EKS00GFL

### Removal

1. Disconnect battery negative terminal.
2. Remove inner socket from the ring, while pressing the hook on the ring out from square hole.
3. Disconnect power socket connector.
4. Remove ring from power socket finisher while pressing pawls.



### Installation


Installation is in the reverse order of removal.

## Front Power Socket RH (For Cigarette Lighter), Front Power Socket (Center Armrest), Console Power Socket REMOVAL AND INSTALLATION

EKS00GFM

### Removal

1. Remove inner socket from the ring, while pressing the hook on the ring out from square hole.
2. Disconnect power socket connector.
3. Remove ring from power socket finisher while pressing pawls.



### Installation

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

WW

# HORN



PFP:25610

## HORN

### Wiring Diagram — HORN —

EKS00AEW

## WW-HORN-01



REFER TO THE FOLLOWING.  
(M31) - SUPER MULTIPLE JUNCTION (SMJ)

\* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

WKWA3702E


# HORN

EKS00AEX

## Removal and Installation

### REMOVAL

1. Remove the front grille. Refer to [EI-20, "FRONT GRILLE"](#) .
2. Disconnect horn connector.
3. Remove horn bolt and remove horn from vehicle.



### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

WW

# HORN

---