

SECTION **HA**

MODIFICATION NOTICE:

- Wiring diagrams have been changed.
- Auto air conditioner has been added to LHD models for Europe.

CONTENTS

MANUAL

TROUBLE DIAGNOSES	1002
Circuit Diagram - Air Conditioner.....	1002
Wiring Diagram - A/C -	1003
Main Power Supply and Ground Circuit Check.....	1006
Diagnostic Procedure.....	1007
Electrical Components Inspection	1009

AUTO


DESCRIPTION	1011
Introduction	1011
Features	1011
Control Operation.....	1012
TROUBLE DIAGNOSES	1013
How to Perform Trouble Diagnoses for Quick and Accurate Repair	1013
Operation Check	1014
Symptom Chart.....	1016
Checking Resistor.....	1018
Preliminary Check.....	1019
Component Location.....	1022
Circuit Diagram - Auto Air Conditioner/LHD Models.....	1023
Circuit Diagram - Push Control Unit/LHD Models.....	1024
Wiring Diagram - A/C, A -/LHD Models.....	1025
Main Power Supply and Ground Circuit Check	1031
Diagnostic Procedure 1	1032
Diagnostic Procedure 2	1034
Diagnostic Procedure 3	1035
Diagnostic Procedure 4	1037
Diagnostic Procedure 5	1038

Diagnostic Procedure 6	1039
Diagnostic Procedure 7	1042
Diagnostic Procedure 8	1043
Diagnostic Procedure 9	1045
Diagnostic Procedure 10	1046
Diagnostic Procedure 11	1049
Diagnostic Procedure 12	1050
Diagnostic Procedure 13	1051
Diagnostic Procedure 14	1052
Diagnostic Procedure 15	1054
Electrical Components Inspection	1057
Push Control System	1060
Removal and Installation	1062
Overhaul - Push control unit assembly	1062
Control Linkage Adjustment.....	1064
SYSTEM DESCRIPTION	1066
Overview of Control System	1066
Control System Input Components.....	1066
Control System Auto Amplifier (Auto amp.)	1070
Control System Output Components.....	1074

MANUAL AND AUTO



SERVICE PROCEDURES	1084
Refrigerant Lines.....	1084
Compressor Mounting.....	1086
Compressor - DKV-14C (ZEXEL make).....	1087
Compressor Clutch - DKV-14C (ZEXEL make)	1087
Thermal Protector - DKV-14C (ZEXEL make)	1090
SERVICE DATA AND SPECIFICATIONS (SDS)	1091
General Specifications	1091
Inspection and Adjustment	1091

Circuit Diagram — Air Conditioner






Wiring Diagram — A/C —

HA-A/C, M-04



Wiring Diagram — A/C — (Cont'd)



HA-A/C, M-05




Refer to last page (Foldout page).

(M5), (E101)

Wiring Diagram — A/C — (Cont'd)



Refer to last page (Foldout page).
 (M5), (E101)
 (M32)




Main Power Supply and Ground Circuit Check

POWER SUPPLY FUSE CHECK FOR A/C SYSTEM

Check the following fuses.

- 15A fuse (No. 19 and 20) for blower motor.
- 7.5A fuse (No. 21) for thermo control amp.

For detailed circuit, refer to “Wiring Diagram”.




THERMO CONTROL AMP. CHECK

Power supply circuit check

Check power supply circuit for thermo control amp. with ignition switch ON.

1. Disconnect thermo control amp. harness connector.
2. Connect voltmeter from harness side.
3. Measure voltage across terminal No. ① and body ground.

Voltmeter terminal		Voltage
⊕	⊖	
①	Body ground	Approx. 12V



Ground circuit check






Check body ground circuit for thermo control amp. with ignition switch ON, air conditioner switch ON and fan switch ON.

1. Disconnect thermo control amp. harness connector.
2. Connect ohmmeter from harness side.
3. Check for continuity between terminal No. ② and body ground.

Ohmmeter terminal		Continuity
⊕	⊖	
②	Body ground	Yes

If the ground circuit is NG, check the following.


- A/C switch (Refer to HA-1009.)
- Fan switch (Refer to HA-1009.)
- Harness for open or short between thermo control amp. and A/C switch
- Harness for open or short between A/C switch and fan switch
- Fan switch ground circuit



Diagnostic Procedure



SYMPTOM: Magnet clutch does not engage when A/C switch and fan switch are ON.

- Perform **PRELIMINARY CHECK 1** before referring to the following flow chart.



Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure (Cont'd)



F Note

Check circuit continuity between thermo switch harness terminal No. ① and triple-pressure switch harness terminal No. ④.
Continuity should exist.
 If OK, check harness for short.

OK

CHECK THERMO SWITCH.
 Refer to HA-1010.

CHECK TRIPLE-PRESSURE SWITCH.
 Refer to HA-1010.

NG → Check refrigerant charge amount.

OK

Replace triple-pressure switch.

G Note

Check circuit continuity between triple-pressure switch harness terminal No. ① and thermo control amp. harness terminal No. ③.
Continuity should exist.
 If OK, check harness for short.


OK

CHECK POWER SUPPLY AND GROUND CIRCUIT FOR THERMO CONTROL AMP.
 Refer to HA-1010.

OK

Replace thermo control amp.

Note:
 If the result is NG or No after checking circuit continuity, repair harness or connector.




Electrical Components Inspection

FAN SWITCH

Check continuity between terminals at each switch position.


Knob position	Continuity between terminals
OFF	
1	(24) — (26) — (25)
2	(23) — (26) — (25)
3	(22) — (26) — (25)
4	(21) — (26) — (25)



A/C SWITCH

Check continuity between terminals at each switch position.

Switch condition	Terminal No.		Continuity
	⊕	⊖	
A/C			Yes
ON	(13)	(12)	
OFF			No



A/C RELAY


Check continuity between terminal Nos. (3) and (5).

Conditions	Continuity
12V direct current supply between terminal Nos. (1) and (2)	Yes
No current supply	No

If NG, replace relay.


Electrical Components Inspection (Cont'd)

TRIPLE-PRESSURE SWITCH




	Terminals	High-pressure side line pressure kPa (bar, kg/cm ² , psi)	Operation	Continuity
Low-pres- sure side	① - ④	Increasing to 152.0 - 201.0 (1.520 - 2.010, 1.55 - 2.05, 22.0 - 29.2)	ON	Exists.
		Decreasing to 152.0 - 201.0 (1.520 - 2.010, 1.55 - 2.05, 22.0 - 29.2)	OFF	Does not exist.
Medium- pressure side*	② - ③	Increasing to 1,422 - 1,618 (14.22 - 16.18, 14.5 - 16.5, 206 - 235)	ON	Exists.
		Decreasing to 1,128 - 1,422 (11.28 - 14.22, 11.5 - 14.5, 164 - 206)	OFF	Does not exist.
High-pres- sure side	① - ④	Decreasing to 2,059 - 2,256 (20.6 - 22.6, 21 - 23, 299 - 327)	ON	Exists.
		Increasing to 2,648 - 2,844 (26.5 - 28.4, 27 - 29, 384 - 412)	OFF	Does not exist.

* For cooling fan motor operation



THERMO CONTROL AMP.

Evaporator outlet air temperature °C (°F)	Thermo amp. operation	Tester
Decreasing to 0.1 - 0.9 (32 - 34)	Turn OFF	Approx. 12V
Increasing to 2.5 - 3.5 (37 - 38)	Turn ON	Approx. 0V



THERMO SWITCH

Water tempera- ture °C (°F)	Terminal No.		Continuity
	⊕	⊖	
Over 105 (221)			No
Less than 100 (212)	①	②	Yes

Introduction

The automatic temperature control (ATC) system provides automatic regulation of the discharged air temperature and the discharged air volume (Blower speed).

The air outlet door, intake door and compressor magnet clutch are controlled by the manual operation of each switch.

Features

Air mix door control (Automatic temperature control)

The air mix door is automatically controlled so that in-vehicle temperature will reach, and be maintained at the operator selected "set temperature". For a given set temperature, the air mix door position will depend on: Ambient temperature, in-vehicle temperature, amount of sunload, set temperature and A/C switch signals.

Fan speed control

When the fan control switch is in the Auto position, the blower speed is automatically controlled, depending on: Ambient temperature, in-vehicle temperature, amount of sunload, set temperature, and A/C switch signals. It is also controlled by the manual operation of the fan control switch.

Starting fan speed control

When engine coolant temperature is low, the air outlet door position is detected by the microswitch and if this is set in B/L, FOOT or FOOT/DEF blower speed is controlled to prevent a large amount of cold air from being discharged into the floor area.

Outlet door control

This can be selected by operation of the mode switch.


Intake door control

This can be selected by changing the REC switch position.

Compressor magnet clutch control

When the A/C switch is ON, the thermistor detects evaporator temperature. The thermo control amplifier controls clutch ON/OFF operation depending on the evaporator temperature.

Control Operation

**FAN SWITCH**

This switch turns the fan ON and OFF, and controls fan speed.

MODE SWITCHES

These switches allow outlet air to flow.

TEMPERATURE CONTROL LEVER

This lever allows the temperature of the outlet air to be adjusted.

RECIRCULATION SWITCH

OFF position:

Outside air is drawn into the passenger compartment.

ON position:

Interior air is recirculated inside the vehicle.


AIR CONDITIONER SWITCH

Start the engine, move the fan switch to the desired (Auto to 3) position and press the air conditioner switch to turn ON the air conditioner. The indicator light will come on when the air conditioner is ON. To stop the air conditioner, push the switch again to return it to the original position.

The air conditioner cooling function operates only when the engine is running.

How to Perform Trouble Diagnoses for Quick and Accurate Repair

WORK FLOW



Operation Check

The purpose of the operational check is to confirm that the system is as it should be. The systems which will be checked are the blower, mode (discharge air), intake air, temperature decrease, temperature increase and A/C switch.


CONDITIONS:

Engine running and at normal operating temperature.

PROCEDURE:


1. Check blower

- 1) Slide FAN switch to AUTO.
Blower should operate at speed AUTO.
- 2) Then slide switch to speed 1.
- 3) Continue checking blower speed until all speeds are checked.
- 4) Leave blower on speed 3.



2. Check discharge air

- 1) Press button.
VENT indicator should light.
- 2) Confirm that all discharge air comes out of face vents.
- 3) Press button.
B/L indicator should light.
- 4) Confirm that discharge air comes out of face vents and foot vents.
- 5) Press button.
FOOT indicator should light.
- 6) Confirm that discharge air comes out of foot vents.
- 7) Press button.
F/D indicator should light.
- 8) Confirm that discharge air comes out of foot vents with some air from defroster vents.
- 9) Press button.
DEF indicator should light.
- 10) Confirm that all discharge air comes out of defroster vents.




Discharge air flow


Mode control knob	Air outlet/distribution		
	Face	Foot	Defroster
	100%	-	-
	70%	30%	-
	40%	60%	-
	40%	30%	30%
	-	-	100%

RHA937G

Operation Check (Cont'd)


3. Check recirculation

- 1) Press  button.
RECIRCULATION indicator should light.
- 2) Listen for intake door position change (you should hear sound change slightly).




4. Check temperature decrease

- 1) Slide temperature lever to full cold.
- 2) Check for cold air at discharge air outlets.




5. Check temperature increase

- 1) Slide temperature lever to full hot.
- 2) Check for hot air at discharge air outlets.



6. Check A/C switch

Move fan control lever to the desired position (AUTO to 3) and press air conditioner button to turn ON air conditioner. Indicator light will come on when air conditioner is ON.



Symptom Chart

DIAGNOSTIC TABLE

PROCEDURE	Preliminary Check			Diagnostic Procedure															Main Power Supply and Ground Circuit Check			
	HA-1019	HA-1020	HA-1021	HA-1032	HA-1034	HA-1035	HA-1037	HA-1038	HA-1039	HA-1042	HA-1043	HA-1045	HA-1046	HA-1049	HA-1050	HA-1051	HA-1052	HA-1054	HA-1031	HA-1031	HA-1031	HA-1031
REFERENCE PAGE	Preliminary check 1	Preliminary check 2	Preliminary check 3	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4	Diagnostic Procedure 5	Diagnostic Procedure 6	Diagnostic Procedure 7	Diagnostic Procedure 8	Diagnostic Procedure 9	Diagnostic Procedure 10	Diagnostic Procedure 11	Diagnostic Procedure 12	Diagnostic Procedure 13	Diagnostic Procedure 14	Diagnostic Procedure 15	15A Fuses	7.5A Fuse	Push control unit	Auto amp.
SYMPTOM																						
A/C does not blow cold air.		○		○									○						○	○	○	○
Blower motor does not rotate at all. (Fan switch [AUTO] [1] [2] [3])		①		②															○	○	○	○
Blower motor does not rotate at all when the fan speed is in AUTO. (It operates in 1, 2, or 3-speed.)					①														○	○	○	○
Blower motor fan speed does not change when fan speed is in AUTO. (Fan speed is fixed in Hi or MH.)						①													○	○	○	○
Blower motor fan speed does not change when fan speed is in AUTO. (Fan speed is fixed in LO.)							①												○	○	○	○
Starting fan speed control does not operate.								①												○	○	○
There is too much difference between setting temp. on P.T.C. and in-vehicle temp.		①							②											○	○	○
Air mix door motor does not operate normally.		①								②										○	○	○
Air outlet does not change.											②									○	○	○
Intake door does not change in VENT, B/L or FOOT mode.	①											①								○	○	○
Magnetic clutch does not engage when A/C switch and fan switch are ON.													①							○	○	○
Ambient sensor circuit is open or shorted.														①						○	○	○
In-vehicle sensor circuit is open or shorted.															①					○	○	○
Sunload sensor circuit is open or shorted.																①				○	○	○
Thermal transmitter circuit is open or shorted.																	①			○	○	○
Illumination or indicators of push control unit do not come on.																		○		○	○	○
Noise			①																	○	○	○

①, ②: The number means checking order.

○: As for the order of inspection, refer to each flow chart. (It depends on malfunctioning portion.)

TROUBLE DIAGNOSES Symptom Chart (Cont'd)

AUTO

Electrical Components Inspection

Blower motor																					—	
Fan resistor																						—
AC switch	<input type="radio"/>																					—
REC switch		<input type="radio"/>																				—
VENT switch			<input type="radio"/>																			—
B/L switch				<input type="radio"/>																		—
FOOT switch					<input type="radio"/>																	—
F/D switch						<input type="radio"/>																—
DEF switch							<input type="radio"/>															—
Fan switch								<input type="radio"/>														—
PTC									<input type="radio"/>													—
	<input type="radio"/>																					HA-1066
Air mix door motor						<input type="radio"/>																HA-1077
PBR							<input type="radio"/>															HA-1078
Mode door motor								<input type="radio"/>														HA-1061
Intake door motor									<input type="radio"/>													HA-1061
Auto amp.										<input type="radio"/>												HA-1070
Ambient sensor							<input type="radio"/>															HA-1068
In-vehicle sensor								<input type="radio"/>														HA-1067
Sunload sensor										<input type="radio"/>												HA-1069
Thermal transmitter											<input type="radio"/>											Refer to EL section.
AC relay												<input type="radio"/>										HA-1058
AC switch relay													<input type="radio"/>									HA-1070
LO relay														<input type="radio"/>								HA-1058
ML relay															<input type="radio"/>							HA-1058
MH relay																<input type="radio"/>						HA-1058
HI relay																	<input type="radio"/>					HA-1058
Thermo control amp.																						HA-1058
Triple-pressure switch																						HA-1058
Magnet clutch																						HA-1067
Thermal protector																						Com- pressor
ECM																						HA-1090
Illumination system																						Refer to EC section.
AC mode switch																						Refer to EL section.
Aspirator motor																						HA-1070
Harness																						HA-1068
																						—

Checking Resistor

Checking resistors are used for trouble diagnoses of blower motor operation and air mix door motor operation. Use checking resistor when inspecting portions with $\boxed{C/R}^*1$, $\boxed{C/R}^*2$ in flow chart.

CAUTION:

Select checking resistors which have resistance values corresponding with those indicated in table below, and connect to respective sensors.


	Checking resistor	Ambient sensor	In-vehicle sensor	Wattage
Blower motor operation check	$\boxed{C/R}^*1$	1,000 Ω	1,500 Ω	1/4W
Air mix door motor operation check	$\boxed{C/R}^*2$		2,490 Ω	

1. Disconnect ambient sensor and in-vehicle sensor harness connectors.
2. Connect checking resistors to ambient sensor harness connector and in-vehicle sensor harness connector when inspecting portions with $\boxed{C/R}^*1$, $\boxed{C/R}^*2$ in flow chart in trouble diagnoses.
3. Turn ignition switch ON.
4. Turn A/C switch ON.
5. Turn VENT switch ON.
6. Keep sunload sensor away from sunlight by covering it.

Preliminary Check

PRELIMINARY CHECK 1


Intake door is not set at "FRESH".



Preliminary Check (Cont'd)

PRELIMINARY CHECK 2


A/C does not blow cold air.















Preliminary Check (Cont'd)

PRELIMINARY CHECK 3


Noise




Component Location



Circuit Diagram — Auto Air Conditioner/LHD Models




Circuit Diagram — Push Control Unit/LHD Models






Wiring Diagram — A/C, A —/LHD Models

HA-A/C, A-01







Wiring Diagram — A/C, A —/LHD Models
(Cont'd)

HA-A/C, A-02



Wiring Diagram — A/C, A —/LHD Models
(Cont'd)

HA-A/C, A-03



Refer to last page (Foldout page).


(M5), (E101)

TROUBLE DIAGNOSES

AUTO

Wiring Diagram — A/C, A —/LHD Models (Cont'd)

HA-A/C, A-04




Preceding page



Refer to last page (Foldout page).



M5, E101




TROUBLE DIAGNOSES

AUTO

Wiring Diagram — A/C, A —/LHD Models (Cont'd)

HA-A/C, A-05



13	12	16	8	○	6	4	2	(M406)
14	11	9	15	17	7	5	3	W

○	(M409)			
2	4	3	1	W

□	(M412)	
1	2	L






○	(M414)								
7	8	6	5	4	3	2	1	17	BR

TROUBLE DIAGNOSES

AUTO

Wiring Diagram — A/C, A —/LHD Models (Cont'd)

HA-A/C, A-06




Refer to last page (Foldout page).

(M5), (E101)

Main Power Supply and Ground Circuit Check

POWER SUPPLY CIRCUIT CHECK FOR AUTO A/C SYSTEM

Check power supply circuit for auto air conditioning system. Refer to "POWER SUPPLY ROUTING" in EL section and Wiring Diagram.




PUSH CONTROL UNIT CHECK

Check power supply circuit for push control unit with ignition switch at ACC.

1. Disconnect push control unit harness connector.
2. Connect voltmeter from harness side.
3. Measure voltage across terminal No. ⑭ and body ground.


Voltmeter terminal		Voltage
⊕	⊖	
⑭	Body ground	Approx. 12V



Check body ground circuit for push control unit with ignition switch ON.

1. Disconnect push control unit harness connector.
2. Connect ohmmeter from harness side.
3. Check for continuity between terminal No. ⑰ and body ground.

Ohmmeter terminal		Continuity
⊕	⊖	
⑰	Body ground	Yes




AUTO AMP. CHECK

Check power supply circuit for auto amp. with ignition switch ON.

1. Disconnect auto amp. harness connector.
2. Connect voltmeter from harness side.
3. Measure voltage across terminal No. ① and body ground.





Voltmeter terminal		Voltage
⊕	⊖	
①	Body ground	Approx. 12V



Check body ground circuit for auto amp. with ignition switch OFF.

1. Disconnect auto amp. harness connector.
2. Connect ohmmeter from harness side.
3. Check for continuity between terminal No. ⑰ and body ground.


Ohmmeter terminal		Continuity
⊕	⊖	
⑰	Body ground	Yes



Diagnostic Procedure 1


SYMPTOM: Blower motor does not rotate at all. (Fan switch "AUTO", "1", "2", "3")

- Perform PRELIMINARY CHECK 2 before referring to the following flow chart.



Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 1 (Cont'd)



```






    graph TD
        A((A)) --> B[CHECK RESISTOR AFTER DISCONNECTING IT.]
        B -- NG --> C[Replace resistor.]
        B -- OK --> D[CHECK FAN SWITCH AFTER DISCONNECTING IT. (Refer to Electrical Components Inspection.) (HA-1057)]
        D -- NG --> E[Replace fan switch.]
        D -- OK --> F[Check circuit continuity between fan switch harness terminal No. 26 and body ground.]
        F -- OK --> G[Replace blower motor.]
    
```

E Note

Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 2

SYMPTOM: Blower motor does not rotate at all when the fan speed is in AUTO. (It operates in 1, 2, or 3-speed only.)



A

CHECK POWER SUPPLY FOR A/C (LO) RELAY.
Disconnect LO relay harness connector. Do approx. 12 volts exist between LO relay harness terminal No. ① and body ground?

NG → Check 7.5A fuse (No. 21) at fuse block. (Refer to "POWER SUPPLY ROUTING" in EL section and Wiring Diagram.)

OK ↓

B

Check circuit continuity between LO relay harness terminal No. ② and body ground.

NG → **CHECK FAN SWITCH AFTER DISCONNECTING IT.** (Refer to Electrical Components Inspection.) (HA-1057)

OK ↓

NG → Replace fan switch.

E Note

Check circuit continuity between LO relay harness terminal No. ② and fan switch harness terminal No. 24.

C

CHECK POWER SUPPLY FOR LO RELAY.
Do approx. 12 volts exist between LO relay harness terminal No. ③ and body ground?

NG → **D** Note





Check circuit continuity between resistor harness terminal No. ④ and LO relay harness terminal No. ③.

OK ↓

(Go to next page.)


Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 2 (Cont'd)



Diagnostic Procedure 3





SYMPTOM: Blower motor fan speed does not change when fan speed is in AUTO. (Fan speed is fixed in HI or MH.)



A
(Go to next page.)

Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.






Diagnostic Procedure 3 (Cont'd)






Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 4

SYMPTOM: Blower motor fan speed does not change when fan speed is in AUTO. (Fan speed is fixed in LO.)




Diagnostic Procedure 4 (Cont'd)




Diagnostic Procedure 5

SYMPTOM: Starting fan speed control does not operate.




Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.






Diagnostic Procedure 6

SYMPTOM: There is too much difference between setting temp. on PTC and in-vehicle temperature.






- Perform PRELIMINARY CHECK 2 before referring to the following flow chart.



Diagnostic Procedure 6 (Cont'd)



Diagnostic Procedure 6 (Cont'd)



D

CHECK COIL SIDE CIRCUIT OF A/C SWITCH RELAY.
Does continuity exist between A/C switch relay harness terminal No. ② and body ground?

NG → **F** Note
Check circuit continuity between A/C switch relay harness terminal No. ② and push control unit harness terminal No. ⑬.

OK

CHECK A/C SWITCH RELAY AFTER DISCONNECTING IT.

OK → **E** Note
Check circuit continuity between A/C switch relay harness terminal No. ⑤ and auto amp. harness terminal No. ⑨.

NG → Replace A/C switch relay.

C

G

CHECK POWER SUPPLY FOR ASPIRATOR MOTOR.
Disconnect aspirator motor harness connector.
Do approx. 12 volts exist between aspirator motor harness terminal No. ① and body ground?

NG → Check 7.5A fuse (No. ⑳) at fuse block. (Refer to "POWER SUPPLY ROUTING" in EL section and Wiring Diagram.)

OK

H Note




CHECK BODY GROUND CIRCUIT FOR ASPIRATOR MOTOR.
Does continuity exist between aspirator motor harness terminal No. ② and body ground?

OK → Replace aspirator motor.

Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 7

SYMPTOM: Air mix door motor does not operate normally.
 ● Perform PRELIMINARY CHECK 2 before referring to the following flow chart.



CHECK AUTO AMP. AND PTC.
 Connect checking resistor.
 (Refer to page HA-1018.)
 Does air outlet temperature change when you move PTC from 20°C (68°F) to 30°C (86°F)?

CHECK SENSOR CIRCUIT.

	How to repair
Ambient sensor circuit	Go to Diagnostic Procedure 11.
In-vehicle sensor circuit	Go to Diagnostic Procedure 12.

CHECK PTC.
 (Refer to HA-1066.)

C

CHECK FOR OUTPUT OF AUTO AMP.
 Connect checking resistor.
 Do approx. 10.5 volts exist between air mix door motor harness terminals No. ② and ① when you move PTC from 20°C (68°F) to 30°C (86°F) or when you move PTC from 30°C (86°F) to 20°C (68°F)?

Air mix door operation	Terminal No.		Voltage
	②	①	
Cold → Hot	⊕	⊖	Approx. 10.5V
Hot → Cold	⊖	⊕	
Stop	—	—	0V

Replace air mix door motor.

A Note

CHECK PTC CIRCUIT BETWEEN PTC AND AUTO AMP.
 Disconnect PTC and auto amp. harness connectors. Check circuit continuity between PTC harness terminal No. ⑰ and auto amp. harness terminal No. ④.

B Note

Check circuit continuity between PTC harness terminal No. ③ and auto amp. harness terminal No. ⑤.

Replace PTC.

Disconnect auto amp. and air mix door motor harness connectors.

Note

Check circuit continuity between auto amp. harness terminal No. ⑫ (⑬) and air mix door motor harness terminal No. ② (①).




Replace auto amp.

Note:
 If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 8

SYMPTOM: Air outlet does not change.

- Main Power Supply and Ground Circuit Check before referring to the following flow chart.



A

CHECK MODE DOOR MOTOR POSITION SWITCH.

1. Turn VENT switch ON with ignition switch at ON position.
2. Turn ignition switch OFF. Disconnect push control unit connector.
3. Check if continuity exists between each terminal on push control unit harness connector and body ground.
4. Using above procedures, check for continuity in any other mode, as indicated in chart.

Mode switch	Terminal No.		Continuity
	⊕	⊖	
VENT	① or ②	Body ground	Yes
B/L	② or ③		
FOOT	③ or ④		
F/D	④ or ⑤		
DEF	⑤ or ⑥		

NG

Disconnect mode door motor harness connector.

B Note

CHECK BODY GROUND CIRCUIT FOR MODE DOOR MOTOR.

Does continuity exist between mode door motor harness terminal No. ⑰ and body ground?

OK

C Note

Check circuit continuity between each terminal on push control unit and on mode door motor.

Terminal No.		Continuity
⊕	⊖	
Push control unit	Mode door motor	Yes
①	①	
②	②	
③	③	
④	④	
⑤	⑤	
⑥	⑥	
⑦	⑦	
⑧	⑧	

OK


CHECK SIDE LINK.

OK

Ⓐ (Go to next page.)

Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 8 (Cont'd)






(A)
Reconnect push control unit and mode door motor harness connectors.

D
CHECK FOR OUTPUT OF PUSH CONTROL UNIT.
Do approx. 12 volts exist between push control unit harness terminal No. ⑦ and ⑧ when mode is switched from "VENT" to "DEF" or when mode is switched from "DEF" to "VENT"?

NG → Replace control amp. built-in push control unit.

Terminal No.		Mode door motor	
⑦	⑧	Mode door operation	Direction of linkage rotation
—	—	Stop	Stop
⊖	⊕	VENT → DEF	Clockwise
⊕	⊖	DEF → VENT	Counter-clockwise


OK
Replace mode door motor.



Diagnostic Procedure 9

SYMPTOM: Intake door does not change.






- Perform **PRELIMINARY CHECK 1** and **Main Power Supply and Ground Circuit Check** before referring to the following flow chart.



Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 10

SYMPTOM: Magnet clutch does not engage when A/C switch and fan switch are ON.



A

CHECK POWER SUPPLY FOR COMPRESSOR.
Disconnect compressor harness connector.
Do approx. 12 volts exist between compressor harness terminal No. ① and body ground?

Yes → Check the following.
● Magnet clutch coil
● Thermal protector
↓ NG
Replace magnet clutch. Refer to HA-1087.

No →

B Note

Check circuit continuity between A/C relay harness terminal No. ⑤ and compressor harness terminal No. ①.
Continuity should exist.
If OK, check harness for short.

OK →

C

CHECK POWER SUPPLY FOR A/C RELAY.
Do approx. 12 volts exist between A/C relay harness terminal No. ③ and body ground?

No → Check power supply circuit and 7.5A fuse (No. ⑳), located in the fuse block. (Refer to "POWER SUPPLY ROUTING" in EL section and Wiring Diagram.)

Yes →

D

CHECK POWER SUPPLY FOR A/C RELAY.
Do approx. 12 volts exist between A/C relay harness terminal No. ① and body ground?

Yes → Check power supply circuit and 7.5A fuse (No. ⑳), located in the fuse block. (Refer to "POWER SUPPLY ROUTING" in EL section and Wiring Diagram.)

No →

E NG

Replace A/C relay.

OK → Reconnect A/C relay.

E Note




Check circuit continuity between A/C relay harness terminal No. ② and thermo switch harness terminal No. ②.
Continuity should exist.
If OK, check harness for short.

OK →

(Go to next page.)

Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 10 (Cont'd)



F Note

Check circuit continuity between thermo switch harness terminal No. ① and triple-pressure switch harness terminal No. ④.

Continuity should exist.
If OK, check harness for short.

OK

CHECK THERMO SWITCH.
Refer to HA-1059.

OK

CHECK TRIPLE-PRESSURE SWITCH.
Refer to HA-1058.

NG

Check refrigerant charge amount.

OK

G Note

Check circuit continuity between triple-pressure switch harness terminal No. ① and thermo control amp. harness terminal No. ③.

Continuity should exist.
If OK, check harness for short.

OK

Replace triple-pressure switch.

OK

CHECK POWER SUPPLY FOR THERMO CONTROL AMP.
(Refer to Main Power Supply and Ground Circuit Check.) (HA-1031)

H

CHECK BODY GROUND CIRCUIT FOR THERMO CONTROL AMP.
Disconnect thermo control amp. harness connector.
Does continuity exist between thermo control amp. harness terminal No. ② and body ground?

OK

Replace fan switch.

NG




Disconnect push control unit harness connector.

B

(Go to next page.)

Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 10 (Cont'd)



(B)

I Note

Check circuit continuity between thermo control amp. harness terminal No. (2) and push control unit harness terminal No. (13).

OK

CHECK A/C SWITCH OF PUSH CONTROL UNIT. (Refer to Electrical Components Inspection.) (HA-1057)

NG → Replace control amp. built into push control unit.

OK

Disconnect fan switch harness connector.

J Note

Check circuit continuity between push control unit harness terminal No. (12) and fan switch harness terminal No. (25).

OK

K Note

Check circuit continuity between fan switch harness terminal No. (26) and body ground.





OK

CHECK FAN SWITCH. (Refer to Electrical Components Inspection.) (HA-1057)




Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 11

SYMPTOM: Ambient sensor circuit is open or shorted.




Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.






Diagnostic Procedure 12

SYMPTOM: In-vehicle sensor circuit is open or shorted.




Note:

If the result is NG or No after checking circuit continuity, repair harness or connector.






Diagnostic Procedure 13

SYMPTOM: Sunload sensor circuit is open or shorted.




Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.





Diagnostic Procedure 14

SYMPTOM: Thermal transmitter circuit is open or shorted.



Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 14 (Cont'd)



A

CHECK A/C MODE SWITCH.
(Refer to HA-1070.)

OK

NG

Replace A/C mode switch.

D Note

Check circuit continuity between thermal transmitter harness terminal No. ① and A/C mode switch harness terminal No. ③ and between A/C mode switch harness terminal No. ③ and body ground.


B Note

Check circuit continuity between auto amp. harness terminal No. ⑩ and A/C mode switch harness terminal No. ① and between auto amp. harness terminal No. ⑩ and body ground.

OK

Replace auto amp.

Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.



Diagnostic Procedure 15

SYMPTOM: Illumination or indicators of push control unit do not come on.

- Perform Main Power Supply and Ground Circuit Check before referring to the following flow chart.

Turn ignition switch and lighting switch ON.





CHECK ILLUMINATION AND INDICATORS.

- Turn A/C, REC and fan switches ON.
- Push VENT, B/L, FOOT, F/D and DEF switches in order.
- Check for incidents and follow the repairing methods as shown:

INCIDENTS								"How to repair"	
ILL. Push control unit	VENT	B/L	FOOT	F/D	DEF	REC	A/C		
×	○	○	○	○	○	○		Go to DIAGNOSTIC PROCEDURE 15-1.	
	○	○	○	○	○	○	×	Go to DIAGNOSTIC PROCEDURE 15-2.	
○	×	×	×	×	×	×		Go to DIAGNOSTIC PROCEDURE 15-3.	
	△								Replace control amp. built into push control unit.
○	×	×	×	×	×	×	○	Replace push control amp. built into push control unit.	
	×	×	×	×	×	×	○	Go to DIAGNOSTIC PROCEDURE 15-4.	

○: Illumination or indicator comes on.
 ×: Illumination or indicator does not come on.
 △: Some indicators for VENT, B/L, FOOT, F/D, DEF or REC come on.




Diagnostic Procedure 15 (Cont'd)
DIAGNOSTIC PROCEDURE 15-1




Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.

Diagnostic Procedure 15 (Cont'd)


DIAGNOSTIC PROCEDURE 15-2



DIAGNOSTIC PROCEDURE 15-3



Note:
If the result is NG or No after checking circuit continuity, repair harness or connector.



DIAGNOSTIC PROCEDURE 15-4

Turn ignition switch and lighting switch OFF.

Disconnect push control unit harness connector.


A Note
CHECK BODY GROUND CIRCUIT FOR PUSH CONTROL UNIT.
 Does continuity exist between push control unit harness terminal No. ⑰ and body ground?

↓ OK

Replace control amp. built-in push control unit.

Note:

If the result is NG or No after checking circuit continuity, repair harness or connector.




Electrical Components Inspection

FAN SWITCH

Check continuity between terminals at each switch position.

TERMINAL	LEVER POSITION				
	OFF	AUTO	1	2	3
⑳					○
㉑				○	○
㉒			○	○	○
㉓		○	○	○	○
㉔		○	○	○	○
㉕		○	○	○	○




A/C SWITCH

Check continuity between terminals at each switch position.

Switch condition	Terminal No.		Continuity
	⊕	⊖	
A/C			Yes
ON	⑬	⑫	
OFF			

**Electrical Components Inspection (Cont'd)
A/C RELAY, HI, MH, ML, and LO RELAYS**


Check continuity between terminal Nos. ③ and ⑤.



Conditions	Continuity
12V direct current supply between terminal Nos. ① and ②	Yes
No current supply	No


If NG, replace relay.

TRIPLE-PRESSURE SWITCH



	Terminals	High-pressure side line pressure kPa (bar, kg/cm ² , psi)	Operation	Continuity
Low-pressure side	① - ④	Increasing to 152.0 - 201.0 (1.520 - 2.010, 1.55 - 2.05, 22.0 - 29.2)	ON	Exists.
		Decreasing to 152.0 - 201.0 (1.520 - 2.010, 1.55 - 2.05, 22.0 - 29.2)	OFF	Does not exist.
Medium-pressure side*	② - ③	Increasing to 1,422 - 1,618 (14.22 - 16.18, 14.5 - 16.5, 206 - 235)	ON	Exists.
		Decreasing to 1,128 - 1,422 (11.28 - 14.22, 11.5 - 14.5, 164 - 206)	OFF	Does not exist.
High-pressure side	① - ④	Decreasing to 2,059 - 2,256 (20.6 - 22.6, 21 - 23, 299 - 327)	ON	Exists.
		Increasing to 2,648 - 2,844 (26.5 - 28.4, 27 - 29, 384 - 412)	OFF	Does not exist.


* For cooling fan motor operation



THERMO CONTROL AMP.


Evaporator outlet air temperature °C (°F)	Thermo amp. operation	Tester
Decreasing to 0.1 - 0.9 (32 - 34)	Turn OFF	Approx. 12V
Increasing to 2.5 - 3.5 (37 - 38)	Turn ON	Approx. 0V

**Electrical Components Inspection (Cont'd)
THERMO SWITCH**



Water temperature °C (°F)	Terminal No.		Continuity
	⊕	⊖	
Over 105 (221)			No
Less than 100 (212)	①	②	Yes

Push Control System



SHA163F

This push control system operates the intake and mode door motors to activate their corresponding doors.

SWITCHES AND THEIR CONTROL FUNCTIONS

Switch	Indicator illuminates							Air outlet	Intake air	Compressor
	A/C									
A/C	○									ON*1
Mode			○					VENT		
				○				B/L		
					○			FOOT		
						○		F/D	FRE	
							○	DEF	FRE	
								REC		



*1: Compressor is operated by thermo control amp.

Push Control System (Cont'd)

MODE DOOR MOTOR

The mode door motor is located on the left side of the heater unit. Through the side link it opens and closes the vent, foot and defroster doors.



When one mode switch is pushed, the position switch built into it reads the corresponding mode to determine the direction of motor rotation. As soon as the desired mode is set, the position switch stops the motor.




Terminal No.		Mode door motor	
⑦	⑧	Mode door operation	Direction of linkage rotation
—	—	Stop	Stop
⊖	⊕	VENT → DEF	Clockwise
⊕	⊖	DEF → VENT	Counterclockwise

INTAKE DOOR MOTOR


The intake door motor is installed on the intake unit. When the door position is determined by pushing the "REC" switch on the control panel, the motor rotates and the air inlet is changed.





Removal and Installation


1. Remove cluster lid C.



- 2. Remove audio (radio).
- 3. Remove seven screws of push control unit and BRKT.
- 4. Disconnect push control unit, in-vehicle sensor and PTC harness connectors.
- 5. Remove push control unit.
- 6. Installation is in the reverse order of removal.

Overhaul — Push control unit assembly

SEC. 272




RHA035H


Overhaul — Push control unit assembly (Cont'd)

1. Remove control knobs.

Wrap knobs with a cloth and pull in direction indicated by arrow as shown in figure at left. Be careful not to scratch knobs during removal.




2. Remove PTC and disconnect illumination harness connectors.




3. Remove control base.

Undo hook at each end of control box and remove control base from control box by moving it in direction indicated by arrow.




4. Remove fan switch.



5. Remove illumination bulb.

Wrap finisher with a cloth and remove knobs using pliers or similar tool. Be careful not to scratch finisher's surface.

Overhaul — Push control unit assembly (Cont'd)



6. Remove control knobs.
7. Remove control case.

8. Remove illumination plate.

Be careful not to scratch control amp. when removing illumination plate.


9. Remove finisher plate.
10. Remove control amp.

Be careful not to damage substrate when removing.

11. Disconnect temperature control cable.
12. Installation is in reverse order of removal.

Control Linkage Adjustment

MODE DOOR




1. Remove auto amplifier and relay bracket.
2. Move side link by hand and hold mode door in VENT mode.
3. Install mode door motor on heater unit and connect it to the auto A/C harness.
4. Turn ignition switch to ON.
5. Turn VENT switch ON.
6. Attach mode door motor rod to side link rod holder.
7. Turn DEF switch ON. Check that side link operates at the fully-open position. Also turn VENT switch ON to check that side link operates at the fully-open position.

Control Linkage Adjustment (Cont'd)


AIR MIX DOOR

1. Install air mix door motor on heater unit and connect it to the auto A/C harness.
2. Disconnect ambient sensor harness connector and connect terminals No. ⑤ and ⑤⑤ with a jumper cable.
3. Set PTC at 18°C (65°F) and air mix door motor at "full cold".
4. Move air mix door lever by hand and hold it at the full-cold position.
5. Attach air mix door lever to rod holder.
6. Check that air mix door operates properly when PTC is moved from 18 to 32°C (65 to 85°F).





INTAKE DOOR

1. Connect intake door motor harness connector before installing to intake door motor.
2. Turn ignition switch to ON.
3. Turn REC switch OFF.
4. Set intake door lever in FRE and install intake door motor on intake unit.
5. Check that intake door operates properly when REC switch is turned ON and OFF.



Overview of Control System

The control system consists of a) input sensors and switches, b) the automatic amplifier (microcomputer), and c) outputs. The relationship of these components is shown in the diagram below.



Control System Input Components



POTENTIO TEMPERATURE CONTROL (PTC)

The PTC is built into the control unit. It has a variable resistance which changes according to the set temperature. This resistance is connected to the temperature lever.

Control System Input Components (Cont'd)


PTC

After disconnecting PTC harness connector, measure resistance between terminals ③ and ⑰ at PTC harness side.



IN-VEHICLE SENSOR



The in-vehicle sensor is attached to the right side of the control unit. It converts variations in the temperature of the compartment air drawn in by the aspirator into a resistance value, which is then input into the auto amplifier.



Control System Input Components (Cont'd)


After disconnecting in-vehicle sensor harness connector, measure resistance between terminals ① and ② at sensor harness side, using the table below.

Temperature °C (°F)	Resistance kΩ
0 (32)	6.0
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (95)	1.51
40 (104)	1.27




ASPIRATOR MOTOR

The aspirator motor is located in front of the heater unit. The aspirator motor continuously draws compartment air into the in-vehicle sensor while the ignition switch is ON.



Check that smoke is properly sucked into in-vehicle sensor when a lighted cigarette is moved close to the sensor.




AMBIENT SENSOR

The ambient sensor is located on the hood lock stay. It detects the ambient temperature and converts it into a resistance value, which is then input into the auto amplifier.

Control System Input Components (Cont'd)


After disconnecting ambient sensor harness connector, measure resistance between terminals ① and ② at sensor harness side, using the table below.

Temperature °C (°F)	Resistance kΩ
-20 (-4)	9.98
-10 (14)	5.57
0 (32)	3.26
10 (50)	1.98
20 (68)	1.25
25 (77)	1.00
30 (86)	0.81
40 (104)	0.54



SUNLOAD SENSOR


The sunload sensor is located on the center defroster grille. It detects sunload entering through the windshield by means of a photo diode and converts it into a current value which is then input to the auto amplifier.



Measure voltage between terminals ⑤ and ⑥ at auto air conditioner harness side, using the table below.

Input current mA	Output voltage V
0	5.00
0.1	4.09
0.2	3.18
0.3	2.27
0.4	1.36
0.5	0.45

- When checking sunload sensor, select a place where sun shines directly on it.




Control System Input Components (Cont'd)

A/C MODE SWITCH


The A/C mode switch is installed around the side link of the heater unit and operates the link in response to the position of the mode switch.

The operation of this A/C mode switch is as shown below:




A/C mode switch operation

MODE	VENT	B/L	FOOT	FOOT/DEF	DEF
Terminal No.	①	○	○	○	○
	②	○	○	○	○
	③		○	○	○



A/C SWITCH RELAY


The A/C switch relay is located on the left side of the engine room. When the A/C switch and fan switch are ON, the A/C switch relay operates and transmits A/C operation signals to the auto amplifier.



Control System Auto Amplifier (Auto amp.)

The auto amplifier has a built-in microcomputer which processes the information sent from the various sensors needed for air conditioner operation. The air mix door motor and blower motor are then controlled.

Signals from the various switches and the Potentio Temperature Control (PTC) are directly entered into the auto amplifier.



**Control System Auto Amplifier (Auto amp.)
(Cont'd)****SUNLOAD INPUT PROCESS**



The auto amp. also includes a processing circuit which “averages” the variations in detected sunload over a period of time. This prevents drastic swings in the ATC system operation due to small of quick variations in detected sunload.

For example, consider driving along a road bordered by an occasional group of large trees. The sunload detected by the sunload sensor will vary whenever the trees obstruct the sunlight. The processing circuit averages the detected sunload over a period of time, so that the (insignificant) effect of the trees momentarily obstructing the sunlight does not cause any change in the ATC system operation. On the other hand, shortly after entering a long tunnel, the system will recognize the change in sunload, and the system will react accordingly.

**Control System Auto Amplifier (Auto amp.)
(Cont'd)**

SUNLOAD COMPENSATION

The auto amplifier compensates for sunload by altering the air mix door position and air flow volume according to the amount of sunload detected by the sunload sensor. When the amount of sunload is great, the air mix door is moved toward the "COLD" side. Along with this air mix door movement, air flow volume will also be changed.




Control System Auto Amplifier (Auto amp.)
(Cont'd)


A/C SWITCH COMPENSATION

The auto amplifier alters the air mix door position and air flow volume according to a signal emitted from the A/C switch.

When the A/C switch is "ON", the auto amplifier compensates for the PBR's input signal and moves the air mix door toward the "HOT" side.



SHA494CB



SHA495CB

Control System Output Components

AIR MIX DOOR CONTROL (Automatic temperature control)


Component parts

Air mix door control system components are:

- 1) Auto amplifier
- 2) Ambient sensor
- 3) In-vehicle sensor
- 4) Sunload sensor
- 5) Air mix door motor (PBR)
- 6) A/C switch

System operation



The air mix door is automatically controlled so that in-vehicle temperature is maintained to the set temperature. The temperature set by the PTC (Potentio Temperature Control) and the temperature detected by the in-vehicle sensor and ambient sensor are compensated by the sunload sensor signal. The auto amplifier then determines the air mix door position. The air mix door position detected by the PBR is compensated by the ON-OFF operation of the A/C switch. The air mix door position determined by the auto amplifier is compared with that detected by the PBR. The auto amplifier then transmits the signal to the air mix door motor in order to activate it.



SHA566CB

Control System Output Components (Cont'd)

Air mix door control specifications




SENSOR INPUT PROCESS

The auto amplifier detects the voltage produced by each sensor, the PBR and fixed resistor. The fixed resistor is built into the auto amplifier. 12-volt power voltage is first converted to approximately 5 volts by the constant voltage circuit where it is then applied to the ground line of the auto amplifier via the fixed resistor and the sensor. In this manner, the auto amplifier monitors the voltages of the fixed resistor, each sensor and the PBR to determine sensor input.


Control System Output Components (Cont'd)

OPERATION OF AIR MIX DOOR MOTOR

- Example ①
 When the temperature in the vehicle is lower than the set temperature.
 When the temperature in the vehicle is low, in-vehicle sensor resistance is great and the input voltage to the auto amplifier becomes great. As a result, the voltage from the air mix door position arithmetic circuit also becomes great.
 When this voltage is greater than the voltage from the PBR, comparator (1), Tr ① and Tr ④ turn ON.
 Accordingly terminal No. ⑫ becomes ⊕ and terminal No. ⑬ becomes ⊖. The air mix door motor rotates clockwise and the air mix door moves toward the "HOT" side.




As the air mix door moves toward the "HOT" side, the voltage from the PBR becomes greater and consequently becomes equal to that from the air mix door position arithmetic circuit. As a result, comparator (1) turns OFF and the air mix door motor stops.




Control System Output Components (Cont'd)

- Example ②
 When the temperature in the vehicle is higher than the set temperature.
 When the temperature in the vehicle is high, in-vehicle sensor resistance is small and the input voltage to the auto amplifier becomes small. As a result, the voltage from the air mix door position arithmetic circuit also becomes small. When this voltage is smaller than the voltage from the PBR, comparator (2), Tr ② and Tr ③ turn ON. Accordingly terminal No. ⑬ becomes ⊕ and terminal No. ⑫ becomes ⊖. The air mix door motor rotates counterclockwise and the air mix door moves toward the "COLD" side.




As the air mix door moves toward the "COLD" side, the voltage from the PBR becomes smaller and consequently becomes equal to that from the air mix door position arithmetic circuit. As a result, comparator (2) turns OFF and the air mix door motor stops.




AIR MIX DOOR MOTOR



The air mix door motor is attached to the heater unit. It rotates so that the air mix door is opened to a position set by the auto amplifier. Motor rotation is conveyed through a shaft. The air mix door position is then fed back to the auto amplifier by the PBR built into the air mix door motor.



Control System Output Components (Cont'd)




2	1	Air mix door operation	Direction of lever movement
⊕	⊖	COLD → HOT	Clockwise (Toward passenger compartment)
—	—	STOP	STOP
⊖	⊕	HOT → COLD	Counterclockwise (Toward engine compartment)



PBR

Measure voltage between terminals ③ and ④ at vehicle harness side.



Ignition switch: ON

- Ensure tester pointer deflects smoothly when PTC is moved from 20°C (65°F) to 30°C (85°F) and vice versa.

Control System Output Components (Cont'd)

FAN SPEED CONTROL

Component parts


Fan speed control system components are:

- 1) Auto amplifier
- 2) In-vehicle sensor
- 3) Ambient sensor
- 4) Sunload sensor
- 5) A/C switch relay
- 6) A/C switch
- 7) Fan switch
- 8) Blower motor
- 9) Resistance
- 10) HI, MH, ML and LO relays



System operation

Blower fan speed is automatically controlled so that the in-vehicle temperature is maintained to the set temperature.

The temperature set by the PTC (Potentio Temperature Control) and the temperature detected by the in-vehicle sensor and ambient sensor are compensated by the sunload sensor signal. The auto amplifier then determines fan speed from the ON-OFF operation of the A/C switch. The fan speed decision by the auto amplifier activates the fan relay and the blower fan motor rotates. When the A/C switch is ON, fan speed is activated in 4 steps, HI, MH, ML, and LO. When the A/C switch is OFF, fan speed is activated in 3 steps, MH, ML, and LO.



Control System Output Components (Cont'd)




Signals from each sensor, PTC, A/C switch etc. are sent to the air flow volume arithmetic circuit in the auto amplifier. Air flow volume is determined by this circuit.

- (1) When the air flow volume is set to ML
 The air flow volume arithmetic circuit gives current to Tr ③, which turns the ML relay on. Thus, the blower motor rotates in the ML condition.

Control System Output Components (Cont'd)


(2) When set to HI

The air flow volume arithmetic circuit gives current to Tr ①, which turns the HI relay on. Thus, the blower motor rotates in the HI condition. Also, Tr ② and Tr ③ are receiving current and as a result the ML and MH relays are on.



(3) When set to LO

The air flow volume arithmetic circuit does not give any current to Tr ①, ② nor ③. Only the LO relay turns on and so the blower motor rotates in the LO condition.




Control System Output Components (Cont'd)

STARTING FAN SPEED CONTROL


The starting fan control system is so designed to prevent excess cold air from being expelled after the engine is started when the engine coolant temperature is low.

The component parts related to this system are the water temperature sensor microswitch, HI, MH, ML and LO relays, blower motor, resistance and auto amplifier.

When the fan switch is set to AUTO, the microswitch to ON (either B/L, FOOT or FOOT/DEF) and the engine coolant temperature is below 50°C (122°F), the speed of the blower motor is fixed in the LO position.




SHA188DA




LO, ML, MH AND HI RELAYS

The LO and ML relays are located on the auto amplifier bracket, and the MH and HI relays are installed on the back side of the audio unit. Each fan relay operates according to the air flow volume determined by the auto amplifier. The blower motor then operates accordingly.



Control System Output Components (Cont'd)




SHA578CA

Refrigerant Lines

● Refer to "Precautions for Refrigerant Connection".

RHD MODELS





- : Refrigerant leak checking order
- : (Tightening torque)
- □ : (Wrench size)
- : (O-ring size)
- ⊙ : N·m (kg-m, ft-lb)
- A** : 20 - 29 (2.0 - 3.0, 14 - 22)
- C** : 14 - 18 (1.4 - 1.8, 10 - 13)
- ⊙ : N·m (kg-m, in-lb)
- D** : 10 - 20 (1.0 - 2.0, 87 - 174)
- E** : 8 - 11 (0.8 - 1.1, 69 - 95)

Refrigerant Lines (Cont'd)


● Refer to "Precautions for Refrigerant Connection".

LHD MODELS





- : Refrigerant leak checking order
- : (Tightening torque)
- □ : (Wrench size)
- : (O-ring size)
- Ⓜ : N·m (kg-m, ft-lb)
- Ⓐ : 20 - 29 (2.0 - 3.0, 14 - 22)
- Ⓒ : 14 - 18 (1.4 - 1.8, 10 - 13)
- Ⓜ : N·m (kg-m, in-lb)
- Ⓓ : 10 - 20 (1.0 - 2.0, 87 - 174)
- Ⓔ : 8 - 11 (0.8 - 1.1, 69 - 95)

Compressor Mounting




Compressor — DKV-14C (ZEXEL make)




Compressor Clutch — DKV-14C (ZEXEL make)

REMOVAL

- When removing center bolt, hold clutch disc with clutch disc wrench.




- Remove the clutch disc using Tool KV99232340. Insert holder's three pins into the clutch disc. Rotate the holder clockwise to hook it onto the plate. Then, tighten the center bolt to remove the clutch disc. When tightening the center bolt, insert a round bar (screwdriver, etc.) between two of the pins (as shown in the left-hand figure) to prevent clutch disc rotation. After removing the clutch disc, remove the shims from either the drive shaft or the clutch disc.



- Remove the snap ring using external snap ring pliers.

Compressor Clutch — DKV-14C (ZEXEL make) (Cont'd)



- Pulley removal
Use any commercially available pulley puller. Position the center of it on the end of the drive shaft, and remove the pulley assembly.



For pressed pulleys:

To prevent deformation of the pulley groove, the puller claws should be hooked under (not into) the pulley groove.

For machine latched pulleys:

Align the pulley puller groove with the pulley groove, and then remove the pulley assembly.

- Remove the field coil harness clip using a screwdriver.
- Remove the three field coil fixing screws and remove the field coil.



INSPECTION

Clutch disc


If the contact surface shows signs of damage due to excessive heat, replace clutch disc and pulley.

Pulley

Check the appearance of the pulley assembly. If the contact surface of the pulley shows signs of excessive grooving, replace both the pulley and clutch disc. The contact surfaces of the pulley assembly should be cleaned with a suitable solvent before reinstallation.

Coil

Check coil for loose connection or cracked insulation.





INSTALLATION


- Install the field coil.
- **Be sure to align the coil's pin with the hole in the compressor's front head.**
- Install the field coil harness clip using a screwdriver.

Compressor Clutch — DKV-14C (ZEXEL make) (Cont'd)


- Install the pulley assembly using the installer and a hand press, and then install the snap ring using snap ring pliers.



- Install the clutch disc on the drive shaft, together with the original shim(s). Press the clutch disc down by hand.




- Using the holder to prevent drive plate rotation, tighten the bolt to 12 to 15 N·m (1.2 to 1.5 kg·m, 9 to 11 ft·lb) torque.
- **After tightening the bolt, check that the pulley rotates smoothly.**



- Check clearance around the entire periphery of clutch disc.
Disc-to-pulley clearance:
0.3 - 0.6 mm (0.012 - 0.024 in)
 If the specified clearance is not obtained, replace adjusting spacer and readjust.

BREAK-IN OPERATION

When replacing compressor clutch assembly, always conduct the break-in operation. This is done by engaging and disengaging the clutch about thirty times. Break-in operation raises the level of transmitted torque.



Thermal Protector — DKV-14C (ZEXEL make) INSPECTION

- When servicing, do not allow foreign matter to get into compressor.
- Check continuity between two terminals.

General Specifications

COMPRESSOR

Model	ZEXEL make DKV-14C	
Type	Vane rotary	
Displacement	cm ³ (cu in)/rev.	140 (8.54)
Cylinder bore x stroke	mm (in)	—
Direction of rotation	Clockwise (Viewed from drive end)	
Drive belt	A Type	

LUBRICANT

Type	KLH00-PAGRO	
Capacity	mℓ (Imp fl oz)	
Total in system	200 (7.0)	
Compressor (Service parts) charging amount	200 (7.0)	

Inspection and Adjustment

REFRIGERANT

Type	HFC-134a (R-134a)	
Capacity	kg (lb)	0.50 - 0.60 (1.10 - 1.32)

COMPRESSOR

Clutch disc-to-pulley clearance	0.3 - 0.6	
	mm (in)	(0.012 - 0.024)

ENGINE IDLING SPEED (When A/C is ON.)

- Refer to EC section.

BELT TENSION

- Refer to MA section (“Checking Drive Belts”, “ENGINE MAINTENANCE”).