

SECTION **EL**

**MODIFICATION NOTICE:**

Wiring diagrams have been changed.

**CONTENTS**

<b>PRECAUTIONS</b> .....	2003	<b>REAR FOG LAMP</b> .....	2036
Supplemental Restraint System (SRS) “AIR		Wiring Diagram - R/FOG -/LHD Models .....	2036
BAG” and “SEAT BELT PRE-TENSIONER” ..	2003	Wiring Diagram - R/FOG -/RHD Models .....	2037
<b>POWER SUPPLY ROUTING</b> .....	2004	<b>TURN SIGNAL AND HAZARD WARNING</b>	
Schematic .....	2004	<b>LAMPS</b> .....	2038
Wiring Diagram - POWER - .....	2005	Wiring Diagram - TURN -/Type-1 .....	2038
<b>STARTING SYSTEM</b> .....	2012	Wiring Diagram - TURN -/Type-2 .....	2040
Wiring Diagram - START -/M/T Models .....	2012	<b>ILLUMINATION</b> .....	2043
<b>CHARGING SYSTEM</b> .....	2013	Wiring Diagram - ILL -/LHD Models .....	2043
Wiring Diagram - CHARGE -/Gasoline		Wiring Diagram - ILL -/RHD Models .....	2045
Engine .....	2013	<b>INTERIOR ROOM LAMP</b> .....	2047
Wiring Diagram - CHARGE -/Diesel Engine ..	2014	Wiring Diagram - ROOM/L - .....	2047
Construction .....	2015	<b>SPOT LAMP</b> .....	2048
Service Data and Specifications (SDS) .....	2016	Wiring Diagram - INT/L - .....	2048
<b>COMBINATION SWITCH</b> .....	2017	<b>METER AND GAUGES</b> .....	2049
Check .....	2017	Combination Meter .....	2049
<b>HEADLAMP - Conventional Type</b> - .....	2018	Wiring Diagram - METER -/Gasoline Engine	
Wiring Diagram - H/LAMP -/LHD Models .....	2018	with Tachometer .....	2052
Wiring Diagram - H/LAMP -/RHD Models .....	2020	Wiring Diagram - METER -/Diesel Engine with	
<b>HEADLAMP - Daytime Light System</b> - .....	2022	Tachometer .....	2054
Wiring Diagram - DTRL - .....	2022	Wiring Diagram - METER -/Gasoline Engine	
<b>HEADLAMP - Dim-dip Lamp System</b> - .....	2025	without Tachometer .....	2056
Wiring Diagram - DIMDIP - .....	2025	Wiring Diagram - METER -/Diesel Engine	
<b>HEADLAMP - Headlamp Aiming Control</b> - .....	2028	without Tachometer .....	2057
Wiring Diagram - H/AIM - .....	2028	Unified Control Meter System Description .....	2058
<b>PARKING, LICENSE AND TAIL LAMPS</b> .....	2030	Meter/gauge Operation and Odo/Trip Meter	
Wiring Diagram - TAIL/L -/Except LHD		Segment Check in Diagnosis Mode .....	2058
Models .....	2030	Flexible Print Circuit (FPC) (Models with	
Wiring Diagram - TAIL/L -/LHD Models .....	2032	Tachometer) .....	2059
<b>STOP LAMP</b> .....	2034	Trouble Diagnoses/Models with Tachometer ..	2060
Wiring Diagram - STOP/L - .....	2034	Trouble Diagnoses/Models without	
<b>BACK-UP LAMP</b> .....	2035	Tachometer .....	2065
Wiring Diagram - BACK/L -/M/T Models .....	2035	Electrical Components Inspection .....	2070

<b>WARNING LAMPS</b> .....	2072	Wiring Diagram - WINDOW -/Without	
Schematic .....	2072	Interruption Detection Function.....	2109
Wiring Diagram - WARN -/Gasoline Engine....	2073	Trouble Diagnoses/Without Interruption	
Wiring Diagram - WARN -/Diesel Engine.....	2078	Detection Function .....	2113
Electrical Components Inspection .....	2083	System Description/With Interruption Detection	
Wiring Diagram - CHIME -/LHD Models.....	2084	Function .....	2114
Wiring Diagram - CHIME -/RHD Models.....	2085	Schematic/With Interruption Detection	
<b>FRONT WIPER AND WASHER</b> .....	2086	Function .....	2115
Wiring Diagram - WIPER -/LHD Models with		Wiring Diagram - WINDOW -/With Interruption	
Intermittent .....	2086	Detection Function .....	2116
Wiring Diagram - WIPER -/LHD Models		Trouble Diagnoses/With Interruption Detection	
without Intermittent.....	2087	Function .....	2120
Wiring Diagram - WIPER -/RHD M/T Models		<b>POWER DOOR LOCK</b> .....	2122
with Intermittent.....	2088	System Description .....	2122
Wiring Diagram - WIPER -/RHD Models		Wiring Diagram - D/LOCK - .....	2123
without Intermittent.....	2090	Trouble Diagnosis .....	2125
<b>HEADLAMP WASHER</b> .....	2092	<b>MULTI-REMOTE CONTROL SYSTEM</b> .....	2129
Wiring Diagram - HLC - .....	2092	System Description .....	2129
<b>HORN</b> .....	2093	Schematic .....	2130
Wiring Diagram - HORN - .....	2093	Wiring Diagram - MULTI - .....	2131
<b>CIGARETTE LIGHTER</b> .....	2094	Trouble Diagnoses.....	2135
Wiring Diagram - CIGAR - .....	2094	ID Code Entry Procedure .....	2139
<b>CLOCK</b> .....	2095	<b>NATS (Nissan Anti-Theft System)/Models with</b>	
Wiring Diagram - CLOCK - .....	2095	<b>KA24E</b> .....	2140
<b>REAR WINDOW DEFOGGER AND MIRROR</b>		Wiring Diagram - NATS - .....	2140
<b>DEFOGGER</b> .....	2096	<b>NATS (Nissan Anti-Theft System)/Diesel</b>	
Wiring Diagram - DEF -/LHD Models .....	2096	<b>engine</b> .....	2141
Wiring Diagram - DEF -/RHD Models .....	2097	Wiring Diagram - NATS -/LHD Models.....	2141
Electrical Components Inspection .....	2098	Wiring Diagram - NATS -/RHD Models.....	2142
<b>AUDIO</b> .....	2099	<b>LOCATION OF ELECTRICAL UNITS</b> .....	2143
Wiring Diagram - AUDIO -/LHD Models		Engine Compartment.....	2143
Type-2 .....	2099	Passenger Compartment .....	2144
Wiring Diagram - AUDIO -/LHD Models		<b>HARNES LAYOUT</b> .....	2146
Type-3 .....	2100	Main Harness.....	2146
Wiring Diagram - AUDIO -/RHD Models .....	2102	Engine Room Harness.....	2152
<b>AUDIO ANTENNA</b> .....	2103	Engine Control Harness.....	2160
Power Antenna/Wiring Diagram - P/ANT - .....	2103	Alternator Harness .....	2164
<b>POWER DOOR MIRROR</b> .....	2104	Instrument Harness.....	2165
Wiring Diagram - MIRROR -/LHD Models.....	2104	Room Lamp Harness/LHD Models.....	2166
Wiring Diagram - MIRROR -/RHD Models.....	2105	Room Lamp Harness/RHD Models .....	2167
<b>HEATED SEAT</b> .....	2106	Chassis Harness and Tail Harness .....	2168
Wiring Diagram - H/SEAT - .....	2106	Front Door Harness (LH side) .....	2169
<b>POWER WINDOW</b> .....	2108	Front Door Harness (RH side).....	2170
Schematic/Without Interruption Detection		<b>WIRING DIAGRAM CODES (CELL CODES).....</b>	2171
Function .....	2108		

WIRING DIAGRAM REFERENCE CHART

COOLING FAN .....	LC SECTION
ECCS, IGNITION SYSTEM, QUICK-GLOW SYSTEM, FUEL HEATER SYSTEM ..	EC SECTION
ANTI-LOCK BRAKE SYSTEM .....	BR SECTION
SRS "AIR BAG" .....	RS SECTION
HEATER AND AIR CONDITIONER .....	HA SECTION

## PRECAUTIONS

---

### Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER” used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The SRS system composition which is available to NISSAN MODEL D22 is as follows (The composition varies according to the destination and optional equipment.):

Driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioner, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

#### **WARNING:**

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral Cable and wiring harnesses (except “SEAT BELT PRE-TENSIONER”) covered with yellow insulation either just before the harness connectors or for the complete harness are related to the SRS.**










# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-02

-  : Diesel engine
-  : LHD models for Europe
-  : RHD models for Europe






# POWER SUPPLY ROUTING


## Wiring Diagram — POWER — (Cont'd)

### ACCESSORY POWER SUPPLY — IGNITION SW. IN "ACC" OR "ON"

EL-POWER-04



RA : RHD A/T models  
 NR : Except RA  
 \*1... RA 2P , NR 110



Refer to last page (Foldout page).

M5, E101  
 M85, E104





# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

### IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START"

EL-POWER-05



Refer to last page (Foldout page).

(M5), (E101)



(M85), (E104)

# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-06

- ⬡ : Diesel engine
- ⬡ : KA engine
- ⬡ : Carburetor engine
- ⬡ : RHD A/T models
- ⬡ : Except ⬡
- \*1...⬡ 2L, ⬡ 2F
- \*2...⬡ 10A, ⬡ 15A





Refer to last page (Foldout page).

- ⬡, ⬡
- ⬡, ⬡

# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)




EL-POWER-07



# STARTING SYSTEM

## Wiring Diagram — START —/M/T Models

EL-START-01




Refer to last page (Foldout page).

M5, E101

# CHARGING SYSTEM

## Wiring Diagram — CHARGE —/Gasoline Engine


EL-CHARGE-01



1	2	3	4	5	6	7	8	9	10	11	(N2)		
12	13	14	15	16	17	18	19	20	21	22	23	24	BR

36	37	38	39	40	41	42	(N6)		
27	28	29	30	31	32	33	34	35	BR

21	22	23	24	25	26	27	28	29	(N10)	41	42	43	44	45	46	47	48	49	50	51	(N11)				
30	31	32	33	34	35	36	37	38	39	40	BR	52	53	54	55	56	57	58	59	60	61	62	63	64	W






# CHARGING SYSTEM

## Construction

SEC. 231  
LR170-765



MEL383IA

# CHARGING SYSTEM

## Service Data and Specifications (SDS)

### ALTERNATOR

Type	LR170-765	LR160-728F
	HITACHI	
Applied model	KA24	TD25
Nominal rating      V-A	12-70	12-60
Ground polarity	Negative	
Minimum revolution under no-load (When 13.5V is applied)      rpm	Less than 1,000	
Hot output current (When 13.5V is applied)      A/rpm	More than 17/1,300 More than 54/2,500 More than 75/5,000	More than 17/1,300 More than 48/2,500 More than 57/5,000
Regulated output voltage      V	14.1 - 14.7	
Minimum length of brush mm (in)	6.0 (0.236)	
Brush spring pressure N (g, oz)	1.0 - 3.43 (102 - 350, 3.60 - 12.34)	
Slip ring minimum outer diameter mm (in)	26.0 (1.024)	
Rotor (Field coil) resistance      Ω	2.58	


\*: Models with power steering and air conditioner



# COMBINATION SWITCH

## Check

### LHD MODELS



LIGHTING SWITCH

	OFF			1ST			2ND		
	A	B	C	A	B	C	A	B	C
5									
6			○						
7									
8			○						
9			○						
10									
11				○	○	○	○	○	○
12				○	○	○	○	○	○
25									

WIPER AND WASHER SWITCH (With intermittent)

	OFF	INT	LO	HI	WASH
	13				
14	○	○			
15	○				
16					
17		○			
18					

WIPER AMPLIFIER (In combination switch)

WIPER AND WASHER SWITCH (Without intermittent)

	OFF	LO	HI	WASH
	13	○		
14	○			
15				
16				
17		○	○	
18				○


TURN SIGNAL LAMP SWITCH

	L	N	R
	1	○	
2			○
3	○		

REAR FOG LAMP SWITCH

	OFF	ON
	26	
27		○


HORN SWITCH (Without air bag)



# HEADLAMP — Conventional Type —

## Wiring Diagram — H/LAMP —/LHD Models

EL-H/LAMP-01



Refer to last page (Foldout page).


(M5), (E101)

# HEADLAMP — Conventional Type —

## Wiring Diagram — H/LAMP —/LHD Models (Cont'd)

EL-H/LAMP-02

TM : With tachometer  
 WT : Without tachometer  
 \*1... TM 29 , WT 51  
 \*2... TM 27 , WT 50



1	2	3	4	5	6	7	8	9	10	11	(N2) BR	
12	13	14	15	16	17	18	19	20	21	22		23

36	37	38	39	40	41	42	(N6) BR	
27	28	29	30	31	32	33		34


41	42	43	44	45	46	47	48	49	50	51	(N11) W	
52	53	54	55	56	57	58	59	60	61	62		63



# HEADLAMP — Conventional Type —

## Wiring Diagram — H/LAMP —/RHD Models

### EL-H/LAMP-03



Refer to last page (Foldout page).


(M5), (E101)  
(M85), (E104)

# HEADLAMP — Conventional Type —

## Wiring Diagram — H/LAMP —/RHD Models (Cont'd)

EL-H/LAMP-04

TM : With tachometer  
WT : Without tachometer  
 \*1... TM 29 , WT 51  
 \*2... TM 27 , WT 50



1	2	3	4	5	6	7	8	9	10	11	<span style="border: 1px solid black; border-radius: 50%; padding: 2px;">N2</span> BR	
12	13	14	15	16	17	18	19	20	21	22		23

36	37	38	39	40	41	42	<span style="border: 1px solid black; border-radius: 50%; padding: 2px;">N6</span> BR	
27	28	29	30	31	32	33		34


41	42	43	44	45	46	47	48	49	50	51	<span style="border: 1px solid black; border-radius: 50%; padding: 2px;">N11</span> W	
52	53	54	55	56	57	58	59	60	61	62		63

3 E13 , E26  
1 2 B , B

# HEADLAMP — Daytime Light System —

## Wiring Diagram — DTRL —


EL-DTRL-01



1	2	3	4	5	6	7	8	9	10	11	(N2)		
12	13	14	15	16	17	18	19	20	21	22	23	24	BR

36	37	38	39	40	41	42	(N6)		
27	28	29	30	31	32	33	34	35	BR

21	22	23	24	25	26	27	28	29	(N10)	41	42	43	44	45	46	47	48	49	50	51	(N11)				
30	31	32	33	34	35	36	37	38	39	40	BR	52	53	54	55	56	57	58	59	60	61	62	63	64	W








Refer to last page (Foldout page).

(M5), (E101)

# HEADLAMP — Daytime Light System — Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-02



Refer to last page (Foldout page).


(M5), (E101)

# HEADLAMP — Daytime Light System —

## Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-03

- Ⓜ: With tachometer
- Ⓜ: Without tachometer
- \*1... Ⓜ 29 , Ⓜ 51
- \*2... Ⓜ 27 , Ⓜ 50



1	2	3	4	5	6	7	8	9	10	11	(N2)		
12	13	14	15	16	17	18	19	20	21	22	23	24	BR

36	37	38	39	40	41	42	(N6)		
27	28	29	30	31	32	33	34	35	BR

41	42	43	44	45	46	47	48	49	50	51	(N11)		
52	53	54	55	56	57	58	59	60	61	62	63	64	W

3	(E13)	(E26)
1 2	B	B

1	9	10	(E64)
11		4	GY

Refer to last page (Foldout page).


(M5), (E101)



# HEADLAMP — Dim-dip Lamp System —

## Wiring Diagram — DIMDIP —

EL-DIMDIP-01



8	7	6	(E66)
2	5	3	GY

Refer to last page  
(Foldout page).



(M5), (E101)



# HEADLAMP — Dim-dip Lamp System —

## Wiring Diagram — DIMDIP — (Cont'd)


EL-DIMDIP-03



# HEADLAMP — Headlamp Aiming Control —

## Wiring Diagram — H/AIM —

EL-H/AIM-01





Refer to last page (Foldout page).

M5, E101

# HEADLAMP — Headlamp Aiming Control — Wiring Diagram — H/AIM — (Cont'd)

EL-H/AIM-02





Refer to last page (Foldout page).

(M5), (E101)

# PARKING, LICENSE AND TAIL LAMPS

## Wiring Diagram — TAIL/L —/Except LHD Models


EL-TAIL/L-01



Refer to last page (Foldout page).

(M5), (E101)



(M85), (E104)



# PARKING, LICENSE AND TAIL LAMPS

## Wiring Diagram — TAIL/L —/Except LHD Models (Cont'd)

EL-TAIL/L-02









# PARKING, LICENSE AND TAIL LAMPS

## Wiring Diagram — TAIL/L —/LHD Models (Cont'd)


### EL-TAIL/L-04




# STOP LAMP

## Wiring Diagram — STOP/L —

EL-STOP/L-01




- $\langle \text{EU} \rangle$  : For Europe
- $\langle \text{NE} \rangle$  : Except for Europe
- $\langle \text{CS} \rangle$  : For Europe, Australia and China except A-chassis
- $\langle \text{XS} \rangle$  : Except  $\langle \text{CS} \rangle$
- $\langle \text{UL} \rangle$  : LHD models for Europe
- $\langle \text{XL} \rangle$  : Except  $\langle \text{UL} \rangle$
- \*1...  $\langle \text{UL} \rangle$  R,  $\langle \text{XL} \rangle$  P/L
- \*2...  $\langle \text{CS} \rangle$  5,  $\langle \text{XS} \rangle$  4



# BACK-UP LAMP

## Wiring Diagram — BACK/L —/M/T Models

### EL-BACK/L-01



- <L> : LHD models
  - <R> : RHD models
  - <G> : Gasoline engine
  - <D> : Diesel engine
  - <EU> : For Europe
  - <NE> : Except for Europe
  - <CS> : For Europe, Australia and China except A-chassis
  - <XS> : Except <CS>
- \*1... <L> 4G, <R> 5C  
 \*2... <L> 4H, <R> 4C  
 \*3... <EU> 1, <NE> 5  
 \*4... <CS> 6, <XS> 5





Refer to last page  
(Foldout page).

M5, E101

# REAR FOG LAMP

## Wiring Diagram — R/FOG —/LHD Models

EL-R/FOG-01



Refer to last page (Foldout page).

(M5), (E101)





# TURN SIGNAL AND HAZARD WARNING LAMPS

## Wiring Diagram — TURN —/Type-1

FOR EUROPE (Single cab)

EL-TURN-01





HEL703A

# TURN SIGNAL AND HAZARD WARNING LAMPS

## Wiring Diagram — TURN —/Type-1 (Cont'd)

EL-TURN-02



Refer to last page (Foldout page).




⊠M5, ⊠E101  
⊠M85, ⊠E104

# TURN SIGNAL AND HAZARD WARNING LAMPS

## Wiring Diagram — TURN —/Type-2

FOR EUROPE (King cab and Double cab)

EL-TURN-03





HEL705A



# TURN SIGNAL AND HAZARD WARNING LAMPS



## Wiring Diagram — TURN —/Type-2 (Cont'd)



# TURN SIGNAL AND HAZARD WARNING LAMPS

## Wiring Diagram — TURN —/Type-2 (Cont'd)

EL-TURN-05





Refer to last page (Foldout page).

M5, E101

# ILLUMINATION

## Wiring Diagram — ILL —/LHD Models

EL-ILL-01



Refer to last page (Foldout page).

ⓂⓅ, ⒺⓁ

# ILLUMINATION



## Wiring Diagram — ILL —/LHD Models (Cont'd)

EL-ILL-02

- ◻EU: For Europe
- ◻WC: With CD deck
- ◻AM: Without CD deck (1-speaker radio)
- ◻FM: Without CD deck (For Europe and with 2 or 4-speakers radio)
- ◻SG: GL and S-GL grade for the Middle East
- ◻TM: With tachometer
- ◻WT: Without tachometer
- \*1... ◻AM R/G, ◻WC P/L
- \*2... ◻TM 37, ◻WT 22
- \*3... ◻TM 33, ◻WT 27
- \*4... ◻TM 34, ◻WT 46

IGNITION SWITCH  
ON or START






Refer to  
EL-POWER.



# ILLUMINATION

## Wiring Diagram — ILL —/RHD Models


EL-ILL-03



# ILLUMINATION

## Wiring Diagram — ILL —/RHD Models (Cont'd)

EL-ILL-04



1	2	3	4	5	6	7	8	9	10	11	(N2)		
12	13	14	15	16	17	18	19	20	21	22	23	24	BR


36	37	38	39	40	41	42	(N6)		
27	28	29	30	31	32	33	34	35	BR

21	22	23	24	25	26	27	28	29	(N10)	41	42	43	44	45	46	47	48	49	50	51	(N11)				
30	31	32	33	34	35	36	37	38	39	40	BR	52	53	54	55	56	57	58	59	60	61	62	63	64	W


# INTERIOR ROOM LAMP

## Wiring Diagram — ROOM/L —

EL-ROOM/L-01



- ⬡ : LHD models
- ⬢ : RHD models
- ⬤ : RHD A/T models
- ⬥ : Except ⬤
- ⬦ : For Europe and models with multi-remote control system
- ⬧ : Except ⬦
- ⬨ : For Australia and models with multi-remote control system
- ⬩ : Double cab models (For Australia and models with multi-remote control system)
- ⬪ : Single cab and King cab models
- ⬫ : Double cab models
- \*1... ⬡ 11F, ⬢ 11E
- \*2... ⬦ 2, ⬧ 1




Refer to last page (Foldout page).

- ⬡, ⬢, ⬤, ⬥, ⬦, ⬧, ⬨, ⬩, ⬪, ⬫
- ⬬, ⬭, ⬮, ⬯, ⬰, ⬱, ⬲, ⬳, ⬴, ⬵, ⬶, ⬷, ⬸, ⬹, ⬺, ⬻, ⬼, ⬽, ⬾, ⬿, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50

# SPOT LAMP

## Wiring Diagram — INT/L —

EL-INT/L-01



- ⬡ : LHD models
- ⬢ : RHD models
- ⬤ : RHD A/T models
- ⬣ : Except ⬤
- \*1... ⬡ 11F, ⬢ 11E



Refer to last page (Foldout page).

⬢, ⬡


⬢, ⬡



# METER AND GAUGES

## Combination Meter


### WITH TACHOMETER



# METER AND GAUGES

## Combination Meter (Cont'd)

WITHOUT TACHOMETER



- (D) : Diesel engine
- (KA) : KA engine
- (ME) : For the Middle East
- (RF) : With rear fog lamp
- (AB) : With air bag
- (AS) : With ABS

(N9)

10	11	12	13	14	15	16	17	18	19	20
1	2	3	4	5	6	7	8	9		

(White)

(N10)


21	30
22	31
23	32
24	33
25	34
	35
	36
26	37
27	38
28	39
29	40

(Brown)

(N11)

51	50	49	48	47		46	45	44	43	42	41	
64	63	62	61	60	59	58	57	56	55	54	53	52

(White)




HEL715A

# METER AND GAUGES

## Combination Meter (Cont'd)



### CONSTRUCTION (Without tachometer)



# METER AND GAUGES

## Wiring Diagram — METER —/Gasoline Engine with Tachometer

EL-METER-01



Refer to last page (Foldout page).

M5, E101


M85, E104



# METER AND GAUGES

## Wiring Diagram — METER —/Diesel Engine with Tachometer

EL-METER-03



1	2	3	4	5	6	7	8	9	10	11	(N2)		
12	13	14	15	16	17	18	19	20	21	22	23	24	BR

1	2	3	4	5	6	7	(N4)	36	37	38	39	40	41	42	(N6)				
8	9	10	11	12	13	14	15	16	W	27	28	29	30	31	32	33	34	35	BR





Refer to last page (Foldout page).

(M5), (E101)

# METER AND GAUGES

## Wiring Diagram — METER —/Diesel Engine with Tachometer (Cont'd)

EL-METER-04





Refer to last page (Foldout page).

(M5), (E101)

# METER AND GAUGES

## Wiring Diagram — METER —/Gasoline Engine without Tachometer

EL-METER-05



Refer to last page (Foldout page).


(M5), (E101)




# METER AND GAUGES

## Wiring Diagram — METER —/Diesel Engine without Tachometer

EL-METER-06



1	2	3	4	5	6	7	8	9	10	11	(N2)	21	22	23	24	25	26	27	28	29	(N10)				
12	13	14	15	16	17	18	19	20	21	22	23	24	BR	30	31	32	33	34	35	36	37	38	39	40	BR



Refer to last page (Foldout page).

(M5), (E101)

# METER AND GAUGES

## Unified Control Meter System Description


### UNIFIED CONTROL METER

Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled totally by unified meter control unit.

## Meter/gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

### DIAGNOSIS FUNCTION

- Odo/trip meter segment can be checked in diagnosis mode.
- Meters/gauges can be checked in diagnosis mode.




### HOW TO ALTERNATE DIAGNOSIS MODE

1. Turn ignition switch to ON and change odo/trip meter to "TRIP A" or "TRIP B".
2. Turn ignition switch to OFF.
3. Turn ignition switch to ON when pushing odo/trip meter switch.
4. Confirm that trip meter indicates "000.0".
5. Push odo/trip meter switch more than three times within 5 seconds.
6. All odo/trip meter segments should be turned on.

**NOTE: If some segments are not turned on, unified meter control unit should be replaced.**

At this point, the unified control meter is turned to diagnosis mode.




7. Push odo/trip meter switch. Indication of each meter/gauge should be as shown left during pushing odo/trip meter switch if it is no malfunctioning.

**NOTE: It takes about 1 minute for indication of fuel gauge to become stable.**


## METER AND GAUGES

### Meter/gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode (Cont'd)




### Flexible Print Circuit (FPC) (Models with Tachometer)

Tachometer, fuel gauge and water temperature gauge are connected with unified meter control unit (speedometer) by Flexible Print Circuit (FPC) connector. When replace or remove and install unified control unit (speedometer), disconnect and connect FPC connector according to the following steps.



#### DISCONNECT

1. Open connector cover.
2. Release connector lock by holding both ends of it and pulling it up.
3. Disconnect FPC by pulling it up.




#### CONNECT

1. Insert FPC into connector and lock connector pushing FPC downward.
2. Check secure connection of FPC.
3. Check continuity of check land terminals for secure connection of FPC.  
**Resistance: 0Ω**
4. Close connector cover.

# METER AND GAUGES

## Trouble Diagnoses/Models with Tachometer

### PRELIMINARY CHECK



## METER AND GAUGES

### Trouble Diagnoses/Models with Tachometer (Cont'd)

Before starting trouble diagnoses below, perform PRELIMINARY CHECK, EL-2060.

#### SYMPTOM CHART 1 (MALFUNCTION IS INDICATED IN DIAGNOSIS MODE)

Symptom	Possible causes	Repair order
Speedometer and/or odo/trip meter indicate(s) malfunction in Diagnosis mode.	<ul style="list-style-type: none"> <li>● Speedometer (Unified meter control unit)</li> </ul>	<ul style="list-style-type: none"> <li>● Replace speedometer (unified meter control unit).</li> </ul>
Multiple meter/gauge indicate malfunction in Diagnosis mode.		
One of tachometer/fuel gauge/water temp. gauge indicates malfunction in Diagnosis mode.	<ul style="list-style-type: none"> <li>● Meter/Gauge</li> <li>● Speedometer (Unified meter control unit)</li> </ul>	<ol style="list-style-type: none"> <li>1. Check resistance of meter/gauge indicating malfunction. If the resistance is NG, replace the meter/gauge. Refer to "METER/GAUGE RESISTANCE CHECK", EL-2070.</li> <li>2. If the resistance is OK, replace speedometer (unified meter control unit).</li> </ol>

#### SYMPTOM CHART 2 (NO MALFUNCTION IS INDICATED IN DIAGNOSIS MODE)


Symptom	Possible causes	Repair order
Speedometer and odo/trip meter are malfunctioning.	<ol style="list-style-type: none"> <li>1. Sensor                             <ul style="list-style-type: none"> <li>- Speedometer, Odo/Trip meter</li> </ul> </li> <li>2. FPC connector</li> <li>3. Speedometer (Unified meter control unit)</li> </ol>	<ol style="list-style-type: none"> <li>1. Check vehicle speed sensor. INSPECTION/VEHICLE SPEED SENSOR (Refer to EL-2063.)</li> <li>2. Check FPC connector. Refer to "FLEXIBLE PRINT CIRCUIT (FPC)", EL-2059.</li> <li>3. Replace speedometer (unified meter control unit).</li> </ol>
Multiple meter/gauge are malfunctioning. (except speedometer, odo/trip meter)	<ol style="list-style-type: none"> <li>1. FPC connector</li> <li>2. Speedometer (Unified meter control unit)</li> </ol>	<ol style="list-style-type: none"> <li>1. Check FPC connector. Refer to "FLEXIBLE PRINT CIRCUIT (FPC)", EL-2059.</li> <li>2. Replace speedometer (unified meter control unit).</li> </ol>
One of tachometer/fuel gauge/water temp. gauge is malfunctioning.	<ol style="list-style-type: none"> <li>1. Sensor/Engine revolution signal                             <ul style="list-style-type: none"> <li>- Tachometer</li> <li>- Fuel gauge</li> <li>- Water temp. gauge</li> </ul> </li> <li>2. FPC connector</li> <li>3. Speedometer (Unified meter control unit)</li> </ol>	<ol style="list-style-type: none"> <li>1. Check the sensor for malfunctioning meter/gauge. INSPECTION/ENGINE REVOLUTION SIGNAL (Refer to EL-2063.) INSPECTION/FUEL TANK GAUGE (Refer to EL-102.) INSPECTION/THERMAL TRANSMITTER (Refer to EL-2064.)</li> <li>2. Check FPC connector. Refer to "Flexible Print Circuit (FPC)", EL-2059.</li> <li>3. Replace speedometer (unified meter control unit).</li> </ol>

## METER AND GAUGES

### Trouble Diagnoses/Models with Tachometer (Cont'd)

#### POWER SUPPLY AND GROUND CIRCUIT CHECK


##### Power supply circuit check



Terminals		Ignition switch position		
⊕	⊖	OFF	ACC	ON
②	Ground	Battery voltage	Battery voltage	Battery voltage
③⑦	Ground	0V	0V	Battery voltage

If NG, check the following.

- 7.5A fuse [No. ③], located in fuse block (J/B)]
- 10A fuse [No. ②①], located in fuse block (J/B)]
- Harness for open or short between fuse and combination meter







##### Ground circuit check

Terminals	Continuity
③ - Ground	Yes

# METER AND GAUGES

## Trouble Diagnoses/Models with Tachometer (Cont'd)

### INSPECTION/VEHICLE SPEED SENSOR



### INSPECTION/ENGINE REVOLUTION SIGNAL (Models with tachometer)

Engine	Check item	Terminals		Explanation
		⊕	⊖	
ECM controlled engine	DC voltage	⑮	③	Higher rpm = Higher voltage Lower rpm = Lower voltage Voltage should change with rpm.
Carburetor	AC voltage			
Diesel TD27 and QD32				





If NG, check the following.

Engine	Check item
ECM controlled engine	<ul style="list-style-type: none"> <li>● Harness for open or short and connection</li> </ul>
Carburetor	<ul style="list-style-type: none"> <li>● Harness for open or short and connection</li> <li>● Resistor etc.</li> </ul>
Diesel TD27 and QD32	<ul style="list-style-type: none"> <li>● Harness for open or short and connection</li> <li>● Engine revolution sensor etc.</li> </ul>


# METER AND GAUGES

## Trouble Diagnoses/Models with Tachometer (Cont'd)

### INSPECTION/FUEL LEVEL SENSOR



### INSPECTION/THERMAL TRANSMITTER






# METER AND GAUGES

## Trouble Diagnoses/Models without Tachometer

### PRELIMINARY CHECK



## METER AND GAUGES

### Trouble Diagnoses/Models without Tachometer (Cont'd)

Before starting trouble diagnoses below, perform PRELIMINARY CHECK, EL-2065.

#### SYMPTOM CHART 1 (MALFUNCTION IS INDICATED IN DIAGNOSIS MODE)

Symptom	Possible causes	Repair order
Odo/trip meter indicate(s) malfunction in Diagnosis mode.	<ul style="list-style-type: none"> <li>● Unified meter control unit</li> </ul>	<ul style="list-style-type: none"> <li>● Replace unified meter control unit.</li> </ul>
Multiple meter/gauge indicate malfunction in Diagnosis mode.		
One of speedometer/tachometer/fuel gauge/water temp. gauge indicates malfunction in Diagnosis mode.	<ul style="list-style-type: none"> <li>● Meter/Gauge</li> <li>● Unified meter control unit</li> </ul>	<ol style="list-style-type: none"> <li>1. Check resistance of meter/gauge indicating malfunction. If the resistance is NG, replace the meter/gauge. Refer to "METER/GAUGE RESISTANCE CHECK", EL-2070.</li> <li>2. If the resistance is OK, replace unified meter control unit.</li> </ol>

#### SYMPTOM CHART 2 (NO MALFUNCTION IS INDICATED IN DIAGNOSIS MODE)


Symptom	Possible causes	Repair order
One/or more of speedometer/tachometer/fuel gauge/water temp. gauge is malfunctioning.	<ol style="list-style-type: none"> <li>1. Sensor                             <ul style="list-style-type: none"> <li>- Vehicle speed signal</li> <li>- Fuel gauge</li> <li>- Water temp. gauge</li> </ul> </li> <li>2. Unified meter control unit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check the sensor for malfunctioning meter/gauge. INSPECTION/VEHICLE SPEED SENSOR (Refer to EL-2068.) INSPECTION/FUEL LEVEL SENSOR (Refer to EL-2064.) INSPECTION/THERMAL TRANSMITTER (Refer to EL-2069.)</li> <li>2. Replace unified meter control unit.</li> </ol>

## METER AND GAUGES

### Trouble Diagnoses/Models without Tachometer (Cont'd)

#### POWER SUPPLY AND GROUND CIRCUIT CHECK


##### Power supply circuit check



Terminals		Ignition switch position		
⊕	⊖	OFF	ACC	ON
①	Ground	Battery voltage	Battery voltage	Battery voltage
②	Ground	0V	0V	Battery voltage

If NG, check the following.

- 7.5A fuse [No. ③], located in fuse block (J/B)
- 10A fuse [No. ②①], located in fuse block (J/B)
- Harness for open or short between fuse and combination meter






##### Ground circuit check

Terminals	Continuity
②③ - Ground	Yes

# METER AND GAUGES

## Trouble Diagnoses/Models without Tachometer (Cont'd)





### INSPECTION/VEHICLE SPEED SENSOR




# METER AND GAUGES

## Trouble Diagnoses/Models without Tachometer (Cont'd)

### INSPECTION/FUEL LEVEL SENSOR



### INSPECTION/THERMAL TRANSMITTER






# METER AND GAUGES

## Electrical Components Inspection

### METER/GAUGE RESISTANCE CHECK

1. Disconnect FPC connector (Combination meter with tachometer). Refer to EL-2059.
2. Check resistance between terminals (the points of installation screws) of meter/gauge after removing meter/gauge.

Screws		Resistance $\Omega$
Tachometer	Fuel/Temp. gauge	
A - C	A - C	Approx. 140 - Approx. 260
B - D	B - C	Approx. 230 - Approx. 310



### FUEL LEVEL SENSOR UNIT CHECK

- For removal, refer to FE section.
- Check the resistance between terminals ① and ③.

Ohmmeter	Float position mm (in)				Resistance value $\Omega$	
	(+)	(-)	60ℓ (13-1/4 Imp gal) tank	80ℓ (17-5/8 Imp gal) tank		
③	①	*1	Full	253 (9.96)	77 (3.03)	Approx. 4 - 6
		*2	1/2	130 (5.12)	191 (7.52)	
		*3	Empty	27 (1.06)	299 (11.77)	


\*1 and \*3: When float rod is in contact with stopper.

## METER AND GAUGES

### Electrical Components Inspection (Cont'd)

#### THERMAL TRANSMITTER CHECK


Check the resistance between the terminals of thermal transmitter and body ground.



Water temperature	Resistance
60°C (140°F)	Approx. 167 - 211Ω
100°C (212°F)	Approx. 47 - 53Ω


#### VEHICLE SPEED SENSOR SIGNAL CHECK

1. Remove vehicle speed sensor from transmission.
2. Turn vehicle speed sensor pinion quickly and measure voltage between terminals (a) and (b).



# WARNING LAMPS

## Schematic







# WARNING LAMPS

## Wiring Diagram — WARN —/Gasoline Engine

EL-WARN-01



- (L) : LHD models
- (R) : RHD models
- (KE) : KA24E engine
- (KN) : KA24DE engine
- (EK) : Except KA24DE engine
- (LK) : LHD models with KA24DE engine
- (RK) : RHD models with KA24DE engine
- (AS) : With ABS
- (2W) : 2-wheel drive models
- (4W) : 4-wheel drive models
- (TM) : With tachometer
- (WT) : Without tachometer
- \*1... (TM) 37, (WT) 22
- \*2... (TM) 42, (WT) 47
- \*3... (TM) 38, (WT) 49
- \*4... (TM) 10, (WT) 13
- \*5... (L) 1, (R) 10
- \*6... (KE) R/W, (KN) OR/B
- \*7... (KE) 24, (KN) 13
- \*8... (L) 12H, (R) 4H
- \*9... (2W) 10, (4W) 21




Refer to last page (Foldout page).

- (M5), (E101)
- (M32)
- (F51)
- (E4)

# WARNING LAMPS

## Wiring Diagram — WARN —/Gasoline Engine (Cont'd)

EL-WARN-02



1 2 3 4 5 6 7	(M18)	1 2 0 3	(M53)	24 13 17 18	(M80)	(M82)	1 2 3 4 5	(M94)
8 9 10 11 12 13 14 15 16	W	4 5 6 7 8	W	3 4 12 11 6 5	Y	1 2	6 7 8 9 10 11 12	W
				21 22 20 15 19 1 16 2				

1	(M109)	1 2 3 4 5 6 7 8 9 10 11	(N2)	1 2 3 4 5 6 7	(N4)	36 37 38 39 40 41 42	(N6)
2	W	12 13 14 15 16 17 18 19 20 21 22 23 24	BR	8 9 10 11 12 13 14 15 16	W	27 28 29 30 31 32 33 34 35	BR
3							



21 22 23 24 25 26 27 28 29	(N10)	41 42 43 44 45 46 47 48 49 50 51	(N11)
30 31 32 33 34 35 36 37 38 39 40	BR	52 53 54 55 56 57 58 59 60 61 62 63 64	W

HEL724A

# WARNING LAMPS

## Wiring Diagram — WARN —/Gasoline Engine (Cont'd)

EL-WARN-03





Refer to last page (Foldout page).

(M5), (E101)  
 (M85), (E104)

# WARNING LAMPS

## Wiring Diagram — WARN —/Gasoline Engine (Cont'd)

EL-WARN-04



Refer to last page (Foldout page).

(M5), (E101)



(M85), (E104)

(M70)

# WARNING LAMPS

## Wiring Diagram — WARN —/Gasoline Engine (Cont'd)

EL-WARN-05



Refer to last page (Foldout page).



M5, E101

\* : This connector is not shown in "HARNES LAYOUT".

# WARNING LAMPS

## Wiring Diagram — WARN —/Diesel Engine

EL-WARN-06




Refer to last page (Foldout page).

M5, E101  
E4

# WARNING LAMPS

## Wiring Diagram — WARN —/Diesel Engine (Cont'd)

EL-WARN-07



1 2 3 4 5 6 7 (M18) W	1 2 3 4 5 6 7 8 (M53) W	24 13 17 18 3 4 12 11 6 5 (M80) Y	1 2 (M82) W	1 2 3 4 5 (M94) W
8 9 10 11 12 13 14 15 16	4 5 6 7 8	21 22 20 15 19 1 16 2	1 2	6 7 8 9 10 11 12

1 (M109) W	1 2 3 4 5 6 7 8 9 10 11 (N2) BR	1 2 3 4 5 6 7 (N4) W	36 37 38 39 40 41 42 (N6) BR
2 W	12 13 14 15 16 17 18 19 20 21 22 23 24	8 9 10 11 12 13 14 15 16	27 28 29 30 31 32 33 34 35
3			


21 22 23 24 25 26 27 28 29 (N10) BR	41 42 43 44 45 46 47 48 49 50 51 (N11) W
30 31 32 33 34 35 36 37 38 39 40	52 53 54 55 56 57 58 59 60 61 62 63 64

HEL729A

# WARNING LAMPS

## Wiring Diagram — WARN —/Diesel Engine (Cont'd)

EL-WARN-08



1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

 (M8), (M116)
 

1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

 (M21) W
 

1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

 (M108) B, GY
 

1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

 (M259) BR, BR
 (E5) BR

1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

 (N2) BR
 

36	37	38	39	40	41	42		
27	28	29	30	31	32	33	34	35

 (N6) BR

1	2	3	4	5	6	7	8	9	10	11
10	11	12	13	14	15	16	17	18	19	20

 (N9) W
 

41	42	43	44	45	46	47	48	49	50	51		
52	53	54	55	56	57	58	59	60	61	62	63	64

 (N11) W

1	2
1	2

 (E2) GY

Refer to last page (Foldout page).


(M5), (E101)



# WARNING LAMPS

## Wiring Diagram — WARN —/Diesel Engine (Cont'd)

EL-WARN-09



1	2	3	4	5	6	7	8	9	10	(N1)
11	12	13	14	15	16	17	18	19	20	W

1	2	3	4	5	6	7	8	9	10	11	(N2)
12	13	14	15	16	17	18	19	20	21	22	BR

1	2	3	4	5	6	7	(N4)
8	9	10	11	12	13	14	W

36	37	38	39	40	41	42	(N6)
27	28	29	30	31	32	33	BR

1	2	3	4	5	6	7	8	9	(N9)
10	11	12	13	14	15	16	17	18	W

41	42	43	44	45	46	47	48	49	50	51	(N11)
52	53	54	55	56	57	58	59	60	61	62	W

1	2	3	4	5	(C3)
					GY

2	(A7)	
3	4	(A8)
		GY

1	2	3	4	5	(A13)
6	7	8	9	10	GY

1	2	3	4	5	6	7	(C9)
8	9	10	11	12	13	14	W



Refer to last page  
(Foldout page).

(M5), (E101)

# WARNING LAMPS

## Wiring Diagram — WARN —/Diesel Engine (Cont'd)


EL-WARN-10



Refer to last page (Foldout page).

M5, E101

## WARNING LAMPS



### Electrical Components Inspection

#### FUEL WARNING LAMP SENSOR CHECK



- It will take a short time for the bulb to light.

# WARNING LAMPS

## Wiring Diagram — CHIME —/LHD Models

### LIGHT WARNING BUZZER

EL-CHIME-02



Refer to last page (Foldout page).


(M5), (E101)

# WARNING LAMPS

## Wiring Diagram — CHIME —/RHD Models

### LIGHT WARNING BUZZER


### EL-CHIME-03



# FRONT WIPER AND WASHER

## Wiring Diagram — WIPER —/LHD Models with Intermittent

EL-WIPER-01






Refer to last page  
(Foldout page).

(M5) , (E101)

# FRONT WIPER AND WASHER

## Wiring Diagram — WIPER —/LHD Models without Intermittent

EL-WIPER-02




Refer to last page  
(Foldout page).

M5 , E101

# FRONT WIPER AND WASHER

## Wiring Diagram — WIPER —/RHD M/T Models with Intermittent

EL-WIPER-03



3	2
6	5

(M221)
W

(F21)
W

1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16





(F55)
W



# FRONT WIPER AND WASHER

## Wiring Diagram — WIPER —/RHD M/T Models with Intermittent (Cont'd)

EL-WIPER-04





Refer to last page  
(Foldout page).

(M5) , (E101)

# FRONT WIPER AND WASHER

## Wiring Diagram — WIPER —/RHD Models without Intermittent

EL-WIPER-07



Refer to last page  
(Foldout page).


(M5) , (E101)

# FRONT WIPER AND WASHER

## Wiring Diagram — WIPER —/RHD Models without Intermittent (Cont'd)

EL-WIPER-08



⬡KA : KA engine  
⬡EK : Except ⬡KA



# HEADLAMP WASHER

## Wiring Diagram — HLC —

EL-HLC-01





Refer to last page (Foldout page).

M5, E101

# HORN

## Wiring Diagram — HORN —

EL-HORN-01



Refer to last page (Foldout page).



(M5), (E101)  
(M85), (E104)

\* : This connector is not shown in "HARNES LAYOUT".

# CIGARETTE LIGHTER

## Wiring Diagram — CIGAR —


EL-CIGAR-01



# CLOCK

## Wiring Diagram — CLOCK —

EL-CLOCK-01



1	2	3	4	5	6	7	8	9	10	11	N2		
12	13	14	15	16	17	18	19	20	21	22	23	24	BR


1	2	3	4	5	6	7	N4	36	37	38	39	40	41	42	N6		
8	9	10	11	12	13	14	W	27	28	29	30	31	32	33	34	35	BR

21	22	23	24	25	26	27	28	29	N10	41	42	43	44	45	46	47	48	49	50	51	N11				
30	31	32	33	34	35	36	37	38	39	40	BR	52	53	54	55	56	57	58	59	60	61	62	63	64	W

# REAR WINDOW DEFOGGER AND MIRROR DEFOGGER


## Wiring Diagram — DEF —/LHD Models

EL-DEF-01



Refer to EL-POWER.

- ⊖G : Gasoline engine
  - ⊖D : Diesel engine
  - ⊖MD : With mirror defogger
  - ⊖MS : Only with mirror defogger
  - ⊖XS : Except ⊖MS
  - ⊖KC : King cab models with rear window defogger
  - ⊖DC : Double cab models with rear window defogger
- \*1... ⊖MS 2G, ⊖XS 11B  
 \*2... ⊖MS 1G, ⊖XS 10C  
 \*3... ⊖G 12C, ⊖D 9J  
 \*4... ⊖G 6G, ⊖D 9H



Refer to last page (Foldout page).



⊖M5, ⊖E101



# REAR WINDOW DEFOGGER AND MIRROR DEFOGGER

## Wiring Diagram — DEF —/RHD Models


EL-DEF-02



Refer to last page (Foldout page).

(M5), (E101)  
 (M85), (E104)

# REAR WINDOW DEFOGGER AND MIRROR DEFOGGER



## Electrical Components Inspection

### REAR WINDOW DEFOGGER SWITCH

Check continuity between terminals when rear window defogger switch is pushed and released.


Terminals	Condition	Continuity
① - ②	Rear window defogger switch is pushed	Yes
	Rear window defogger switch is released	No

# AUDIO



## Wiring Diagram — AUDIO —/LHD Models Type-2

WITH 2 OR 4-SPEAKERS (Without CD deck) AND WITH 1-SPEAKER

EL-AUDIO-02



- (KU) : KA engine for Europe
- (4S) : Models with 4-speakers
- (PA) : Models with power antenna
- (PW) : Models with power window
- (WP) : Except (PW)
- \*1... (PW) BR/W, (WP) B/W
- \*2... (PW) BR, (WP) B




# AUDIO

## Wiring Diagram — AUDIO —/LHD Models Type-3

WITH 4-SPEAKERS (With CD deck)





EL-AUDIO-03



# AUDIO

## Wiring Diagram — AUDIO —/LHD Models Type-3 (Cont'd)


EL-AUDIO-04




# AUDIO

## Wiring Diagram — AUDIO —/RHD Models

EL-AUDIO-05





- ⬡2S: Models with 2 or 4-speakers
- ⬡4S: Models with 4-speakers
- ⬡PA: Models with power antenna
- ⬡PW: Models with power window
- ⬡WP: Except ⬡PW
- \*1... ⬡PW BR/W, ⬡WP B/W
- \*2... ⬡PW BR, ⬡WP B



# AUDIO ANTENNA

## Power Antenna/Wiring Diagram — P/ANT —

EL-P/ANT-01




Refer to last page (Foldout page).

(M5), (E101)

# POWER DOOR MIRROR

## Wiring Diagram — MIRROR —/LHD Models

EL-MIRROR-01



1	2	3	4	5	6	7	8	(D1)	(D34)				
9	10	11	12	13	14	15	16	17	18	19	20	W	W

1	2	3	(D4)	(D34)
GY	GY	GY	GY	

2	3	1	9	(D14)	
5	7	4	6	8	GY


HEL757A



# POWER DOOR MIRROR

## Wiring Diagram — MIRROR —/RHD Models

EL-MIRROR-03



1	2	3	4	5	6	7	8	(D1)	(D31)				
9	10	11	12	13	14	15	16	17	18	19	20	W	W


1	2	3	(D4)	(D34)
GY	GY			

2	3		1	9	(D14)	
5	7	4		6	8	GY

# HEATED SEAT

## Wiring Diagram — H/SEAT —



EL-H/SEAT-01



# HEATED SEAT

## Wiring Diagram — H/SEAT — (Cont'd)


EL-H/SEAT-02



\* : This connector is not shown in "HARNESS LAYOUT".

# POWER WINDOW



## Schematic/Without Interruption Detection Function



# POWER WINDOW

## Wiring Diagram — WINDOW —/Without Interruption Detection Function

EL-WINDOW-01



Refer to last page (Foldout page).

(M5), (E101)

(M85), (E104)



# POWER WINDOW

## Wiring Diagram — WINDOW —/Without Interruption Detection Function (Cont'd)

EL-WINDOW-02

Preceding page A W




: LHD models  
 : RHD models



# POWER WINDOW

## Wiring Diagram — WINDOW —/Without Interruption Detection Function (Cont'd)




EL-WINDOW-03



# POWER WINDOW

## Wiring Diagram — WINDOW —/Without Interruption Detection Function (Cont'd)

EL-WINDOW-04



HEL764A



# POWER WINDOW

## Trouble Diagnoses/Without Interruption Detection Function

Symptom	Possible cause	Repair order
None of the power windows can be operated using any switch.	<ol style="list-style-type: none"> <li>1. 30A fusible link and circuit breaker-1</li> <li>2. Grounds (M1) and (M54)</li> <li>3. Power window relay</li> <li>4. Open/short in power window main switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 30A fusible link (letter [b], located in fusible link and fuse box) and circuit breaker-1, located in fuse block. Turn ignition switch "ON" and verify battery positive voltage is present at terminal ① of power window main switch and terminal ⑤ of sub-switch.</li> <li>2. Check grounds (M1) and (M54).</li> <li>3. Check power window relay.</li> <li>4. Check harness between power window relay and power window main switch for open/short circuit.</li> </ol>
Driver side power window cannot be operated but other windows can be operated.	<ol style="list-style-type: none"> <li>1. Driver side power window regulator circuit</li> <li>2. Driver side power window regulator</li> </ol>	<ol style="list-style-type: none"> <li>1. Check harness between power window main switch and power window regulator for open or short circuit.</li> <li>2. Check driver side power window regulator.</li> </ol>
One or some of power window except driver side power window cannot be operated.	<ol style="list-style-type: none"> <li>1. Power window sub-switch</li> <li>2. Passenger side power window regulator</li> <li>3. Power window main switch</li> <li>4. Power window circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window sub-switch.</li> <li>2. Check power window regulator of malfunctioning power window.</li> <li>3. Check power window main switch.</li> <li>4-1. Check harnesses between power window main switch and power window sub-switch for open/short circuit.</li> <li>4-2. Check harnesses between power window sub-switch and power window regulator for open/short circuit.</li> </ol>
Passenger power window cannot be operated using power window main switch but can be operated by power window sub-switch.	<ol style="list-style-type: none"> <li>1. Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window main switch.</li> </ol>
Driver side power window auto function cannot be operated using power window main switch.	<ol style="list-style-type: none"> <li>1. Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window main switch.</li> </ol>

# POWER WINDOW

---

## System Description/With Interruption Detection Function

### OUTLINE

Power window system consists of

- CPU (combined with power window main switch)
- four power window regulators

When ignition switch is in the "ON" position, power window can be operated depending on power window sub/main switch condition.

### OPERATIVE CONDITION

- Power windows can be raised or lowered with each sub-switch or the power window main switch located on the driver's door trim when ignition switch is in the "ON" position and power window lock switch on the driver's door trim is unlocked.
- When power window lock switch is locked, no windows can be raised or lowered except for driver's side window.
- When ignition switch is in the "ON" position, to fully open/close the driver's side window, press down/pull up completely on the automatic switch (main switch) and release it; it needs not be held. The window will automatically open/close all the way. To stop the window, pull up/press down then release the switch.
- After turning ignition switch to OFF, the driver's side window can be raised or lowered for 15 minutes. The timer control for supplying power after turning ignition switch to "OFF" will be canceled when the driver's side door is closed. (Except models for Europe)

### INTERRUPTION DETECTION FUNCTION

CPU (combined with power window main switch) monitors the power window regulator motor operation and the power window position (full closed or other) for driver's power window by the signals from encoder and limit switch in front power window regulator (driver's side).

When CPU (combined with power window main switch) detects interruption during the following close operation in the driver's side door,

- automatic close operation when ignition switch is in the "ON" position
- automatic close operation during power window timer operation
- manual close operation during power window timer operation





CPU (combined with power window main switch) controls driver's power window regulator motor for open and the power window will be lowered about 150 mm (5.91 in).



# POWER WINDOW

## Wiring Diagram — WINDOW —/With Interruption Detection Function

EL-WINDOW-05






Refer to last page (Foldout page).

M5, E101

# POWER WINDOW

## Wiring Diagram — WINDOW —/With Interruption Detection Function (Cont'd)




EL-WINDOW-06



# POWER WINDOW

## Wiring Diagram — WINDOW —/With Interruption Detection Function (Cont'd)



EL-WINDOW-07



# POWER WINDOW

## Wiring Diagram — WINDOW —/With Interruption Detection Function (Cont'd)

EL-WINDOW-08



HEL769A

# POWER WINDOW

## Trouble Diagnoses/With Interruption Detection Function



Symptom	Possible cause	Repair order
None of the power windows can be operated using any switch.	<ol style="list-style-type: none"> <li>1. 10A fuse, 30A fusible link</li> <li>2. Ground circuit</li> <li>3. Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 10A fuse [No. 20], located in fuse block (J/B)], 30A fusible link (letter b), located in fuse and fusible link box).</li> <li>2. Check ground circuit of power window main switch terminal 19.</li> <li>3. Check power window main switch.</li> </ol>
Driver side power window cannot be operated but other windows can be operated.	<ol style="list-style-type: none"> <li>1. Driver side power window regulator circuit</li> <li>2. Driver side power window regulator</li> <li>3. M52 circuit breaker-2</li> <li>4. M52 circuit breaker-2 circuit</li> <li>5. Power window main switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check harness between power window main switch and driver side power window regulator for open or short circuit.</li> <li>2. Check driver side power window regulator.</li> <li>3. Check M52 circuit breaker-2.</li> <li>4. Check harness between M52 circuit breaker-2 and 30A fusible link (letter b), located in fuse and fusible link box).</li> <li>5-1. Check harness between power window main switch terminal 13 and 10A fuse [No. 20], located in fuse block (J/B)].</li> <li>5-2. Check harness between power window main switch terminal 5 and M52 circuit breaker.</li> </ol>
One or more power windows except driver's side window cannot be operated.	<ol style="list-style-type: none"> <li>1. Power window sub-switches</li> <li>2. Power window regulators</li> <li>3. Power window main switch</li> <li>4. Power window circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window sub-switch.</li> <li>2. Check power window regulator.</li> <li>3. Check power window main switch.</li> <li>4-1. Check harnesses between power window main switch and power window sub-switch for open/short circuit.</li> <li>4-2. Check harnesses between power window sub-switch and power window regulator for open/short circuit.</li> </ol>
Power windows except driver's side window cannot be operated using power window main switch but can be operated by power window sub-switch.	<ol style="list-style-type: none"> <li>1. Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window main switch.</li> </ol>
Driver side power window automatic operation does not function properly.	<ol style="list-style-type: none"> <li>1. Power window main switch</li> <li>2. Encoder and limit switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window main switch.</li> <li>2. Check encoder and limit switch. (EL-2121)</li> </ol>
Timer control for supplying power after turning ignition switch to "OFF" does not operate properly. (Except models for Europe)	<ol style="list-style-type: none"> <li>1. Driver side door switch circuit</li> <li>2. Driver side door switch</li> <li>3. Ignition switch ON signal circuit</li> <li>4. Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check harness between driver side door switch and power window main switch.</li> <li>2. Check driver side door switch.</li> <li>3. Check ignition switch ON signal circuit to power window main switch.</li> <li>4. Check power window main switch.</li> </ol>



# POWER WINDOW

## Trouble Diagnoses/With Interruption Detection Function (Cont'd)

### ENCODER AND LIMIT SWITCH CHECK



**CHECK DOOR WINDOW SLIDE MECHANISM**  
Check the following.

- Obstacles in window, glass molding, etc.
- Worn or deformed glass molding
- Door sash tilted too far inward or outward
- Door window regulator

NG → Remove obstacles or repair door window slide mechanism.

**A**  
**CHECK POWER SUPPLY TO LIMIT SWITCH**

1. Disconnect driver side power window regulator connector.
2. Turn ignition switch ON.
3. Check voltage between power window main switch terminal ⑨ and ground.  
**Approx. 5V should exist.**

NG → Replace power window main switch.

**CHECK LIMIT SWITCH OPERATION**

1. Turn ignition switch OFF.
2. Connect driver side power window regulator connector.
3. Turn ignition switch ON.
4. Check voltage between power window main switch terminal ⑨ and ground during power window closing operation.

**B**  
**CHECK ENCODER**  
Measure voltage between power window main switch terminal ⑯ and ground with oscilloscope when power window is in automatic closing operation.  
If check result is NG, replace power window regulator motor (front driver side).  
If check result is OK, replace power window main switch.

Terminal No.	Condition	Voltage (DCV)
⑨	Approx. 15 mm (0.59 in) below the full closed position to full closed position	Approx. 5
	Other positions	Approx. 0

**RESET LIMIT SWITCH**  
Reset limit switch. Refer to BT section. Then check voltage between power window main switch terminal ⑨ and ground during power window closing operation at least ten times.

NG → Replace power window regulator motor (front driver side).

Terminal No.	Condition	Voltage (DCV)
⑨	Approx. 15 mm (0.59 in) below the full closed position to full closed position	Approx. 5
	Other positions	Approx. 0

**B**  
**CHECK ENCODER**  
Measure voltage between power window main switch terminal ⑯ and ground with oscilloscope when power window is in automatic closing operation.

NG → Replace power window regulator motor (front driver side).

OK → Replace power window main switch.

# POWER DOOR LOCK

---

## System Description

Power is supplied at all times

- through 30A fusible link (Letter **b**, located in the fusible link and fuse box)
- to circuit breaker-1 (terminal ① of fuse block)
- through circuit breaker-1 (terminal ⑦ of fuse block)
- to smart entrance control unit terminal ⑪.

Ground is supplied to smart entrance control unit terminal ⑱ through body grounds **M1** and **M54**.

### INPUT

When the door lock & unlock switch (power window main switch) is in LOCKED position, ground signal is supplied

- to smart entrance control unit terminal ④
- through door lock & unlock switch terminal ⑭
- to door lock & unlock switch terminal ③
- through body grounds **M1** and **M54**.

When the door lock & unlock switch (power window main switch) is in UNLOCKED position, ground signal is supplied

- to smart entrance control unit terminal ⑤
- through door lock & unlock switch terminal ⑦
- to door lock & unlock switch terminal ③
- through body grounds **M1** and **M54**.

Driver side door key cylinder and driver side lock knob are connected to lock knob switch with a rod. When lock knob switch is in UNLOCKED position, ground signal is supplied

- to smart entrance control unit terminal ②
- through lock knob switch terminal ②
- to driver side lock knob switch terminal ①
- through body grounds **M1** and **M54**.

When lock knob switch is in LOCKED position, ground signal is interrupted.

Door lock operates according to the conditions of the door lock & unlock switch (power window main switch) and lock knob switch.

### OUTPUT

#### Unlock

Ground is supplied

- to passenger side door lock actuator, rear door lock actuator LH and RH terminal ① (double cab models)
- through smart entrance control unit terminal ⑮

Power is supplied

- to passenger side door lock actuator, rear door lock actuator LH and RH terminal ② (double cab models)
- through smart entrance control unit terminal ⑯

Then, the doors are unlocked.

#### Lock

Ground is supplied

- to passenger side door lock actuator, rear door lock actuator LH and RH terminal ②
- through smart entrance control unit terminal ⑯

Power is supplied




- to passenger side door lock actuator, rear door lock actuator LH and RH terminal ①
- through smart entrance control unit terminal ⑮

Then, the doors are locked.

# POWER DOOR LOCK


## Wiring Diagram — D/LOCK —

EL-D/LOCK-03



Refer to last page (Foldout page).


M5, E101



# POWER DOOR LOCK

## Wiring Diagram — D/LOCK — (Cont'd)

EL-D/LOCK-04



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(M62)  
W



1	2
3	4

(032)  
W



(038) GY, (056) GY, (076) GY

1	2
---	---


(052) W, (072) W

# POWER DOOR LOCK

## Trouble Diagnosis

### SYMPTOM CHART

REFERENCE PAGE	EL-2125	EL-2126	EL-2127	EL-2128
SYMPTOM	Main power supply and ground circuit check	Diagnostic procedure 1 (Door lock and unlock switch check)	Diagnostic procedure 2 (Door lock actuator check)	Diagnostic procedure 3 (Driver side lock knob switch check)
None of the doors lock/unlock when operating any switch.	X		X	
One or more doors are not locked and/or unlocked.			X	
Door lock and unlock switch does not operate.		X		
Lock knob switch on driver's door does not operate.				X




### MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK

#### Main power supply for door lock timer

Terminal		Ignition switch		
⊕	⊖	OFF	ACC	ON
⑪	Ground	Battery voltage	Battery voltage	Battery voltage

#### Ground circuit for door lock timer

Terminals	Continuity
⑱ - Ground	Yes





# POWER DOOR LOCK

## Trouble Diagnosis (Cont'd)

### DIAGNOSTIC PROCEDURE 1

#### (Door lock and unlock switch check)



**A**

**CHECK DOOR LOCK AND UNLOCK SWITCH INPUT SIGNAL.**

OK → Door lock and unlock switch is OK.

1. Disconnect smart entrance control unit connector.
2. Check continuity between control unit terminal ④ or ⑤ and ground.

Terminals	Door lock and unlock switch condition	Continuity
④ - Ground	Lock	Yes
	N and Unlock	No
⑤ - Ground	Unlock	Yes
	N and Lock	No

NG

**B**

**CHECK DOOR LOCK AND UNLOCK SWITCH.**

NG → Replace door lock and unlock switch.

1. Disconnect door lock and unlock switch connector.
2. Check continuity between power window main switch (Door lock and unlock switch) terminals.

Condition	Terminals		
	3	7	14
Lock	○	○	○
N	No continuity		
Unlock	○	○	○

OK



- Check the following.
- Ground circuit for door lock and unlock switch
  - Harness for open or short between door lock and unlock switch and smart entrance control unit connector

# POWER DOOR LOCK

## Trouble Diagnosis (Cont'd)

### DIAGNOSTIC PROCEDURE 2

#### (Door lock actuator check)



**A**

**CHECK DOOR LOCK ACTUATOR CIRCUIT.**  
Check voltage for door lock actuator.

NG → Replace door lock timer. (Before replacing control unit, perform DIAGNOSTIC PROCEDURE 1.)

Lock knob switch condition	Terminals		Voltage V
	⊕	⊖	
Lock	(15)	Ground	Battery voltage
Unlock	(16)	Ground	

OK

**B**

**CHECK DOOR LOCK ACTUATOR.**  
1. Disconnect door lock actuator connector.  
2. Apply 12V direct current to door lock actuator and check operation.

NG → Replace door lock actuator.

Door lock actuator operation	Terminals	
	⊕	⊖
Unlocked → Locked	(1)	(2)
Locked → Unlocked	(2)	(1)

OK



Repair harness between smart entrance control unit connector and door lock actuator.

# POWER DOOR LOCK

## Trouble Diagnosis (Cont'd)

### DIAGNOSTIC PROCEDURE 3

#### (Driver side lock knob switch check)



**A**

**CHECK LOCK KNOB SWITCH INPUT SIGNAL.**  
Check voltage between smart entrance control unit terminal ② and ground.

OK → Driver side lock knob switch is OK.

Lock knob switch condition	Voltage V
Lock	Approx. 12
Unlock	0

NG

**B**

**CHECK LOCK KNOB SWITCH.**  
1. Disconnect driver side lock knob switch connector.  
2. Check continuity between lock knob switch terminals.

NG → Replace lock knob switch.

Terminals	Condition	Continuity
① - ②	Locked	No
	Unlocked	Yes

OK

Check the following.

- Ground circuit for lock knob switch
- Harness for open or short between lock knob switch and smart entrance control unit



# MULTI-REMOTE CONTROL SYSTEM

---

## System Description

### FUNCTION

Multi-remote control system has the following function.

- Door lock
- Door unlock
- Hazard reminder

### LOCK OPERATION

To lock door by multi-remote controller, the following two signals must be received.

- Key switch OFF (when ignition key is not in ignition key cylinder.)
- All door switches CLOSED

When the LOCK signal is input to multi-remote control unit (the antenna of the system is combined with multi-remote control unit), ground is supplied

- through multi-remote control unit terminal ⑩
- to smart entrance control unit terminal ④ and
- to door lock relay terminal ⑥.

Then smart entrance control unit operates to lock doors (except for driver's door) and door lock relay energized to lock driver's door.

### UNLOCK OPERATION

To unlock door by multi-remote controller, the following signal must be received.

- Key switch OFF (when ignition key is not in ignition key cylinder)

When the UNLOCK signal is input to multi-remote control unit (the antenna of the system is combined with multi-remote control unit), ground is supplied

- through multi-remote control unit terminal ⑪
- to smart entrance control unit terminal ⑤ and
- to door lock relay terminal ⑤.

Then smart entrance control unit operates to unlock doors (except for driver's door) and door lock relay is energized to unlock driver's door.

### HAZARD REMINDER

When the doors are locked or unlocked by multi-remote controller, ground is supplied

- to terminal ① of multi-remote control relay-1 and 2
- through multi-remote control unit terminal ⑫.

Then the relays are energized and hazard warning lamp flashes as follows

- Lock operation: Flash once
- Unlock operation: Flash twice

### MULTI-REMOTE CONTROLLER ID CODE ENTRY

A maximum of four remote controllers can be entered. Any attempt to enter a remote controller will erase all ID codes previously entered. Therefore, be sure to receive all remote controllers from the vehicle owner when any ID code entry is performed.


To enter ID code entry, the following signals must be input to the multi-remote control unit.

- Driver side LOCKED signal (from driver side door unlock sensor)
- Door switch CLOSED signal
- Key switch signal (INSERTED/WITHDRAWN)
- Accessory power supply
- Signal from remote controller

For detailed procedure, refer to "ID Code Entry Procedure" in EL-2139.

# MULTI-REMOTE CONTROL SYSTEM



## Schematic



# MULTI-REMOTE CONTROL SYSTEM

## Wiring Diagram — MULTI —

EL-MULTI-01






Refer to last page (Foldout page).

(M5), (E101)

# MULTI-REMOTE CONTROL SYSTEM

## Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-02






HEL775A

# MULTI-REMOTE CONTROL SYSTEM

## Wiring Diagram — MULTI — (Cont'd)




EL-MULTI-03



# MULTI-REMOTE CONTROL SYSTEM

## Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-04



# MULTI-REMOTE CONTROL SYSTEM

## Trouble Diagnoses

### SYMPTOM CHART

Symptom	Possible cause	Diagnoses/service order
No doors can be locked or unlocked by remote control operation. (See NOTE.)	<ol style="list-style-type: none"> <li>1. Remote controller battery</li> <li>2. Key switch (insert)</li> <li>3. Door switch</li> <li>4. Power supply circuit for multi-remote control unit</li> <li>5. Ground circuit for multi-remote control unit</li> <li>6. Remote controller</li> </ol>	<ol style="list-style-type: none"> <li>1. Check remote controller battery. Refer to EL-2136.</li> <li>2. Check key switch (insert) signal at terminal ⑦ of multi-remote control unit.</li> <li>3. Check door switch signal at terminals ① and ② of multi-remote control unit.</li> <li>4. Make sure battery voltage is present at terminal ③ of multi-remote control unit.</li> <li>5. Check continuity between terminal ⑤ of multi-remote control unit and ground.</li> <li>6. Replace remote controller. Refer to EL-2139.</li> </ol>
Driver's door cannot be locked or unlocked by remote controller operation.	Driver side door lock actuator circuit	Check driver side door lock actuator circuit. Refer to EL-2137.
Doors other than driver side cannot be locked or unlocked by remote control operation. (If the power door lock system does not operate correctly, check power door lock system. Refer to EL-2122.)	Lock/unlock signal to smart entrance control unit	<ul style="list-style-type: none"> <li>● When locking is not possible: Check continuity between terminal ⑩ of multi-remote control unit and terminal ④ of smart entrance control unit.</li> <li>● When unlocking is not possible: Check continuity between terminal ⑪ of multi-remote control unit and terminal ⑤ of smart entrance control unit.</li> </ul>
Hazard reminder does not operate properly.	<ol style="list-style-type: none"> <li>1. 10A fuse</li> <li>2. Multi-remote control relay-1 and 2</li> <li>3. Hazard reminder circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 10A fuse (No. ⑤, located in the fuse block).</li> <li>2. Check multi-remote control relay-1 and 2.</li> <li>3. Check harness for open or short between relays and multi-remote control unit terminal ⑫.</li> </ol>
The new ID of remote controller cannot be entered.	<ol style="list-style-type: none"> <li>1. Remote controller battery</li> <li>2. Key switch (insert)</li> <li>3. Door switch</li> <li>4. Driver's door unlock sensor</li> <li>5. Accessory power supply circuit for multi-remote control unit</li> <li>6. Remote controller</li> </ol>	<ol style="list-style-type: none"> <li>1. Check remote controller battery. Refer to EL-2136.</li> <li>2. Check key switch (insert) signal at terminal ⑦ of multi-remote control unit.</li> <li>3. Check door switch signal at terminals ① and ② of multi-remote control unit.</li> <li>4. Check driver's door unlock sensor signal at terminal ⑥ of multi-remote control unit.</li> <li>5. Make sure battery voltage is present at terminal ⑧ of multi-remote control unit while ignition switch is in ACC position.</li> <li>6. Replace remote controller. Refer to EL-2139.</li> </ol>

Refer to "MULTI-REMOTE CONTROL UNIT INSPECTION TABLE" on next page to check the control unit signals.

**NOTE:**



- Always check remote controller battery before replacing remote controller.
- The unlock operation of multi-remote control system does not activate with key inserted in the ignition key cylinder.
- The lock operation of multi-remote controller does not activate with the key inserted ignition key cylinder or if one of the door is opened.

# MULTI-REMOTE CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### MULTI-REMOTE CONTROL UNIT INSPECTION TABLE

Terminal No.	Connections	Condition		Voltage V (approximate values)
1	Driver side door switch	Driver side door	Opened	0
			Closed	12
2	Door switch (all doors)	One of doors is opened		0
		All doors are closed		12
3	Power source (BAT)	—		12
5	Ground	—		—
6	Driver side door unlock sensor	Driver side door	Locked	5
			Unlocked	0
7	Key switch (insert)	Key is in ignition key cylinder		12
		Key is not in ignition key cylinder		0
8	Accessory power supply	Ignition switch	OFF	0
			ACC or ON	12
10	Lock signal	Remote controller LOCK button is pushed (All doors are closed and key is not in ignition key cylinder.)		0
		Other than above condition		12
11	Unlock signal	Remote controller UNLOCK button is pushed (Key is not in ignition key cylinder.)		0
		Other than above condition		12
12	Multi-remote control relay-1, 2	Remote controller LOCK/UNLOCK button is pushed (All doors are closed and key is not in ignition key cylinder.)		0
		Other than above condition		12



### REMOTE CONTROLLER BATTERY CHECK

Remove battery and measure voltage across battery positive and negative terminals, ⊕ and ⊖.

Measuring terminal		Standard value
⊕	⊖	
Battery positive terminal ⊕	Battery negative terminal ⊖	2.5 - 3.0V

**Note:**


**Remote controller does not function if battery is not set correctly.**



# MULTI-REMOTE CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)


### DRIVER SIDE DOOR LOCK ACTUATOR CHECK



**CHECK DOOR LOCK RELAY.**  
Refer to EL-2138.

NG → Replace the relay.

OK




**CHECK POWER SUPPLY FOR DOOR LOCK RELAY.**  
Check voltage between door lock relay terminal ③ and ground.  
**Battery voltage should exist.**

NG → Check the following.

- 30A fusible link (letter **b**), located in fusible link and fuse box) (No. **3**), located in the fusible link and fusible link box).
- Check harness for open or short between fusible link and relay.


OK



**CHECK GROUND CIRCUIT FOR DOOR LOCK RELAY.**  
Check continuity between door lock relay terminal ② and ground.  
**Continuity should exist.**

NG → Repair harness.


OK



**CHECK LOCK SIGNAL FOR DOOR LOCK RELAY.**  
Check continuity between door lock relay terminal ⑥ and multi-remote control unit terminal ⑩.  
**Continuity should exist.**

NG → Check harness for open or short between door lock relay and multi-remote control unit.

OK



**CHECK UNLOCK SIGNAL FOR DOOR LOCK RELAY.**  
Check continuity between door lock relay terminal ⑤ and multi-remote control unit terminal ⑪.  
**Continuity should exist.**

NG → Check harness for open or short between door lock relay and multi-remote control unit.

OK

**CHECK DOOR LOCK ACTUATOR CIRCUIT.**

1. Connect the relays.
2. Disconnect driver side door lock actuator.
3. Check continuity between driver side door lock actuator and door lock relay.  
**Continuity should exist.**

NG → Check harness for open or short between door lock relay and door lock actuator.


OK

Replace door lock actuator.

# MULTI-REMOTE CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### DOOR LOCK RELAY CHECK



Condition		Continuity between terminals					
		1	2	3	4	5	6
Battery voltage not applied between each terminal	③ and ⑤	○	○				
	③ and ⑥		○		○		
Battery voltage applied between each terminal	③ and ⑤	○		○			
	③ and ⑥			○	○		
Always				○		○	○

#### CAUTION:

While applying battery voltage to relay terminals, insert fuse into the circuit.

# MULTI-REMOTE CONTROL SYSTEM

## ID Code Entry Procedure

### Note:


A maximum of four remote controllers can be entered. Any attempt to enter a remote controller will erase all ID codes previously entered. Therefore, be sure to receive all remote controllers from the vehicle owner when any ID code entry is performed.

Enter the identity (ID) code manually when:

- remote controller or control unit is replaced.
- an additional remote controller is activated.

To enter the ID code, follow the procedures below.

### PROCEDURE




### NOTE:

- If you need to activate more than two additional new remote controllers, repeat the procedure "Additional ID code entry" for each new remote controller.
- Any ID codes cannot be entered after termination of the "setting mode".


# NATS (Nissan Anti-Theft System)/Models with KA24E

## Wiring Diagram — NATS —

EL-NATS-01



Refer to EL-POWER.



Refer to last page (Foldout page).




(M5), (E101)

(M32)

# NATS (Nissan Anti-Theft System)/Diesel engine

## Wiring Diagram — NATS —/LHD Models

EL-NATS-02




Refer to last page (Foldout page).

(M5), (E101)

# NATS (Nissan Anti-Theft System)/Diesel engine


## Wiring Diagram — NATS —/RHD Models

EL-NATS-03



Refer to EL-POWER.


Refer to last page (Foldout page).



(M5), (E101)

# LOCATION OF ELECTRICAL UNITS

## Engine Compartment



### RELAY BOX

- ECM relay (KM)
- Fuel pump relay (XM)
- Automatic choke relay (Z engine)
- Fuel heater relay (RHD models for Europe)


- ECM relay (XM)
- Fuel pump relay (KM)
- Cooling fan relay (TD27 and QD32 engines with air conditioner)

- Horn relay
- Air conditioner relay

- Cooling fan relay (KM)
- Defogger relay (NR)
- Park/Neutral position relay (A/T models)
- Relay box-2
- Defogger relay (RHD A/T models)
- Cooling fan relay (LHD A/T models)

- Fuse
- Relay box-1
- Dropping resistor (A/T models)


- (KM) : KA engine M/T models for the Middle East
- (XM) : KA engine except (KM)
- (NR) : Except RHD A/T models



# LOCATION OF ELECTRICAL UNITS

## Passenger Compartment

### LHD MODELS




HEL784A



# LOCATION OF ELECTRICAL UNITS

## Passenger Compartment (Cont'd)


### RHD MODELS



# HARNESS LAYOUT

## Main Harness

### INSTRUMENT PANEL — LHD MODELS



# HARNESS LAYOUT

## Main Harness (Cont'd)

A4 (M1)	—	: Body ground	E1 (M35)	W/10	: Audio unit	F1 (M74)	W/2	: Intake air temperature sensor (With auto A/C)
A4 (M2)	W/2	: Warning buzzer (Diesel engine except for Europe and the Middle East)	E1 (M36)	W/6	: Audio unit (KA24E and with 4-speakers radio)	F1 (M75)	B/2	: Sunload sensor (With auto A/C)
A4 (M3)	W/20	: To (D1)	F3 (M37)	B/2	: Cigarette lighter	B4-G4 (M76)	W/6	: Door lock relay (★1)
A3 (M4)	W/12	: To (D2) (With power window)	G2 (M38)	W/3	: A/C switch (Without auto A/C)	D3 (M77)	BR/2	: Key switch (For Turkey)
A3 (M5)	SMJ	: To (E101)	G2 (M39)	W/6	: Fan switch (Without auto A/C)	C3 (M78)	L/2	: Shift lock brake switch (A/T models)
B3 (M6)	W/24	: To (N1)	E2 (M40)	W/2	: Fan switch illumination (Without auto A/C)	E4 (M79)	Y/12	: Air bag diagnosis sensor unit (With pre-tensioner seat belt)
A3 (M7)	BR/24	: To (N2)	E2 (M41)	W/8	: Hazard switch	E4 (M80)	Y/20	: Air bag diagnosis sensor unit
A2 (M8)	-/2	: Diode (Diesel engine except for Europe and the Middle East)	E2 (M42)	W/6	: Defogger switch (For Europe and SE grade with diesel engine)	F4 (M81)	Y/12	: Air bag diagnosis sensor unit (With pre-tensioner seat belt)
C3 (M9)	L/4	: Accessory relay	G1 (M43)	Y/2	: Air bag module passenger side	F4 (M82)	W/2	: Jumping connector
B4 (M10)	—	: Fuse block	F1 (M44)	BR/4	: Thermo control amplifier	B4 (M83)	L/10	: Diode (KA24DE)
C3 (M11)	GY/14	: Data link connector for CONSULT (With air bag, ABS or ECM)	G2 (M45)	BR/4	: Fan resistor (Without auto A/C)	A3 (M84)	BR/2	: Resistor (A/T models)
B3 (M12)	W/6	: Fuse block	G2 (M46)	W/2	: Blower motor	E3 (M86)	BR/10	: Mode door motor (With auto A/C)
B4 (M13)	B/10	: Check connector (Z24S)	G3 (M49)	W/20	: To (D31)	E3 (M87)	W/2	: In-vehicle sensor (With auto A/C)
B3 (M14)	W/4	: Fuse block	G3 (M50)	W/6	: To (D32) (With power window)	F3 (M88)	GY/20	: A/C auto amp. (With auto A/C)
E3 (M15)	B/3	: Combination flasher unit	F3 (M51)	W/8	: Door lock timer (With power window except for Europe)	G3 (M89)	GY/4	: A/C auto amp. (With auto A/C)
C3 (M16)	B/2	: Stop lamp switch	G3 (M52)	W/2	: Circuit breaker-2 (For Europe)	G3 (M90)	L/2	: Aspirator motor (With auto A/C)
C2 (M17)	W/16	: To (M18) (With air bag)	G3 (M54)	—	: Body ground	G2 (M91)	B/6	: Air mix door motor (With auto A/C)
B1 (M18)	W/16	: To (M17) (With air bag)	F1 (M55)	W/2	: NATS security indicator (For Europe)	F1 (M92)	W/4	: Fan control amp. (With auto A/C)
A1 (M19)	W/6	: To (R1)	A3 (M56)	-/2	: Diode (★1)	F1 (M93)	W/4	: Intake door motor (With auto A/C)
D3 (M20)	W/6	: Ignition switch	B2 (M57)	-/2	: Diode (★1)	<b>Sub-harness</b>		
C2 (M21)	W/1	: Parking brake switch (Stick type)	C2 (M58)	W/12	: Multi-remote control unit (★1)	D1 (M501)	W/10	: To (M35)
G4 (M22)	W6	: Fuel pump control module (Z24S)	F3 (M59)	BR/6	: Multi-remote control relay-2 (★1)	D2 (M502)	W/10	: Audio unit
D2 (M23)	BR/8	: Lighting switch	F4 (M60)	B/5	: Multi-remote control relay-1 (★1)	E1 (M503)	W/4	: Compact disk deck
D2 (M24)	BR/4	: Turn signal lamp switch	F4 (M61)	B/2	: Jumping connector (★1)	Diode (M8)		
D3 (M25)	Y/7	: Lighting switch	F3 (M62)	W/18	: Smart entrance control unit (For Europe)			
C3 (M26)	L/2	: Spiral cable (With air bag)	D2 (M63)	W/3	: Rear fog lamp switch (For Europe and China)			
D2 (M27)	B/1	: A/T check switch (A/T models)	D3 (M64)	W/2	: Key switch (For Europe except Single cab)	<p>★1 : With multi-remote control system ★2 : For Europe...Smart entrance control unit Except for Europe...Door lock timer</p>		
D2 (M28)	GY/8	: Horn switch (Without air bag)	D3 (M65)	W/4	: Smart entrance control unit (For Europe)			
C3 (M29)	W/12	: Wiper and washer switch	D3 (M66)	W/4	: Diode (★1)			
D2 (M30)	W/16	: Glow control unit (TD27 engine except for cold areas and QD engine)	D3 (M67)	GY/20	: NATS antenna amp. (Diesel engine for Europe)			
D4 (M31)	GY/6	: Joint connector-1 (KA engine)	C3 (M67)	GY/16	: ECM (Diesel engine for Europe)			
D4 (M32)	W/64	: ECM (KA24E)	E3 (M68)	W/8	: ECM (Diesel engine for Europe)			
E4 (M33)	—	: Body ground (KA24E)	B2 (M70)	W/24	: NATS IMMUI (KA24E)			
F3 (M34)	W/2	: Ashtray illumination (GL and S-GL grade for the Middle East)	B2 (M71)	W/24	: TCM (Transmission control module) (A/T models)			
			C2 (M72)	-/6	: TCM (Transmission control module) (A/T models)			
					: Joint connector-2 (A/T models)			

# HARNESS LAYOUT

## Main Harness (Cont'd)

### INSTRUMENT PANEL — RHD MODELS




# HARNESS LAYOUT

## Main Harness (Cont'd)


G4 (M1)	—	: Body ground	B1 (M44)	BR/4	: Thermo control amplifier	D4 (M80)	Y/20	: Air bag diagnosis sensor unit
A3 (M2)	W/2	: Warning buzzer (Diesel engine except for Europe and Australia)	A2 (M45)	BR/4	: Fan resistor (Without auto A/C)	A4 (M83)	L/10	: Diode (KA engine)
G4 (M3)	W/20	: To (D1)	A2 (M46)	W/2	: Blower motor	A1 (M84)	BR/2	: Resistor (A/T models)
G3 (M4)	W/12	: To (D2) (With power window)	A2 (M47)	W/16	: To (F55) (KA engine)	G3 (M85)	SMJ	: To (E104) (A/T models)
G3 (M5)	SMJ	: To (E101) (M/T models)	A2 (M48)	W/24	: To (F54) (KA engine)	D3 (M86)	BR/10	: Mode door motor (With auto A/C)
F4 (M6)	W/24	: To (N1)	A3 (M49)	W/20	: To (D31)	D3 (M87)	W/2	: In-vehicle sensor (With auto A/C)
G2 (M7)	BR/24	: To (N2)	A3 (M50)	W/6	: To (D32) (With power window)	B3 (M88)	GY/20	: A/C auto amp. (With auto A/C)
F4 (M9)	L/4	: Accessory relay	B3 (M51)	W/8	: Door lock timer (With power window except for Europe)	B3 (M89)	GY/4	: A/C auto amp. (With auto A/C)
F4 (M10)	—	: Fuse block	G3 (M52)	W/2	: Circuit breaker-2 (For Europe)	B3 (M90)	L/2	: Aspirator motor (With auto A/C)
E4 (M11)	GY/14	: Data link connector for CONSULT (With air bag, ABS or ECM)	B4 (M53)	W/8	: Seat belt timer (For Australia)	B3 (M91)	B/6	: Air mix door motor (With auto A/C)
F3 (M12)	W/6	: Fuse block	A3 (M54)	—	: Body ground	C1 (M92)	W/4	: Fan control amp. (With auto A/C)
F4 (M13)	B/10	: Check connector (Z engine)	B1 (M55)	W/2	: NATS security indicator (For Europe)	B1 (M93)	W/4	: Intake door motor (With auto A/C)
F3 (M14)	W/4	: Fuse block	A1 (M56)	-/2	: Diode (For multi-remote control system)	C1 (M94)	W/12	: To (M95) (With air bag)
C4 (M15)	B/3	: Combination flasher unit	F2 (M57)	-/2	: Diode (For multi-remote control system)	C1 (M95)	W/12	: To (M94) (With air bag)
E3 (M16)	B/2	: Stop lamp switch	F2 (M58)	W/12	: Multi-remote control unit (For multi-remote control system)			
F1 (M19)	W/6	: To (R1)	C4 (M59)	BR/6	: Multi-remote control relay-2 (For Europe except Single cab)			
E3 (M20)	W/6	: Ignition switch	C4 (M60)	B/5	: Multi-remote control relay-1			
D1 (M21)	W/1	: Parking brake switch (Stick type)	C4 (M61)	B/2	: Jumping connector (For Europe except Single cab)			
F4 (M22)	W/6	: Fuel pump control module (Z engine)	B4 (M62)	W/18	: Smart entrance control unit (For Europe)			
D2 (M23)	BR/8	: Lighting switch	D3 (M63)	W/3	: Rear fog lamp switch (For Europe)			
D2 (M24)	BR/4	: Turn signal lamp switch	E3 (M64)	W/2	: Key switch (For Europe except Single cab)			
D3 (M25)	Y/7	: Lighting switch	E2 (M65)	W/4	: NATS antenna amp. (For Europe)			
D3 (M27)	B/1	: Spiral cable (With air bag)	D4 (M66)	GY/20	: ECM (Diesel engine for Europe)			
D2 (M28)	GY/8	: Horn switch (Without air bag)	D4 (M67)	GY/16	: ECM (Diesel engine for Europe)			
D4 (M29)	W/12	: Wiper and washer switch	E1 (M70)	W/24	: TCM (Transmission control module) (A/T models)			
		: Glow control unit (TD27 engine except for Australia and QD engine)	E1 (M71)	GY/24	: TCM (Transmission control module) (A/T models)			
D4 (M30)	W/16	: Glow control unit (TD27 engine for Australia)	D1 (M72)	-/6	: Joint connector-2 (A/T models)			
C1 (M35)	W/10	: Audio unit	E1 (M73)	W/4	: A/T device (A/T models)			
C1 (M36)	W/6	: Audio unit (Double cab models)	B1 (M74)	W/2	: Intake air temperature sensor (With auto A/C)			
C3 (M37)	B/2	: Cigarette lighter	B1 (M75)	B/2	: Sunload sensor (With auto A/C)			
C3 (M38)	W/3	: A/C switch (Without auto A/C)	B4 (M76)	W/6	: Door lock relay (For Europe except Single cab)			
C2 (M39)	W/6	: Fan switch (Without auto A/C)	E4 (M78)	L/2	: Shift lock brake switch (A/T models)			
C2 (M40)	W/2	: Fan switch illumination (Without auto A/C)						
C2 (M41)	W/8	: Hazard switch						
C2 (M42)	W/6	: Defogger switch (For Europe and with power window)						
A2 (M43)	Y/2	: Air bag module passenger side						

### Engine compartment




(M221) W/6 : Wiper motor (Except KA engine)

Diode (M56, M57)



Diode (M83)






# HARNESS LAYOUT

## Main Harness (Cont'd)


### BODY SIDE — LHD MODELS



# HARNESS LAYOUT

## Main Harness (Cont'd)


### BODY SIDE — RHD MODELS



# HARNESS LAYOUT

## Engine Room Harness

LHD MODELS — GASOLINE ENGINE






# HARNESS LAYOUT

## Engine Room Harness (Cont'd)


- E1 (E54) B/5 : Automatic choke relay (Z engine)  
 L/4 : Fuel pump relay (KA engine except M/T models for the Middle East)  
 BR/6 : ECM relay (KA engine M/T models for the Middle East)  
 L/4 : Cooling fan relay (KA engine M/T models for the Middle East)  
 BR/6 : Park/Neutral position (PNP) relay (A/T models)  
 BR/6 : Defogger relay (For Europe)  
 GY/6 : Headlamp aiming motor LH (For Europe)  
 GY/2 : Headlamp washer motor (For Europe)  
 A3 (E60) GY/6 : Headlamp aiming motor RH (For Europe)  
 C1 (E63) GY/6 : Daytime light unit (With daytime light system)  
 B1 (E64) GY/8 : Daytime light unit (With daytime light system)  
 B1 (E65) W/6 : Headlamp washer amplifier (For Europe)  
 C3 (E69) BR/2 : Ambient temperature switch (KA24DE engine)  
 D2 (E70) — : Relay box-2 (A/T models)  
 F1 (E71) L/4 : Cooling fan relay (A/T models)

### PASSENGER COMPARTMENT



- (E101) SMJ : To (M5)  
 (E103) B/2 : Fuse block

Resistor (E9)




- G3 (E1) B/2 : Side turn signal lamp LH (For Europe and China)  
 F2 (E2) GY/2 : Brake fluid level switch  
 F2 (E3) GY/3 : Heated oxygen sensor (KA24E engine)  
 G3 (E4) B/31 : ABS actuator and electric unit (For ABS)  
 E3 (E6) — : Body ground  
 F2 (E7) — : Ignition coil (Z engine)  
 F3 (E8) — : Ignition coil (Z engine)  
 F3 (E9) -/2 : Resistor (Z engine)  
 F3 (E10) W/2 : Condenser (Z engine)  
 F4 (E11) GY/3 : Front combination lamp LH (Except for Europe and China)  
 E4 (E12) BR/3 : Front combination lamp LH (For Europe and China)  
 E5 (E13) B/3 : Headlamp LH  
 D5 (E14) GY/2 : Washer motor  
 D3 (E15) BR/2 : Front wheel sensor LH (For ABS)  
 D4 (E18) GY/2 : Not used (KA engine for the Middle East)  
 E3 (E19) GY/3 : Distributor (Z engine)  
 D4 (E21) B/1 : Compressor (Z engine)  
 B3 (E22) B/1 : Horn low  
 C4 (E23) B/1 : Horn high  
 B3 (E24) GY/2 : Cooling fan motor (KA engine for the Middle East)  
 B4 (E25) B/4 : Triple-pressure switch  
 A3 (E26) B/3 : Headlamp RH  
 A2 (E27) GY/3 : Front combination lamp RH (Except for Europe and China)  
 A2 (E28) BR/3 : Front combination lamp RH (For Europe and China)  
 B2 (E29) GY/2 : To (E204)  
 B2 (E30) B/8 : To (E203)  
 C3 (E31) GY/2 : Front wheel sensor RH (For ABS)  
 B1 (E32) — : Relay box-1 (Fusible link and fuse box)  
 C2 (E33) GY/8 : To (E205) (KA engine)  
 C2 (E34) B/1 : Battery  
 G2 (E36) B/1 : ISC-FI pot control solenoid valve (Z engine)  
 G2 (E37) B/1 : ISC-FI pot control solenoid valve (Z engine)  
 D2 (E39) — : Body ground  
 C1 (E45) B/2 : Side turn signal lamp RH (For Europe and China)  
 D1 (E46) GY/3 : Power antenna  
 (For the Middle East except 4WD models with ABS)  
 E1 (E50) — : Fusible link and fuse box  
 D1 (E51) L/4 : Air conditioner relay  
 D1 (E52) W/3 : Horn relay  
 E1 (E53) L/4 : ECM relay (KA engine for Europe)  
 BR/6 : ECM relay (KA engine M/T models except for Europe and the Middle East, and A/T models)  
 L/4 : Fuel pump relay (KA engine M/T models for the Middle East)

# HARNESS LAYOUT

## Engine Room Harness (Cont'd)

LHD MODELS — DIESEL ENGINE




# HARNESS LAYOUT

## Engine Room Harness (Cont'd)

- D4 **E57** GY/6 : Headlamp aiming motor LH (For Europe)
- D5 **E58** GY/2 : Headlamp washer motor (For Europe)
- B4 **E59** B/2 : Ambient sensor (For auto A/C)  
(For Europe except 2WD models with ABS)
- A3 **E60** GY/6 : Headlamp aiming motor RH (For Europe)
- C1 **E63** GY/6 : Daytime light unit (With daytime light system)
- C1 **E64** GY/8 : Daytime light unit (With daytime light system)
- C1 **E65** W/6 : Headlamp washer amplifier (For Europe)
- E3 **E68** GY/10 : To **A13**

### PASSENGER COMPARTMENT




- E101** SM/J : To **M5**
- E103** B/2 : Fuse block

- G3 **E1** B/2 : Side turn signal lamp LH (For Europe)
- F2 **E2** GY/2 : Brake fluid level switch
- G2 **E4** B/31 : ABS actuator and electric unit (For ABS)
- F3 **E6** — : Body ground
- F4 **E11** GY/3 : Front combination lamp LH (Except for Europe)
- E4 **E12** BR/3 : Front combination lamp LH (For Europe)
- E5 **E13** B/3 : Headlamp LH
- D5 **E14** GY/2 : Washer motor
- E3 **E15** BR/2 : Front wheel sensor LH (For ABS)
- E3 **E17** B/2 : To **A2**
- D3 **E18** GY/2 : Thermostat (Except TD27 engine except for the Middle East and TD engine 2WD models with ABS for Europe)
- C3 **E22** B/1 : Horn low
- C4 **E23** B/1 : Horn high
- B3 **E24** GY/2 : Cooling fan motor (Except TD27 engine except for the Middle East and TD engine 2WD models with ABS for Europe)
- B4 **E25** B/4 : Triple-pressure switch
- A3 **E26** B/3 : Headlamp RH
- A2 **E27** GY/3 : Front combination lamp RH (Except for Europe)
- A2 **E28** BR/3 : Front combination lamp RH (For Europe)
- B2 **E29** GY/2 : To **E204**
- B1 **E30** B/8 : To **E203** (For Europe)
- C3 **E31** GY/2 : Front wheel sensor RH (For ABS)
- B1 **E32** — : Relay box (Fusible link and fuse box)
- B1 **E33** GY/8 : To **E205**
- B2 **E35** B/1 : To **E206**
- C3 **E36** B/1 : IACV-FICD solenoid valve
- C3 **E37** B/1 : IACV-FICD solenoid valve
- D3 **E38** GY/1 : Vacuum warning switch
- D2 **E39** — : Body ground
- C1 **E45** B/2 : Side turn signal lamp RH (For Europe)
- D1 **E46** GY/3 : Power antenna (For Europe except 2WD models with ABS)
- F1 **E50** — : Fusible link and fuse box
- F1 **E51** L/4 : Air conditioner relay
- F1 **E52** W/3 : Horn relay
- F1 **E53** L/4 : Cooling fan relay (Except TD27 engine except for the Middle East and TD engine 2WD models with ABS for Europe)
- G1 **E55** L/4 : Defogger relay (Except for the Middle East)

# HARNESS LAYOUT

## Engine Room Harness (Cont'd)

RHD MODELS — GASOLINE ENGINE




# HARNESS LAYOUT

## Engine Room Harness (Cont'd)


- D2 (E77) GY/2 : Park/Neutral position (PNP) switch (A/T models)
- D2 (E78) GY/8 : Park/Neutral position (PNP) switch (A/T models)
- D2 (E79) BR/8 : To terminal cord assembly (A/T models)
- C2 (E80) GY/3 : Revolution sensor (A/T models)

### PASSENGER COMPARTMENT



- (E101) SMJ : To (M5) (M/T models)
- (E103) B/2 : Fuse block
- (E104) SMJ : To (M85) (A/T models)

Resistor (E9)




- G3 (E1) B/2 : Side turn signal lamp LH (For Australia)
- D2 (E2) GY/2 : Brake fluid level switch
- E3 (E6) — : Body ground
- F2 (E7) — : Ignition coil (Z engine)
- F3 (E8) — : Ignition coil (Z engine)
- F3 (E9) -/2 : Resistor (Z engine)
- F3 (E10) W/2 : Condenser (Z engine)
- F4 (E11) GY/3 : Front combination lamp LH (Except for Australia)
- E4 (E12) BR/3 : Front combination lamp LH (For Australia)
- E5 (E13) B/3 : Headlamp LH
- D5 (E14) GY/2 : Washer motor
- E3 (E19) GY/3 : Distributor (Z engine)
- E3 (E21) B/1 : Compressor (Z engine)
- B3 (E22) B/1 : Horn low
- B4 (E25) B/4 : Triple-pressure switch
- A3 (E26) B/3 : Headlamp RH
- A2 (E27) GY/3 : Front combination lamp RH (Except for Australia)
- A2 (E28) BR/3 : Front combination lamp RH (For Australia)
- B2 (E29) GY/2 : To (E204)
- B2 (E30) B/8 : To (E203)
- B1 (E32) — : Relay box-1 (Fusible link and fuse box)
- C3 (E33) GY/8 : To (E205) (KA engine)
- C3 (E34) B/1 : Battery
- D1 (E36) B/1 : ISC-FI pot control solenoid valve (Z engine)
- D1 (E37) B/1 : ISC-FI pot control solenoid valve (Z engine)
- C1 (E39) — : Body ground
- C1 (E45) B/2 : Side turn signal lamp RH (For Australia)
- E2 (E47) GY/3 : Carburetor (Z engine)
- F1 (E50) — : Fusible link and fuse box
- F1 (E51) L/4 : Air conditioner relay
- F1 (E52) W/3 : Horn relay
- F1 (E53) BR/6 : ECM relay (KA engine)
- G1 (E54) B/5 : Automatic choke relay (Z engine)
- L/4 : Fuel pump relay (KA engine)
- G1 (E55) BR/6 : Defogger relay (M/T models for AAustralia)
- BR/6 : Park/Neutral position (PNP) relay (A/T models)
- C3 (E68) BR/2 : Ambient temperature switch (KA engine)
- B1 (E70) — : Relay box-2 (A/T models)
- F2 (E72) BR/6 : Defogger relay (A/T models)
- D2 (E76) GY/2 : Dropping resistor (A/T models)

# HARNESS LAYOUT

## Engine Room Harness (Cont'd)

RHD MODELS — DIESEL ENGINE






# HARNESS LAYOUT

## Engine Room Harness (Cont'd)

G1	<b>E54</b>	L/4	: Fuel heater relay (For Europe)
G1	<b>E55</b>	BR/6	: Defogger relay (TD27 engine for Australia and TD25, 25Ti and QD engine)
F2	<b>E56</b>	GY/4	: Fuel filter (For fuel heater)(For Europe)
C3	<b>E59</b>	B/2	: Ambient sensor (For auto A/C)
D2	<b>E61</b>	B/2	: EGRC-solenoid valve (Throttle chamber)(For Europe)
D2	<b>E62</b>	BR/2	: EGRC-solenoid valve (EGR valve)(For Europe)
D1	<b>E66</b>	GY/6	: Dim-dip lamp unit (For Europe)
C1	<b>E67</b>	GY/4	: Dim-dip lamp unit (For Europe)
E3	<b>E68</b>	GY/10	: To <b>A13</b>
E2	<b>E81</b>	B/2	: Dropping resistor (TD engine for Australia)
D1	<b>E82</b>	W/1	: Glow relay-2 (TD engine for Australia)
D1	<b>E83</b>	W/1	: Glow relay-2 (TD engine for Australia)
D1	<b>E84</b>	G/2	: Glow relay-2 (TD engine for Australia)

G3	<b>E1</b>	B/2	: Side turn signal lamp LH (For Europe and Australia)
D2	<b>E2</b>	GY/2	: Brake fluid level switch
G2	<b>E4</b>	B/31	: ABS actuator and electric unit (For ABS)
F2	<b>E5</b>	BR/2	: Fuel filter switch
F2	<b>E6</b>	—	: Body ground
F4	<b>E11</b>	GY/3	: Front combination lamp LH (Except for Europe and Australia)
F4	<b>E12</b>	BR/3	: Front combination lamp LH (For Europe and Australia)
E5	<b>E13</b>	B/3	: Headlamp LH
D5	<b>E14</b>	GY/2	: Washer motor
E4	<b>E15</b>	BR/2	: Front wheel sensor LH (For ABS)
E3	<b>E17</b>	B/2	: To <b>A2</b>
D3	<b>E18</b>	GY/2	: Thermoswitch (For Europe except 2WD models with ABS and QD engine)
C3	<b>E22</b>	B/1	: Horn low
B4	<b>E23</b>	B/1	: Horn high (For Europe and QD engine except for Australia)
B3	<b>E24</b>	GY/2	: Cooling fan motor (For Europe except 2WD models with ABS and QD engine)
B4	<b>E25</b>	B/4	: Triple-pressure switch
A3	<b>E26</b>	B/3	: Headlamp RH
A2	<b>E27</b>	GY/3	: Front combination lamp RH (Except for Europe and Australia)
A2	<b>E28</b>	BR/3	: Front combination lamp RH (For Europe and Australia)
B2	<b>E29</b>	GY/2	: To <b>E204</b>
B1	<b>E30</b>	B/8	: To <b>E203</b> (For Europe)
C3	<b>E31</b>	GY/2	: Front wheel sensor RH (For ABS)
B2	<b>E32</b>	—	: Relay box-1 (Fusible link and fuse box)
B1	<b>E33</b>	GY/8	: To <b>E205</b>
B2	<b>E35</b>	B/1	: To <b>E206</b>
C3	<b>E36</b>	B/1	: IACV-FICD solenoid valve
C3	<b>E37</b>	B/1	: IACV-FICD solenoid valve
D3	<b>E38</b>	GY/1	: Vacuum warning switch (Except for Australia)
D2	<b>E39</b>	—	: Body ground
B1	<b>E42</b>	W/1	: Glow relay-1
C1	<b>E43</b>	W/1	: Glow relay-1
C1	<b>E44</b>	G/2	: Glow relay-1
C1	<b>E45</b>	B/2	: Side turn signal lamp RH (For Europe and Australia)
G3	<b>E46</b>	GY/3	: Power antenna (For Europe except 2WD model with ABS)
E1	<b>E48</b>	B/1	: To <b>E301</b> (QD engine)
E2	<b>E49</b>	L/2	: To <b>E302</b> (TD engine)
F1	<b>E50</b>	—	: Fusible link and fuse box
F1	<b>E51</b>	L/4	: Air conditioner relay
F1	<b>E52</b>	W/3	: Horn relay
F1	<b>E53</b>	L/4	: Cooling fan relay (For Europe except 2WD models with ABS and QD engine)

### PASSENGER COMPARTMENT




**E101** SMJ : To **M5**  
**E103** B/2 : Fuse block

### Sub-harness

D1 **E301** B/1 : To **E48** (QD engine)  
D2 **E302** L/2 : To **E49** (TD engine)  
E2 **E303** — : Glow plug

# HARNESS LAYOUT

## Engine Control Harness






# HARNESS LAYOUT

## Engine Control Harness (Cont'd)

### PASSENGER COMPARTMENT




- (F51) W/48 : ECM
- (F53) GY/6 : Joint connector
- (F54) W/24 : To (M48)
- (F55) W/16 : To (M47)
- (F56) -/2 : Diode

- B2 (F2) B/2 : IACV-FICD solenoid valve
- C1 (F3) BR/2 : IACV-AAC valve
- C1 (F4) GY/3 : Mass air flow sensor (With three way catalyst)
- D1 (F5) B/6 : To (F104)
- C1 (F6) BR/4 : Mass air flow sensor (Without three way catalyst)
- B2 (F7) — : Engine ground
- B2 (F8) — : Engine ground
- C3 (F9) B/1 : Thermal transmitter
- D1 (F10) B/3 : To (F121)
- D1 (F11) -/2 : Resistor
- D3 (F12) B/1 : Compressor
- E3 (F13) GY/2 : Distributor
- E3 (F14) GY/6 : Distributor
- C3 (F15) GY/2 : Engine coolant temperature sensor
- C3 (F16) GY/2 : Injector No.1
- D2 (F17) GY/2 : Injector No.2
- D2 (F18) GY/2 : Injector No.3
- E2 (F19) GY/2 : Injector No.4
- F2 (F20) GY/8 : Wiper amplifier (A/T models)
- F2 (F21) W/6 : Wiper motor
- E2 (F22) B/3 : Heated oxygen sensor (With three way catalyst)


### Sub-harness

- B2 (F102) BR/3 : Throttle position sensor
- B2 (F103) GY/3 : Throttle position switch (A/T models)
- C2 (F104) B/6 : To (F5)
- E2 (F121) B/3 : To (F10)
- C3 (F122) -/2 : Knock sensor
- D3 (F123) B/1 : Oil pressure switch

Resistor (F11)




Diode (F56)



# HARNESS LAYOUT

## Engine Control Harness (Cont'd)

KA ENGINE




- |             |      |  |             |      |   |
|-------------|------|--|-------------|------|---|
| <b>E201</b> | —    | : Battery  | <b>E213</b> | B/1  | : Oil pressure switch (KA24E)                     |
| <b>E202</b> | —    | : Fusible link and fuse box                                  | <b>E215</b> | —    | : Starter motor                                   |
| <b>E203</b> | B/8  | : To <b>E30</b>  | <b>E218</b> | GY/1 | : Starter motor                                   |
| <b>E204</b> | GY/2 | : To <b>E29</b>  | <b>E219</b> | GY/2 | : Back-up lamp switch (M/T models)                |
| <b>E205</b> | GY/8 | : To <b>E33</b>  | <b>E220</b> | B/2  | : Park/Neutral position (PNP) switch (M/T models) |
| <b>E207</b> | GY/2 | : Power steering oil pressure switch (RHD 4WD models)        | <b>E221</b> | GY/1 | : Transfer switch (4WD models)                    |
| <b>E208</b> | B/2  | : Power steering oil pressure switch (Except RHD 4WD models) | <b>E222</b> | GY/1 | : Transfer switch (4WD models)                    |
| <b>E210</b> | —    | : Alternator (B)   | <b>E223</b> | GY/2 | : Vehicle speed sensor                            |
| <b>E211</b> | —    | : Alternator (E)   |             |      |   |
| <b>E212</b> | GY/2 | : Alternator (S.L)   |             |      |   |

# HARNESS LAYOUT


## Engine Control Harness (Cont'd)

DIESEL ENGINE




# HARNESS LAYOUT

## Alternator Harness




- |       |       |   |
|-------|-------|---|
| (A1)  | —     | : Body ground   |
| (A2)  | B/2   | : To (E17)  |
| (A4)  | B/1   | : Compressor  |
| (A5)  | B/1   | : Oil pressure switch (For fuel heater)<br>(Except QD engine for Australia) |
| (A6)  | —     | : Alternator (B)  |
| (A7)  | —     | : Alternator (E)  |
| (A8)  | GY/2  | : Alternator (S.L)  |
| (A9)  | GY/2  | : Thermoswitch (Turbocharger models and except for Europe)                  |
| (A10) | BR/2  | : Revolution sensor   |
| (A11) | GY/2  | : Engine coolant temperature sensor   |
| (A12) | B/1   | : Thermal transmitter   |
| (A13) | GY/10 | : To (E68)  |




# HARNESS LAYOUT

## Instrument Harness

### LHD MODELS




### RHD MODELS



# HARNESS LAYOUT


## Room Lamp Harness/LHD Models

### SINGLE AND KING CAB



HEL810A

### DOUBLE CAB




HEL811A

# HARNESS LAYOUT

## Room Lamp Harness/RHD Models

### DOUBLE CAB



HEL812A

# HARNESS LAYOUT


## Chassis Harness and Tail Harness

### Tail harness

- T1** W/6 : Rear combination lamp RH  
(A-chassis models and except for Europe, Australia and China)
- T2** W/8 : Rear combination lamp RH  
(For Europe, Australia and China except A-chassis models)
- T3** GY/2 : License plate lamp RH (With step bumper)
- T4** GY/8 : To **C7**
- T5** GY/2 : License plate lamp RH (Without step bumper)
- T6** GY/2 : License plate lamp LH (Without step bumper)
- T7** B/2 : License plate lamp LH (With step bumper)
- T8** W/6 : Rear combination lamp LH  
(A-chassis models and except for Europe, Australia and China)
- T9** W/8 : Rear combination lamp LH  
(For Europe, Australia and China except A-chassis models)
- T10** GY/2 : Rear fog lamp (RHD A-chassis models for Europe)
- T11** B/2 : To **C8** (For Europe)
- T12** GY/2 : Rear fog lamp (LHD A-chassis models for Europe)

### Chassis harness

- C2** W/6 : To **M112** (With ABS)
- C3** GY/6 : Fuel level sensor unit and fuel pump
- C5** GY/4 : To rear wheel sensor sub-harness (For ABS)(4WD models)
- C6** GY/2 : Rear wheel sensor (For ABS)(2WD models)
- C7** GY/8 : To **T4**
- C8** B/2 : To **T11** (For Europe)
- C9** W/16 : To **M121**






# HARNESS LAYOUT

## Front Door Harness (LH side)

### LHD MODELS


- |  |   |
|--|---|
| (D1) W/20 : To (M3)  | (D8) GY/2 : Lock knob switch (With power door lock without multi-remote control system) |
| (D2) W/12 : To (M4) (With power window)  | (D9) BR/3 : Door mirror defogger (With power window for Europe)                         |
| (D3) BR/2 : Front speaker  | (D10) GY/4 : Door lock actuator (With multi-remote control system)                      |
| (D4) GY/5 : Door mirror actuator (With power door mirror except for the Middle East) | (D11) GY/3 : Door mirror actuator (With power door mirror for the Middle East)          |
| (D5) W/16 : Power window main switch   | (D12) GY/6 : Power window regulator (With power window for Europe)                      |
| (D7) B/2 : Power window regulator (With power window except for Europe)              | (D13) W/3 : Power window main switch (With power window for Europe)                     |
|  | (D14) GY/12 : Door mirror remote control switch   |



HEL814A

### RHD MODELS

- |  |
|--|
| (D31) W/20 : To (M49)                                      |
| (D32) W/6 : To (M50) (With power window)                   |
| (D33) BR/2 : Front speaker                                 |
| (D34) GY/5 : Door mirror actuator (With power door mirror) |
| (D35) W/8 : Power window sub-switch (With power window)    |
| (D37) B/2 : Power window regulator (With power window)     |
| (D38) GY/4 : Door lock actuator (With power door lock)     |
| (D39) BR/3 : Door mirror defogger (With power door mirror) |




HEL815A

# HARNESS LAYOUT

## Front Door Harness (RH side)

### LHD MODELS


- (D31) W/20 : To (M49)
- (D32) W/6 : To (M50) (With power window)
- (D33) BR/2 : Front speaker
- (D34) GY/5 : Door mirror actuator (With power door mirror except for the Middle East)
- (D35) W/8 : Power window sub-switch (With power window)
- (D37) B/2 : Power window regulator (With power window)
- (D38) GY/4 : Door lock actuator (With power door lock)
- (D39) BR/3 : Door mirror defogger (With power window for Europe)
- (D41) BR/3 : Door mirror actuator (With power door mirror for the Middle East)



HEL816A

### RHD MODELS

- (D1) W/20 : To (M3)
- (D2) W/12 : To (M4) (With power window)
- (D3) BR/2 : Front speaker
- (D4) GY/5 : Door mirror actuator (With power window)
- (D5) W/16 : Power window main switch
- (D7) B/2 : Power window regulator (With power window except for Europe)
- (D8) GY/2 : Lock knob switch (With power door lock without multi-remote control system)
- (D9) BR/3 : Door mirror defogger (With power window)
- (D10) GY/4 : Door lock actuator (With multi-remote control system)
- (D12) GY/6 : Power window regulator (With power window for Europe)
- (D13) W/3 : Power window main switch (With power window for Europe)
- (D14) GY/12 : Door mirror remote control switch (With power window)



HEL817A

## WIRING DIAGRAM CODES (CELL CODES)

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
AAC/V	EC	IACV-AAC Valve
ABS	BR	Anti-lock Brake System
A/C, M	HA	Manual Air Conditioner
A/C, A	HA	Auto Air Conditioner
AT/IND	EL	A/T Indicator
AUDIO	EL	Audio
BACK/L	EL	Back-up Lamp
BA/FTS	AT	BATT/A/T Fluid Temperature Sensor and TCM Power Supply
CHARGE	EL	Charging System
CHIME	EL	Warning Chime
CHOKE	EC	Automatic Choke
CIGAR	EL	Cigarette Lighter
CLOCK	EL	Clock
CMPS	EC	Camshaft Position Sensor
COOL/F	LC	Cooling Fan Control
DEF	EL	Rear Window Defogger and Mirror Defogger
DIMDIP	EL	Headlamp — With Dim-dip Lamp System
D/LOCK	EL	Power Door Lock
DTRL	EL	Headlamp — With Daytime Light System
ECTS	EC	Engine Coolant Temperature Sensor
EGRC/V	EC	EGRC — Solenoid Valve
ENGSS	AT	Engine Speed Signal
FCUT	EC	Fuel Cut Solenoid Valve
F/HEAT	EC	Fuel Heater System
FICD	EC	IACV-FICD Solenoid Valve
FIPO	EC	ISC-FI Pot
FPCM	EC	Fuel Pump Control Module
F/PUMP	EC	Fuel Pump
GLOW	EC	Quick-glow System
H/AIM	EL	Headlamp Aiming Control
HEATER	HA	Heater
H/LAMP	EL	Headlamp
HLC	EL	Headlamp Washer
HO2S	EC	Heated Oxygen Sensor
HORN	EL	Horn
H/SEAT	EL	Heated Seat

Code	Section	Wiring Diagram Name
IGN	EC	Ignition System
IGN/SG	EC	Ignition Signal
ILL	EL	Illumination
INJECT	EC	Injector
INT/L	EL	Spot Lamp
KS	EC	Knock Sensor
LOAD	EC	Electric Load Signal
LPSV	AT	Line Pressure Solenoid Valve
MAFS	EC	Mass Air Flow Sensor
MAIN	EC, AT	Main Power Supply and Ground Circuit
METER	EL	Speedometer, Tachometer, Temp. and Fuel Gauges
MIL/DL	EC	MIL and Data Link Connector For CONSULT
MIRROR	EL	Power Door Mirror
MULTI	EL	Multi-remote Control System
NATS	EL	Nissan Anti-theft System
NONDTC	AT	Non-detectable Items
OVRCSV	AT	Overrun Clutch Solenoid Valve
P/ANT	EL	Power Antenna
PGC/V	EC	EVAP Canister Purge Control Solenoid Valve
PLA	EC	Partial Load Advance Control
PNP/SW	EC	Park/Neutral Position Switch
POWER	EL	Power Supply Routing
PST/SW	EC	Power Steering Oil Pressure Switch
R/FOG	EL	Rear Fog Lamp
ROOM/L	EL	Interior Room Lamp
SHIFT	AT	Shift Lock System
SSV/A	AT	Shift Solenoid Valve A
SSV/B	AT	Shift Solenoid Valve B
SRS	RS	Supplemental Restraint System
S/SIG	EC	Start Signal
START	EL	Starting System
STOP/L	EL	Stop Lamp
SWL/V	EC	Swirl Control Valve Control Solenoid Valve
TAIL/L	EL	Parking, License and Tail Lamps
TCV	AT	Torque Converter Clutch Solenoid Valve

## WIRING DIAGRAM CODES (CELL CODES)

Code	Section	Wiring Diagram Name
TPS	EC, AT	Throttle Position Sensor
TURN	EL	Turn Signal and Hazard Warning Lamps
VSS	EC	Vehicle Speed Sensor
VSSAT	AT	Vehicle Speed Sensor A/T (Revolution Sensor)

Code	Section	Wiring Diagram Name
VSSMTR	AT	Vehicle Speed Sensor Meter
WARN	EL	Warning Lamps
WINDOW	EL	Power Window
WIPER	EL	Front Wiper and Washer