

## SECTION **EL**

### MODIFICATION NOTICE:

- Wiring diagrams have been changed.
- Combination meter has been changed.
- Headlamp has been changed.
- Headlamp aiming control has been added.
- Headlamp washer has been added.
- A hazard reminder feature has been added to the multi-remote control system.
- NATS (Nissan Anti-Theft System) has been changed.

## CONTENTS

<b>PRECAUTIONS</b> .....	3004	Wiring Diagram - DIMDIP - .....	3033
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" ..	3004	Bulb Replacement.....	3036
<b>POWER SUPPLY ROUTING</b> .....	3005	Aiming Adjustment .....	3036
Schematic .....	3005	<b>HEADLAMP - Headlamp Aiming Control -</b> .....	3037
Wiring Diagram - POWER - .....	3006	Wiring Diagram - H/AIM - .....	3037
<b>BATTERY</b> .....	3013	<b>PARKING, LICENSE AND TAIL LAMPS</b> .....	3039
Service Data and Specifications (SDS).....	3013	Wiring Diagram - TAIL/L -/Except LHD Models for Europe .....	3039
<b>STARTING SYSTEM</b> .....	3014	Wiring Diagram - TAIL/L -/LHD Models for Europe.....	3041
Wiring Diagram - START -/M/T Models .....	3014	<b>STOP LAMP</b> .....	3043
Construction .....	3015	Wiring Diagram - STOP/L - .....	3043
Service Data and Specifications (SDS).....	3017	<b>BACK-UP LAMP</b> .....	3044
<b>CHARGING SYSTEM</b> .....	3018	Wiring Diagram - BACK/L -/M/T Models .....	3044
Wiring Diagram - CHARGE -/Diesel Engine ...	3018	<b>REAR FOG LAMP</b> .....	3045
Wiring Diagram - CHARGE - (KA engine) .....	3019	Wiring Diagram - R/FOG -/LHD Models .....	3045
Construction .....	3020	Wiring Diagram - R/FOG -/RHD Models .....	3046
Service Data and Specifications (SDS).....	3022	<b>TURN SIGNAL AND HAZARD WARNING LAMPS</b> .....	3047
<b>HEADLAMP - Conventional Type -</b> .....	3023	Wiring Diagram - TURN - .....	3047
Wiring Diagram - H/LAMP -/LHD Models.....	3023	Trouble Diagnoses.....	3049
Wiring Diagram - H/LAMP -/RHD Models .....	3025	<b>ILLUMINATION</b> .....	3050
Bulb Replacement.....	3027	Wiring Diagram - ILL -/LHD Models .....	3050
Aiming Adjustment .....	3027	Wiring Diagram - ILL -/RHD Models.....	3052
Low Beam .....	3028	<b>INTERIOR ROOM LAMP</b> .....	3054
<b>HEADLAMP - Daytime Light System -</b> .....	3029	Wiring Diagram - ROOM/L - .....	3054
Wiring Diagram - DTRL - .....	3029	<b>SPOT LAMP</b> .....	3055
Bulb Replacement.....	3032	Wiring Diagram - INT/L - .....	3055
Aiming Adjustment .....	3032		
<b>HEADLAMP - Dim-dip Lamp System -</b> .....	3033		

<b>METER AND GAUGES</b> .....	3056	Wiring Diagram - AUDIO -/RHD Models .....	3114
System Description .....	3056	<b>AUDIO ANTENNA</b> .....	3115
Combination Meter/With Tachometer .....	3057	Power Antenna/Wiring Diagram - P/ANT - .....	3115
Combination Meter/Without Tachometer .....	3058	<b>POWER DOOR MIRROR</b> .....	3116
Schematic/With Tachometer .....	3059	Wiring Diagram - MIRROR -/LHD Models.....	3116
Schematic/Without Tachometer .....	3060	Wiring Diagram - MIRROR -/RHD Models.....	3117
Construction .....	3061	<b>HEATED SEAT</b> .....	3118
Wiring Diagram - METER -/Gasoline Engine		Wiring Diagram - H/SEAT - .....	3118
with Tachometer .....	3062	<b>POWER WINDOW</b> .....	3120
Wiring Diagram - METER -/Gasoline Engine		Schematic/Without Interruption Detection	
without Tachometer .....	3064	Function .....	3120
Wiring Diagram - METER -/LHD Diesel Engine		Schematic/With Interruption Detection	
Models with Tachometer.....	3065	Function .....	3121
Wiring Diagram - METER -/RHD Diesel		Wiring Diagram - WINDOW -/Without	
Engine Models with Tachometer .....	3067	Interruption Detection Function.....	3122
Wiring Diagram - METER -/Diesel Engine		Wiring Diagram - WINDOW -/With Interruption	
without Tachometer .....	3069	Detection Function .....	3126
Meter/Gauge Operation and Odo/Trip Meter		Trouble Diagnoses/Without Interruption	
Segment Check in Diagnosis Mode .....	3070	Detection Function .....	3130
Trouble Diagnoses/With Tachometer .....	3071	Trouble Diagnoses/With Interruption Detection	
Trouble Diagnoses/Without Tachometer .....	3076	Function .....	3131
<b>WARNING LAMPS</b> .....	3081	<b>POWER DOOR LOCK</b> .....	3133
Schematic/With Tachometer.....	3081	Wiring Diagram - D/LOCK - .....	3133
Schematic/Without Tachometer .....	3082	<b>MULTI-REMOTE CONTROL SYSTEM</b> .....	3135
Wiring Diagram - WARN -/Gasoline Engine		System Description .....	3135
with Tachometer .....	3083	<b>MULTI-REMOTE CONTROL SYSTEM</b> .....	3136
Wiring Diagram - WARN -/Gasoline Engine		Wiring Diagram - MULTI - .....	3136
without Tachometer .....	3087	Trouble Diagnoses.....	3137
Wiring Diagram - WARN -/Diesel Engine with		ID Code Entry Procedure .....	3139
Tachometer.....	3091	Remote Controller Battery Replacement.....	3140
Wiring Diagram - WARN -/Diesel Engine		<b>THEFT WARNING SYSTEM</b> .....	3141
without Tachometer .....	3095	Wiring Diagram - PRWIRE - .....	3141
<b>A/T INDICATOR</b> .....	3100	<b>NATS (Nissan Anti-Theft System)</b> .....	3142
Wiring Diagram - AT/IND -/RHD Models.....	3100	Component Parts and Harness Connector	
Wiring Diagram - CHIME -/LHD Models.....	3101	Location.....	3142
Wiring Diagram - CHIME -/RHD Models .....	3102	System Description .....	3143
<b>FRONT WIPER AND WASHER</b> .....	3103	System Composition .....	3144
Wiring Diagram - WIPER -/Without Intermittent		Wiring Diagram - NATS -/LHD Models.....	3145
for Floor-shift.....	3103	Wiring Diagram - NATS -/RHD Diesel Engine	
Wiring Diagram - WIPER -/Without Intermittent		Models.....	3146
for RHD Column-shift Models.....	3106	CONSULT-II.....	3147
<b>HEADLAMP WASHER</b> .....	3108	Trouble Diagnoses.....	3149
Wiring Diagram - HLC - .....	3108	How to Replace NATS IMMU.....	3160
<b>HORN</b> .....	3109	<b>LOCATION OF ELECTRICAL UNITS</b> .....	3161
Wiring Diagram - HORN - .....	3109	Engine Compartment.....	3161
<b>CIGARETTE LIGHTER</b> .....	3110	Passenger Compartment.....	3162
Wiring Diagram - CIGAR - .....	3110	<b>HARNES LAYOUT</b> .....	3164
<b>CLOCK</b> .....	3111	Main Harness.....	3164
Wiring Diagram - CLOCK - .....	3111	Engine Room Harness.....	3174
<b>REAR WINDOW DEFOGGER AND MIRROR</b>		Engine Control Harness/KA engine.....	3182
<b>DEFOGGER</b> .....	3112	Engine Control Harness.....	3184
Wiring Diagram - DEF - .....	3112	Engine Harness .....	3185
<b>AUDIO</b> .....	3113	Alternator Harness .....	3187
Wiring Diagram - AUDIO -/LHD Models.....	3113	Instrument Harness.....	3189

---

Chassis Harness and Tail Harness.....	3190
Front Door Harness (LH side) .....	3191
Front Door Harness (RH side).....	3192

Rear Door Harness.....	3193
<b>WIRING DIAGRAM CODES (CELL CODES).....</b>	<b>3194</b>

## PRECAUTIONS

---

### **Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”**

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER” used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The SRS system composition which is available to NISSAN MODEL D22 is as follows (The composition varies according to the destination and optional equipment.):

Driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioner, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.


Information necessary to service the system safely is included in the **RS section** of this Service Manual.

#### **WARNING:**

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow harness connector.**

# POWER SUPPLY ROUTING

## Schematic





# POWER SUPPLY ROUTING


## Wiring Diagram — POWER —

### BATTERY POWER SUPPLY — IGNITION SWITCH IN ANY POSITION

EL-POWER-01



Refer to last page (Foldout page).  
M5 , E101





# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-02



- : YD and ZD engines
- : LHD models for Europe
- : YD engine
- : TD, QD and ZD engines
- \*1 80A :
- 60A :



# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-03



Refer to last page (Foldout page).

(M5), (E101)





# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

### ACCESSORY POWER SUPPLY — IGNITION SW. IN "ACC" OR "ON"

EL-POWER-04





Refer to last page (Foldout page).  
 M5, E101

# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

### IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START"

EL-POWER-05







Refer to last page (Foldout page).  
 M5, E101



# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-06

-  : Z engine
-  : ZD engine
-  : KA engine for Europe
-  : With ECM control engine except KA engine for Europe

- \*1 W/L : 
- W/R : 
- \*2 15A : 
- 10A : 
- \*3 W/L : 
- BR/Y : 





Refer to last page (Foldout page).

(M5), (E101)

# POWER SUPPLY ROUTING

## Wiring Diagram — POWER — (Cont'd)

EL-POWER-07



# BATTERY


## Service Data and Specifications (SDS)

Applied model		Europe
		YD25
		Standard
Type		110D26R
Capacity	V-AH	12-64

# STARTING SYSTEM

## Wiring Diagram — START —/M/T Models

EL-START-01





Refer to last page (Foldout page).

M5, E101

# STARTING SYSTEM


## Construction



# STARTING SYSTEM

## Construction (Cont'd)

**SEC. 233**  
**M2TSO571**



MEL702P



# STARTING SYSTEM

## Service Data and Specifications (SDS)

### STARTER



Type		M2TS0571	M3T29482D	S114-348A	S114-295B	S13-527B	
		MITSUBISHI		HITACHI			
Applied model		Reduction		Non-reduction		Reduction	
		2WD	4WD	2WD		4WD	
		YD25		Z24		ZD30	
System voltage		Standard		Standard	Option	Standard	
No-load		12					
Terminal voltage	V	11.0		11.5		11.0	
Current	A	Less than 145		Less than 60		Less than 160*	
Revolution	rpm	More than 3,200		More than 6,500	More than 7,000	More than 6,000	
Minimum diameter of commutator	mm (in)	31.4 (1.236)		39.0 (1.535)		35.5 (1.398)	
Minimum length of brush	mm (in)	11.0 (0.433)		11.5 (0.453)	12.0 (0.472)	11.0 (0.433)	
Brush spring tension	N (kg, lb)	26.7 - 36.1 (2.7 - 3.7, 6.0 - 8.2)		13.7 - 25.5 (1.4 - 2.6, 3.1 - 5.7)	17.7 - 21.6 (1.8 - 2.2, 4.0 - 4.9)	17.6 - 21.6 (1.8 - 2.2, 4.0 - 4.9)	
Clearance between bearing metal and armature shaft	mm (in)	Less than 0.2 (0.008)					
Clearance "ℓ" between pinion front edge and pinion stopper	mm (in)	—		0.5 - 2.0 (0.020 - 0.079)	0.3 - 2.5 (0.012 - 0.098)		
Movement "ℓ" in height of pinion assembly	mm (in)	0.5 - 2.0 (0.020 - 0.079)		—		0.3 - 2.0 (0.01 - 0.079)	

\*: Includes magnet switch current.

# CHARGING SYSTEM

## Wiring Diagram — CHARGE —/Diesel Engine

EL-CHARGE-01






# CHARGING SYSTEM


## Construction

**SEC. 231**  
**LR160-728E**



SEL544V

**SEC. 231**  
**A3TB0699**




MEL704P

**EL-3020**


# CHARGING SYSTEM

## Construction (Cont'd)

SEC. 231  
LR160-745



MEL703P



PKIA1240E

### Disassembly (For LR160-745)

- When removing alternator pulley, use special service tool (KV10118200).

# CHARGING SYSTEM

## Service Data and Specifications (SDS)

### ALTERNATOR



Type	A5TA5271	A7TA8471	A5TA5372	A3TB0699	LR160-745	LR160-728E
	MITSUBISHI				HITACHI	
Applied model	KA24DE	Z24		YD25	ZD30	TD27, QD32
		Standard	Option*			
Nominal rating V-A	12-70	12-35	12-70	12-90	12-60	
Ground polarity	Negative					
Minimum revolution under no-load (When 13.5V is applied) rpm	Less than 1,300				Less than 1,000	
Hot output current (When 13.5V is applied) A/rpm	More than 14/1,300 More than 54/2,500	More than 27/2,500	More than 18/1,300 More than 51/2,500	More than 29/1,300 More than 76/2,500 More than 88/5,000	More than 17/1,300 More than 48/2,500 More than 57/5,000	
Regulated output voltage V	14.1 - 14.7					
Minimum length of brush mm (in)	5.0 (0.20)				6.0 (0.236)	
Brush spring pressure N (g, oz)	4.8 - 6.0 (487 - 612, 17.25 - 21.59)				1.0 - 3.43 (102 - 350, 3.60 - 12.34)	
Slip ring minimum outer diameter mm (in)	22.1 (0.870)				26.0 (1.024)	
Rotor (Field coil) resistance $\Omega$	2.5 - 2.9	2.7 - 3.2	2.5 - 2.9	2.1 - 2.5	2.6	2.58

\*: Models with power steering and air conditioner

# HEADLAMP — Conventional Type —

## Wiring Diagram — H/LAMP —/LHD Models

EL-H/LAMP-01



Refer to last page (Foldout page).

(M5), (E101)


# HEADLAMP — Conventional Type —

## Wiring Diagram — H/LAMP —/LHD Models (Cont'd)

EL-H/LAMP-02

⊡ : With tachometer  
⊡ : Without tachometer

\*1 46 : ⊡  
51 : ⊡  
\*2 47 : ⊡  
50 : ⊡



1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24


N2  
BR

45	46	47	48	49	50	51	52	53	54	55		
56	57	58	59	60	61	62	63	64	65	66	67	68

N6  
BR

41	42	43	44	45	46	47	48	49	50	51		
52	53	54	55	56	57	58	59	60	61	62	63	64

N11  
W






# HEADLAMP — Conventional Type —

## Wiring Diagram — H/LAMP —/RHD Models

EL-H/LAMP-03



Refer to last page (Foldout page).


(M5), (E101)

# HEADLAMP — Conventional Type —

## Wiring Diagram — H/LAMP —/RHD Models (Cont'd)

EL-H/LAMP-04

- : With tachometer
- : Without tachometer
- \*1 46 :
- 47 :
- \*2 51 :
- 50 :



1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24


BR

45	46	47	48	49	50	51	52	53	54	55		
56	57	58	59	60	61	62	63	64	65	66	67	68


BR

41	42	43	44	45	46	47	48	49	50	51		
52	53	54	55	56	57	58	59	60	61	62	63	64

W



## HEADLAMP — Conventional Type —




### Bulb Replacement

The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- **Grasp only the plastic base when handling the bulb. Never touch the glass envelope.**
1. Disconnect the battery cable.
  2. Disconnect the harness connector from the back side of the bulb.
  3. Pull off the rubber cap.
  4. Push and raise retaining pin to loosen it.
  5. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
  6. Install in the reverse order of removal.

#### CAUTION:

**Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.**




### Aiming Adjustment

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. Aimers should be in good repair, calibrated and operated in accordance with respective operation manuals.

If any aimer is not available, aiming adjustment can be done as follows:

**For details, refer to the regulations in your own country.**

- a. **Keep all tires inflated to correct pressures.**
- b. **Place vehicle and tester on one and same flat surface.**
- c. **See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).**




#### CAUTION:


**Be sure aiming switch is set to "0" when performing aiming adjustment on vehicles equipped with headlamp aiming control.**

# HEADLAMP — Conventional Type —

Multi-beam type headlamp




Non-multi-beam type headlamp



## Low Beam

1. Turn headlamp low beam on.
  2. Use adjusting screws to perform aiming adjustment.
- First tighten the adjusting screw all the way and then make adjustment by loosening the screw.





- Adjust headlamps so that main axis of light is parallel to center line of body and is aligned with point P shown in illustration.
  - Figure to the left shows headlamp aiming pattern for driving on right side of road; for driving on left side of road, aiming pattern is reversed.
  - Dotted lines in illustration show center of headlamp.
- “H” : Horizontal center line of headlamps  
 “WL” : Distance between each headlamp center  
 “L” : 5,000 mm (196.85 in)  
 “C” : 65 mm (2.56 in)

# HEADLAMP — Daytime Light System —




## Wiring Diagram — DTRL —

EL-DTRL-01



Refer to last page (Foldout page).




(M5), (E101)



# HEADLAMP — Daytime Light System —

## Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-02




Refer to last page (Foldout page).

(M5), (E101)

# HEADLAMP — Daytime Light System —

## Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-03



- Ⓜ : With tachometer
- Ⓞ : Without tachometer
- \*1 46 : Ⓜ
- 51 : Ⓞ
- \*2 47 : Ⓜ
- 50 : Ⓞ

1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(N2) BR

45	46	47	48	49	50	51	52	53	54	55		
56	57	58	59	60	61	62	63	64	65	66	67	68

(N6) BR

41	42	43	44	45	46	47	48	49	50	51		
52	53	54	55	56	57	58	59	60	61	62	63	64

(N11) W

3	
1	2

(E13) B, (E26) B

1	9	10
11		4

(E64) SB

Refer to last page (Foldout page).

(M5), (E101)

## HEADLAMP — Daytime Light System —

---

### **Bulb Replacement**

For bulb replacement, refer to “HEADLAMP — Conventional Type —” EL-3027.

### **Aiming Adjustment**



For aiming adjustment, refer to “HEADLAMP — Conventional Type —” EL-3027.



# HEADLAMP — Dim-dip Lamp System —

## Wiring Diagram — DIMDIP —

EL-DIMDIP-01









Refer to last page (Foldout page).

(M5), (E101)

# HEADLAMP — Dim-dip Lamp System —

## Wiring Diagram — DIMDIP — (Cont'd)

### EL-DIMDIP-02





Refer to last page (Foldout page).

M5, E101

# HEADLAMP — Dim-dip Lamp System —

## Wiring Diagram — DIMDIP — (Cont'd)

EL-DIMDIP-03



### **Bulb Replacement**

For bulb replacement, refer to EL-3027.



### **Aiming Adjustment**

For aiming adjustment, refer to EL-3027.

# HEADLAMP — Headlamp Aiming Control —

## Wiring Diagram — H/AIM —

EL-H/AIM-01




Refer to last page (Foldout page).

⬡ M5 , ⬡ E101

# HEADLAMP — Headlamp Aiming Control —

## Wiring Diagram — H/AIM — (Cont'd)

EL-H/AIM-02



1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(N1) W, (N2) BR



(N7) W



(E57), (E60)


Refer to last page (Foldout page).

(M5), (E101)


# PARKING, LICENSE AND TAIL LAMPS

## Wiring Diagram — TAIL/L —/Except LHD Models for Europe

EL-TAIL/L-01



- MB : With multi-beam type headlamp
- XM : Without multi-beam type headlamp
- LN : For Europe and LHD models except for Europe
- RX : RHD models except for Europe





Refer to last page (Foldout page).

M5 , E101

# PARKING, LICENSE AND TAIL LAMPS

## Wiring Diagram — TAIL/L —/Except LHD Models for Europe (Cont'd)

EL-TAIL/L-02










# PARKING, LICENSE AND TAIL LAMPS

## Wiring Diagram — TAIL/L —/LHD Models for Europe

EL-TAIL/L-03



Refer to last page (Foldout page).





# PARKING, LICENSE AND TAIL LAMPS

## Wiring Diagram — TAIL/L —/LHD Models for Europe (Cont'd)

EL-TAIL/L-04



- ⬡CH⬡ : A-chassis models
- ⬡XH⬡ : Except A-chassis models
- ⬡SB⬡ : Models with step bumper
- ⬡XB⬡ : Except ⬡SB⬡
- \*1 4 : ⬡CH⬡
- 5 : ⬡XH⬡



# STOP LAMP

## Wiring Diagram — STOP/L —



### EL-STOP/L-01



# BACK-UP LAMP

## Wiring Diagram — BACK/L —/M/T Models

EL-BACK/L-01






Refer to last page (Foldout page).

<M5> , <E101>

# REAR FOG LAMP








## Wiring Diagram — R/FOG —/LHD Models

EL-R/FOG-01



Refer to last page (Foldout page).




<M5> , <E101>



# REAR FOG LAMP








## Wiring Diagram — R/FOG —/RHD Models

EL-R/FOG-02



Refer to last page (Foldout page).



⬡M5⬡, ⬡E101⬡



# TURN SIGNAL AND HAZARD WARNING LAMPS

## Wiring Diagram — TURN —



EL-TURN-01



# TURN SIGNAL AND HAZARD WARNING LAMPS

## Wiring Diagram — TURN — (Cont'd)

EL-TURN-02





# TURN SIGNAL AND HAZARD WARNING LAMPS



## Trouble Diagnoses

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	<ol style="list-style-type: none"> <li>1. Hazard switch</li> <li>2. Combination flasher unit</li> <li>3. Open in combination flasher unit circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check hazard switch.</li> <li>2. Refer to combination flasher unit check.</li> <li>3. Check wiring to combination flasher unit for open circuit.</li> </ol>
Turn signal lamps do not operate but hazard warning lamps operate.	<ol style="list-style-type: none"> <li>1. 10A fuse</li> <li>2. Hazard switch</li> <li>3. Turn signal switch</li> <li>4. Open in turn signal switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 10A fuse (No. <span style="border: 1px solid black; padding: 0 2px;">10</span>), located in fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal <span style="border: 1px solid black; border-radius: 50%; padding: 0 2px;">2</span> (R/W) of hazard switch.</li> <li>2. Check hazard switch.</li> <li>3. Check turn signal switch.</li> <li>4. Check G wire between combination flasher unit and turn signal switch for open circuit.</li> </ol>
Hazard warning lamps do not operate but turn signal lamps operate.	<ol style="list-style-type: none"> <li>1. 10A fuse</li> <li>2. Hazard switch</li> <li>3. Open in hazard switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 10A fuse (No. <span style="border: 1px solid black; padding: 0 2px;">5</span>), located in fuse block). Verify battery positive voltage is present at terminal <span style="border: 1px solid black; border-radius: 50%; padding: 0 2px;">3</span> (R/Y) of hazard switch.</li> <li>2. Check hazard switch.</li> <li>3. Check G wire between combination flasher unit and hazard switch for open circuit.</li> </ol>
Front or side turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds <span style="border: 1px solid black; border-radius: 50%; padding: 0 2px;">E6</span> and <span style="border: 1px solid black; border-radius: 50%; padding: 0 2px;">E39</span></li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds <span style="border: 1px solid black; border-radius: 50%; padding: 0 2px;">E6</span> and <span style="border: 1px solid black; border-radius: 50%; padding: 0 2px;">E39</span>.</li> </ol>
Rear turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds <span style="border: 1px solid black; border-radius: 50%; padding: 0 2px;">M1</span> and <span style="border: 1px solid black; border-radius: 50%; padding: 0 2px;">M54</span></li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds <span style="border: 1px solid black; border-radius: 50%; padding: 0 2px;">M1</span> and <span style="border: 1px solid black; border-radius: 50%; padding: 0 2px;">M54</span>.</li> </ol>
LH and RH turn indicators do not operate.	<ol style="list-style-type: none"> <li>1. Ground</li> </ol>	<ol style="list-style-type: none"> <li>1. Check grounds <span style="border: 1px solid black; border-radius: 50%; padding: 0 2px;">M1</span> and <span style="border: 1px solid black; border-radius: 50%; padding: 0 2px;">M54</span>.</li> </ol>
LH or RH turn indicator does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb in combination meter.</li> </ol>

# ILLUMINATION

## Wiring Diagram — ILL —/LHD Models

EL-ILL-01




Refer to last page (Foldout page).

(M5), (E101)


# ILLUMINATION

## Wiring Diagram — ILL —/LHD Models (Cont'd)

EL-ILL-02



- ⬡ : For Europe
- ⬢ : Except for Europe
- ⬣ : With CD deck
- ⬤ : GL and S-GL grade for the Middle East
- ⬥ : CD player or cassette player with AM-FM radio
- ⬦ : With headlamp aiming system
- ⬧ : Except ⬥
- ⬨ : With tachometer
- ⬩ : Without tachometer
- \*1 59 : ⬨ \*2 60 : ⬨
- 27 : ⬩ 46 : ⬩





\*: This connector is not shown in "HARNES LAYOUT".

# ILLUMINATION

## Wiring Diagram — ILL —/RHD Models



EL-ILL-03



# ILLUMINATION

## Wiring Diagram — ILL —/RHD Models (Cont'd)



EL-ILL-04



# INTERIOR ROOM LAMP

## Wiring Diagram — ROOM/L —


EL-ROOM/L-01



# SPOT LAMP

## Wiring Diagram — INT/L —

EL-INT/L-01




# METER AND GAUGES

## System Description

### UNIFIED CONTROL METER

- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled totally by control unit.
- Digital meter is adopted for odo/trip meter.\*
  - \*The record of the odo meter is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter segment can be checked in diagnosis mode.
- Meter/gauge can be checked in diagnosis mode.

### HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER




**Note:**

Turn ignition switch to the "ON" position to operate odo/trip meter.



# METER AND GAUGES

## Combination Meter/With Tachometer





Bulb socket color	Bulb wattage
Brown	1.4W
Black	3.0W

( ) : Bulb socket color

- (ME) : For the Middle East
- (RF) : With rear fog lamp
- (TQ) : TD and QD engines
- (EC) : With ECM control engine

# METER AND GAUGES

## Combination Meter/Without Tachometer



(EA) : Except for Australia

Bulb socket color	Bulb wattage
Brown	1.4W
Black	3.0W


( ) : Bulb socket color

# METER AND GAUGES

## Schematic/With Tachometer

- (LA) : LHD models with A/T
- (RA) : RHD models with A/T
- (D) : With diesel engine
- (AB) : With air bag
- (AS) : With ABS
- (RF) : With rear fog lamp
- (EC) : With ECM control engine (Except TD27)

- (EA) : With ECM control engine (Except TD27) or for Australia
- (TQ) : TD and QD engines
- (4W) : 4-wheel drive models
- (ME) : For the Middle East
- (SW) : For Europe, Australia and the Middle East




GEL390A

# METER AND GAUGES

## Schematic/Without Tachometer


- (A) : A/T models
- (D) : With diesel engine
- (AB) : With air bag
- (AS) : With ABS
- (RF) : With rear fog lamp
- (EC) : With ECM control engine (Except TD27)
- (TQ) : TD and QD engines
- (4W) : 4-wheel drive models
- (ME) : For the Middle East
- (SW) : For Europe, Australia and the Middle East
- (XA) : Except for Australia




# METER AND GAUGES

## Construction

### WITH TACHOMETER






### WITHOUT TACHOMETER



# METER AND GAUGES

## Wiring Diagram — METER —/Gasoline Engine with Tachometer

EL-METER-01



Refer to last page (Foldout page).



(M5), (E101)

# METER AND GAUGES

## Wiring Diagram — METER —/Gasoline Engine with Tachometer (Cont'd)

EL-METER-02

- L : LHD models
- R : RHD models
- EU : For Europe
- NE : Except for Europe
- CB : Carburetor engine
- VG : VG engine
- LK : LHD models with KA engine
- RK : RHD models with KA engine
- RV : RHD models with KA engine and VG engine
- \*1 3C: L    \*2 3: EU    \*3 18: RK
- 6A: R    18: NE    7: VG





Refer to last page (Foldout page).

- M5 , E101
- M32
- F51

# METER AND GAUGES

## Wiring Diagram — METER —/Gasoline Engine without Tachometer

EL-METER-03



Refer to last page (Foldout page).





M5, E101




# METER AND GAUGES

## Wiring Diagram — METER —/LHD Diesel Engine Models with Tachometer

EL-METER-04







Refer to last page (Foldout page).





# METER AND GAUGES

## Wiring Diagram — METER —/LHD Diesel Engine Models with Tachometer (Cont'd)

EL-METER-05

-  : YD engine
-  : ZD engine
-  : YD and ZD engines
-  : TD and QD engines





Refer to last page (Foldout page).

M5, E101

# METER AND GAUGES

## Wiring Diagram — METER —/RHD Diesel Engine Models with Tachometer





EL-METER-06





# METER AND GAUGES



## Wiring Diagram — METER —/RHD Diesel Engine Models with Tachometer (Cont'd)

EL-METER-07

-  : YD engine
-  : ZD engine
-  : YD and ZD engines
-  : TD and QD engines













Refer to last page (Foldout page).

 , 

# METER AND GAUGES

## Wiring Diagram — METER —/Diesel Engine without Tachometer

EL-METER-08



Refer to last page (Foldout page).

(M5), (E101)

## METER AND GAUGES




### Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

#### DIAGNOSIS FUNCTION

- Odo/trip meter segment can be checked in diagnosis mode.
- Meters/gauges can be checked in diagnosis mode.

#### HOW TO ALTERNATE DIAGNOSIS MODE

1. Turn ignition switch to ON and change odo/trip meter to "TRIP A" or "TRIP B".
2. Turn ignition switch to OFF.
3. Turn ignition switch to ON when pushing odo/trip meter switch.
4. Confirm that trip meter indicates "000.0".
5. Push odo/trip meter switch more than three times within 5 seconds.



6. All odo/trip meter segments should be turned on.

**NOTE: If some segments are not turned on, unified meter control unit with odo/trip meter should be replaced.**


At this point, the unified control meter is turned to diagnosis mode.

7. Push odo/trip meter switch. Indication of each meter/gauge should be as shown left during pushing odo/trip meter switch if it is no malfunctioning.

**NOTE: It takes about a few seconds for indication of fuel gauge to become stable.**

# METER AND GAUGES

## Trouble Diagnoses/With Tachometer PRELIMINARY CHECK



SEL269Y

\*1: Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode (EL-3070)

\*2: POWER SUPPLY AND GROUND CIRCUIT CHECK (EL-3072)

\*3: Symptom Chart (EL-3071)

### SYMPTOM CHART

Symptom	Possible causes	Repair order
One of speedometer/fuel gauge/water temp. gauge is malfunctioning.	1. Sensor signal - Vehicle speed signal - Fuel gauge - Water temp. gauge 2. Unified meter control unit	1. Check the sensor for malfunctioning meter/gauge. INSPECTION/VEHICLE SPEED SIGNAL (Refer to EL section "Vehicle speed signal" in original Service Manual.) INSPECTION/FUEL LEVEL SENSOR UNIT INSPECTION/THERMAL TRANSMITTER 2. Replace unified meter control unit.
Multiple meter/gauge are malfunctioning. (except odo/trip meter)		


Before starting trouble diagnoses below, perform PRELIMINARY CHECK, EL-3071.

## METER AND GAUGES

### Trouble Diagnoses/With Tachometer (Cont'd)

#### POWER SUPPLY AND GROUND CIRCUIT CHECK


##### Power supply circuit check



Terminals		Ignition switch position		
⊕	⊖	OFF	ACC	ON
⑱ (R/G)	Ground	Battery voltage	Battery voltage	Battery voltage
⑰ (W/B)	Ground	0V	0V	Battery voltage

If NG, check the following.

- 10A fuse [No. 11], located in fuse block (J/B)
- 10A fuse [No. 6], located in fuse block (J/B)
- Harness for open or short between fuse and combination meter



##### Ground circuit check







Terminals	Continuity
⑳ - Ground (B)	Yes





# METER AND GAUGES

## Trouble Diagnoses/With Tachometer (Cont'd) INSPECTION/VEHICLE SPEED SENSOR

### Without ABS for the Middle East and Except for the Middle East






## INSPECTION/ENGINE REVOLUTION SIGNAL




# METER AND GAUGES

## Trouble Diagnoses/With Tachometer (Cont'd) INSPECTION/FUEL LEVEL SENSOR UNIT



# METER AND GAUGES

## Trouble Diagnoses/With Tachometer (Cont'd) INSPECTION/THERMAL TRANSMITTER



CHECK THERMAL TRANSMITTER.  
Refer to EL section "THERMAL TRANSMITTER" in original Service Manual Pub. No. SM7E-0D22G1.

NG

Repair or replace.

OK

**A**

### CHECK HARNESS FOR OPEN OR SHORT.

1. Disconnect combination connector and thermal transmitter connector.
2. Check continuity between combination meter terminal ①9 (Y/R) and thermal transmitter connector (E9), (M209), (E209) terminal ①.

**Continuity should exist.**

3. Check continuity between combination meter terminal ①9 (Y/R) and ground.

**Continuity should not exist.**

NG

Repair harness or connector.


OK

Thermal transmitter is OK.

# METER AND GAUGES

## Trouble Diagnoses/Without Tachometer

### PRELIMINARY CHECK



SEL269Y

\*1: Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode (EL-3070)

\*2: POWER SUPPLY AND GROUND CIRCUIT CHECK (EL-3077)

\*3: Symptom Chart (EL-3076)

### SYMPTOM CHART

Symptom	Possible causes	Repair order
One of speedometer/fuel gauge/water temp. gauge is malfunctioning.	1. Sensor signal - Vehicle speed signal - Fuel gauge - Water temp. gauge 2. Unified meter control unit	1. Check the sensor for malfunctioning meter/gauge. INSPECTION/VEHICLE SPEED SIGNAL (Refer to EL section "Vehicle speed signal" in original Service Manual.) INSPECTION/FUEL LEVEL SENSOR UNIT INSPECTION/THERMAL TRANSMITTER 2. Replace unified meter control unit.
Multiple meter/gauge are malfunctioning. (except odo/trip meter)		


Before starting trouble diagnoses below, perform PRELIMINARY CHECK, EL-3076.

## METER AND GAUGES

### Trouble Diagnoses/Without Tachometer (Cont'd)

#### POWER SUPPLY AND GROUND CIRCUIT CHECK


##### Power supply circuit check



Terminals		Ignition switch position		
⊕	⊖	OFF	ACC	ON
②① (R/G)	Ground	Battery voltage	Battery voltage	Battery voltage
②② (W/B)	Ground	0V	0V	Battery voltage

If NG, check the following.

- 10A fuse [No. ⑥], located in fuse block (J/B)
- 10A fuse [No. ⑪], located in fuse block (J/B)
- Harness for open or short between fuse and combination meter



##### Ground circuit check



Terminals	Continuity
②③ - Ground (B)	Yes

# METER AND GAUGES

## Trouble Diagnoses/Without Tachometer (Cont'd)

### INSPECTION/VEHICLE SPEED SENSOR

#### Without ABS for the Middle East and Except for the Middle East



**A**

#### CHECK VEHICLE SPEED SENSOR OUTPUT.

1. Remove vehicle speed sensor from transmission.
2. Check voltage between combination meter connector (N10) terminals ②④ (W) and ③⑦ (R) while quickly turning speed sensor pinion.

**Voltage: Approx. 0.5V**

OK

Vehicle speed sensor is OK.

NG

**B**

#### CHECK VEHICLE SPEED SENSOR.

- Check resistance between vehicle speed sensor connector (E223) terminals ① (W) and ② (R).

**Resistance: Approx. 250Ω**

NG




Replace vehicle speed sensor.

OK

Check harness for open or short between combination meter and vehicle speed sensor.


# METER AND GAUGES

## Trouble Diagnoses/Without Tachometer (Cont'd) INSPECTION/FUEL LEVEL SENSOR UNIT



# METER AND GAUGES

## Trouble Diagnoses/Without Tachometer (Cont'd) INSPECTION/THERMAL TRANSMITTER



CHECK THERMAL TRANSMITTER.  
Refer to EL section "THERMAL TRANSMITTER" in original Service Manual Pub. No. SM7E-0D22G1.

NG

Repair or replace.

OK

**A**

### CHECK HARNESS FOR OPEN OR SHORT.

1. Disconnect combination connector and thermal transmitter connector.
2. Check continuity between combination meter terminal ③④ (Y/R) and thermal transmitter connector (E9, M209, E209) terminal ①.

**Continuity should exist.**

3. Check continuity between combination meter terminal ③④ (Y/R) and ground.

**Continuity should not exist.**

NG

Repair harness or connector.


OK

Thermal transmitter is OK.




# WARNING LAMPS

## Schematic/With Tachometer



# WARNING LAMPS





## Schematic/Without Tachometer




# WARNING LAMPS

## Wiring Diagram — WARN —/Gasoline Engine with Tachometer

EL-WARN-01





Refer to last page (Foldout page).



# WARNING LAMPS

## Wiring Diagram — WARN —/Gasoline Engine with Tachometer (Cont'd)

EL-WARN-02








Refer to last page (Foldout page).  
M5, E101


# WARNING LAMPS

## Wiring Diagram — WARN —/Gasoline Engine with Tachometer (Cont'd)

EL-WARN-03






Refer to last page (Foldout page).



# WARNING LAMPS

## Wiring Diagram — WARN —/Gasoline Engine with Tachometer (Cont'd)

EL-WARN-04




\*: This connector is not shown in "HARNES LAYOUT".

Refer to last page (Foldout page).  
(M5), (E101)





# WARNING LAMPS

## Wiring Diagram — WARN —/Gasoline Engine without Tachometer

### EL-WARN-05



- <KA> : KA engine
- <LK> : LHD models with KA engine
- <LG> : LHD models with KA engine except for Europe
- <RK> : RHD models with KA engine
- <ZK> : Z engine and KA engine for Europe
- 4W : 4-wheel drive models
- EU : For Europe
- NE : Except for Europe
- \*1 18 : EU
- 13 : NE





Refer to last page (Foldout page).

- M5, E101
- M32
- F51

# WARNING LAMPS

## Wiring Diagram — WARN —/Gasoline Engine without Tachometer (Cont'd)

EL-WARN-06



Refer to last page (Foldout page).



M5, E101



# WARNING LAMPS

## Wiring Diagram — WARN —/Gasoline Engine without Tachometer (Cont'd)

EL-WARN-07




Refer to last page (Foldout page).

(M5), (E101)  
(E4)

# WARNING LAMPS

## Wiring Diagram — WARN —/Gasoline Engine without Tachometer (Cont'd)

EL-WARN-08





1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

N2  
BR

41	42	43	44	45	46	47	48	49	50	51		
52	53	54	55	56	57	58	59	60	61	62	63	64

N11  
W



Refer to last page (Foldout page).


M5, E101

\*: This connector is not shown in "HARNES LAYOUT".



# WARNING LAMPS

## Wiring Diagram — WARN —/Diesel Engine with Tachometer

EL-WARN-09



- YZ : YD and ZD engines
  - TQ : TD and QD engines
  - LZ : LHD models with YD and ZD engines
  - RZ : RHD models with YD and ZD engines
  - 4W : 4-wheel drive models
  - LX : LHD models except for Europe
  - RX : RHD models except for Europe
  - FB : With fuel filter warning buzzer
  - OF : Without fuel filter warning buzzer
- \*1 L/R : FB
- W/G : OF








Refer to last page (Foldout page).

- M5, E101
- M32
- F51

# WARNING LAMPS

## Wiring Diagram — WARN —/Diesel Engine with Tachometer (Cont'd)

EL-WARN-10










Refer to last page (Foldout page).

M5, E101

M32



F51



# WARNING LAMPS

## Wiring Diagram — WARN —/Diesel Engine with Tachometer (Cont'd)

EL-WARN-11




Refer to last page (Foldout page).

M5, E101  
E4

# WARNING LAMPS



## Wiring Diagram — WARN —/Diesel Engine with Tachometer (Cont'd)

EL-WARN-12



1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(N2) BR  
(N4) W



\*: This connector is not shown in "HARNESS LAYOUT".


Refer to last page (Foldout page).

(M5), (E101)



# WARNING LAMPS

## Wiring Diagram — WARN —/Diesel Engine without Tachometer

EL-WARN-13



- YZ : YD and ZD engines
- TQ : TD and QD engines
- LZ : LHD models with YD and ZD engines
- RZ : RHD models with YD and ZD engines
- 4W : 4-wheel drive models
- LX : LHD models except for Europe and the Middle East
- RX : RHD models except for Europe
- FB : With fuel filter warning buzzer
- OF : Without fuel filter warning buzzer
- \*1 L/R : FB
- W/G : OF





Refer to last page (Foldout page).

- M5, E101
- M32
- F51

# WARNING LAMPS

## Wiring Diagram — WARN —/Diesel Engine without Tachometer (Cont'd)

EL-WARN-14



Refer to last page (Foldout page).


M5, E101  
M32  
F51



# WARNING LAMPS

## Wiring Diagram — WARN —/Diesel Engine without Tachometer (Cont'd)


EL-WARN-15




# WARNING LAMPS

## Wiring Diagram — WARN —/Diesel Engine without Tachometer (Cont'd)

EL-WARN-16



- (AS) : With ABS
- (AB) : With air bag
- (SK) : Stick type
- (CL) : Center lever type
- (2W) : 2-wheel drive models
- (4W) : 4-wheel drive models
- (L4) : LHD models with 4-wheel drive
- (R4) : RHD models with 4-wheel drive
- \*1 2 : (2W) \*4 10 : (2W)
- 1 : (4W) 21 : (4W)
- \*2 G/OR : (2W)
- L/R : (4W)
- \*3 8H : (2W)
- 12H : (L4)
- 4H : (R4)




Refer to last page (Foldout page).  
 (M5), (E101)  
 (E4)

# WARNING LAMPS

## Wiring Diagram — WARN —/Diesel Engine without Tachometer (Cont'd)

EL-WARN-17



4W : 4-wheel drive models  
AS : With ABS

1	2	3	4	5	6	7	8	9	10	11	N2	41	42	43	44	45	46	47	48	49	50	51	N11				
12	13	14	15	16	17	18	19	20	21	22	23	24	BR	52	53	54	55	56	57	58	59	60	61	62	63	64	W







Refer to last page (Foldout page).  
M5, E101

\*: This connector is not shown in "HARNESS LAYOUT".

# AT INDICATOR

## Wiring Diagram — AT/IND —/RHD Models

EL-AT/IND-01



Refer to last page (Foldout page).

(M5), (E101)

# A/T INDICATOR






## Wiring Diagram — CHIME —/LHD Models

### LIGHT WARNING BUZZER

EL-CHIME-02

Refer to EL-POWER.

- DL : With daytime light system
- ED : Without daytime light system
- \*1 W/R : DL
- W/L : ED



Refer to last page (Foldout page).





M5, E101

# A/T INDICATOR

## Wiring Diagram — CHIME —/RHD Models

### LIGHT WARNING BUZZER

EL-CHIME-03






# FRONT WIPER AND WASHER

## Wiring Diagram — WIPER —/Without Intermittent for Floor-shift

RHD MODELS KA ENGINE

EL-WIPER-03



Refer to last page (Foldout page).


(M5), (E101)  
(M10)

# FRONT WIPER AND WASHER

## Wiring Diagram — WIPER —/Without Intermittent for Floor-shift (Cont'd)

RHD MODELS

EL-WIPER-04



1	2	3
4	5	6

(M12)  
W

3	2
6	5

(F21)  
W

1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

(F55)  
W

Refer to last page (Foldout page).

(M10)





# FRONT WIPER AND WASHER


## Wiring Diagram — WIPER —/Without Intermittent for Floor-shift (Cont'd)

EL-WIPER-05


⬡EU⬢ : For Europe  
 ⬡NE⬢ : Except for Europe



(M28) : ⬡EU⬢  
 GY



(M28) : ⬡NE⬢  
 GY



(E14)  
 GY


Refer to last page (Foldout page).

(M5) , (E101)

# FRONT WIPER AND WASHER

## Wiring Diagram — WIPER —/Without Intermittent for RHD Column-shift Models

EL-WIPER-06



1	2	3
4	5	6

(M12)  
W

2	1
---	---

(E14)  
GY

3	2	1
7	6	5

(F20)  
GY

3	2	
6	5	4

(F21)  
W

1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

(F55)  
W

Refer to last page (Foldout page).






(M5), (E101)

(M10)

# FRONT WIPER AND WASHER

## Wiring Diagram — WIPER —/Without Intermittent for RHD Column-shift Models (Cont'd)


EL-WIPER-07



# HEADLAMP WASHER

## Wiring Diagram — HLC —

EL-HLC-01



1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(N1) W  
(N2) BR

1	2	3	4	5	6	7
8	9	10	11	12	13	14

(N8) BR  
(1, 2) (E58) GY

1	2	3
4	5	

(E65) W



Refer to last page (Foldout page).

(M5), (E101)

# HORN

## Wiring Diagram — HORN —

EL-HORN-01



Refer to last page (Foldout page).



(M5), (E101)

\*: This connector is not shown in "HARNESS LAYOUT".

# CIGARETTE LIGHTER

## Wiring Diagram — CIGAR —


EL-CIGAR-01



# CLOCK

## Wiring Diagram — CLOCK —

EL-CLOCK-01



1	2	3	4	5	6	7	8	9	10	11		
12	13	14	15	16	17	18	19	20	21	22	23	24

(N2) BR (N4) W

21	22	23	24	25	26	27	28	29		
30	31	32	33	34	35	36	37	38	39	40

(N10) BR




41	42	43	44	45	46	47	48	49	50	51		
52	53	54	55	56	57	58	59	60	61	62	63	64

(N11) W

# REAR WINDOW DEFOGGER AND MIRROR DEFOGGER

## Wiring Diagram — DEF —

EL-DEF-01










# AUDIO

## Wiring Diagram — AUDIO —/LHD Models

EL-AUDIO-04









Refer to last page (Foldout page).

(M5), (E101)

# AUDIO

## Wiring Diagram — AUDIO —/RHD Models

EL-AUDIO-06









Refer to last page (Foldout page).

(M5), (E101)

# AUDIO ANTENNA

## Power Antenna/Wiring Diagram — P/ANT —

### EL-P/ANT-01



Refer to last page (Foldout page).


(M5), (E101)

\*: This connector is not shown in "HARNESS LAYOUT".




# POWER DOOR MIRROR

## Wiring Diagram — MIRROR —/LHD Models

EL-MIRROR-01




1	2	3	4	5	6	7	8	9		
10	11	12	13	14	15	16	17	18	19	20






# POWER DOOR MIRROR

## Wiring Diagram — MIRROR —/RHD Models

EL-MIRROR-03





1	2	3	4	5	6	7	8	9		
10	11	12	13	14	15	16	17	18	19	20



# HEATED SEAT

## Wiring Diagram — H/SEAT —



EL-H/SEAT-01



# HEATED SEAT

## Wiring Diagram — H/SEAT — (Cont'd)

EL-H/SEAT-02



\*: This connector is not shown in "HARNES LAYOUT"









# POWER WINDOW

## Wiring Diagram — WINDOW —/Without Interruption Detection Function

EL-WINDOW-01




Refer to last page (Foldout page).

M5, E101

# POWER WINDOW

## Wiring Diagram — WINDOW —/Without Interruption Detection Function (Cont'd)

EL-WINDOW-02



1	2	3	4	5
6	7	8	9	10
11	12			

(D2)  
W

8	9		3	5	6
7	14	16	15	1	12
11	10				

(D5) : (L)  
W

3	5	6	1	9	8
16	15		11	10	14
7					

(D5) : (R)  
W



1	2

(D7)  
B

# POWER WINDOW

## Wiring Diagram — WINDOW —/Without Interruption Detection Function (Cont'd)


EL-WINDOW-03









# POWER WINDOW

## Wiring Diagram — WINDOW —/Without Interruption Detection Function (Cont'd)

EL-WINDOW-04







- : LHD models
- : RHD models
- : Double cab models



# POWER WINDOW

## Wiring Diagram — WINDOW —/With Interruption Detection Function

EL-WINDOW-05



Refer to last page (Foldout page).

M5, E101

# POWER WINDOW


## Wiring Diagram — WINDOW —/With Interruption Detection Function (Cont'd)

EL-WINDOW-06

Refer to EL-POWER.



Preceding page PU

- : LHD models
- : RHD models
- : For Europe
- : For the Middle East
- \*1 G/R :
- R/Y :



POWER WINDOW MAIN SWITCH (D5)







Next page



# POWER WINDOW

## Wiring Diagram — WINDOW —/With Interruption Detection Function (Cont'd)

EL-WINDOW-07












# POWER WINDOW

## Wiring Diagram — WINDOW —/With Interruption Detection Function (Cont'd)

EL-WINDOW-08



# POWER WINDOW

## Trouble Diagnoses/Without Interruption Detection Function

Symptom	Possible cause	Repair order
None of the power windows can be operated using any switch.	<ol style="list-style-type: none"> <li>1. 40A fusible link and circuit breaker-1</li> <li>2. Grounds (M1) and (M54)</li> <li>3. Power window relay</li> <li>4. Open/short in power window main switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 40A fusible link (letter C), located in fusible link and fuse box) and circuit breaker-1, located in fuse block. Turn ignition switch "ON" and verify battery positive voltage is present at terminal ① of power window main switch and terminal ⑤ of sub-switch.</li> <li>2. Check grounds (M1) and (M54).</li> <li>3. Check power window relay.</li> <li>4. Check harness between power window relay and power window main switch for open/short circuit.</li> </ol>
Driver side power window cannot be operated but other windows can be operated.	<ol style="list-style-type: none"> <li>1. Driver side power window regulator circuit</li> <li>2. Driver side power window regulator</li> </ol>	<ol style="list-style-type: none"> <li>1. Check harness between power window main switch and power window regulator for open or short circuit.</li> <li>2. Check driver side power window regulator.</li> </ol>
One or some of power window except driver side power window cannot be operated.	<ol style="list-style-type: none"> <li>1. Power window sub-switch</li> <li>2. Passenger side power window regulator</li> <li>3. Power window main switch</li> <li>4. Power window circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window sub-switch.</li> <li>2. Check power window regulator of malfunctioning power window.</li> <li>3. Check power window main switch.</li> <li>4-1. Check harnesses between power window main switch and power window sub-switch for open/short circuit.</li> <li>4-2. Check harnesses between power window sub-switch and power window regulator for open/short circuit.</li> </ol>
Passenger power window cannot be operated using power window main switch but can be operated by power window sub-switch.	<ol style="list-style-type: none"> <li>1. Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window main switch.</li> </ol>
Driver side power window auto function cannot be operated using power window main switch.	<ol style="list-style-type: none"> <li>1. Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window main switch.</li> </ol>

# POWER WINDOW



## Trouble Diagnoses/With Interruption Detection Function

Symptom	Possible cause	Repair order
None of the power windows can be operated using any switch.	<ol style="list-style-type: none"> <li>1. 10A fuse, 40A fusible link</li> <li>2. Ground circuit</li> <li>3. Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 10A fuse [No. 12], located in fuse block (J/B)], 40A fusible link (letter C), located in fuse and fusible link box).</li> <li>2. Check ground circuit of power window main switch terminal 19.</li> <li>3. Check power window main switch.</li> </ol>
Driver side power window cannot be operated but other windows can be operated.	<ol style="list-style-type: none"> <li>1. Driver side power window regulator circuit</li> <li>2. Driver side power window regulator</li> <li>3. M52 circuit breaker-2</li> <li>4. M52 circuit breaker-2 circuit</li> <li>5. Power window main switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check harness between power window main switch and driver side power window regulator for open or short circuit.</li> <li>2. Check driver side power window regulator.</li> <li>3. Check M52 circuit breaker-2.</li> <li>4. Check harness between M52 circuit breaker-2 and 40A fusible link (letter C), located in fuse and fusible link box).</li> <li>5-1. Check harness between power window main switch terminal 13 and 10A fuse [No. 12], located in fuse block (J/B)].</li> <li>5-2. Check harness between power window main switch terminal 5 and M52 circuit breaker.</li> </ol>
One or more power windows except driver's side window cannot be operated.	<ol style="list-style-type: none"> <li>1. Power window sub-switches</li> <li>2. Power window regulators</li> <li>3. Power window main switch</li> <li>4. Power window circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window sub-switch.</li> <li>2. Check power window regulator.</li> <li>3. Check power window main switch.</li> <li>4-1. Check harnesses between power window main switch and power window sub-switch for open/short circuit.</li> <li>4-2. Check harnesses between power window sub-switch and power window regulator for open/short circuit.</li> </ol>
Power windows except driver's side window cannot be operated using power window main switch but can be operated by power window sub-switch.	<ol style="list-style-type: none"> <li>1. Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window main switch.</li> </ol>
Driver side power window automatic operation does not function properly.	<ol style="list-style-type: none"> <li>1. Power window main switch</li> <li>2. Encoder and limit switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window main switch.</li> <li>2. Check encoder and limit switch. (EL-3132)</li> </ol>
Timer control for supplying power after turning ignition switch to "OFF" does not operate properly. (Except models for Europe)	<ol style="list-style-type: none"> <li>1. Driver side door switch circuit</li> <li>2. Driver side door switch</li> <li>3. Ignition switch ON signal circuit</li> <li>4. Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check harness between driver side door switch and power window main switch.</li> <li>2. Check driver side door switch.</li> <li>3. Check ignition switch ON signal circuit to power window main switch.</li> <li>4. Check power window main switch.</li> </ol>

# POWER WINDOW

## Trouble Diagnoses/With Interruption Detection Function (Cont'd)

### ENCODER AND LIMIT SWITCH CHECK



**CHECK DOOR WINDOW SLIDE MECHANISM**  
Check the following.

- Obstacles in window, glass molding, etc.
- Worn or deformed glass molding
- Door sash tilted too far inward or outward
- Door window regulator

NG → Remove obstacles or repair door window slide mechanism.

OK

**A** **CHECK POWER SUPPLY TO LIMIT SWITCH**

1. Disconnect driver side power window regulator connector.
2. Turn ignition switch ON.
3. Check voltage between power window main switch terminal ⑨ and ground.  
**Approx. 5V should exist.**

NG → Replace power window main switch.

OK

**CHECK LIMIT SWITCH OPERATION**

1. Turn ignition switch OFF.
2. Connect driver side power window regulator connector.
3. Turn ignition switch ON.
4. Check voltage between power window main switch terminal ⑨ and ground during power window closing operation.

**B** **CHECK ENCODER**  
Measure voltage between power window main switch terminal ⑩ and ground with oscilloscope when power window is in automatic closing operation. If check result is NG, replace power window regulator motor (front driver side). If check result is OK, replace power window main switch.

Terminal No.	Condition	Voltage (DCV)
⑨	Approx. 15 mm (0.59 in) below the full closed position to full closed position	Approx. 5
	Other positions	Approx. 0

OK

NG

**RESET LIMIT SWITCH**  
Reset limit switch. Refer to BT section. Then check voltage between power window main switch terminal ⑨ and ground during power window closing operation at least ten times.

NG → Replace power window regulator motor (front driver side).

Terminal No.	Condition	Voltage (DCV)
⑨	Approx. 15 mm (0.59 in) below the full closed position to full closed position	Approx. 5
	Other positions	Approx. 0

OK

**B** **CHECK ENCODER**  
Measure voltage between power window main switch terminal ⑩ and ground with oscilloscope when power window is in automatic closing operation.

NG → Replace power window regulator motor (front driver side).









OK

Replace power window main switch.

# POWER DOOR LOCK

## Wiring Diagram — D/LOCK —

EL-D/LOCK-03








Refer to last page (Foldout page).

(M5), (E101)

# POWER DOOR LOCK

## Wiring Diagram — D/LOCK — (Cont'd)

EL-D/LOCK-04



# MULTI-REMOTE CONTROL SYSTEM

---

## System Description

### FUNCTION

Multi-remote control system has the following function.

- Door lock
- Door unlock
- Hazard reminder

### LOCK OPERATION

When the LOCK signal is input to multi-remote control unit (the antenna of the system is combined with multi-remote control unit), ground is supplied

- through multi-remote control unit terminal ⑤
- to smart entrance control unit terminal ④.

Then smart entrance control unit supplies power and ground to each door lock actuator.

### UNLOCK OPERATION

When the UNLOCK signal is input to multi-remote control unit (the antenna of the system is combined with multi-remote control unit), ground is supplied

- through multi-remote control unit terminal ⑥
- to smart entrance control unit terminal ⑤.

Then smart entrance control unit supplies power and ground to each door lock actuator.

### HAZARD REMINDER

When the doors are locked or unlocked (signal from driver's door unlock sensor) by multi-remote controller, power is supplied

- through multi-remote control unit terminals ③ and ⑧
- to the hazard warning lamps

Then hazard warning lamp flash as follows.

- Lock operation: Flash once
- Unlock operation: Flash twice

### MULTI-REMOTE CONTROLLER ID CODE ENTRY

A maximum of four remote controllers can be entered. Any attempt to enter a remote controller will erase all ID codes previously entered. Therefore, be sure to receive all remote controllers from the vehicle owner when any ID code entry is performed.

To enter ID code entry, the following signals must be input to the multi-remote control unit.


- Ignition switch ON signal
- Battery power supply
- Signal from remote controller

For detailed procedure, refer to "ID Code Entry Procedure" in EL-3139.

# MULTI-REMOTE CONTROL SYSTEM

## Wiring Diagram — MULTI —

EL-MULTI-01



3	2	1
8	7	6

(M58)  
BR

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(M62)  
W



1	2	3	4	5	6	7	8	9
10	11	12	13	14	15	16	17	18
19	20							

(D1)  
W

3	2
4	1

(D10)  
SB



# MULTI-REMOTE CONTROL SYSTEM

## Trouble Diagnoses

### SYMPTOM CHART

Symptom	Possible cause	Diagnoses/service order
No doors can be locked or unlocked by remote control operation. (See NOTE.)	<ol style="list-style-type: none"> <li>1. Power door lock system</li> <li>2. Remote controller battery</li> <li>3. Door lock/unlock circuit</li> <li>4. Ignition power supply circuit for multi-remote control unit</li> <li>5. Power supply circuit for multi-remote control unit</li> <li>6. Ground circuit for multi-remote control unit</li> <li>7. Remote controller</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power door lock operation.</li> <li>2. Check remote controller battery. Refer to EL-3140.</li> <li>3. Check harness for open or short between multi-remote control unit and smart entrance control unit.</li> <li>4. Make sure battery voltage is present at terminal ④ of multi-remote control unit while ignition switch is in IGN position.</li> <li>5. Make sure battery voltage is present at terminal ② of multi-remote control unit.</li> <li>6. Check continuity between terminal ① of multi-remote control unit and ground.</li> <li>7. Replace remote controller. Refer to EL-3139.</li> </ol>
Hazard reminder does not operate properly.	<ol style="list-style-type: none"> <li>1. Hazard reminder output to hazard warning lamps</li> <li>2. Hazard reminder circuit</li> <li>3. Driver's door unlock sensor</li> </ol>	<ol style="list-style-type: none"> <li>1. Check hazard reminder output to hazard warning lamps at terminals ③ and ⑧ of multi-remote control unit.</li> <li>2. Check the harness for open or short between hazard warning lamps and multi-remote control unit.</li> <li>3. Check driver's door unlock sensor signal at terminal ⑦ of multi-remote control unit.</li> </ol>
The new ID of remote controller cannot be entered.	<ol style="list-style-type: none"> <li>1. Remote controller battery</li> <li>2. Ignition power supply circuit for multi-remote control unit</li> <li>3. Driver's door unlock sensor</li> <li>4. Remote controller</li> </ol>	<ol style="list-style-type: none"> <li>1. Check remote controller battery. Refer to EL-3140.</li> <li>2. Make sure battery voltage is present at terminal ④ of multi-remote control unit while ignition switch is in IGN position.</li> <li>3. Check driver's door unlock sensor signal at terminal ⑦ of multi-remote control unit.</li> <li>4. Replace remote controller. Refer to EL-3139.</li> </ol>

Refer to "MULTI-REMOTE CONTROL UNIT INSPECTION TABLE" on next page to check the control unit signals.

**NOTE:**


- The lock operation of multi-remote control system does not activate with the ignition key ON position.

# MULTI-REMOTE CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### MULTI-REMOTE CONTROL UNIT INSPECTION TABLE


Terminal No.	Connections	Condition	Voltage (V) (approximate values)
1	Ground	—	—
2	Power source (BAT)	—	12
3	Hazard warning lamp RH	Remote controller LOCK/UNLOCK button is pushed (All doors are closed and key is not in ignition key cylinder.)	12
		Other than above condition	0
4	Ignition power supply	Ignition switch	OFF ON or START
			0 12
5	Lock signal	Remote controller LOCK button is pushed (All doors are closed and key is not in ignition key cylinder.)	0
		Other than above condition	5
6	Unlock signal	Remote controller UNLOCK button is pushed (Key is not in ignition key cylinder.)	0
		Other than above condition	5
7	Driver side door unlock sensor	Driver side door	Locked Unlocked
			5 0
8	Hazard warning lamp LH	Remote controller LOCK/UNLOCK button is pushed (All doors are closed and key is not in ignition key cylinder.)	12
		Other than above condition	0




# MULTI-REMOTE CONTROL SYSTEM

## ID Code Entry Procedure

### Activation of the registration mode:



### Registration mode



# MULTI-REMOTE CONTROL SYSTEM

## Remote Controller Battery Replacement


**NOTE:**

- Be careful not to touch the circuit board or battery terminal.
- The remote controller is water-resistant. However, if it does get wet, immediately wipe it dry.
- Push the remote controller button two or three times to check its operation after replacing battery.

STEP 1

STEP 2

STEP 3




SEL241X


# THEFT WARNING SYSTEM

## Wiring Diagram — PRWIRE —

EL-PRWIRE-01




Refer to last page (Foldout page).



# NATS (Nissan Anti-Theft System)

## Component Parts and Harness Connector Location



**NOTE:**

If customer reports a "No Start" condition, request ALL KEYS to be brought to the Dealer in case of a NATS malfunction.

# NATS (Nissan Anti-Theft System)

## System Description

NATS has the following immobilizer functions:

- Since only NATS ignition keys, whose ID nos. have been registered into the ECM and IMMU of NATS, allow the engine to run, operation of a stolen vehicle without a NATS registered key is prevented by NATS.  
That is to say, NATS will immobilize the engine if someone tries to start it without the registered key of NATS.
- This version of NATS has dongle unit to improve its anti-theft performance (RHD models for Europe). Dongle unit has its own ID which is registered into NATS IMMU. So it dongle unit is replaced, initialization must be carried out.
- When malfunction of dongle unit is detected:
  - The security indicator lamp illuminates for about 15 minutes after ignition switch is turned to ON.
  - When dongle unit has a malfunction and the indicator lamp is illuminated, engine can not be started. However, engine can be started only one time when security indicator turns off in about 15 minutes after ignition switch is turned to ON.
- Both of the originally supplied ignition key IDs have been NATS registered.  
If requested by the vehicle owner, a maximum of five key IDs can be registered into the NATS components.
- The NATS security indicator (NATS security ind.) blinks when the ignition switch is in “OFF” or “ACC” position. Therefore, NATS warns outsiders that the vehicle is equipped with the anti-theft system.
- When NATS detects trouble, the security indicator lamp lights up as follows.

Condition IGN ON and	With Dongle	Without Dongle
	Security Indicator	Security Indicator
NATS malfunction (except dongle unit) is detected	1. 6 times blinking 2. Staying ON after ignition switch is turned ON	Staying ON
Only malfunction of dongle unit is detected.	Staying ON <b>for about 15 minutes</b> after ignition switch is turned ON.	—
Malfunction of NATS and engine related parts are detected	1. 6 times blinking 2. Staying ON after ignition switch is turned ON	Staying ON
Just after initialization of NATS	6 times blinking	—


- NATS trouble diagnoses, system initialization and additional registration of other NATS ignition key IDs must be carried out using CONSULT-II hardware and CONSULT-II NATS software.  
Regarding the procedures of NATS initialization and NATS ignition key ID registration, refer to CONSULT-II operation manual, NATS.
- **When servicing a malfunction of the NATS (indicated by lighting up of security Indicator Lamp) or registering another NATS ignition key ID no., it is necessary to re-register original key identification. Therefore, be sure to receive ALL KEYS from vehicle owner.**

# NATS (Nissan Anti-Theft System)

## System Composition

The immobilizer function of the NATS consists of the following:

- NATS ignition key
- NATS immobilizer control unit (NATS IMMU), located in the ignition key cylinder
- Engine control module (ECM)
- Dongle unit (RHD models for Europe)
- NATS security indicator










# NATS (Nissan Anti-Theft System)

## Wiring Diagram — NATS —/LHD Models

### EL-NATS-01







Refer to last page (Foldout page).






# NATS (Nissan Anti-Theft System)

## Wiring Diagram — NATS —/RHD Diesel Engine Models


EL-NATS-02



Refer to last page (Foldout page).



# NATS (Nissan Anti-Theft System)



## CONSULT-II

### CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch OFF.
2. Insert NATS program card into CONSULT-II.

#### Program card

#### AEN00A/B


3. Connect CONSULT-II to Data link connector which is located behind the fuse box cover.

4. Turn ignition switch ON.
5. Touch "START".



6. Perform each diagnostic test mode according to each service procedure.

**For further information, see the CONSULT-II Operation Manual, NATS.**






# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses

### WORK FLOW



# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### SYMPTOM MATRIX CHART 1 (Self-diagnosis related item)

SYMPTOM	Displayed "SELF-DIAG RESULTS" on CONSULT-II screen.	DIAGNOSTIC PROCEDURE (Reference page)	SYSTEM (Malfunctioning part or mode)	REFERENCE PART NO. OF ILLUSTRATION ON DIAGNOSTIC SYSTEM DIAGRAM
<ul style="list-style-type: none"> <li>● Security indicator lighting up*</li> <li>● Engine does not start</li> </ul>	ECM INT CIRC-IMMU	PROCEDURE 1 (EL-3152)	ECM	B
	CHAIN OF ECM-IMMU	PROCEDURE 2 (EL-3153)	In rare case, "CHAIN OF ECM-IMMU might be stored during key registration procedure, even if the system is not malfunctioning.	—
			Open circuit in battery voltage line of IMMU circuit	C1
			Open circuit in ignition line of IMMU circuit	C2
			Open circuit in ground line of IMMU circuit	C3
			Open circuit in communication line between IMMU and ECM	C4
			Short circuit between IMMU and ECM communication line and battery voltage line	C4
			Short circuit between IMMU and ECM communication line and ground line	C4
			ECM	B
			IMMU	A
	DIFFERENCE OF KEY	PROCEDURE 3 (EL-3155)	Unregistered key	D
			IMMU	A
	CHAIN OF IMMU-KEY	PROCEDURE 4 (EL-3156)	Malfunction of key ID chip	E
			IMMU	A
			Open circuit in ground line of dongle unit circuit	C6
Open or short circuit in communication line between IMMU and dongle unit			C5	
Dongle unit			G	
<ul style="list-style-type: none"> <li>● Security indicator lighting up*</li> <li>● Engine hard to start</li> </ul>	ID DISCORD, IMM-ECM	PROCEDURE 5 (EL-3157)	System initialization has not yet been completed.	F
			ECM	B
	LOCK MODE	PROCEDURE 6 (EL-3158)	LOCK MODE	D

\*: When NATS detects trouble, the security indicator lights up while ignition key is in the "ON" position.

\*: When the vehicle is equipped with dongle unit, the security indicator blinks 6 times just after ignition switch is turned to ON. Then the security indicator will light up while ignition key is in the ON position.


# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### SYMPTOM MATRIX CHART 2 (Non self-diagnosis related item)

SYMPTOM	DIAGNOSTIC PROCEDURE (Reference page)	SYSTEM (Malfunctioning part or mode)	REFERENCE PART NO. OF ILLUSTRATION ON DIAG- NOSTIC SYSTEM DIAGRAM
Security ind. does not light up.	PROCEDURE 7 (EL-3159)	Security ind.	—
		Open circuit between Fuse and NATS IMMU	—
		Continuation of initialization mode	—
		NATS IMMU	A
Security ind. does not blink just after initialization even if the vehicle is equipped with dongle unit.	PROCEDURE 8 (EL-3160)	NATS might be initialized without connecting dongle unit properly.	—
		Open circuit in ground line of dongle unit circuit	C6
Security ind. does not blink just after ignition switch is turned to ON when some malfunction related to NATS is detected even if the vehicle is equipped with dongle unit.	PROCEDURE 8 (EL-3160)	Open or short circuit in communication line between IMMU and dongle unit	C5
		Dongle unit	G

### DIAGNOSTIC SYSTEM DIAGRAM



# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 1

Self-diagnostic results:

“ECM INT CIRC-IMMU” displayed on CONSULT-II screen

**A**

SELF-DIAG RESULTS	
DTC RESULTS	TIME
ECM INT CIRC-IMMU	0

SEL152X

**A**



Confirm SELF-DIAGNOSTIC RESULTS “ECM INT CIRC-IMMU” displayed on CONSULT-II screen.  
Ref. part No. B.



Replace ECM.



Perform initialization with CONSULT-II.  
For the operation of initialization, refer to “CONSULT-II operation manual NATS”.



# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 2






Self-diagnostic results:

“CHAIN OF ECM-IMMU” displayed on CONSULT-II screen










**A**

SELF-DIAG RESULTS	
DTC RESULTS	TIME
ECM INT CIRC-IMMU	0

SEL153X










\*: In rare case, “CHAIN OF ECM-IMMU” might be stored during key registration procedure, even if the system is not malfunctioning.



# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)



# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 3

Self-diagnostic results:

“DIFFERENCE OF KEY” displayed on CONSULT-II screen

**A**


SELF DIAG RESULTS	
DTC RESULTS	TIME
DIFFERENCE OF KEY	0

SEL163X

**B**

IMMU INITIALIZATION
INITIALIZATION FAIL
THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.

SEL566W



# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 4




Self-diagnostic results:

“CHAIN OF IMMU-KEY” displayed on CONSULT-II screen

**A**

SELF DIAG RESULTS	
DTC RESULTS	TIME
CHAIN OF IMMU-KEY	0

SEL165X



**A**

Confirm SELF-DIAGNOSTIC RESULTS “CHAIN OF IMMU-KEY” displayed on CONSULT-II screen.

OK

CHECK NATS IGNITION KEY ID CHIP. Start engine with another registered NATS ignition key.  
**Does the engine start?**

Yes

- Ignition key ID chip is malfunctioning.

- Replace the ignition key.

**Ref. part No. E**

- Perform initialization with CONSULT-II. For the initialization procedure, refer to “CONSULT-II operation manual NATS”.

No

Is this vehicle equipped with dongle unit (RHD models for Europe)?

No

- IMMU is malfunctioning.

- Replace IMMU.

**Ref. part No. A**

- Perform initialization with CONSULT-II. For the initialization procedure, refer to “CONSULT-II operation manual NATS”.

Yes

CHECK HARNESS CONNECTOR CONNECTION. Check the following harness connector connection: (M68), (N12)  
**Does the engine start?**

Yes

System is OK. (The malfunction is caused by improper connector connection.)

No

**B**

CHECK GROUND CIRCUIT FOR DONGLE UNIT. Check continuity between dongle unit terminal ① (B/W) and ground.  
**Continuity should exist.**

No

Repair harness.  
**Ref. part No. C6**

Yes

**C D**

CHECK INTERFACE CIRCUIT.

- Check continuity between IMMU connector (M68) terminal ② (P) and dongle unit terminal ① (P) (Open circuit check)  
**Continuity should exist.**
- Check continuity between IMMU connector (M68) terminal ② (P) and ground. (Short circuit check)  
**Continuity should not exist.**

No

Repair harness.  
**Ref. part No. C5**

Yes

Dongle unit is malfunctioning.

- Replace dongle unit. **Ref. part No. G**
- Perform initialization with CONSULT-II. For the initialization procedure, refer to “CONSULT-II operation manual NATS”.

# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 5

Self-diagnostic results:

"ID DISCORD, IMM-ECM" displayed on CONSULT-II screen

**A**


SELF-DIAG RESULTS	
DTC RESULTS	TIME
ID DISCORD, IMM-ECM	0

SEL166X

**B**

IMMU INITIALIZATION
INITIALIZATION FAIL
THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.

SEL566W



# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 6

Self-diagnostic results:

“LOCK MODE” displayed on CONSULT-II screen

**A**


SELF DIAG RESULTS	
DTC RESULTS	TIME
LOCK MODE	0

SEL167X

**B**

IMMU INITIALIZATION
INITIALIZATION FAIL
THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.

SEL566W






# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 7


#### “SECURITY IND. DOES NOT LIGHT UP”



# NATS (Nissan Anti-Theft System)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 8




**A**

**CHECK GROUND CIRCUIT FOR DONGLE UNIT.**  
Check continuity between dongle unit connector (N12) terminal ① (B/W) and ground.  
**Continuity should exist.**

No → Repair harness.  
Ref. part No. C6

Yes




**B**


**CHECK INTERFACE CIRCUIT.**  
1. Check continuity between IMMU connector (M68) terminal ② (P) and dongle unit connector (N12) terminal ⑦ (P). (Open circuit check)  
**Continuity should exist.**  
2. Check continuity between IMMU connector (M68) terminal ② (P) and ground. (Short circuit check)  
**Continuity should exist.**

No → Repair harness.  
Ref. part No. C5

Yes



Dongle unit is malfunctioning.  
1. Replace dongle unit.  
**Ref. part No. G**  
2. Perform initialization with CONSULT-II.  
For the initialization procedure, refer to "CONSULT-II operation manual NATS".



## How to Replace NATS IMMU


### NOTE:

- If NATS IMMU is not installed correctly, NATS system will not operate properly and SELF-DIAG RESULTS on CONSULT-II screen will show "LOCK MODE".




# LOCATION OF ELECTRICAL UNITS

## Engine Compartment




## RELAY BOX



# LOCATION OF ELECTRICAL UNITS

## Passenger Compartment




HEL849B

# LOCATION OF ELECTRICAL UNITS

## Passenger Compartment (Cont'd)


### RHD MODELS



# HARNESS LAYOUT

## Main Harness


### INSTRUMENT PANEL — LHD MODELS



# HARNESS LAYOUT

## Main Harness (Cont'd)


A4 (M1)	—	: Body ground	F3 (M37)	B/2	: Cigarette lighter	F1 (M74)	W/2	: Intake air temperature sensor (With auto A/C)
A4 (M2)	W/2	: Warning buzzer (Diesel engine except for Europe and the Middle East)	G2 (M38)	W/3	: A/C switch (Without auto A/C)	F1 (M75)	B/2	: Sunload sensor (With auto A/C)
A4 (M3)	W/20	: To (D1)	G2 (M39)	W/6	: Fan switch (Without auto A/C)	C2 (M76)	W/6	: Option connector (For Europe) (For theft warning system)
A3 (M4)	W/12	: To (D2) (With power window)	E2 (M40)	W/2	: Fan switch illumination (Without auto A/C)	C3 (M78)	L/2	: Shift lock brake switch (With A/T)
A3 (M5)	SMJ	: To (E101)	E2 (M41)	W/8	: Hazard switch	E4 (M79)	Y/12	: Air bag diagnosis sensor unit (For pre-tensioner seat belt)
A3 (M6)	W/24	: To (N1)	E2 (M42)	W/6	: Defogger switch (Except for the Middle East except Single cab with TD engine)	E4 (M80)	Y/20	: Air bag diagnosis sensor unit
B3 (M7)	BR/24	: To (N2)	G1 (M43)	Y/2	: Front passenger air bag module	F4 (M81)	Y/12	: Air bag diagnosis sensor unit (For pre-tensioner seat belt)
A2 (M8)	-/2	: Diode (Diesel engine except for Europe and the Middle East)	F1 (M44)	BR/4	: Thermo control amplifier	C3 (M82)	B/2	: Brake pedal position switch (YD25)
C3 (M9)	L/4	: Fuel pump relay (KA engine)	G2 (M45)	BR/4	: Fan resistor (Without auto A/C)	B4 (M83)	L/10	: Diode (KA24DE)
B4 (M10)	—	: Fuse block	G2 (M46)	W/2	: Blower motor	A3 (M84)	BR/2	: Resistor (With A/T)
B4 (M11)	W/16	: Data link connector	G3 (M49)	W/20	: To (D31)	C2 (M85)	GY/6	: Accelerator work unit (YD25)
B3 (M12)	W/6	: Fuse block	G3 (M50)	W/6	: To (D32) (With power window)	E3 (M86)	BR/10	: Mode door motor (With auto A/C)
B4 (M13)	B/10	: Check connector (Z24S)	F3 (M51)	W/8	: Door lock timer (With power window except for Europe)	E3 (M87)	W/2	: In-vehicle sensor (With auto A/C)
B3 (M14)	W/4	: Fuse block	G3 (M52)	W/2	: Circuit breaker-2 (For Europe and with gasoline engine for the Middle East)	G3 (M88)	GY/20	: A/C auto amp. (With auto A/C)
E3 (M15)	B/3	: Combination flasher unit	G3 (M54)	—	: Body ground	G3 (M89)	GY/16	: A/C auto amp. (With auto A/C)
C3 (M16)	B/2	: Stop lamp switch	F1 (M55)	W/2	: Security indicator (With NATS)	G3 (M90)	L/2	: Aspirator motor (With auto A/C)
A2 (M19)	W/6	: To (R1)	G3 (M56)	-/2	: Diode (Z24S)	G2 (M91)	B/6	: Air mix door motor (With auto A/C)
D3 (M20)	W/6	: Ignition switch	A5 (M57)	-/2	: Diode (Z24S)	F1 (M92)	W/4	: Fan control amp. (With auto A/C)
D2 (M21)	W/1	: Parking brake switch (Stick type)	C3 (M58)	BR/8	: Multi-remote control unit (For Europe)	F1 (M93)	W/4	: Intake door motor (With auto A/C)
G4 (M22)	W/6	: Fuel pump control module (Z24S)	F3 (M59)	BR/6	: Defogger relay	C2 (M94)	BR/3	: Accelerator position sensor (ZD30)
D2 (M23)	BR/8	: Lighting switch • Turn signal lamp switch	E4 (M60)	L/4	: Rear fog lamp relay (Except for the Middle East)	C2 (M95)	GY/3	: Accelerator position switch (ZD30)
D2 (M24)	BR/4	: Lighting switch	F3 (M62)	W/18	: Smart entrance control unit (For Europe)	E1 (M98)	W/12	: Audio unit (Via sub-harness) (Except for Europe)
D3 (M25)	Y/7	: Spiral cable (With air bag)	D2 (M63)	W/3	: Rear fog lamp switch (For Europe and with KA engine except for the Middle East)	Diode (M8)		
C3 (M26)	L/2	: A/T check switch (With A/T)	E3 (M68)	W/8	: NATS IMMU (For Europe)	Diode (M56)		
D2 (M27)	B/1	: Horn switch (Without air bag)	B2 (M70)	W/24	: TCM (Transmission control module) (With A/T)	Diode (M55, M57)		
D2 (M28)	GY/8	: Wiper and washer switch	B2 (M71)	GY/24	: TCM (Transmission control module) (With A/T)	Fuel pump control module		
D3 (M29)	W/12	: Glow control unit (TD engine except for cold areas and QD engine)	B2 (M72)	-/6	: Joint connector-2 (With A/T)	CHARGE warning lamp		
C3 (M30)	W/16	: Glow control unit (TD engine for cold areas)				Alternator (L)		
D4 (M31)	GY/6	: Joint connector-1 (KA engine)				OIL warning lamp		
D4 (M32)	SMJ	: ECM (KA, YD and ZD engines)				OIL pressure switch		
D4 (M33)	—	: Joint connector-3 (KA engine for Europe)						
F3 (M34)	W/2	: Ashtray illumination (With gasoline engine for the Middle East)						
E1 (M35)	W/10	: Audio unit (For Europe)						



# HARNESS LAYOUT

## Main Harness (Cont'd)

### INSTRUMENT PANEL — RHD MODELS




# HARNESS LAYOUT

## Main Harness (Cont'd)


G4 (M1)	—	: Body ground	A2 (M46)	W/2	: Blower motor	G3 (M85)	GY/6	: Accelerator work unit (YD engine)
G4 (M3)	W/20	: To (D1)	A2 (M47)	W/16	: To (F55) (KA, VG, YD and ZD engines)	D3 (M86)	BR/10	: Mode door motor (With auto A/C)
G4 (M4)	W/12	: To (D2)	A2 (M48)	W/24	: To (F54) (KA, VG, YD and ZD engines)	D3 (M87)	W/2	: In-vehicle sensor (With auto A/C)
G3 (M5)	SMJ	: To (E101)	A3 (M49)	W/20	: To (D31)	B3 (M88)	GY/20	: A/C auto amp. (With auto A/C)
F4 (M6)	W/24	: To (N1)	A3 (M50)	W/6	: To (D32) (With power window)	B3 (M89)	GY/16	: A/C auto amp. (With auto A/C)
G2 (M7)	BR/24	: To (N2)	B3 (M51)	W/8	: Door lock timer (With power window except for Europe)	B3 (M90)	L/2	: Aspirator motor (With auto A/C)
E4 (M9)	L/4	: Fuel pump relay (KA and VG engines)	G3 (M52)	W/2	: Circuit breaker-2 (For Europe)	B3 (M91)	B/6	: Air mix door motor (With auto A/C)
F4 (M10)	—	: Fuse block	A3 (M54)	—	: Body ground	C1 (M92)	W/4	: Fan control amp. (With auto A/C)
F4 (M11)	W/16	: Data link connector	B1 (M55)	W/2	: Security indicator (For Europe)	B1 (M93)	W/4	: Intake door motor (With auto A/C)
F3 (M12)	W/6	: Fuse block	A3 (M56)	-/2	: Diode (Z engine)	G3 (M94)	BR/3	: Accelerator position sensor (ZD engine)
F4 (M13)	B/10	: Check connector (Z engine)	A3 (M57)	-/2	: Diode (Z engine)	G3 (M95)	GY/3	: Accelerator position switch (ZD engine)
F3 (M14)	W/4	: Fuse block	F2 (M58)	BR/8	: Multi-remote control unit (For Europe)	G3 (M96)	W/3	: Accelerator switch (F/C) (ZD engine)
C4 (M15)	B/3	: Combination flasher unit	C4 (M59)	BR/6	: Defogger relay (Except models without intermittent wiper for Australia)	E4 (M97)	W/2	: Kickdown switch (With A/T with VG engine)
E3 (M16)	B/2	: Stop lamp switch	C3 (M60)	L/4	: Rear fog lamp relay (For Europe)	C1 (M98)	W/12	: Audio unit (Via sub-harness) (Except for Europe)
F1 (M19)	W/6	: To (R1)	B4 (M62)	W/18	: Smart entrance control unit (For Europe)			
E3 (M20)	W/6	: Ignition switch	D3 (M63)	W/3	: Rear fog lamp switch (For Europe)			
D1 (M21)	W/1	: Parking brake switch (Stick type)	D4 (M66)	GY/20	: ECM (Diesel engine with EGR)			
F4 (M22)	W/6	: Fuel pump control module (Z engine)	D4 (M67)	GY/16	: ECM (Diesel engine with EGR)			
D2 (M23)	BR/8	: Lighting switch	E3 (M68)	W/8	: NATS IMMU (For Europe)			
D2 (M24)	BR/4	: Turn signal lamp switch	E2 (M69)	W/48	: TCM (Transmission control module) (With A/T with VG engine)			
D3 (M25)	Y/7	: Lighting switch	E1 (M70)	W/24	: TCM (Transmission control module) (With A/T with KA engine)			
D3 (M27)	B/1	: Horn switch (Without air bag)	E1 (M71)	GY/24	: TCM (Transmission control module) (With A/T with KA engine)			
D2 (M28)	GY/8	: Wiper and washer switch	E1 (M73)	W/4	: A/T device (With A/T with column shift)			
D4 (M29)	W/12	: Glow control unit (TD27 engine without EGR except for Australia and QD engine)	B1 (M74)	W/2	: Intake air temperature sensor (With auto A/C)			
D4 (M30)	W/16	: Glow control unit (TD27 engine for Australia)	B1 (M75)	B/2	: Sunload sensor (With auto A/C)			
C1 (M35)	W/16	: Audio unit (For Europe)	F2 (M76)	W/6	: Option connector for theft warning system (For Europe)			
C3 (M37)	B/2	: Cigarette lighter	E4 (M78)	L/2	: Shift lock brake switch (With A/T)			
C3 (M38)	W/3	: A/C switch (Without auto A/C)	C4 (M79)	Y/12	: Air bag diagnosis sensor unit (With air bag for Europe and Australia)			
C2 (M39)	W/6	: Fan switch (Without auto A/C)	C4 (M80)	Y/20	: Air bag diagnosis sensor unit (With air bag)			
C2 (M40)	W/2	: Fan switch illumination (Without auto A/C)	D4 (M81)	Y/12	: Air bag diagnosis sensor unit (With air bag for Europe and Australia)			
C2 (M41)	W/8	: Hazard switch	E4 (M82)	B/2	: Brake pedal position switch (YD engine)			
C2 (M42)	W/6	: Defogger switch (Except models without intermittent wiper for Australia)	A4 (M83)	L/10	: Diode (KA engine)			
A2 (M43)	Y/2	: Air bag module passenger side	A1 (M84)	BR/2	: Resistor (With A/T)			
B1 (M44)	BR/4	: Thermo control amplifier						
A2 (M45)	BR/4	: Fan resistor (Without auto A/C)						

### Engine compartment




(M221) W/6 : Wiper motor (Z, TD and QD engines)

Diode (M56, M57)




Diode (M83)



# HARNESS LAYOUT

## Main Harness (Cont'd)

### BODY SIDE — LHD MODELS






# HARNESS LAYOUT

## Main Harness (Cont'd)

### BODY SIDE — RHD MODELS



\*1 : For bench seat  
\*2 : For separated seat

- (M101) GY/2 : G sensor (For ABS)
- (M102) BR/2 : G sensor (For ABS)
- (M103) B/1 : Door switch driver side (Except for Europe)
- (M104) B/1 : Door switch passenger side (For Europe and Australia)
- (M105) BR/2 : To D53 (Double cab models with rear speaker)
- (M106) W/2 : To D52 (Double cab models with power door lock)
- (M107) W/3 : To D51 (Double cab models with power window)
- (M108) B/1 : Parking brake switch (Center lever type) (Separated seat models)
- (M109) W/3 : Seat belt switch (For Europe and Australia)
- (M112) W/6 : To C2 (For ABS)
- (M113) BR/2 : To D73 (Double cab models with rear speaker)
- (M114) W/2 : To D72 (Double cab models with power door lock)
- (M115) W/3 : To D71 (Double cab models with power window)
- (M117) W/2 : Condenser (Z and KA engines)
- (M118) B/3 : Door switch driver side (For Europe)
- (M119) W/3 : To heated seat sub-harness LH (For Europe)
- (M120) W/6 : To M601 (For Europe)
- (M121) W/16 : To C9
- (M122) W/3 : To heated seat sub-harness RH (For Europe)
- (M123) W/4 : Front LH seat belt pre-tensioner (With air bag for Europe and Australia)
- (M124) W/4 : Front RH seat belt pre-tensioner (With air bag for Europe and Australia)
- (M125) W/6 : A/T device (A/T models with floor shift)
- (M601) W/6 : To M120
- (M602) L/4 : Heated seat switch LH
- (M603) W/4 : Heated seat switch RH


#### Console harness

- (M601) W/6 : To M120
- (M602) L/4 : Heated seat switch LH
- (M603) W/4 : Heated seat switch RH

# HARNESS LAYOUT

## Main Harness (Cont'd)

ENGINE COMPARTMENT — LHD models



HEL857B

# HARNES LAYOUT

## Main Harness (Cont'd)

### Sub-harness


B1	(M202)	L/2	:	EVAP canister purge control solenoid valve
B2	(M205)	BR/3	:	Throttle position sensor
B2	(M206)	GY/3	:	Throttle position switch
C3	(M207)	—	:	Engine ground
C3	(M208)	—	:	Engine ground
C3	(M209)	B/1	:	Thermal transmitter
E3	(M212)	B/1	:	Compressor
D3	(M213)	GY/2	:	Distributor
D3	(M214)	GY/6	:	Distributor
D3	(M215)	GY/2	:	Engine coolant temperature sensor
D3	(M216)	B/2	:	Injector No.1
D2	(M217)	B/2	:	Injector No.2
D2	(M218)	B/2	:	Injector No.3
E2	(M219)	B/2	:	Injector No.4
C1	(M221)	W/6	:	Wiper motor
D2	(M223)	BR/2	:	IACV-AAC valve
C2	(M224)	PU/2	:	IACV-FICD solenoid valve
E3	(M231)	SB/3	:	Heated oxygen sensor 1
B1	(M237)	BR/4	:	Mass air flow sensor
B2	(M238)	GY/2	:	To (M331)

B3 (M331) GY/2 : To (M238)  
 C3 (M332) GY/2 : Knock sensor

# HARNES LAYOUT

## Main Harness (Cont'd)

### ENGINE COMPARTMENT — YD ENGINE (LHD models)



# HARNESS LAYOUT


---

NOTE

# HARNESS LAYOUT

## Engine Room Harness

### LHD MODELS — GASOLINE ENGINE




# HARNESS LAYOUT

## Engine Room Harness (Cont'd)


- D1 (E52) L/4 : Air conditioner relay
- E1 (E53) W/3 : Horn relay
- E1 (E54) BR/6 : Park/neutral position relay (With A/T)
- E1 (E55) B/5 : Automatic choke relay (Z engine)
- BR/6 : ECM relay (KA engine)
- D4 (E57) -/3 : Headlamp aiming motor LH (For the Middle East and Europe)
- D5 (E58) GY/2 : Headlamp washer motor (For Europe)
- C4 (E59) B/2 : Ambient sensor (For Europe)
- A3 (E60) -/3 : Headlamp aiming motor RH (For the Middle East and Europe)
- C1 (E63) SB/6 : Daytime light unit (With daytime light system)
- B1 (E64) SB/8 : Daytime light unit (With daytime light system)
- B1 (E65) W/6 : Headlamp washer amplifier (For Europe)
- C3 (E69) BR/2 : Ambient temperature switch (KA engine)

### PASSENGER COMPARTMENT



- (E101) SMJ : To (M5)
- (E103) B/2 : Fuse block

Resistor (E9)




- G3 (E1) GY/2 : Side turn signal lamp LH (With multi-beam type headlamp)
- F2 (E2) GY/2 : Brake fluid level switch
- G3 (E4) B/31 : ABS actuator and electric unit (For ABS)
- E4 (E6) — : Body ground
- F2 (E7) — : Ignition coil (Z engine)
- F3 (E8) — : Ignition coil (Z engine)
- F3 (E9) -/2 : Resistor (Z engine)
- F3 (E10) W/2 : Condenser (Z engine)
- F4 (E11) GY/3 : Front combination lamp LH (Without multi-beam type headlamp)
- E5 (E12) GY/3 : Front combination lamp LH (With multi-beam type headlamp)
- E5 (E13) B/3 : Headlamp LH
- D5 (E14) GY/2 : Washer motor
- E3 (E15) BR/2 : Front wheel sensor LH (For ABS)
- E3 (E16) BR/2 : Intake air temperature sensor (KA engine for Europe)
- E3 (E19) GY/3 : Distributor (Z engine)
- D4 (E20) GY/2 : Option connector (For hood switch) (For Europe)
- D3 (E21) B/1 : Compressor (Z engine)
- B3 (E22) B/1 : Horn low
- C4 (E23) B/1 : Horn high
- B3 (E24) GY/2 : Cooling fan motor (KA engine for the Middle East and Europe)
- B4 (E25) GY/4 : Triple-pressure switch
- A3 (E26) B/3 : Headlamp RH
- A2 (E27) GY/3 : Front combination lamp RH (Without multi-beam type headlamp)
- A3 (E28) GY/3 : Front combination lamp RH (With multi-beam type headlamp)
- B2 (E29) GY/2 : To (E204)
- B2 (E30) GY/8 : To (E203)
- C3 (E31) GY/2 : Front wheel sensor RH (For ABS)
- B1 (E32) — : Relay box (Fusible link and fuse box)
- C2 (E33) SB/8 : To (E205)
- C2 (E34) B/1 : Battery
- G2 (E36) B/1 : ISC-FI pot control solenoid valve (Z engine)
- G2 (E37) B/1 : ISC-FI pot control solenoid valve (Z engine)
- D2 (E39) — : Body ground
- C3 (E40) B/2 : Power steering oil pressure switch (For Europe)
- D2 (E41) B/1 : Option connector (For front fog lamp) (For Europe)
- C1 (E45) GY/2 : Side turn signal lamp RH (With multi-beam type headlamp)
- D1 (E46) GY/3 : Power antenna (For the Middle East and Europe)
- E1 (E50) — : Fusible link and fuse box
- D1 (E51) L/4 : Cooling fan relay (KA engine for the Middle East and Europe)

# HARNESS LAYOUT

## Engine Room Harness (Cont'd)

LHD MODELS — DIESEL ENGINE






# HARNESS LAYOUT

## Engine Room Harness (Cont'd)

- D4 **E57** -/3 : Headlamp aiming motor LH (For the Middle East and Europe)
- D5 **E58** GY/2 : Headlamp washer motor (For Europe)
- B4 **E59** B/2 : Ambient sensor (For auto A/C) (YD and ZD engines)
- A3 **E60** -/3 : Headlamp aiming motor RH (For the Middle East and Europe)
- C1 **E63** SB/6 : Daytime light unit (With daytime light system)
- C1 **E64** SB/8 : Daytime light unit (With daytime light system)
- C1 **E65** W/6 : Headlamp washer amplifier (For Europe)
- E3 **E68** GY/8 : To **A13** (TD and QD engines)
- E3 **E70** BR/3 : To **A14** (YD and ZD engines)
- A2 **E71** B/2 : To **E231** (YD and ZD engines)
- A2 **E72** B/1 : To **E232** (YD and ZD engines)

### PASSENGER COMPARTMENT




- E101** SMJ : To **M5**
- E103** B/2 : Fuse block

- G3 **E1** GY/2 : Side turn signal lamp LH (Except for the Middle East)
- F2 **E2** GY/2 : Brake fluid level switch
- G2 **E4** B/31 : ABS actuator and electric unit (For ABS)
- F3 **E6** — : Body ground
- F4 **E11** GY/3 : Front combination lamp LH (For the Middle East)
- E5 **E12** GY/3 : Front combination lamp LH (Except for the Middle East)
- E5 **E13** B/3 : Headlamp LH
- D5 **E14** GY/2 : Washer motor
- E4 **E15** BR/2 : Front wheel sensor LH (For ABS)
- E3 **E16** GY/2 : Intake air temperature sensor (YD and ZD engines)
- E3 **E17** B/2 : To **A2**
- D3 **E18** GY/2 : Thermostat (TD engine for the Middle East and QD engines)
- E5 **E20** GY/2 : Option connector (For hood switch) (For Europe)
- C3 **E22** B/1 : Horn low
- C4 **E23** B/1 : Horn high
- B4 **E24** GY/2 : Cooling fan motor (TD engine for the Middle East, QD, YD and ZD engines)
- B4 **E25** GY/4 : Triple-pressure switch
- A3 **E26** B/3 : Headlamp RH
- A2 **E27** GY/3 : Front combination lamp RH (For the Middle East)
- A3 **E28** GY/3 : Front combination lamp RH (Except for the Middle East)
- B1 **E29** GY/2 : To **E204**
- B1 **E30** GY/8 : To **E203** (YD and ZD engines)
- C3 **E31** GY/2 : Front wheel sensor RH (For ABS)
- B1 **E32** — : Relay box (Fusible link and fuse box)
- B1 **E33** SB/8 : To **E205**
- C3 **E35** B/1 : To **E206** (TD and QD engines)
- D3 **E36** B/1 : IACV-FICD solenoid valve (TD and QD engines)
- D3 **E37** B/1 : IACV-FICD solenoid valve (TD and QD engines)
- D2 **E39** — : Body ground
- D1 **E41** B/1 : Option connector (For front fog lamp) (For Europe)
- D2 **E42** W/1 : Gloe relay-1 (YD and ZD engines)
- D2 **E43** W/1 : Gloe relay-1 (YD and ZD engines)
- D2 **E44** G/2 : Gloe relay-1 (YD and ZD engines)
- C1 **E45** GY/2 : Side turn signal lamp RH (Except for the Middle East)
- D1 **E46** GY/3 : Power antenna (For Europe)
- F1 **E50** — : Fusible link and fuse box
- F1 **E51** L/4 : Cooling fan relay (TD engine for the Middle East, QD, YD and ZD engines)
- F1 **E52** L/4 : Air conditioner relay
- F1 **E53** W/3 : Horn relay
- G1 **E55** BR/6 : ECM relay (YD and ZD engines)

# HARNESS LAYOUT

## Engine Room Harness (Cont'd)

RHD MODELS — GASOLINE ENGINE




# HARNESS LAYOUT

## Engine Room Harness (Cont'd)


G3	(E1)	GY/2	: Side turn signal lamp LH
D2	(E2)	GY/2	: Brake fluid level switch
E3	(E6)	—	: Body ground
F2	(E7)	—	: Ignition coil (Z engine)
F3	(E8)	—	: Ignition coil (Z engine)
F3	(E9)	-/2	: Resistor (Z engine)
F3	(E10)	W/2	: Condenser (Z engine)
C4	(E12)	GY/3	: Front combination lamp LH
E5	(E13)	B/3	: Headlamp LH
D5	(E14)	GY/2	: Washer motor
E3	(E17)	B/2	: To (A2) (VG engine)
E3	(E19)	GY/3	: Distributor (Z engine)
E3	(E21)	B/1	: Compressor (Z engine)
B3	(E22)	B/1	: Horn low
B4	(E25)	GY/4	: Triple-pressure switch
A3	(E26)	B/3	: Headlamp RH
A3	(E28)	GY/3	: Front combination lamp RH (For Australia)
B2	(E29)	GY/2	: To (E204) (Except VG engine)
			To (E502) (VG engine)
B2	(E30)	GY/8	: To (E203) (Except VG engine)
B1	(E32)	—	: Relay box (Fusible link and fuse box)
B1	(E33)	SB/8	: To (E205) (Except VG engine)
C3	(E34)	B/1	: Battery
D1	(E36)	B/1	: ISC-FI pot control solenoid valve (Z engine)
D1	(E37)	B/1	: ISC-FI pot control solenoid valve (Z engine)
C1	(E39)	—	: Body ground
C1	(E45)	GY/2	: Side turn signal lamp RH
E2	(E47)	GY/3	: Carburetor (Z engine)
F1	(E50)	—	: Fusible link and fuse box
F1	(E52)	L/4	: Air conditioner relay
F1	(E53)	W/3	: Horn relay
G1	(E54)	BR/6	: Park/Neutral position relay (With A/T)
G1	(E55)	BR/6	: ECM relay (KA engine)
		L/4	: ECM relay (VG engine)
		B/5	: Automatic choke relay (Z engine)
C3	(E69)	BR/2	: Ambient temperature switch (KA engine)

E3	(E73)	GY/2	: To (A3) (VG engine)
D2	(E76)	GY/2	: Dropping resistor (With A/T)
D2	(E77)	GY/2	: Park/Neutral position switch (With A/T)
D2	(E78)	GY/8	: Park/Neutral position switch (With A/T)
D2	(E79)	BR/8	: To terminal cord assembly (With A/T)
C2	(E80)	GY/3	: Revolution sensor (With A/T)

### PASSENGER COMPARTMENT




(E101)	SMJ	: To (M5)
(E103)	B/2	: Fuse block



# HARNESS LAYOUT

## Engine Room Harness (Cont'd)

RHD MODELS — DIESEL ENGINE




# HARNESS LAYOUT

## Engine Room Harness (Cont'd)

D2 <b>E61</b>	B/2	: EGRC-solenoid valve (Throttle chamber) (TD engine with EGR)
D2 <b>E62</b>	BR/2	: EGRC-solenoid valve (EGR valve) (TD engine with EGR)
D1 <b>E66</b>	GY/6	: Dim-dip lamp unit (For Europe)
C1 <b>E67</b>	GY/4	: Dim-dip lamp unit (For Europe)
E3 <b>E68</b>	GY/8	: To <b>A13</b> (TD and QD engines)
E3 <b>E70</b>	BR/3	: To <b>A14</b> (YD and ZD engines)
A2 <b>E71</b>	B/2	: To <b>E231</b> (YD and ZD engines)
A2 <b>E72</b>	B/1	: To <b>E232</b> (YD and ZD engines)
E2 <b>E81</b>	B/2	: Dropping resistor (TD engine for Australia)
D1 <b>E82</b>	W/1	: Glow relay-2 (TD engine for Australia)
D1 <b>E83</b>	W/1	: Glow relay-2 (TD engine for Australia)
D1 <b>E84</b>	G/2	: Glow relay-2 (TD engine for Australia)

### PASSENGER COMPARTMENT



**E101** SMJ : To **M5**  
**E103** B/2 : Fuse block


### Sub-harness

D1 <b>E301</b>	B/1	: To <b>E48</b> (QD engine)
D2 <b>E302</b>	L/2	: To <b>E49</b> (TD engine)
E2 <b>E303</b>	—	: Glow plug (TD and QD engines)

G3 <b>E1</b>	GY/2	: Side turn signal lamp LH
D2 <b>E2</b>	GY/2	: Brake fluid level switch
G2 <b>E4</b>	B/31	: ABS actuator and electric unit (For ABS)
F2 <b>E5</b>	BR/2	: Fuel filter switch (Except for Europe)
F2 <b>E6</b>	—	: Body ground
C5 <b>E12</b>	GY/3	: Front combination lamp LH
E4 <b>E13</b>	B/3	: Headlamp LH
D5 <b>E14</b>	GY/2	: Washer motor
E4 <b>E15</b>	BR/2	: Front wheel sensor LH (For ABS)
F2 <b>E16</b>	GY/2	: Intake air temperature sensor (YD and ZD engines)
E3 <b>E17</b>	B/2	: To <b>A2</b>
D3 <b>E18</b>	GY/2	: Thermostat (QD engine)
E5 <b>E20</b>	GY/2	: Option connector (For hood switch) (For Europe)
C3 <b>E22</b>	B/1	: Horn low
B4 <b>E23</b>	B/1	: Horn high (ZD engine except for Australia, YD and QD engines)
B4 <b>E24</b>	GY/2	: Cooling fan motor (Except TD engine)
B4 <b>E25</b>	GY/4	: Triple-pressure switch
A3 <b>E26</b>	B/3	: Headlamp RH
A3 <b>E28</b>	BR/3	: Front combination lamp RH
A1 <b>E29</b>	GY/2	: To <b>E204</b>
B1 <b>E30</b>	GY/8	: To <b>E203</b> (With ECM control engine)
C3 <b>E31</b>	GY/2	: Front wheel sensor RH (For ABS)
B2 <b>E32</b>	—	: Relay box (Fusible link and fuse box)
B1 <b>E33</b>	SB/8	: To <b>E205</b>
B2 <b>E35</b>	B/1	: To <b>E206</b> (TD and QD engines)
C3 <b>E36</b>	B/1	: IACV-FICD solenoid valve (TD and QD engines)
C3 <b>E37</b>	B/1	: IACV-FICD solenoid valve (TD and QD engines)
D2 <b>E39</b>	—	: Body ground
C1 <b>E41</b>	B/1	: Option connector (For front fog lamp) (For Europe)
B1 <b>E42</b>	W/1	: Glow relay-1
C1 <b>E43</b>	W/1	: Glow relay-1
C1 <b>E44</b>	G/2	: Glow relay-1
C1 <b>E45</b>	GY/2	: Side turn signal lamp RH
G3 <b>E46</b>	GY/3	: Power antenna (For Europe)
E1 <b>E48</b>	B/1	: To <b>E301</b> (QD engine)
E2 <b>E49</b>	L/2	: To <b>E302</b> (TD engine)
F1 <b>E50</b>	—	: Fusible link and fuse box
F1 <b>E51</b>	L/4	: Cooling fan relay (Except TD engine)
F1 <b>E52</b>	L/4	: Air conditioner relay
F1 <b>E53</b>	W/3	: Horn relay
G1 <b>E55</b>	BR/6	: ECM relay (YD and ZD engines)
C3 <b>E59</b>	B/2	: Ambient sensor (YD and ZD engines)

# HARNESS LAYOUT


## Engine Control Harness/KA engine



# HARNESS LAYOUT


## Engine Control Harness/KA engine (Cont'd)

### PASSENGER COMPARTMENT




- (F51) W/48 : ECM
- (F53) GY/6 : Joint connector-1
- (F54) W/24 : To (M48)
- (F55) W/16 : To (M47)
- (F56) -/2 : Diode

Resistor (F11)



Diode (F56)



- B2 (F2) B/2 : IACV-FICD solenoid valve
- C1 (F3) BR/2 : IACV-AAC valve
- C1 (F4) GY/3 : Mass air flow sensor (With three way catalyst)
- D1 (F5) GY/6 : To (F104)
- C1 (F6) BR/4 : Mass air flow sensor (Without three way catalyst)
- B2 (F7) — : Engine ground
- B2 (F8) — : Engine ground
- C3 (F9) B/1 : Thermal transmitter
- D1 (F10) B/3 : To (F121)
- D1 (F11) -/2 : Resistor
- D3 (F12) B/1 : Compressor
- E3 (F13) GY/2 : Distributor
- E3 (F14) GY/6 : Distributor
- C3 (F15) GY/2 : Engine coolant temperature sensor
- C3 (F16) GY/2 : Injector No.1
- D2 (F17) GY/2 : Injector No.2
- D2 (F18) GY/2 : Injector No.3
- E2 (F19) GY/2 : Injector No.4
- F2 (F20) GY/8 : Wiper amplifier (A/T models)
- F2 (F21) W/6 : Wiper motor
- E2 (F22) B/3 : Heated oxygen sensor 1 (With three way catalyst)


### Sub-harness

- B2 (F102) BR/3 : Throttle position sensor
- B2 (F103) GY/3 : Throttle position switch (A/T models)
- C2 (F104) B/6 : To (F5)
- E2 (F121) B/3 : To (F10)
- C3 (F122) -/2 : Knock sensor
- D3 (F123) GY/1 : Oil pressure switch

# HARNESS LAYOUT

## Engine Control Harness

### ENGINE COMPARTMENT — YD ENGINE (RHD models)




HEL875B



# HARNESS LAYOUT

## Engine Harness

### KA ENGINE




- (E201) — : Battery
- (E202) — : Fusible link and fuse box
- (E203) GY/8 : To (E30)
- (E204) GY/2 : To (E29)
- (E205) SB/8 : To (E33)
- (E207) GY/2 : Power steering oil pressure switch  
(RHD 4WD models except for Europe)
- (E208) B/2 : Power steering oil pressure switch  
(Except RHD 4WD models except for Europe)
- (E210) — : Alternator (B)
- (E211) — : Alternator (E)
- (E212) GY/2 : Alternator (S,L)

- (E215) — : Starter motor
- (E218) GY/1 : Starter motor
- (E219) GY/2 : Back-up lamp switch (With M/T)
- (E220) B/2 : Park/Neutral position switch (With M/T)
- (E221) GY/1 : Transfer switch (4WD models)
- (E222) GY/1 : Transfer switch (4WD models)
- (E223) GY/2 : Vehicle speed sensor
- (E227) GY/2 : Crankshaft position sensor (OBD) (For Europe)
- (E229) GY/1 : Oil pressure switch (For Europe)

# HARNESS LAYOUT

## Engine Harness (Cont'd)


YD ENGINE




- (E201) : Battery
- (E203) GY/8 : To (E30)
- (E204) GY/2 : To (E29)
- (E205) SB/8 : To (E33)
- (E209) B/1 : Thermal transmitter
- (E215) — : Starter motor
- (E216) B/1 : Starter motor
- (E219) GY/2 : Back-up lamp switch
- (E220) B/2 : Park/Neutral position switch
- (E221) GY/1 : Transfer switch
- (E222) GY/1 : Transfer switch
- (E223) GY/2 : Vehicle speed sensor
- (E229) GY/1 : Oil pressure sensor
- (E230) GY/2 : Crankshaft position sensor (TDC)
- (E231) B/2 : To (E71)
- (E232) B/1 : To (E72)
- (E233) GY/2 : Engine coolant temperature sensor
- (E234) GY/6 : EGR volume control valve
- (E236) GY/8 : To (M278) (LHD models)
- (E237) GY/10 : To (F35) (RHD models)
- (E238) B/9 : To (M279) (LHD models)
- (E239) — : To (F36) (RHD models)
- : Electronic control fuel injection pump
- : Glow plug

# HARNESS LAYOUT

## Alternator Harness




<b>A1</b>	—	: Body ground
<b>A2</b>	B/2	: To <b>(E17)</b>
<b>A4</b>	B/1	: Compressor
<b>A6</b>	—	: Alternator (B)
<b>A7</b>	—	: Alternator (E)
<b>A8</b>	GY/2	: Alternator (S.L)
<b>A10</b>	BR/2	: Revolution sensor
<b>A11</b>	GY/2	: Engine coolant temperature sensor
<b>A12</b>	B/1	: Thermal transmitter
<b>A13</b>	GY/8	: To <b>(E68)</b>



# HARNESS LAYOUT

## Alternator Harness (Cont'd)

YD ENGINE




- A1** : Body ground
- A2** : To **E17**
- A4** : Compressor
- A6** : Alternator (B)
- A7** : Alternator (E)
- A8** : Alternator (S,L)
- A14** : To **E70**


# HARNESS LAYOUT

## LHD MODELS

### Instrument Harness



## RHD MODELS



# HARNESS LAYOUT


## Chassis Harness and Tail Harness

### Tail harness

- (T1)** W/6 : Rear combination lamp RH  
(A-chassis models or with smooth rear body except for Europe, Australia and China)
- (T2)** W/8 : Rear combination lamp RH (For Europe, Australia and China except A-chassis models or with regular rear body)
- (T3)** GY/2 : License plate lamp RH (With step bumper)
- (T4)** SB/8 : To **(C7)**
- (T5)** GY/2 : License plate lamp RH (Without step bumper)
- (T6)** GY/2 : License plate lamp LH (Without step bumper)
- (T7)** B/2 : License plate lamp LH (With step bumper)
- (T8)** W/6 : Rear combination lamp LH  
(A-chassis models or with smooth rear body except for Europe, Australia and China)
- (T9)** W/8 : Rear combination lamp LH (For Europe, Australia and China except A-chassis models or with regular rear body)
- (T10)** GY/2 : Rear fog lamp (RHD A-chassis models for Europe)
- (T12)** GY/2 : Rear fog lamp (LHD A-chassis models for Europe)

### Chassis harness

- (C2)** W/6 : To **(M112)** (With ABS)
- (C3)** GY/5 : Fuel level sensor unit and fuel pump
- (C5)** SB/4 : To rear wheel sensor sub-harness (For ABS) (4WD models and 2WD models with LT30 rear brake)
- (C6)** GY/2 : Rear wheel sensor (For ABS) (2WD models with LT26B rear brake)
- (C7)** SB/8 : To **(T4)**
- (C9)** W/16 : To **(M121)**
- (C10)** BR/2 : High-mounted stop lamp (With guard bar for the Middle East)




# HARNESS LAYOUT

## LHD MODELS

### Front Door Harness (LH side)


- |  |  |
|--|--|
| <b>D1</b> W/20 : To <b>M3</b>  | <b>D9</b> BR/3 : Door mirror defogger (With power window for Europe)                               |
| <b>D2</b> W/12 : To <b>M4</b> (With power window)  | <b>D10</b> SB/4 : Door lock actuator (With multi-remote control system)                            |
| <b>D3</b> BR/2 : Front speaker   | <b>D11</b> GY/3 : Door mirror actuator (With power door mirror for the Middle East)                |
| <b>D4</b> GY/5 : Door mirror actuator (With power door mirror except for the Middle East)          | <b>D12</b> SB/6 : Power window regulator (With power window with interruption detection function)  |
| <b>D5</b> W/16 : Power window main switch  | <b>D13</b> W/3 : Power window main switch (With power window with interruption detection function) |
| <b>D7</b> B/2 : Power window regulator (With power window without interruption detection function) | <b>D14</b> W/10 : Door mirror remote control switch  |
| <b>D8</b> GY/2 : Lock knob switch (With power door lock without multi-remote control system)       |  |



HEL811B

## RHD MODELS

- |   |
|---|
| <b>D31</b> W/20 : To <b>M49</b>                                 |
| <b>D32</b> W/6 : To <b>M50</b> (With power window)              |
| <b>D33</b> BR/2 : Front speaker                                 |
| <b>D34</b> GY/5 : Door mirror actuator (With power door mirror) |
| <b>D35</b> W/8 : Power window sub-switch (With power window)    |
| <b>D37</b> B/2 : Power window regulator (With power window)     |
| <b>D38</b> SB/4 : Door lock actuator (With power door lock)     |
| <b>D39</b> BR/3 : Door mirror defogger (With power door mirror) |




HEL885B

# HARNESS LAYOUT

## Front Door Harness (RH side)

### LHD MODELS


- (D31) W/20 : To (M49)
- (D32) W/6 : To (M50) (With power window)
- (D33) BR/2 : Front speaker
- (D34) GY/5 : Door mirror actuator (With power door mirror except for the Middle East)
- (D35) W/8 : Power window sub-switch (With power window)
- (D37) B/2 : Power window regulator (With power window)
- (D38) SB/4 : Door lock actuator (With power door lock)
- (D39) BR/3 : Door mirror defogger (With power door mirror except for the Middle East)
- (D41) BR/3 : Door mirror actuator (With power door mirror for the Middle East)



HEL812B

### RHD MODELS

- (D1) W/20 : To (M3)
- (D2) W/12 : To (M4) (With power window)
- (D3) BR/2 : Front speaker
- (D4) GY/5 : Door mirror actuator (With power window)
- (D5) W/16 : Power window main switch
- (D7) B/2 : Power window regulator (With power window except for Europe)
- (D8) GY/2 : Lock knob switch (With power door lock without multi-remote control system)
- (D9) BR/3 : Door mirror defogger (With power window for Europe)
- (D10) SB/4 : Door lock actuator (With multi-remote control system)
- (D12) SB/6 : Power window regulator (With power window for Europe)
- (D13) W/3 : Power window main switch (With power window for Europe)
- (D14) W/10 : Door mirror remote control switch (With power window)



HEL884B




# HARNESS LAYOUT

## LH SIDE

## Rear Door Harness


- (D51) W/3 : To (M107)
- (D52) W/2 : To (M106)
- (D53) BR/2 : To (M105)
- (D54) B/2 : Rear speaker
- (D55) B/2 : Power window regulator
- (D56) SB/4 : Door lock actuator
- (D57) W/8 : Power window sub-switch



HEL886B

## RH SIDE

- (D71) W/3 : To (M115)
- (D72) W/2 : To (M114)
- (D73) BR/2 : To (M113)
- (D74) B/2 : Rear speaker
- (D75) B/2 : Power window regulator
- (D76) SB/4 : Door lock actuator
- (D77) W/8 : Power window sub-switch



HEL887B

## WIRING DIAGRAM CODES (CELL CODES)

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
AAC/V	EC	IACV-AAC Valve
ABS	BR	Anti-lock Brake System
A/C, A	HA	Auto Air Conditioner
A/C, M	HA	Manual Air Conditioner
ACC/SW	EC	Accelerator Switch
A/CCOT	EC	Air Conditioner Control
AIRREG	EC	IACV-Air Regulator
APS	EC	Accelerator Position Sensor
AT/IND	EL	A/T Indicator
AUDIO	EL	Audio
BACK/L	EL	Back-up Lamp
BA/FTS	AT	BATT/A/T Fluid Temperature Sensor and TCM Power Supply
BOOST	EC	Turbocharger Boost Sensor
BRK/SW	EC	Brake Switch Signal
CHARGE	EL	Charging System
CHIME	EL	Warning Chime
CHOKE	EC	Automatic Choke
CIGAR	EL	Cigarette Lighter
CKPS	EC	Crankshaft Position Sensor
CLOCK	EL	Clock
CMPS	EC	Camshaft Position Sensor
COOL/F	LC, EC	Cooling Fan Control
DEF	EL	Rear Window Defogger and Mirror Defogger
DIMDIP	EL	Headlamp — With Dim-dip Lamp System
D/LOCK	EL	Power Door Lock
DTRL	EL	Headlamp — With Daytime Light System
ECMRLY	EC	ECM Relay
ECTS	EC	Engine Coolant Temperature Sensor
EGRC/V	EC	EGRC — Solenoid Valve
EGVC/V	EC	EGR Volume Control Valve
ENGSS	AT	Engine Speed Signal
FCUT	EC	Fuel Cut Solenoid Valve
FICD	EC	IACV-FICD Solenoid Valve
FIPO	EC	ISC-FI Pot
FPCM	EC	Fuel Pump Control Module
F/PUMP	EC	Fuel Pump

Code	Section	Wiring Diagram Name
GLOW	EC	Quick-glow System
H/AIM	EL	Headlamp Aiming Control
HEATER	HA	Heater
HEATUP	EC	Heat up Switch
H/LAMP	EL	Headlamp
HLC	EL	Headlamp Washer
HO2S	EC	Heated Oxygen Sensor
HORN	EL	Horn
H/SEAT	EL	Heated Seat
IATS	EC	Intake Air Temperature Sensor
IGN	EC	Ignition System
IGN/SG	EC	Ignition Signal
ILL	EL	Illumination
INJECT	EC	Injector
INJPMP	EC	Electronic Control Fuel Injection Pump
INT/L	EL	Spot Lamp
INT/V	EC	Intake Air Control Valve Control Solenoid Valve
KS	EC	Knock Sensor
LOAD	EC	Electric Load Signal
LPSV	AT	Line Pressure Solenoid Valve
MAFS	EC	Mass Air Flow Sensor
MAIN	EC, AT	Main Power Supply and Ground Circuit
METER	EL	Speedometer, Tachometer, Temp. and Fuel Gauges
MIL/DL	EC	MIL and Data Link Connectors
MIRROR	EL	Power Door Mirror
MULTI	EL	Multi-remote Control System
NATS	EL	Nissan Anti-theft System
NONDTC	AT	Non-detectable Items
O2H1B1	EC	Heated Oxygen Sensor 1 Heater
O2H2B1	EC	Heated Oxygen Sensor 2 Heater
O2S1B1	EC	Heated Oxygen Sensor 1
O2S2B1	EC	Heated Oxygen Sensor 2
OVRCSV	AT	Overrun Clutch Solenoid Valve
P/ANT	EL	Power Antenna
PGC/V	EC	EVAP Canister Purge Control Solenoid Valve
PLA	EC	Partial Load Advance Control

## WIRING DIAGRAM CODES (CELL CODES)

Code	Section	Wiring Diagram Name
PNP/SW	EC	Park/Neutral Position Switch
POWER	EL	Power Supply Routing
PRWIRE	EL	Theft Warning System Pre-wire
PST/SW	EC	Power Steering Oil Pressure Switch
R/FOG	EL	Rear Fog Lamp
ROOM/L	EL	Interior Room Lamp
SHIFT	AT	Shift Lock System
SSV/A	AT	Shift Solenoid Valve A
SSV/B	AT	Shift Solenoid Valve B
SRS	RS	Supplemental Restraint System
S/SIG	EC	Start Signal
START	EL	Starting System
STOP/L	EL	Stop Lamp
SWL/V	EC	Swirl Control Valve Control Solenoid Valve

Code	Section	Wiring Diagram Name
TAIL/L	EL	Parking, License and Tail Lamps
TCV	AT	Torque Converter Clutch Solenoid Valve
TPS	EC, AT	Throttle Position Sensor
TP/SW	EC	Throttle Position Sensor
TURN	EL	Turn Signal and Hazard Warning Lamps
VSS	EC	Vehicle Speed Sensor
VSSA/T	AT	Vehicle Speed Sensor A/T (Revolution Sensor)
VSSMTR	AT	Vehicle Speed Sensor Meter
WARN	EL	Warning Lamps
WINDOW	EL	Power Window
WIPER	EL	Front Wiper and Washer