

Edition: May 2010

Publication No. SM1E-1Z62U0



All rights reserved. No part of this Service Manual may be reproduced or stored in a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, recording or otherwise, without the prior written permission of NISSAN MOTOR CO., LTD.

QUICK REFERENCE INDEX

A GENERAL INFORMATION	GI General Information
B ENGINE	EM Engine Mechanical
	LU Engine Lubrication System
	CO Engine Cooling System
	EC Engine Control System
	FL Fuel System
	EX Exhaust System
	STR Starting System
	ACC Accelerator Control System
C HYBRID	
D TRANSMISSION & DRIVE-LINE	TM Transaxle & Transmission
	DLN Driveline
	FAX Front Axle
	RAX Rear Axle
E SUSPENSION	FSU Front Suspension
	RSU Rear Suspension
	SCS Suspension Control System
	WT Road Wheels & Tires
F BRAKES	BR Brake System
	PB Parking Brake System
	BRC Brake Control System
G STEERING	ST Steering System
	STC Steering Control System
H RESTRAINTS	SB Seat Belt
	SBC Seat Belt Control System
	SR SRS Airbag
	SRC SRS Airbag Control System
I VENTILATION, HEATER & AIR CONDITIONER	VTL Ventilation System
	HA Heater & Air Conditioning System
	HAC Heater & Air Conditioning Control System
J BODY INTERIOR	INT Interior
	IP Instrument Panel
	SE Seat
	ADP Automatic Drive Positioner
K BODY EXTERIOR, DOORS, ROOF & VEHICLE SECURITY	DLK Door & Lock
	SEC Security Control System
	GW Glass & Window System
	PWC Power Window Control System
	RF Roof
	EXT Exterior
	BRM Body Repair
L DRIVER CONTROLS	MIR Mirrors
	EXL Exterior Lighting System
	INL Interior Lighting System
	WW Wiper & Washer
	DEF Defogger
	HRN Horn
M ELECTRICAL & POWER CONTROL	PWO Power Outlet
	BCS Body Control System
	LAN LAN System
	PCS Power Control System
	CHG Charging System
	PG Power Supply, Ground & Circuit Elements
N DRIVER INFORMATION & MULTIMEDIA	MWI Meter, Warning Lamp & Indicator
	WCS Warning Chime System
	AV Audio, Visual & Navigation System
O CRUISE CONTROL & DRIVER ASSISTANCE	CCS Cruise Control System
	DAS Driver Assistance System
P MAINTENANCE	MA Maintenance

A

B

D

E

F

G

H

I

J

K

L

M

N

O

P

FOREWORD

This manual contains maintenance and repair procedure for the 2011 INFINITI QX56.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately. Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.



INFINITI®

QUICK REFERENCE CHART QX56

PFP:00000

ENGINE TUNE-UP DATA (VK56VD)

ELS0003W

Engine model		VK56VD
Firing order		1-8-7-3-6-5-4-2
Idle speed A/T (In "P or N" position)	rpm	600 ± 50
Ignition timing (BTDC at idle speed)		12° ± 2°
CO% at idle		0.7 - 9.9 % and engine runs smoothly
Tensions of drive belt		Auto adjustment by auto tensioner
Radiator cap relief pressure	kPa (kg/cm ² , psi)	
Standard		108.2 - 127.8 (1.1 - 1.3, 15.7 - 18.5)
Limit		98 (1.0, 14)
Cooling system leakage testing pressure	kPa (kg/cm ² , psi)	186 (1.9, 27)
Compression pressure	kPa (kg/cm ² , psi)/rpm	
Standard		1,667 (17, 242)/200
Minimum		1,226 (12.5, 178)/200
Differential limit between cylinders		98 (1.0, 14)/200
Spark plug (Iridium-tipped type)	Make	NGK
	Standard type	DILKAR7B11
	Gap (Standard)	1.1 (0.043)

FRONT WHEEL ALIGNMENT

ELS0003X

Item		Standard	
Measurement wheel		Left side	Right side
Camber Degree minute (Decimal degree)	Minimum	−0°45' (−0.75°)	−0°55' (−0.91°)
	Nominal	0° 00' (0.00°)	−0°10' (−0.17°)
	Maximum	0° 45' (0.75°)	0° 35' (0.58°)
	Left and right difference	0° 33' (0.55°) or less	
Caster Degree minute (Decimal degree)	Minimum	2° 20' (2.34°)	2° 40' (2.67°)
	Nominal	3° 05' (3.08°)	3° 25' (3.42°)
	Maximum	3° 50' (3.83°)	4° 10' (4.16°)
	Left and right difference	0° 45' (0.75°) or less	
Kingpin inclination Degree minute (Decimal degree)	Minimum	—	—
	Nominal	13° 20' (13.33°)* ¹	13° 25' (13.42°)* ¹
	Maximum	—	—
Toe-in	Total toe-in Distance	Minimum	In 1.4 mm (0.055 in)
		Nominal	In 2.4 mm (0.094 in)
		Maximum	In 3.4 mm (0.134 in)
	Toe angle (left wheel or right wheel) Degree minute (Decimal degree)	Minimum	In 0° 03' (0.05°)
		Nominal	In 0° 05' (0.08°)
		Maximum	In 0° 07' (0.11°)

*1: The minimum value and maximum value is the same as the nominal value.

Measure value under unladen*² conditions.

*2: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

REAR WHEEL ALIGNMENT

ELS0003Y

Item		Standard	
Camber Degree minute (Decimal degree)	Minimum	−1° 00' (−1.00°)	
	Nominal	−0° 30' (−0.50°)	
	Maximum	0° 00' (0.00°)	
	Left and right difference	0° 45' (0.75°) or less	
Toe-in	Total toe-in Distance	Minimum	0 mm (0 in)
		Nominal	In 3.4 mm (0.134 in)
		Maximum	In 6.8 mm (0.268 in)
	Toe angle (left wheel or right wheel) Degree minute (Decimal degree)	Minimum	0° 00' (0.00°)
		Nominal	In 0° 07' (0.12°)
		Maximum	In 0° 14' (0.23°)

Measure value under unladen* conditions.

*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

BRAKE PEDAL

Unit : mm (in)

Item	Standard
Brake pedal height	168.5 (6.63) – 178.5 (7.03)
Depressed brake pedal height [Depressing 490 N (50 kg, 110 lb) while turning the engine ON]	100 (3.94) or more

FRONT DISK BRAKE

Unit : mm (in)

Item		Limit
Brake pad	Wear thickness	1.5 (0.059)
	Wear thickness	28.5 (1.122)
Disc rotor	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.053 (0.0021)

REAR DISK BRAKE

Unit : mm (in)

Item		Limit
Brake pad	Wear thickness	2.0 (0.079)
	Wear thickness	18.0 (0.709)
Disc rotor	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.05 (0.0020)

REFILL CAPACITIES

ELS00040

UNIT		Liter	US measure
Fuel tank		98.4	26 gal
Engine Coolant (With reservoir tank) at MAX level		14.9	15-6/8 qt
Engine oil	Drain and refill		
	With oil filter change	6.5	6-7/8 qt
	Without oil filter change	6.2	6-4/8 qt
	Dry engine (Overhaul)	7.6	8 qt
Transmission		10.0	10-5/8 qt
Transfer		1.5	3-1/8 pt
Final drive	Front	0.75	1-5/8 pt
	Rear	1.75	3-3/4 pt
Power steering system		1.0	7/8 qt
Air conditioning system	Compressor oil	0.21	7.1 fl oz
	Refrigerant	1.05 kg	2.32 lb