

FRONT & REAR SUSPENSION

SECTION SU


CONTENTS

FRONT SUSPENSION	2	WHEELARCH HEIGHT (UNLADEN*1)	16
Precautions	2	WHEEL RUNOUT	16
PRECAUTIONS	2	WHEEL BALANCE	16
Preparation	2	REAR SUSPENSION	17
SPECIAL SERVICE TOOLS	2	Precautions	17
COMMERCIAL SERVICE TOOLS	2	PRECAUTIONS	17
Noise, Vibration and Harshness (NVH)		Preparation	17
Troubleshooting	4	COMMERCIAL SERVICE TOOLS	17
NVH TROUBLESHOOTING CHART	4	Noise, Vibration and Harshness (NVH)	
Components	5	Troubleshooting	17
On-vehicle Service	6	Components	18
FRONT SUSPENSION PARTS	6	On-vehicle Service	19
BALANCING WHEELS	6	REAR SUSPENSION PARTS	19
TIRE ROTATION	8	REAR WHEEL ALIGNMENT	19
FRONT WHEEL ALIGNMENT	8	Removal and Installation	22
Coil Spring and Shock Absorber	10	REMOVAL	23
COMPONENTS	10	INSTALLATION	23
REMOVAL AND INSTALLATION	11	Coil Spring and Shock Absorber	23
DISASSEMBLY	11	REMOVAL AND INSTALLATION	23
INSPECTION	11	DISASSEMBLY	24
ASSEMBLY	12	INSPECTION	24
Stabilizer Bar	12	ASSEMBLY	24
REMOVAL AND INSTALLATION	12	Torsion Beam, Lateral Link and Control Rod	25
Transverse Link and Lower Ball Joint	13	DISASSEMBLY	25
REMOVAL AND INSTALLATION	13	INSPECTION	25
INSPECTION	13	ASSEMBLY	25
Service Data and Specifications (SDS)	15	Service Data and Specifications (SDS)	27
GENERAL SPECIFICATIONS (FRONT)	15	GENERAL SPECIFICATIONS (REAR)	27
FRONT WHEEL ALIGNMENT (UNLADEN*1)	15	REAR WHEEL ALIGNMENT (UNLADEN*)	27
LOWER BALL JOINT	15		

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

FRONT SUSPENSION

Precautions



Precautions

PRECAUTIONS

- When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground. Oil will shorten the life of rubber bushes. Be sure to wipe off any spilled oil.
- *: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
- After installing removed suspension parts, check wheel alignment and adjust if necessary.
- Use flare nut wrench when removing or installing brake tubes.
- Always torque brake lines when installing.
- Lock nuts are un reusable parts; always use new ones. When replacing, do not wipe the oil off the new lock nut before tightening.

NLSU0001

Preparation

SPECIAL SERVICE TOOLS

NLSU0002

Tool number Tool name	Description
HT72520000 Ball joint remover	Removing tie-rod outer end and lower ball joint
	PAT.P NT146


COMMERCIAL SERVICE TOOLS

NLSU0003

Tool name	Description
Attachment Wheel alignment	Measure wheel alignment a: Screw M24 x 1.5 pitch b: 35 mm (1.38 in) dia. c: 65 mm (2.56 in) dia. d: 56 mm (2.20 in) e: 12 mm (0.47 in) NT148
1 Flare nut crowfoot 2 Torque wrench	Removing and installing each brake piping a: 10 mm (0.39 in) NT360

FRONT SUSPENSION

Preparation (Cont'd)

Tool name	Description		
Spring compressor		Removing and installing coil spring	GI
			MA
			EM
	NT717		

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

FRONT SUSPENSION

Noise, Vibration and Harshness (NVH) Troubleshooting

Noise, Vibration and Harshness (NVH) Troubleshooting

=NLSU0004

NVH TROUBLESHOOTING CHART

NLSU0004S01


Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Symptom		Possible Cause and SUSPECTED PARTS										Reference page
Symptom	SUSPENSION	Noise	x	x	x	x	x	x				SU-5, 18
		Shake	x	x	x	x		x				SU-11, 23
		Vibration	x	x	x	x	x					—
		Shimmy	x	x	x	x		x				—
		Judder	x	x	x							—
		Poor quality ride or handling	x	x	x	x		x	x			SU-10, 22
	TIRES	Noise	x						x	x	x	SU-8
		Shake	x						x	x	x	SU-12
		Vibration								x		SU-8
		Shimmy	x						x	x		—
		Judder	x						x	x	x	—
		Poor quality ride or handling	x						x	x	x	—
	ROAD WHEEL	Noise	x						x	x	x	—
		Shake	x						x	x	x	—
		Shimmy, Judder	x						x	x	x	—
		Poor quality ride or handling	x						x	x	x	—

x: Applicable

Components

NLSU0005



 : N·m (kg·m, ft·lb)

NAX008





1. Front suspension member
2. Stabilizer bar
3. Transverse link

4. Member pin stay
5. Knuckle

6. Strut assembly
7. Coil spring

FRONT SUSPENSION

On-vehicle Service



On-vehicle Service

FRONT SUSPENSION PARTS

NLSU0006

Check front axle and front suspension parts for excessive play, cracks, wear or other damage.

- Shake each front wheel to check for excessive play.
- Make sure that cotter pin is inserted.
- Retighten all axle and suspension nuts and bolts to the specified torque.

Tightening torque:

Refer to "FRONT SUSPENSION", SU-5.

- Check strut (shock absorber) for oil leakage or other damage.
- Check suspension ball joint for grease leakage and ball joint dust cover for cracks or other damage.
If ball joint dust cover is cracked or damaged, replace transverse link.

- Check spring height from top of wheelarch to the ground.
 - a) Vehicle must be unladen*, parked on a level surface, and tires checked for proper inflation and wear (tread wear indicator must not be showing).
*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
 - b) Bounce vehicle up and down several times before measuring.
Standard height: Refer to SDS, SU-16.
 - c) Spring height is not adjustable. If out of specification, check for worn springs or suspension parts.

- Check suspension ball joint end play.
 - a) Jack up front of vehicle and set the stands.
 - b) Clamp dial indicator onto transverse link and place indicator tip on lower edge of brake caliper.
 - c) Make sure front wheels are straight and brake pedal is depressed.
 - d) Place a pry bar between transverse link and inner rim of road wheel.
 - e) While raising and releasing pry bar, observe maximum dial indicator value.

Vertical end play: 0 mm (0 in)

- f) If ball joint movement is beyond specifications, remove and replace it.


BALANCING WHEELS

NLSU0042

- Adjust wheel balance using road wheel center.

Wheel balance (Maximum allowable unbalance):

Refer to SDS, SU-16.



Preliminary Inspection

Aluminum wheel

NLSU0042S01

NLSU0042S0101

1. Check tires for wear and improper inflation.
2. Check wheels for deformation, cracks and other damage. If deformed, remove wheel and check wheel runout.
- a. Remove tire from aluminum wheel and mount on a tire balance machine.
- b. Set dial indicator as shown in the illustration.

Wheel runout (Dial indicator value):

Refer to SDS, SU-16.

3. Check front wheel bearings for looseness.
4. Check front suspension for looseness.
5. Check steering linkage for looseness.
6. Check that front shock absorbers work properly.
7. Check vehicle posture (Unladen).

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



Steel wheel

NLSU0042S0102

1. Check tires for wear and improper inflation.
2. Check wheels for deformation, cracks and other damage. If deformed, remove wheel and check wheel runout.
- a. Remove tire from steel wheel and mount wheel on a tire balance machine.
- b. Set two dial indicators as shown in the illustration.
- c. Set each dial indicator to 0.
- d. Rotate wheel and check dial indicators at several points around the circumference of the wheel.
- e. Calculate runout at each point as shown below.

$$\text{Radial runout} = (A + B)/2$$

$$\text{Lateral runout} = (C + D)/2$$
- f. Select maximum positive runout value and the maximum negative value. Add the two values to determine total runout. In case a positive or negative value is not available, use the maximum value (negative or positive) for total runout. If the total runout value exceeds the limit, replace steel wheel.


Wheel runout:

Refer to SDS, SU-16.

3. Check front wheel bearings for looseness.
4. Check front suspension for looseness.
5. Check steering linkage for looseness.
6. Check that front shock absorbers work properly.
7. Check vehicle posture (Unladen).

FRONT SUSPENSION

On-vehicle Service (Cont'd)



TIRE ROTATION

- Do not include the T-type spare tire when rotating the tires. NLSU0043


Wheel nuts:

: 98 - 118 N·m (10.0 - 12.0 kg-m, 72 - 87 ft-lb)

FRONT WHEEL ALIGNMENT

Before checking front wheel alignment, be sure to make a preliminary inspection (Unladen*). NLSU0045

*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.



Camber, Caster and Kingpin Inclination


Camber, caster and kingpin inclination are preset at factory and cannot be adjusted. NLSU0045S01

- Measure camber, caster and kingpin inclination of both right and left wheels with a suitable alignment gauge.

Camber, caster and kingpin inclination:

Refer to SDS, SU-15.

- If camber, caster or kingpin inclination is not within specification, inspect front suspension parts. Replace damaged or worn out parts.



Toe-in

Measure toe-in using the following procedure. NLSU0045S02

WARNING:

- Always perform the following procedure on a flat surface.
- Make sure that no person is in front of the vehicle before pushing it.

- Bounce front of vehicle up and down to stabilize the posture.
- Push the vehicle straight ahead about 5 m (16 ft).
- Put a mark on base line of tread (rear side) of both tires at the same height as hub center. These are measuring points.


- Measure distance "A" (rear side).
- Push the vehicle slowly ahead to rotate the wheels 180 degrees (1/2 turn).

If the wheels have rotated more than 180 degrees (1/2 turn), try the above procedure again from the beginning. Never push vehicle backward.

- Measure distance "B" (front side).


Total toe-in:

Refer to SDS, SU-15.



FRONT SUSPENSION

On-vehicle Service (Cont'd)



7. Adjust toe-in by varying the length of steering tie-rods.
 - a. Loosen lock nuts.
 - b. Adjust toe-in by screwing tie-rods in and out.


Standard length "L":

Refer to ST-27, "SDS".

- c. Tighten lock nuts to specified torque.

Lock nut tightening torque:

Refer to ST-16, "POWER STEERING GEAR AND LINK-AGE".



Front Wheel Turning Angle

1. Set wheels in straight-ahead position. Then move vehicle forward until front wheels rest on turning radius gauge properly.
2. Rotate steering wheel all the way right and left; measure turning angle.

Do not hold the steering wheel on full lock for more than 15 seconds.

Wheel turning angle (Full turn):

Refer to SDS, SU-15.


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

FRONT SUSPENSION

Coil Spring and Shock Absorber

Coil Spring and Shock Absorber COMPONENTS

=NLSU0008




NAX009

- | | | |
|----------------------------|------------------------------------|-----------------------|
| 1. Strut mount upper plate | 8. Coil spring | 15. Member pin stay |
| 2. Strut spacer | 9. Shock absorber | 16. Suspension member |
| 3. Strut mount insulator | 10. Wheel hub and steering knuckle | 17. Washer |
| 4. Thrust bearing | 11. Cotter pin | 18. Bush |
| 5. Upper spring seat | 12. Transverse link | 19. Clamp |
| 6. Upper rubber seat | 13. Washer | 20. Stabilizer |
| 7. Bound bumper rubber | 14. Connecting rod | |


FRONT SUSPENSION

Coil Spring and Shock Absorber (Cont'd)



REMOVAL AND INSTALLATION

- Remove shock absorber fixing bolt and nut (to hoodledge).^{NLSU0009}
- Do not remove piston rod lock nut on vehicle.




DISASSEMBLY

- Set shock absorber on vise, then **loosen** piston rod lock nut.^{NLSU0010}
 - Do not remove piston rod lock nut at this time.
- Compress spring with Tool so that shock absorber mounting insulator can be turned by hand.

WARNING:

Make sure that the pawls of the two spring compressors are firmly hooked on the spring. The spring compressors must be tightened alternately so as not to tilt the spring.



- Remove piston rod lock nut.

INSPECTION

Shock Absorber Assembly

- Check for smooth operation through a full stroke, both compression and extension.^{NLSU0011}
- Check for oil leakage on welded or gland packing portions.^{NLSU0011S01}
- Check piston rod for cracks, deformation or other damage. Replace if necessary.

Mounting Insulator and Rubber Parts

- Check cemented rubber-to-metal portion for separation or cracks. Check rubber parts for deterioration. Replace if necessary.^{NLSU0011S02}

Thrust Bearing


- Check thrust bearing parts for abnormal noise or excessive rattle in axial direction.^{NLSU0011S06}
- Replace if necessary.

Coil Spring

- Check for cracks, deformation or other damage. Replace if necessary.^{NLSU0011S03}

FRONT SUSPENSION


Coil Spring and Shock Absorber (Cont'd)




ASSEMBLY

- When installing coil spring on strut, it must be positioned as shown in the figure at left.

NLSU0012



- When installing spring seat, make sure that it is positioned as shown.




Stabilizer Bar


REMOVAL AND INSTALLATION

- Remove stabilizer bar.

NLSU0017






- When installing stabilizer, make sure clamp faces in correct direction.



- Check stabilizer for deformation or cracks. Replace if necessary.
- Check rubber bushings for deterioration or cracks. Replace if necessary.
- Check ball joint can rotate in all directions. If movement is not smooth and free, replace stabilizer bar connecting rod.

FRONT SUSPENSION

Transverse Link and Lower Ball Joint



Transverse Link and Lower Ball Joint

REMOVAL AND INSTALLATION

NLSU0018

1. Remove wheel bearing lock nut.
2. Remove tie-rod ball joint.
3. Remove strut lower bracket fixing bolts and nuts.
4. Separate drive shaft from knuckle by slightly tapping drive shaft end.

Cover boots with shop towel so as not to damage them when removing drive shaft.

5. Separate lower ball joint stud from knuckle with tool. Refer to AX-5, "FRONT AXLE — Wheel Hub and Knuckle".

6. Remove fixing bolts.
7. Remove transverse link and lower ball joint.
8. During installation, final tightening must be carried out at curb weight with tires on the ground.

Tightening torque:

Refer to "FRONT SUSPENSION", SU-10.

9. After installation, check wheel alignment. Refer to "ON-VEHICLE SERVICE — Front Wheel Alignment", SU-8.

INSPECTION

NLSU0019

Transverse Link

NLSU0019S01

- Check transverse link for damage, cracks or deformation. Replace it if necessary.
- Check rubber bushing for damage, cracks and deformation. Replace transverse link if necessary.

Lower Ball Joint

NLSU0019S02

- Check ball joint for play. Replace transverse link assembly if any of the following cases occur. Ball stud is worn, play in axial direction is excessive or joint is hard to swing. Before checking, turn ball joint at least 10 revolutions so that ball joint is properly broken in.


Swinging force "A":

(measuring point: cotter pin hole of ball stud):

7.8 - 82.4 N (0.8 - 8.4 kg, 1.8 - 18.5 lb)

Turning torque "B":

0.50 - 4.90 N·m (5.1 - 50 kg-cm, 4.4 - 43.4 in-lb)



FRONT SUSPENSION

Transverse Link and Lower Ball Joint (Cont'd)

Vertical end play "C":

0 mm (0 in)

- Check dust cover for damage. Replace it and cover clamp if necessary.

FRONT SUSPENSION

Service Data and Specifications (SDS)

Service Data and Specifications (SDS)

GENERAL SPECIFICATIONS (FRONT)

=NLSU0020

Suspension type	Independent MacPherson strut
Shock absorber type	Double-acting hydraulic
Stabilizer bar	Standard equipment

FRONT WHEEL ALIGNMENT (UNLADEN*1)

NLSU0021

		QG engine	YD engine
Camber Degree minute (Decimal degree)	Minimum	-1°05' (-1.08°)	
	Nominal	-0°20' (-0.33°)	
	Maximum	0°25' (0.42°)	
	Left and right difference	45' (0.75°)	
Caster Degree minute (Decimal degree)	Minimum	2°04' (2.07°)	2°01' (2.02°)
	Nominal	2°49' (2.82°)	2°46' (2.77°)
	Maximum	3°34' (3.57°)	3°31' (3.52°)
	Left and right difference	45' (0.75°)	
Kingpin inclination Degree minute (Decimal degree)	Minimum	13°40' (13.67°)	
	Nominal	14°25' (14.42°)	
	Maximum	15°10' (°15.17)	
Total toe-in	Distance (A - B) mm (in)	Minimum	1 (0.04)
		Nominal	2 (0.08)
		Maximum	3 (0.12)
	Angle (left plus right) Degree minute (Decimal degree)	Minimum	0°01' (0.02°)
		Nominal	0°04' (0.07°)
		Maximum	0°07' (0.12°)
Wheel turning angle Full turn*2	Inside Degree minute (Decimal degree)	Minimum	34°30' (34.50°)
		Nominal	38°00' (38.00°)
		Maximum	39°00' (39.00°)
	Outside Degree minute (Decimal degree)	Nominal	31°00' (31.00°)

*1: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

*2: On power steering models, wheel turning force (at circumference of steering wheel) of 98 to 147 N (10 to 15 kg, 22 to 33 lb) with engine idle.

*3: "Ground clearance up" model

LOWER BALL JOINT

NLSU0022


Swinging force "A" (Measuring point: cotter pin hole of ball stud) N (kg, lb)	7.8 - 82.4 (0.8 - 8.4, 1.8 - 18.5)
Turning torque "B" N·m (kg·cm, in·lb)	0.50 - 4.90 (5.1 - 50.0, 4.4 - 43.4)
Vertical end play "C" mm (in)	0 (0)

FRONT SUSPENSION

Service Data and Specifications (SDS) (Cont'd)

WHEELARCH HEIGHT (UNLADEN*1)

NLSU0041
Unit: mm (in)



SFA818A

195/65R15				205/55R16			
QG18		YD22		QG18		YD22	
FR	RR	FR	RR	FR	RR	FR	RR
703 (27.68)	671 (26.42)	700 (27.56)	671 (26.42)	703 (27.68)	670 (26.38)	700 (27.56)	670 (26.38)

*1: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

*2: "Ground clearance up" model

WHEEL RUNOUT


NLSU0023

Wheel type	Aluminum	Steel wheel
Radial runout limit mm (in)	0.3 (0.012)	0.5 (0.020)
Lateral runout limit mm (in)	0.3 (0.012)	0.8 (0.031)

WHEEL BALANCE

NLSU0044

Maximum allowable unbalance	Dynamic (At rim flange) g (oz)	10 (0.35) (one side)
	Static g (oz)	20 (0.71)





Precautions

PRECAUTIONS

- When installing each rubber part, final tightening must be carried out under unladen condition* with tires on ground. Oil will shorten the life of rubber bushes. Be sure to wipe off any spilled oil.
*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
- Use flare nut wrench when removing or installing brake tubes.
- After installing removed suspension parts, check wheel alignment.
- Do not jack up at the trailing arm and lateral link.
- Always torque brake lines when installing.
- Lock nuts are unreusable parts; always use new ones. When replacing, do not wipe the oil off of the new lock nut before tightening.

Preparation

COMMERCIAL SERVICE TOOLS

Tool name	Description
Equivalent to 1 Flare nut crowfoot 2 Torque wrench	Removing and installing brake piping a: 10 mm (0.39 in)  NT360
Spring compressor	Removing and installing coil spring  NT717

Noise, Vibration and Harshness (NVH) Troubleshooting


Refer to "Noise, Vibration and Harshness (NVH) Troubleshooting", "FRONT SUSPENSION", SU-4.

REAR SUSPENSION

Components

Components

NLSU0028




 : N·m (kg-m, ft-lb)

NRA027

- 1. Shock absorber
- 2. Torsion beam

- 3. Control rod
- 4. Lateral link

- 5. Coil spring




On-vehicle Service

REAR SUSPENSION PARTS

Check axle and suspension parts for excessive play, wear or damage. NLSU0029


- Shake each rear wheel to check for excessive play.



- Retighten all nuts and bolts to the specified torque.

Tightening torque:

Refer to "REAR SUSPENSION", SU-18.




- Check shock absorber for oil leakage or other damage.
- Check wheelarch height. Refer to "On-vehicle Service", "FRONT SUSPENSION PARTS", SU-6.

REAR WHEEL ALIGNMENT

Before checking rear wheel alignment, be sure to make a preliminary inspection (Unladen*). NLSU0030

*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.



Preliminary Inspection

Aluminum wheel

- Check tires for wear and improper inflation.
- Check wheels for deformation, cracks and other damage. If deformed, remove wheel and check wheel runout.
 - Remove tire from aluminum wheel and mount on a tire balance machine.
 - Set dial indicator as shown in the illustration.


Wheel runout (Dial indicator value):

Refer to SDS, SU-16.

REAR SUSPENSION

On-vehicle Service (Cont'd)

3. Check front wheel bearings for looseness.
4. Check front suspension for looseness.
5. Check steering linkage for looseness.
6. Check that front shock absorbers work properly.
7. Check vehicle posture (Unladen).



Steel wheel


NLSU0030S0102

1. Check tires for wear and improper inflation.
2. Check wheels for deformation, cracks and other damage.
If deformed, remove wheel and check wheel runout.
 - a. Remove tire from steel wheel and mount wheel on a tire balance machine.
 - b. Set two dial indicators as shown in the illustration.
 - c. Set each dial indicator to 0.
 - d. Rotate wheel and check dial indicators at several points around the circumference of the wheel.
 - e. Calculate runout at each point as shown below.
 $\text{Radial runout} = (A + B)/2$
 $\text{Lateral runout} = (C + D)/2$
 - f. Select maximum positive runout value and the maximum negative value.
Add the two values to determine total runout.
In case a positive or negative value is not available, use the maximum value (negative or positive) for total runout.
If the total runout value exceeds the limit, replace steel wheel.

Wheel runout:

Refer to SDS, SU-16.

3. Check front wheel bearings for looseness.
4. Check front suspension for looseness.
5. Check steering linkage for looseness.
6. Check that front shock absorbers work properly.
7. Check vehicle posture (Unladen).



Camber

Camber is preset at factory and cannot be adjusted.

NLSU0030S02



Camber:

Refer to SDS, SU-27.

- If the camber is not within specification, inspect and replace any damaged or worn rear suspension parts.

REAR SUSPENSION

On-vehicle Service (Cont'd)



Toe-in

NLSU0030S03

Toe-in is preset at factory and cannot be adjusted.

Measure toe-in using following procedure. If out of specification, inspect and replace any damaged or worn rear suspension parts.

WARNING:

- Perform following procedure always on a flat surface.
- Make sure that no person is in front of the vehicle before pushing it.

1. Bounce rear of vehicle up and down to stabilize the posture.
2. Push the vehicle straight ahead about 5 m (16 ft).
3. Put a mark on base line of the tread (rear side) of both tires at the same height of hub center. This mark is a measuring point.
4. Measure distance "A" (rear side).
5. Push the vehicle slowly ahead to rotate the wheels 180 degrees (1/2 turn).

If the wheels have rotated more than 180 degrees (1/2 turn), try the above procedure again from the beginning. Never push vehicle backward.

6. Measure distance "B" (front side).

Total toe-in: A - B

Refer to SDS, SU-27.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

REAR SUSPENSION

Removal and Installation

Removal and Installation

NLSU0031







: N·m (kg-m, ft-lb)

NRA028

- | | | |
|------------------------------------|-----------------------|------------------|
| 1. Washer | 6. Bound bumper cover | 10. Torsion beam |
| 2. Bushing | 7. Bound bumper | 11. Lateral link |
| 3. Shock absorber mounting bracket | 8. Coil spring | 12. Control rod |
| 4. Collar | 9. Shock absorber | 13. ABS sensor |
| 5. Bushing | | |

REAR SUSPENSION

Removal and Installation (Cont'd)



REMOVAL

NLSU0031S01

CAUTION:

- Before removing the rear suspension assembly, disconnect the ABS wheel sensor from the assembly. Failure to do so may result in damage to the sensor wires and the sensor becoming inoperative.

Remove suspension assembly.

- Disconnect brake hydraulic lines and parking brake cable at toggle lever. (Models with drum brakes.)
- Disconnect parking brake cable from caliper and remove brake caliper and rotor. (Models with disc brakes.)

Suspend caliper assembly with wire so as not to stretch brake hose.

Be careful not to depress brake pedal, or piston will pop out.

Make sure brake hose is not twisted.

- Using a transmission jack, raise torsion beam a little, and remove nuts and bolts from the trailing arm, shock absorber assembly (lower side) and lateral link (Body side).
- Lower transmission jack, and remove suspension.
- Remove strut securing nuts (upper side). Then pull out strut assembly.

INSTALLATION

NLSU0031S02

- Install suspension assembly.

CAUTION:

Refill with new brake fluid "DOT 4".

Never reuse drained brake fluid.

- Attach torsion beam, at trailing arm and lateral link, to vehicle. Do not tighten bolts at this time.

- Using a transmission jack, place lateral link and control rod horizontally against torsion beam. Tighten lateral link on vehicle.

- Attach shock absorber assembly to vehicle. Then tighten the lower side of shock absorber assembly.

- Lower torsion beam to fully extended position. Remove transmission jack and tighten torsion beam, at trailing arm, to specified torque. Refer to SU-22.

- Install brake hydraulic lines and tighten flare nuts.

⚙️ : 15 - 18 N·m (1.5 - 1.8 kg-m, 11 - 13 ft-lb)

- Install ABS wheel sensor.

Coil Spring and Shock Absorber

REMOVAL AND INSTALLATION


NLSU0032

Remove shock absorber upper and lower fixing nuts.

Do not remove piston rod lock nut on vehicle.

REAR SUSPENSION

Coil Spring and Shock Absorber (Cont'd)



DISASSEMBLY

1. Set shock absorber in vise, then **loosen** piston rod lock nut. NLSU0033
Do not remove piston rod lock nut at this time.
2. Compress spring with Tool so that the shock absorber upper spring seat can be turned by hand.

WARNING:

Make sure that the pawls of the two spring compressors are firmly hooked on the spring. The spring compressors must be tightened alternately so as not to tilt the spring.

3. Remove piston rod lock nut.

INSPECTION

Shock Absorber Assembly


- Check for smooth operation through a full stroke, both compression and extension. NLSU0034
- Check for oil leakage on welded or gland packing portions. NLSU0034S01
- Check piston rod for cracks, deformation or other damage. Replace if necessary.

Upper Rubber Seat and Bushing

Check rubber parts for deterioration or cracks. NLSU0034S02
Replace if necessary.


Coil Spring

Check for cracks, deformation or other damage. Replace if necessary. NLSU0034S03



ASSEMBLY

- Locate upper spring seat as shown. NLSU0035



- When installing coil spring, be careful not to reverse top and bottom direction. (Top end is flat.)
- When installing coil spring on shock absorber, it must be positioned as shown in figure at left.

CAUTION:

Do not reuse piston rod lock nut.

Torsion Beam, Lateral Link and Control Rod
DISASSEMBLY

- Remove torsion beam assembly. Refer to "Removal and Installation", "REAR SUSPENSION", SU-23.
- Remove lateral link and control rod from torsion beam.

NLSU0036

GI

MA

EM

LC

NLSU0037

EC

FE

CL

MT

NLSU0038

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

INSPECTION

- Check for cracks, distortion or other damage. Replace if necessary.

Standard length:

A 207 - 208 mm (8.15 - 8.19 in)

B 394 - 395 mm (15.51 - 15.55 in)

C 601 - 603 mm (23.66 - 23.74 in)

D 106 - 108 mm (4.17 - 4.25 in)

- Check all rubber parts for wear, cracks or deformation. Replace if necessary.

ASSEMBLY

- Temporarily assemble lateral link and control rod.
- When installing the control rod, connect the bush with the smaller inner diameter to the lateral link.

NLSU0038

AT

AX

SU

BR

ST

RS


BT

HA


SC

EL


IDX



ARA072



SRA793A




SRA701A

- Temporarily install lateral link and control rod on torsion beam.
- When installing, place lateral link with the arrow topside.

REAR SUSPENSION

Torsion Beam, Lateral Link and Control Rod (Cont'd)



3. Place lateral link and control rod horizontally against torsion beam, and tighten to the specified torque.
4. Install torsion beam assembly. Refer to "Removal and Installation", "REAR SUSPENSION", SU-23.

REAR SUSPENSION

Service Data and Specifications (SDS)

Service Data and Specifications (SDS)

GENERAL SPECIFICATIONS (REAR)

=NLSU0039

Suspension type	Multi-link beam suspension
Shock absorber type	Double-acting hydraulic

REAR WHEEL ALIGNMENT (UNLADEN*)

NLSU0040

Body			
Camber Degree minute (Decimal degree)		Minimum	-1°45' (-1.75°)
		Nominal	-1°00' (-1.00°)
		Maximum	-0°15' (-0.25°)
Total toe-in	Distance (A - B) mm (in)	Minimum	-3 (-0.12)
		Nominal	1 (0.04)
		Maximum	5 (0.20)
	Angle (left plus right) Degree minute (Decimal degree)	Minimum	-16' (-0.27°)
		Nominal	5'30" (0.09°)
		Maximum	26' (0.43°)

*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

NOTES